Program:

```
void setup()
{
    serial. begin (9600);
    pinMode (13, OUTPUT);
    pinMode (12, OUTPUT);
    pinMode (11, output);
}
void loop()
{
    digital write  (13, HIGH) ;
    digitalwrite  (12, Low);
    digital write  (11, Low);
    delay (1000);
    digital write (13, Low);
    digital write (12, HIGH);
    digital write (11, Low));
    delay (1000);
    digital write (13, Low);
    digital write (12, Low);
    digital write (11, HIGH);
    delay (1000);
}
```