
Beam Direction




Top of box

Red lines mark diffuser groupings


Board A PADE 112*


Board D PADE 115




Map to top board

Fiber numbering, clockwise from top left (front view)










Do not connect these two fiber in front side. Channels reserved for calibration laser

Board B Board C PADE 113 PADE 116 Bottom of box










12 7 8 9 13141516






PADE BOARD VIEW

Tower numbering

Diffuser block #




Front view

1 2 5 10
4 3 6 11
9 8 7 12
16151413

Rear view
10 5 2 1
11 6 3 4
12 7 8 9
13141516

Fiber number



Fiber 1 on top side of mounted diffuser

See spreadsheet file for channel mapping list