| Eyebrow Right Servo | Р | 6 | | | | White Blue | | White Blac | | | k | Blue | | | | Brown | | |
|---------------------|---|----|-----------------------------|------------|------------|-------------|------------|-----------------|-------------|---------------|------------|-------------|-------|-----------|------------|------------|--|----------|
| Eyebrow Left Servo | О | 5 | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| Eye Led Red | N | 4 | | | | Button Left | | | | | | Eye Led Bli | ue | | | Eye Led Gr | een | |
| Push Button Right | М | 3 | | | | | Button Rig | ght | | | | | | | | | | |
| Push Button Left | L | 2 | | | | | | Eye Led Re | ed | | | | | Ear Servo | | | | |
| Eye Led Blue | К | 8 | | | | | | | Eyebrow | Left Servo | | | | | Nose Led | | | |
| | J | 9 | | | | | | | | Eyebrow R | ight Servo | | | | | | | |
| Ear Servo | I | 10 | | | | | | | | | | | | | | | | |
| Nose Led | Н | 11 | | | | | | | | | | | Led | | | | Red | |
| Eye Led Green | G | 12 | | | | | | | | | | | | | | | Ground | |
| | | | | | | VIN white | Green | | | | | | | | | | Green | |
| | | | F | E | D | С | В | А | | | | | | | | | Blue | |
| | | | SW2-2 | SW2-1 | SW1-1 | SW1-2 | Ground | SW2-3 | | | | | | | | | | |
| | | | 6V Out | 6V in | 9V in | 9V out | | Charger Postive | | | | | | | | | | |
| | | | | 6V Battery | 9V Battery | | | | | | | | Servo | Power | Red | | | <u> </u> |
| | | | Switch 2-1 | | Switch 1-1 | | | | | | | | | Ground | Black/Brov | wn | | <u> </u> |
| | | | | Switch 2-2 | | Switch 1-2 | | | | | | | | Signal | Yellow/Ora | ange/White | | |
| | | | 4 Servos Positive, Red wire | | | | | | | | | | | | | | | |
| | | | | | | | All compo | nents must | connect its | s ground here | | | | | | | | |