## mx53 SD 分区说明

1、修改分区脚本 mksdcard. sh

```
#!/bin/sh
#edited by zhangshaoyan,2012/12/25
#uboot:10MB
#root:1GB-uboot
#user:4GB-uboot-root
# destroy the partition table
node=$1
dd if=/dev/zero of=${node} bs=1024 count=1
# call sfdisk to create partition table
sfdisk --force -uM ${node} << EOF
10,1024,83
1025,,83
EOF
2、修改烧写控制文件 ucl. xml
<CMD type="push" body="$ sh mksdcard.sh /dev/mmcblk0"> Partitioning...</CMD>
<CMD type="push" body="mknod block/mmcblk0,mmcblk0p1,/dev/mmcblk0p1,mmcblk0p2,/dev/mmcblk0p2,block"/>
<CMD type="push" body="$ dd if=/dev/zero of=/dev/mmcblk0 bs=512 seek=1536 count=16">Clean U-Boot environment</cmb>
<CMD type="push" body="send" file="imb_dci/u-boot-imb_dci.bin">Sending u-boot.bin</cMD>
<CHD type="push" body="$ dd if=$FILE of=/dev/mmcblk0 bs=512 seek=2 skip=2">write U-Boot to SD</CHD>
<CMD type="push" body="send" file="imb dci/uImage-imb dci">Sending kernel uImage</CMD>
<CMD type="push" body="$ dd if=$FILE of=/dev/mmcblk0 bs=512 seek=2048">write kernel image to SD</CMD>
<CMD type="push" body="$ mkfs.ext3 -j /dev/mmcblk@p1">Formatting rootfs partition</CMD>
<CMD type="push" body="$ mkfs.ext3 -j /dev/mmcblk8p2">Formatting userfs partition</CMD>
<CMD type="push" body="$ mkdir -p /mnt/mmcblk@p1"/>
<CMD type="push" body="$ mount -t ext3 /dev/mmcblk0p1 /mnt/mmcblk0p1"/>
<CMD type="push" body="pipe tar -jxv -C /mnt/mmcblk0p1" file="imb_dci/rootfs-imb_dci.tar.bz2">Sending and writting rootfs</cmb>
<CMD type="push" body="frf">Finishing rootfs write</CMD>
<CMD type="push" body="$ umount /mnt/mmcblk@p1">Unmounting rootfs partition</CMD>
3、修改/etc/fstab 开机自动挂载分区
   mknod /dev/mmcblk0p1 b 179 1
   mknod /dev/mmcblk0p2 b 179 2
   mount - t ext3 /dev/mmcb1k0p2 /tmp
  # cat /etc/fstab
                                     defaults
            /proc
                        proc
proc
                         sysfs
                                                                           0
                                     defaults
sysfs
            /svs
                         /home
/dev/mmcblk0p2
                                     ext3
                                                  defaults
```

Filesystem	Size	Used	Hvallable	Use%	Mounted on	
/dev/root	1007.9M	42.1M	914.6M	4%	/	
/dev/mmcb1k0p2	2.6G	68.1M	2.4G	3%	/home	
/ # <u>_</u>						

由上图可见,分区 1,/dev/mmcblk0p1 大约为 1GB,分区 2,/dev/mmcblk0p2 大约为 2.6GB,合计共 3.6GB,大约为 4GB。

4、完毕!

张绍言 2012/12/26



地址:北京市通州区北杨洼 251号 网址: www.bioequ.com.cn 邮箱: info@bioequ.com.cn