Running Command

```
python serial_logger_datacollection.py
```

Environment

- 1. Please downlaod python first
- 2. verify python is installed.

Please open the terminal



type down python --version Or python3 --version, one of this should show some print outs.

3. Install the required libraries

```
pip install pyserial
```

or

```
python -m pip install pyserial
```

- 4. Save the python code in one folder. and open a terminal in that folder
- 5. You can start running now

python serial_logger_datacollection.py

Before running the code, please make sure the arduino is connected.