## **Dead-Weight tester**

## Objective:

It is used to calibrated all kinds of pressure gauges such as industrial pressure gauges , engine indicators and piezoelectric transducers

By comparing pressure in the required calibrated device and the add weight on the primary piston

## Table of the observation and results:

## Observation:

Actual pressure	Indicated pressure		
<u>(kg/cm²)</u>	<u>Loading</u>	<u>Unloading</u>	<u>Average</u>
<u>o</u>	<u>o</u>	<u>o</u>	
1	<u>1.1</u>	<u>1.1</u>	<u>1.1</u>
<u>2</u>	<u>2.1</u>	<u>2.1</u>	<u>2.1</u>
<u>3</u>	3.2	<u>3.21</u>	<u>3.2</u>
4	<u>4.4</u>	<u>4.25</u>	4.325
<u>5</u>	<u>5.4</u>	<u>5.4</u>	<u>5.4</u>
<u>6</u>	<u>6.5</u>	<u>6.6</u>	<u>6.55</u>

