Worker Interface Profiles (WIP)

Functional Specification

Includes the OCP Profiles for: Worker Control Interface (WCI) Worker Streaming Interface (WSI) Worker Message Interface (WMI) Worker Memory Interface (WMemI) Worker Time Interface (WTI) Authors: Jim Kulp, Shepard Siegel

OpenCPI Page 1 of 88

25 Revision History

Revision	Description of Change	Ву	Date
0.01	Creation	ssiegel	2006-10-12
0.01	Progressive update	ssiegel	2006-10-12
0.03	Progressive update	ssiegel	2006-10-17
0.04	WCI Focus	ssiegel	2006-11-08
0.05	WCI Gloss, Start in on WSI	ssiegel	2006-11-09
0.06	WSI Focus	ssiegel	2006-11-10
0.07 0.08	WSI Re-Focus (rewrite) WCI, WSI Gloss	ssiegel ssiegel	2006-11-13 2006-11-14
0.09	WMeml Rough-out 6.1 and 6.2	ssiegel	2006-11-14
0.10	WMeml Rough-out 6.3	ssiegel	2006-11-16
0.11	WMeml continue	ssiegel	2006-11-17
0.12	WMeml choices 6.5	ssiegel	2006-11-21
0.13	Add to overview, start WMI section 5.1	ssiegel	2006-11-22
0.14 0.15	WMI continue WMI continue, gloss 5.1, removed unnecessary details	ssiegel ssiegel	2006-11-28 2006-11-29
0.16	WMI continue, gloss 5.1, removed differensially details WMI continue, introduce "Worker Choices" Section	ssiegel	2006-11-29
0.17	Reformat with x.2 "Worker Choices"	ssiegel	2006-12-01
0.18	Refine terminology "attributes"	ssiegel	2006-12-02
0.19	Incorporate Jim's v.17 comments	ssiegel	2006-12-04
0.20	Incorporate Jim's v.19 comments	ssiegel	2006-12-05
0.21 0.22	WMeml round-out section 6.1 and 6.2 WMeml gave into OCP 8-bits per Byte Rule	ssiegel	2006-12-05 2006-12-06
0.22	Gloss section WMeml section, incorporate Jim's v22 feedback	ssiegel ssiegel	2006-12-06
0.24	Introduce "Immediate" attribute to WMemI as per team meeting	ssiegel	2006-12-11
0.25	Gloss for first document check-in	ssiegel	2006-12-14
0.26	Add WCI State Machine and Control Operations, Jim's feedback	ssiegel	2006-12-19
0.27	WMeml feedback	ssiegel	2006-12-20
0.28	WMI opcode and message length fix, first checkin-candidate Incorporate Changes from first specification review	ssiegel	2006-12-21 2006-12-28
0.29	Continued glossing	ssiegel ssiegel	2006-12-26
0.31	Remove imprecise SR-MD from WMeml	ssiegel	2007-01-10
0.32	Incorporate feedback from formal design review, part one	ssiegel	2007-02-13
0.33	Incorporate feedback from formal design review, part two	ssiegel	2007-03-02
0.34	Refine explanation of Message and Burst lengths	ssiegel	2007-03-07
0.35	Minor changes in advance of glossing review Rename to "Worker Interface Profiles"	ssiegel	2007-03-09 2007-03-14
0.36 0.37	Burst Precise discussion	ssiegel ssiegel	2007-03-14
0.38	WCI: Detail the writeresp enable behavior	ssiegel	2007-05-22
0.39	Clarify/Correct use of SResp Error (ERR) Response	ssiegel	2007-05-25
0.40	Tan Shade PreciseBurstsOnly in WSI and WMI, detail difference	ssiegel	2007-06-08
0.41	Added stronger NDA mark to cover page and footer	ssiegel	2007-06-22
0.42 0.43	Added observation on framing and MDataLast to WSI (page 42) Added Reset observation	ssiegel ssiegel	2007-06-28 2007-07-23
0.43 (cont.)	Attribute massaging for Precise/Imprecise Burst attributes	ssiegel	2007-07-26
0.44	Attribute massaging for Precise/Imprecise Burst attributes	ssiegel	2007-07-27
0.44 (cont.)	WCI force_aligned defect corrected	ssiegel	2007-08-01
0.45	WCI MFlag response rules clarified	ssiegel	2007-08-06
0.46	WCI nit, WMeml signals, Burst attributes changed	ssiegel	2007-08-07
0.47 0.48	Remove BurstCapable attribute from WMeml Remove MaxIdleCycles and MaxIdleRules	ssiegel	2007-08-08 2007-08-31
0.48 (cont.)	Add Continuous attribute (WSI, WMI, and WMemI)	ssiegel ssiegel	2007-08-31
0.49	Refine Continuous attribute (WSI, WMI, and WMemI) from feedback	ssiegel	2007-09-06
0.50	First inclusion of the schema information	ssiegel	2007-09-10
0.51	Incorporate Shawn's markup to v.47 (part 1)	ssiegel	2007-09-10
0.52	WCI discussion embellished	ssiegel	2007-09-11
0.53 0.54	Corrected wording for WMeml dataaccept configuration paramater Corrected over-determined case for WSI attributes wrt MessageLengthIsExplicit	ssiegel	2007-10-26 2007-11-29
0.54	Added WSI RequestCanLead attribute	ssiegel ssiegel	2007-11-29
0.56	Renamed WSI RequestCanLead attribute to EarlyRequest	ssiegel	2007-11-30
0.57	Added WSI MaxMessageBytes, RemainderEOM Attribute	ssiegel	2008-02-04
0.58	Refined RemainderEOM attribute to support zero-length transfers	ssiegel	2008-03-31
0.61	Major Editorial Update, plus revert RemainderEOM to byte enables in WSI	jkulp	2008-08-19
0.66	Continue Major Editorial edit plus factoring data interface attributes, and more precise endian support, for review of sections 1-6	Jkulp	2008-10-06
0.72	Finish major editorial update, plus more consistency, OCP compliance, abortable attribute	Jkulp	2008-10-21
5.72	on WSI, simplify WMI, fix heading levels in XML schema section	σκαιρ	2000 10-21
1.0	Enter final comments, all typos and clarifications. Add MReqLast to WMeml	jkulp	2008-11-13
1.1	OpenCPI initial version.	Jkulp	2009-10-14
1.2	Added WTI, and clarified areas based on automation (0.77)	jkulp	2010-01-20
1.3	Some typos, property metadata details, WSI abort to DataInfo, reset/clock clarifications	jkulp	2010-06-12

26 27

OpenCPI Page 2 of 88

27 **Table of Contents** 28 1 References 6 29 Definitions6 30 31 32 Requirements8 33 2.3 34 Non-Goals 9 35 2.5 Overview......9 Worker vs. Infrastructure and OCP Master/Slave Roles......12 36 37 38 39 40 41 2.9.1 42 Worker Global Attribute Details.......17 43 44 45 Signal Prefix Guideline18 46 2.10.3 47 3 Worker Control Interface (WCI)20 48 WCI Motivation.......20 49 50 3.2.1 Control and Configuration......21 51 3.2.2 WCI Control Operations 22 52 3.2.3 53 3.2.4 54 3.3 55 3.3.1 56 WCI Worker Attribute Details26 57 WCI OCP Profile/Configuration Parameters27 58 59 60 Indicating Control versus Configuration......29 3.6.1 61 3.6.2 62 3.6.3 63 Worker Control Operation Interrupt on the MFlag[0] signal31 3.6.4 Worker "Endianness" Indicated on the MFlag[1] signal......31 64 3.6.5 65 Worker Attention on the SFlag[0] signal31 3.6.6 66 Configuration Property Access32 3.6.7 67 3.6.8 68 WCI Infrastructure Coping32 69 Worker Data Interfaces......34 70 4.1 71 4.2 Worker Data Interfaces Attribute Summary......35 72 4.3 Worker Data Interfaces Attribute Details.......36 73

74	4.4.1 Worker Data Interface Reset Behavior	37
75	4.4.2 Worker Data Interface Flow Control	38
76	5 Data Widths and Byte Enables in WSI, WMI, and WMemI profiles	39
77	5.1 DataWidth equals ByteWidth	39
78	5.2 DataWidth is a multiple of ByteWidth, and ByteWidth is 8 (bytes are octets)	
79	5.3 DataWidth is a multiple of ByteWidth, and ByteWidth is greater than 8	
80	6 Worker Streaming Interface (WSI)	40
81	6.1 WSI Motivation	40
82	6.2 WSI Overview	40
83	6.3 WSI Attributes	41
84	6.3.1 WSI Attribute Summary	
85	6.3.2 WSI Attribute Details	
86	6.4 WSI OCP Profile/Configuration Parameters	
87	6.5 WSI OCP Signals	
88	6.6 WSI Semantics	
89	6.6.1 Opcode Indication on MReqInfo	
90	6.6.2 Messages (or "frames") are OCP Bursts	
91	6.6.3 Byte enables	
92 93	6.6.4 Aborting Messages	
93 94	6.7 WSI Infrastructure Coping	
95	6.7.2 Infrastructure Best Fractice for Slave/Consumers	
	,	
96 97	7 Worker Message Interface (WMI)	
97 98	7.1 WMI Motivation	
99	7.2.1 WMI Consuming versus Producing:	
100	7.2.2 Indication of message length	
101	7.2.3 Indication of done-with-message	
102	7.2.4 Indication of buffer available	
103	7.2.5 Message content addressing	
104	7.3 WMI Worker Attributes	
105	7.3.1 WMI Attribute Summary	
106	7.3.2 WMI Worker Attribute Details	
107	7.4 WMI OCP Profile/Configuration Parameters	54
108	7.5 WMI OCP Signals	55
109	7.6 WMI Semantics	
110	7.6.1 "Done with Message" (DWM) Indicated on MReqInfo[0]	58
111	7.6.2 No-Data Indication on MAddrSpace[0]	
112	7.6.3 Buffer Availability Indicated on SThreadBusy	
113	7.6.4 Opcode and Message Size Move Downstream on {M S}Flag	
114	7.7 WMI Infrastructure Coping	
115	7.7.1 Infrastructure Best Practice for Slave Producers (feeding Worker Consumers)	
116	7.7.2 Infrastructure Best Practice for Slave Consumers (fed by Worker Producers)	
117	8 Worker Memory Interface (WMemI)	
118	8.1 WMemI Motivation	
119	8.2 WMemI Overview	
120	8.3 WMemI Worker Attributes	
121	8.3.1 WMemI Attribute Summary	65

122	8.3.2	WMemI Attribute Details	65
123	8.4 WM	MemI OCP Profile/Configuration Parameters	66
124	8.5 WM	MemI OCP Signals	67
125	8.6 WM	MemI Semantics	69
126	8.6.1	Two basic modes of WMemI: bursts or not	69
127	8.6.2	Use only Single-Request Multiple-Data for Precise Bursts	69
128	8.6.3	Intra-burst write data flow control	69
129	8.6.4	Intra-burst read data flow control	70
130	8.7 WM	MemI Infrastructure Issues	70
131	8.7.1	Burst support	70
132	8.7.2	Intra-burst flow control	
133	8.7.3	Data/byte widths	71
134	9 Worke	er Time Interface (WTI)	72
135		I Motivation	
136		I Overview	
137	9.3 WT	TI Worker Attributes	73
138		WTI Attribute Summary	
139	9.3.2	WTI Attribute Details	73
140	9.4 WT	TI OCP Profile/Configuration Parameters	73
141	9.5 WT	TI OCP Signals	74
142	9.6 WT	'I Semantics	74
143	9.6.1	Indicating to the worker when time is valid and available	75
144	9.6.2	Indicating to the infrastructure when time is not required	75
145	9.6.3	The simplest case	75
146	9.7 WT	TI Infrastructure Issues	75
147	9.7.1	Time not needed	75
148	9.7.2	Time not available	75
149	10 WIP	XML Schema	76
150		troduction	
151		uick XML Introduction	
152	•	op Level Element: Component Specification	
153	10.3.1		
154	10.3.2		
155	10.3.3	Data Plane Aspects of a Component Specification	
156	10.3.4		
157	10.4 To	op Level Element: Component Implementation Description	83
158	10.4.1	Attributes of a Component Implementation	
159	10.4.2	Control Plane Aspects of a Component Implementation	84
160	10.4.3	Data Plane Aspects of a Component Implementation	
161	10.4.4	Memory Aspects of a Component Implementation	87
162	10.4.5	Time Aspects of a Component Implementation	88
163			

1 References

164165

166

167

168

169

When the term "OCP Specification" is used in this document, the reference is to version 2.2 of the OCP Specification, Document Revision 1.0. The OCP specification and supporting information are available from www.ocpip.org.

Table 1 - Table of Reference Documents

Title	Published By	Link
Open Core Protocol Specification version 2.2	OCP-IP	Public URL: http://www.ocpip.org/socket/ocpspec
IEEE Standard VHDL Language Reference Manual Std. 1076-2002	<u>IEEE</u>	Public URL: http://ieeexplore.ieee.org/Xplore/login.jsp?url=/iel5/7863/21658/0100347 7.pdf

1.1 Definitions

- 170 **Application** IP is either application of infrastructure. Application IP blocks are called workers in this document.
- "(interface) Attribute" The WIP attributes of an interface determine the OCP
 configuration parameters and thus the signals in the interface.
- 174 "(worker) Configuration Properties" Named storage locations of a worker that may
- be read or written. Their values indicate or control aspects of the worker's operation.
- 176 Reading and writing these property values may or may not have side effects on the
- operation of the worker. Configuration properties with side effects can be used for custom worker control. Each worker may have its own, possibly unique, set of
- 179 configuration properties. They may include hardware resource such registers, memory,
- 180 and state.
- 181 **WIP** Worker Interface Profiles The interface profiles defined in this document.
- 182 "(application) Container" A collection of "infrastructure" IP configured to "contain" a
- set of application workers, such that the two combined represent a complete FPGA design. I.e. a "donut" of IP with chip pins on the outside, and the application workers
- residing in the "hole". Interfaces that cross the inside container bounds (between the
- hole and the donut) are between application and infrastructure. Interfaces that stay
- within the hole are between application workers. The outside of the container
- 188 represents off-chip interfaces.
- 189 "(worker) Control Operations" A fixed set of control operations that every worker
- 190 has. The control aspect is a common control model that allows all workers to be
- managed without having to customize the management infrastructure software for each

OpenCPI Page 6 of 88

- 192 piece of IP, while the aforementioned configuration properties are used to specialize
- 193 components.
- 194 "Implementation Attribute" An attribute related to a particular implementation
- 195 (design) of a worker, for one of its interfaces. I.e. one that is not necessarily common
- across a set of implementations of the same high level interface definition.
- 197 **Infrastructure** IP is either application or infrastructure. IP that is not application is
- 198 infrastructure.
- 199 "OCP Configuration Parameter" An OCP-defined parameter used to configure the
- 200 signals of an OCP interface.
- 201 "Opcode" Synonymous with "message type" in the context of this document.
- 202 Opcodes allow multiple message types to be sent across worker data interfaces.
- 203 "**Profile**" A name for a subset of the universe of possible values of OCP configuration
- 204 parameters with a specific and well-defined set of choices, intended to facilitate and
- 205 regularize common usage. See OCP chapter 11 "OCP Profiles".
- 206 "Protocol Attribute" A higher-level attribute more related to "what" is communicated
- than "how". Protocol attributes for communication between connected data interfaces
- that are independent of implementation.
- 209 "Worker" A concrete implementation (and possibly runtime instance) of a component,
- 210 generally existing within a container. "Application IP blocks" (components) are termed
- 211 "workers" in this document.
- 212 "Wxx" A shorthand abbreviation for any of the four interface profiles defined herein
- 213 (WCI, WSI, WMI, WMeml).

2 Introduction

215 **2.1 Purpose**

214

- 216 The purpose of this document is to introduce and describe a collection of Worker
- 217 Interface Profiles (WIP or WIPs)¹ and how to use them to produce WIP-compliant IP. It
- 218 specifies metadata and interfaces used by tools and RTL IP developers, using
- 219 underlying OCP and XML standards. These interfaces are relevant to both application
- and infrastructure/platform developers, but this document is focused on application
- developers, with many infrastructure requirements inferred. I.e., by stating what
- 222 application IP (worker) developers may do, it implies what infrastructure developers
- 223 must "cope" with, and support.

OpenCPI Page 7 of 88

¹ Both "WIP" and "WIPs" are acceptable acronyms. As the mnemonic is shorthand for "Worker Interface Profile**s**", they both refer to a *collection* of profiles. This is the WIP functional spec. It describes and defines the four WIPs.

- 224 Standardized interfaces are understood to separate or decouple the concerns on each
- side of the interface (e.g. application and infrastructure). This decoupling increases
- opportunity for reuse, simplifies overall system design, and helps enable team design
- 227 flows. By hiding details that are not important to the other side of the interface, the
- 228 groundwork is set for deploying solutions where application and infrastructure
- 229 components may be changed without impacting the other.

230 **2.2 Requirements**

- Well-Defined Adaptability
- Well-Defined Interoperability
- Independent from Specific Implementations
- HDL Language-Agnostic, HDL Language-Neutral
- Semantics hold under Hierarchy
- Must support compliance with SCA/CP289

237 **2.3 Goals**

- 238 This document defines, for WIP users, which choices can be made by the IP (core,
- worker) designer about Control, Data, and Memory interfaces, how those choices are
- described, and the implications of those choices on OCP, protocol, timing, and signal
- 241 details.

246

247

248249

250

- Goal 1: **Well-Defined Interoperability**: The WIPs are defined to achieve interoperability
- 243 when connecting the implementations of two designers who make independent choices
- within the categories of Control, Data, and Memory interfaces. This interoperability is
- 245 achieved in several ways, in order of desirability from most-desirable to least-desirable:
 - direct (glue-less) signal connection
 - using tie-off/ignore rules when the signals do not exist on the other side
 - using well-defined adapter glue (gasket logic added between the IP cores)
 - using advice to inform one side of the choices of the other (implies generated/parameterized IP)
- Well defined in this case means, given the interface choices made by both sides, there
- is a well defined way of connecting them such that they interoperate. If there are no
- 253 choices (i.e. there is exactly one interface that must be used in all situations) then this is
- easy. If choices are provided for the convenience or performance of the
- implementations, interoperability is more challenging. This tradeoff is a key force in the
- design of the WIPs: make it easy to design workers, make it possible for them to
- 257 interoperate.
- 258 Goal 2: Bias Towards the Application: The interfaces described here are intended to
- be used either between different application IP blocks, or between application IP blocks
- and the infrastructure blocks that manage the platform. It is a specific goal of the WIPs
- to bias the freedom of choice and ease of design towards the application-side and have
- the infrastructure-side of the platform cope and adapt to these choices. Thus the
- application developer's job is easier, and the platform developer's job is harder (and

OpenCPI Page 8 of 88

- thus the platform is more valuable). This asymmetry recognizes that there are more
- applications than platforms.
- 266 Goal 3: Clearly Defined Choices: The expression of the choices will be crisp and clear,
- such that design artifacts (such as headers and entity declarations) may be
- 268 programmatically generated without ambiguity. Each interface profile (WIP) will have
- 269 attributes that precisely and unambiguously determine OCP configuration parameters
- and OCP signals used as a consequence of the chosen attribute values.
- 271 Goal 4: Completeness for Application IP: The profiles described here will capture
- 272 most requirements for the external interfaces for application IP blocks. Excluded are
- interfaces that contain predetermined or constrained functionality, such as a hardcore,
- 274 pin, or legacy IP.
- 275 **2.4 Non-Goals**
- 276 This document does not intend to prescribe any specific implementation of a particular
- interface.
- 278 This document does not address Transaction Level Modeling (TLM) and other
- 279 verification concerns.
- 280 This document is not intended as a usage tutorial for either the WIPs or the underlying
- OCP semantics. It is recognized that separate documents for application developers
- are needed to reduce the learning and knowledge required to use the WIPs. In
- 283 particular, using the WIPs means using a subset of OCP. Using only this document, the
- reader must read and understand much more of the complete OCP specification than is
- 285 fundamentally required to use the WIPs.
- 286 **2.5 Overview**
- The WIPs are OCP profiles, fully compliant with the OCP specification as well as a thin
- 288 layer of additional metadata and semantic definition, so as to provide utility for their use
- in Control, Data, Memory, and Time interface patterns. All the WIPs taken together use
- a modest subset of OCP.
- 291 The diagram below shows the taxonomy of the worker (component) interfaces
- 292 described in this document. Each interface is defined by choosing one of the 4 profiles,
- and choosing values for the attributes defined for each profile.

OpenCPI Page 9 of 88

Worker Interface Profiles (WIPs) Worker Worker Control Memory Interface **Interface** (WMeml) (WCI) Worker Time Worker Worker Interface Stream (WTI) Message Interface Interface (WSI) (WMI)

Figure 1 - Worker Interface Profile Taxonomy

Worker Data Interfaces

The term "worker" and "component" are used interchangeably in this document; however worker is generally more concrete and closer to an implementation and component is more abstract and closer to a functionally specified entity. The WIP specification presents a worker- centric bias making it easy for the designer to express the choices from the WIP patterns (i.e. control, data, and memory). Worker authors (component implementers) should find that the communication patterns presented here cover substantially all of their core connectivity needs (when they are not already externally specified). They should use this document as the specification for that connectivity.

When the other side of an interface is not connected to a co-located worker (another part of the same application residing in the same FPGA), it is connected to "infrastructure IP". Infrastructure IP includes logic that adapts the outside world to the WIP interfaces and visa versa. Infrastructure IP may also include IP that adapts WIP profiles to each other, when certain profile choices are made on each side that is not directly connectable. Infrastructure IP creators must be aware that they take on an additional burden and value, as they must in general accommodate all possible worker implementation choices *per profile* for a particular interface, not just one worker's implementation choice.

The application (worker) and infrastructure are two sides of the WIP solution; both are aspects of IP development. Both application and infrastructure providers using these WIP profiles of OCP-IP will use this document as the normative spec.

An illustrative example:

294295

296

297

298

299

300

301

302

303

304

305 306

307

308 309

310

311312

313

314

315

316

317

318

319

320

The following diagram shows two (application) workers inside an FPGA. To be a complete FPGA design this application must be surrounded by a container that connects to the external hardware (pins and external devices). In this particular example

OpenCPI Page 10 of 88

322

323 324

325

326

327

328

329

330

331

332

333 334

335

336

337

338 339

340

341

344

345

346

of deploying two of an application's workers on a single FPGA, there are eight OCP links, identified by a numbered circle, each with a master and slave.




Figure 2 - Two Workers in an FPGA

Links 1 and 2 show examples of the Worker Control Interface (WCI). The WCI provides control and configuration for each worker. Each worker in an application will have exactly one WCI slave interface.

WCIs are used to implement the "control plane". Workers (components of the application executing inside an FPGA) are controlled and configured by external entities, usually software.

Links 3 and 4 show examples of the Worker Stream Interface (WSI). The WSI provides unidirectional FIFO streaming with flow control. Workers may have 0 or more WSIs. Consumer WSIs are always slaves. WSI producers are always masters. Link 3 talks to a worker in another chip somewhere else, with help from the container. Link 4 is local.

Links 5 and 6 show examples of the Worker Message Interface (WMI). The WMI provides the ability for workers to actively produce or consume data from buffers with the capability for random addressing and buffer reuse. Workers may have 0 or more WMIs. A worker's WMI interfaces are always masters, regardless if they are producing or consuming. Both links in this case talk to workers in other chips, with help from the container.

342 WSIs and WMIs are used to implement the "data plane". This is the way workers 343 communicate with each other.

Link 7 shows an example of the Worker Memory Interface (WMeml). The WMeml provides the ability for a worker to have a direct or multiplexed link to local memory such as bulk-attached SRAM or DRAM, or embedded BRAM or MRAM. The worker's

WMeml is the master and the infrastructure's WMeml is the slave. 347

OpenCPI Page 11 of 88

349

350

353

354

355

356

357

358 359

- **Link 8 shows an example of the Worker Time Interface (WTI).** The WTI provides the ability for a worker to access the current time (time of day, UTC etc.). The worker's WTI is the master and infrastructure's WTI is the slave.
- 351 2.5.1 Worker vs. Infrastructure and OCP Master/Slave Roles
- 352 The table below lists each of the four WIPs and their OCP roles.

Table 2 - Interface OCP Master/Slave Roles

Interface	Worker OCP Role	Infrastructure OCP Role	
Worker Control Interface (WCI)	Slave	Master	
Worker Streaming Interface (WSI)		ucer is Master umer is Slave	
Worker Message Interface (WMI)	Master	Slave	
Worker Memory Interface (WMemI)	Master	Slave	
Worker Time Interface (WTI)	Master	Slave	

Recall that the OCP Master side of an interface is the side that is generating OCP requests. The figure below shows two workers ($\mathbf{W_1}$ and $\mathbf{W_2}$) communicating messages via WMI, which requires in interposed infrastructure module ($\mathbf{I_A}$) that acts as WMI slave on both sides.




Figure 3 - Two WMI Application Workers Communicating via a buffer

OpenCPI Page 12 of 88

2.6 Document Organization

360

390

391

392

393

394

395

- 361 For each of the four interfaces described, there are sub-sections as follows to describe
- the interface profile. **X** is the particular section describing a profile. **Www** is the name of the profile.
- 364 **X.1 Www Motivation** This section explains the purpose of the profile.
- 365 **X.2 Www Overview** This section provides a high level description of the profile and how it may be used.
- 367 **X.3 Www Attributes** The available choices, from a worker author's perspective, to use this particular profile. These *WIP attributes* determine the OCP configuration
- 369 parameters and the OCP signals. These attribute choices are a simpler and higher level
- 370 set of choices than the lower level details of the multiplicity of the OCP configuration
- parameters. Thus there are tools which automate the generation of OCP configuration
- 372 parameters and signals from these simpler WIP attributes, according to this
- 373 specification. Developers simply specify the attributes, use the tools, and implement
- 374 based on the generated IP definitions and skeletons generated by the tools.
- All attributes have a default value, although some attributes are not used if other attributes are set to specific values.
- 377 The types used in the worker profile attribute tables are specific XML Schema data
- 378 types such as boolean or unsignedInt. The XML namespace prefix (usually xsd:) is
- omitted from the types for readability.
- 380 Observation: In some frameworks, there may be a high-level component description of
- 381 the overall component and its interfaces (frequently called "ports"). This may be an
- 382 Interface Definition Language (IDL) or electronic datasheet such as SPIRIT/IP-XACT. In
- such a case, some of the values for these attributes may be derived or inferred from
- 384 such a high level representation.
- 385 Every interface has a Clock attribute to indicate if the interface requires an OCP clock
- that is different from the OCP clock applied to the WCI. When it is different from the
- WCI clock, it must be specified as one of the clocks in the Clocks global attribute for the
- 388 worker. Every interface has a ClockSignal attribute, whose default is the standard OCP
- name of the clock signal for the interface (with appropriate prefix).

Attribute Name	Type (per XML Schema)	Default Value	Description		
Clock	string	Same as WCI	The name of the clock to be used at this interface		
ClockSignal	String	Empty	The name of the clock signal to be driven at this interface when it is not the OCP standard name (Clk) with appropriate prefix.		

X.4 Www OCP Profile/Configuration Parameters - The worker author does not specify the OCP configuration parameters directly. They are either constant over the profile; or they are strictly derived from the simpler, condensed WIP attributes. This section provides details as to how the OCP configuration parameters are strictly derived from the choice of WIP profile attribute values. This mapping from WIP attributes to OCP configuration parameters is automated by transformation tools that accept the WIP

OpenCPI Page 13 of 88

- 396 attributes as inputs and produce OCP configuration files and/or VHDL entity/component
- 397 definitions as output.
- 398 The OCP Configuration Parameter Table lists parenthetically in the description column
- 399 the attribute(s) that determine the value of each OCP configuration parameter. This
- 400 summarizes the map from attributes to OCP configuration parameters.
- 401 This section and table can be skipped when readers simply want to know how OCP
- 402 signals are derived from WIP attributes, since the table under the next section (Www
- 403 OCP Signals), describes this mapping (attributes to signals) directly, without reference
- 404 to the OCP configuration parameters.
- 405 The values in the table are the explicit values and default-overrides to the OCP
- 406 configuration parameter defaults, based on attribute values (or constant for the profile).
- 407 **X.5 Www OCP Signals** The worker developer does not specify the OCP signals used.
- 408 The profile attributes determine the OCP configuration parameters, which strictly
- 409 determine the OCP signals, per the OCP specification.
- 410 Because the OCP interface semantics are defined by the OCP specification, there is no
- 411 need for this document to describe any OCP signal timings or protocols. As a result of
- 412 the worker interface attribute selections, there can be additional semantic meaning,
- 413 layered above the OCP behavior, for certain signals as described by the next section
- 414 (Www Semantics).
- 415 Clock signals are not listed in the master-to-slave or slave-to-master tables. Refer to
- 416 section 2.7 on OCP Interface Clocking.
- The OCP Signal table for the profile shows which signals may be included, when they
- are included, and what their width is. All of these are determined by the WIP attribute
- 419 values (and the OCP configuration parameters that are determined by the attribute
- 420 values).
- 421 X.6 Www Semantics This subsection describes any added meaning to the signals or
- 422 metadata that are not inferred from the OCP configuration parameters and thus the
- 423 OCP specification.
- 424 X.7 Www Infrastructure Coping Interface specific guidance on how the
- infrastructure needs to cope with the application worker chosen attributes. (E.g.
- 426 generics, generators, and requirements).
- 427 Use cases and examples not part of the normative specification are located outside the
- 428 profile definition sections.

429 **2.7 OCP Interface Clocking**

- 430 This section describes the clocking of the OCP interfaces of workers
- 431 All OCP interaction is between a single master and slave. The clock for each OCP
- interface is in general driven neither by master or slave². It is driven by the

OpenCPI Page 14 of 88

² "The Clk and EnableClk signals are special in that they are supplied by a third (external) entity that is neither of the two modules connected through the OCP Interface". (OCP specification Pp33)

- 433 infrastructure. For this reason, the clock signal has been omitted from each profile's
- 434 Wxx OCP Signal section, even though there is a clear association between clocks and
- 435 interfaces. Thus WIP-compliant workers do not generate or emit clocks.
- 436 Every interface on a worker is assigned to a particular *Named Clock Domain*
- 437 (sometimes abbreviated to "clock"). This capability enables the worker author to express
- which interfaces share, or do not share, synchronization. The default, if no such clock 438
- 439 domain is mentioned for an interface, is that the interface uses the same clock as the
- 440 WCI for the worker (the control interface). The worker metadata is used to specify the
- 441 assignment of interfaces to clocks.
- 442 Worker implementation logic must be consistent with the stated choices. If an interface is assigned to a particular clock domain, it must respect that clock domain. 443
 - Example 1: If a worker consumes a WSI stream on one interface, delays it through a register, and outputs it on another WSI interface; these two interfaces must be placed in the same named clock domain. If the worker author designed the logic so that the output interface was designed for asynchronous operation, then the two interfaces could be in the same named domain, or in different domains.
- 450 Example 2: If a worker implements a fixed N:1 decimator (or 1:M interpolator) 451 then the clocks may be in different named domains with additional specific 452 attributes, which may describe their (rational) relationships.
- 453 Rather than have each interface on a worker carry a clock name attribute, all the clocks 454 associated with a particular worker are collected together in the section on Worker
- 455 Global Attributes. Then each interface can reference the appropriate clock in its own
- 456 "Clock" attribute.

445

446

447

448

449

457

2.8 Reset Propagation and Behavior

- 458 This section describes the reset behavior and propagation rules for a worker.
- 459 Every application worker must have exactly one WCI (Worker Control Interface). That
- 460 WCI interface is connected to the "control system" infrastructure (typically controlled by
- 461 software), not another worker. The control system controls the operational state of the
- 462 worker and configures it. The configuration and control behavior is discussed below in
- 463 the WCI section.
- 464 There are special semantics for the (OCP) reset on the WCI:
- 465 When WCI reset is asserted (MReset n='0') as *input* to the WCI (slave) interface
- 466 of a worker, the worker shall propagate the reset as an output to all other
- 467 interfaces on that worker (as OCP MReset in or SReset in as appropriate for
- 468 each interface).
- 469 The WCI MReset in input signal is in the clock domain of the WCI (per OCP). It is
- 470 the responsibility of the worker to properly propagate the reset indication to the

OpenCPI Page 15 of 88 other interfaces in the appropriate clock domains at each interfaces (data, memory, time etc.).

For all data interfaces on a worker:

Data interfaces have both reset inputs and reset outputs. All worker implementations must insure that reset inputs (or outputs propagated from WCI) at their data interfaces force all OCP output signals at that interface to a proper reset state per OCP.

The simplest (and least helpful for application debugging) worker implementations will have the default "false" value of the "ResetWhileSuspended" attribute of its WCI. This means that the worker is not prepared to retain any particular functionality when it sees reset inputs at its data interfaces (other than obeying OCP rules for output signals at the interface under reset). The control system will know this attribute setting, and consider the worker non-functional if any adjacent (data-connected) workers are reset (via WCI). The worker will be fully reset via WCI reset before any other actions are taken.

The "ResetWhileSuspended" attribute of a worker (when true) indicates this more advanced behavior: the worker will support the Stop control operation and, while suspended, accept data interface resets. Such resets (from adjacent workers) will not render the worker non-functional and thus allow for configuration property operations while in this suspended state even though some data interfaces are in a reset state. After the asserted data interface resets are deasserted, such workers may be resumed via the "start" control operation.

Such a suspended worker receiving a reset on a data interface should interpret the meaning as a "message-level abort", and bring the associated interface to an idle, neutral state, while attempting to minimize the loss of state in the rest of the worker. This may be performed by "disposing of" or "aborting" a message in-flight across a particular interface at the time of reset and preparing that particular interface to properly operate anew following the deassertion of the reset input.

The intent of this per-data-interface reset is to allow some workers to be entirely reset (e.g. if they are locked or behaving badly), while still allowing access to the state of adjacent (and not as badly behaved) workers. In some cases this is simply for debugging, but there are cases where the control system for a certain application may be able to recover from unresponsive workers by suspending adjacent ones (via **stop**), and resetting the "bad" one. The extent to which a worker implementation allows for suspended states and data-interface resets is implementation defined. I.e. some worker implementations may not recover (be resumable) after having data interfaces reset while in the suspended state.

Example: A 3:1 message merge worker receiving a reset on one of its message input interfaces should, if buffering, avoid appending the partially received message to the output, and should understand that any remaining input on that interface will not arrive. It should prepare for new, valid, input following the reset event.

OpenCPI Page 16 of 88

- OCP Reset Policy Applies. See the OCP section on the sideband signal reset; but specifically:
- Reset asserts asynchronously, but de-asserts synchronously.
- Reset shall be asserted for a minimum duration of 16 cycles of the clock domain to which the reset signal is synchronous.
- Workers must be able to reset in this 16-cycle duration.
- 519 Observation: Although system reset will assert asynchronously and de-assert
- 520 synchronously; this does not preclude an implementation from using a fully synchronous
- reset scheme, if so desired. Such an implementation would need to be aware that reset-
- assertion could occur without a relationship to any clock edge and may need to
- 523 synchronized appropriately. WIP-compliant workers must accomplish reset in 16 WCI
- 524 clocks.

528

529

530

531

2.9 Worker Global Attributes

Worker global attributes contain information that is common across the worker, and not specific to an interface.

2.9.1 Worker Global Attribute Summary

Table 3 – Worker Global Attribute Table

Attribute Name	Type (per XML Schema)	Description
Name WIP:Name		The name of the worker[TBD: extra constraints]
Clocks	WIP:Clock	Declaration of a clock for the worker
Endian	WIP:Endian	WCI endian and global endian default

2.9.2 Worker Global Attribute Details

Name WIP:Ident The name of the worker

- 532 Name The name of the worker.
- 533 In VHDL, the worker Name attribute must match (ignoring case) the entity name for top-
- level entity (design unit) for the RTL worker component being described. In Verilog, it
- 535 should match the module name.

Clocks WIP:Clock Declaration of a clock for the worker

- Clocks A set of all the implementation's *Named Clock Domains*. Each interface may reference these clocks to indicate that the interface operates in the domain of that clock.
- 538 Interfaces with no such association are assumed to operate with the same clock as the
- WCI interface. Interfaces may also declare that they "own" a clock, which simply means
- that the clock signal will be specifically be associated with the signals of that interface
- 541 (and use the standard OCP naming for that signal). Interfaces may also simply
- reference other interfaces explicitly, meaning that they use the same clock as the
- referenced interfaces. If a clock is not "owned" by an interface, it requires its own
- explicitly specified name. If no clocks are mentioned at all, a single clock, "owned" by

OpenCPI Page 17 of 88

- the WCI, will be defined and used for all interfaces. See the XML metadata section for syntactic details.
- 547 Constraints (min/max rates etc.) per clock are TBD in this version of this specification.

Endian	WIP:Endian	WCI endian and global endian default

- Endian A string indicating the endianness of the worker's WCI interface behavior and the default endian behavior for all data interfaces.
- The default value (when this attribute is unspecified) is the simple case when workers:
- have no configuration property values of sizes other than the data path of the WCI (32 bits)
- accept or produce messages on any data interface that are only a (byte) multiple of the width of that interface
- process data values not smaller than the width of the data interface.
- If any of these are *not* true, the implementer must specify a non-default value, as defined here:

Attribute Value	Description
neutral	No inherent endianness — the default as described above
big	Big-endian
little	Little-endian
static	The implementation supports both endian via a static configuration input.
dynamic	Runtime supports both, accepted dynamically (on release of WCI reset) from WCI MFlag[1]

WCI MFlag[1]	Description
0	Little-Endian
1	Big-Endian

559 **2.10 Signal Prefix Rules and Guidelines**

- This section describes the rules and guidelines used to generate unique signal names for an RTL component based on interface name and interface profile selected.
- 562 2.10.1 Signal Prefix Rule
- Signals shall be named by forming a signal name that is the concatenation of a unique interface identifier and the OCP signal name separated by the underscore ('_')
- 565 character.

558

- 566 For example:
- 567 MyUniqueInterfaceName_MCmd
- 568 2.10.2 Signal Prefix Guideline
- A default practice of the above rule involves the concatenation of the following substrings, separated by the underscore (' ') character:
- 1. The string "ocp" to indicate behavior per the OCP spec.

OpenCPI Page 18 of 88

- 572 2. The abbreviation for the interface/profile type {WCI|WSI|WMI|WMemI}
 - 3. The interface name
- 574 4. The OCP signal name

575 For example:

573

578

579 580

581

582

583

584

585 586

587 588

```
576 ocp_wsi_chan1_MCmd
```

577 2.10.3 Signal Prefix Example

The VHDL code snippet below shows an example use of the signal prefix naming guideline. This is part of a worker entity declaration. The annotated sections indicate:

- 1. There is no special "types" or "definitions" package required for the WIPs.
- 2. These signals are not explicitly part of any interface. They may or may not be used with a particular WIP.
- 3. Infrastructure with a WSI named "AD0".
- 4. Infrastructure with a WSI named "AD1".

```
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.numeric_std.all;
library WORK;
use WORK.vita49_types.all;
entity app is
      rt (
-- Clock and reset signals...
dataClkDiv2 : in std_logic;
hsdl_clk : in std_logic;
     dataClkDiv2
                                                          137.5 MHz
                                                       -- 62.5 MHz
     hsdl_clk
     local_clk : in std_logic;
dataClkDiv2_rstn : in std_logic;
                                                       -- 33 MHz
                                                       -- Reset synchronized to dataClkDiv2
                                                       -- Reset synchronized to hsdl_clk
     hsdl_clk_rstn
                            : in std_logic;
     local_clk_rstn
                             : in std_logic;

    Reset synchronized to local_clk

     -- A/D Data Interface
     ocp_wsi_ad0_MBurstLength : in std_logic_vector(1 downto 0);
ocp_wsi_ad0_MBurstPrecise : in std_logic;
ocp_wsi_ad0_MCmd : in std_logic_vector(2 downto 0);
                                         : in std_logic_vector(63 downto 0);
     ocp_wsi_adO_MData
     ocp_wsi_ad0_MDataLast
                                         : in
                                                 std_logic;
                                         : in
                                                 std_logic;
     ocp_wsi_adO_MDataValid
     ocp_wsi_adO_MReset_n
                                         : in
                                                 std_logic;
     ocp_wsi_adO_SThreadBusy
ocp_wsi_adO_SReset_n
                                         : out std_logic;
                                         : out std_logic;
                                                 std_logic_vector(1 downto 0);
std_logic;
     ocp_wsi_ad1_MBurstLength
ocp_wsi_ad1_MBurstPrecise
                                         : in
                                           in
                                                 std_logic_vector(2 downto 0);
std_logic_vector(63 downto 0);
std_logic;
     ocp_wsi_ad1_MCmd
                                           in
     ocp_wsi_ad1_MData
                                         : in
     ocp_wsi_ad1_MDataLast
                                         : in
     ocp_wsi_ad1_MDataValid
ocp_wsi_ad1_MReset_n
                                         : in
                                                 std_logic;
std_logic;
     ocp_wsi_ad1_SThreadBusy
ocp_wsi_ad1_SReset_n
                                         : out std_logic;
                                         : out std_logic;
```

Note that entity declarations can be automatically generated using WIP-compliant tools, based on the XML format of the worker's attributes described in the WIP XML Schema section below.

OpenCPI Page 19 of 88

3 Worker Control Interface (WCI)

3.1 WCI Motivation

 The Worker Control Interface's primary goal is to make control plane support simple for worker developers by *insulating them from platform-specific interconnection networks*, busses, bridges and endpoints that may exist between a generic control software and the worker. It is the interface used to control and configure workers by the "control system", which is usually software-based, with intervening infrastructure IP and hardware between the control software and worker IP.

The diagram below illustrates the separation of concerns between Application Software Developer, Platform Supplier, and the worker control interface (WCI) described in this section.




Figure 4 - Worker Control Interface - Separation of Concerns


3.2 WCI Overview

The WCI is how workers are controlled and configured, and exactly one WCI exists in every worker. Worker authors make certain choices for their WCI, such as the types and extent of run-time configurable properties that are to be read or written. The choices, as in all WIP interfaces, are specified in simple XML-based "metadata". This metadata then can be used to generate (for any implementation language) the interface definition used for a particular WCI-based interface.

A set of workers, each with a WCI, may at some point be collected together to be part of an application, running together, collocated, within a single FPGA. The infrastructure provider can generate Control Plane IP (CPIP) for a set of workers, each having a WCI slave. CPIP refers to an implementation of the infrastructure-side logic used to control

OpenCPI Page 20 of 88

 the workers. The CPIP is used by control software to access the WCI of a group of workers in the FPGA.



616 Figure 5 - Relation of CPIP to Workers

3.2.1 Control and Configuration

WCI transactions are either "control" or "configuration".

Control refers to a fixed set of "control operations" that every worker component, explicitly or implicitly, must support. There are seven specific control operations. For some workers, the action associated with a particular WCI Control Operation may be no action at all. Note that while (application) workers must all be uniformly controllable according to this control scheme, infrastructure IP may be configurable using a subset of WCI when it is not appropriate for them to be controllable as application IP.

This control scheme is based on a number of other similar systems, and is intended to be both generally useful and also support enough controllability to be compliant with other component standards. The general model is that workers transition through various states based on the control operations. It is the responsibility of control software to keep track of the states and issue the control operations in the correct sequence. OCP transactions on the WCI interface perform (request) the control operations. Here is a summary of the control operations, which are detailed below.

OpenCPI Page 21 of 88

Table 4 – WCI Fixed Control Operations – Function Overview

WCI Control Operation	Function Overview		
Initialize	Perform any post-reset initializations, before configuration.		
Start	Enter the operational state; start doing the operational work.		
Stop	Suspend work such that operation can be resumed.		
Release	Shut down operations, undoing "initialize".		
Test	Run component-level built-in-test, if available.		
BeforeQuery	Ensure configuration properties are consistent prior to accessing.		
AfterConfig	Act on multiple interdependent configuration property settings.		

Configuration (**Properties**) refers to the set of and access to writeable and readable properties, with and without side effects, within the worker. This is the typical "register file" configuration pattern in many IP designs. Components may also implement their own worker-specific specialized control schemes by read and/or write side effects within the configuration property space. WCI provides the interface to access a worker's configuration properties at run time.

The worker is responsible for the mechanism, which might be an array of registers with write-enable logic and read-back multiplexers. If required or desired by a given worker implementation, properties may be smaller than 32 bits (i.e. 8 or 16), and "packed" with multiple 8 or 16-bit properties in the same 32 bit word. All properties must appear in the configuration "space" on their natural boundaries (see the "force_aligned" semantic in the OCP specification). If a property value is larger than 32 bits, then when the control software changes it, the first 32-bit word of the property value is written *last*, so that the worker knows when the entire value has been updated via the WCI.

3.2.2 WCI Control Operations

In order to keep workers as simple as possible in common cases:

- It is the responsibility of software to sequence these operations properly, so workers
 do not need to check for invalid control operations (issued in the wrong state or in
 the wrong order)
- Metadata known to control software can indicate whether operations are implemented at all (except start, which must be implemented). See the ControlOperations attribute below.

The operations are:

- (Implicit) Reset via the WCI's Mreset_n signal
 - After loading or unsuccessful release, a hard reset to known state
 - Infrastructure/control system automatically asserts reset upon loading
 - Worker must be ready to accept Initialize operation after reset is deasserted
 - Worker can count on reset being asserted for 16 cycles, per OCP

OpenCPI Page 22 of 88

- If there is any possibility that 16 cycles are not enough, use **initialize** to perform initializations that take more time.
 - WCI Reset has special meaning for other interfaces. It is described in section 2.9 on Reset Propagation and Behavior.
 - Workers must be reusable via a reset assertion multiple times after a bitstream load.

667 • Initialize

663

664

665

666

668

673

674

675

676

677

679

680 681

682

683

684

685

686

688

689

690

691 692

693

695

696

697

698

- Needed when additional initialization is required that is not done during reset.
- Allows worker to perform initial work not under reset, to achieve a known ready-670 to-run state
- Appropriate place for worker to perform runtime initialization (e.g. programmatic initialization of a LUT).
 - Worker can internally set initial/default values of properties (if not done via Reset)
 - Worker can't do one-time work based on software-configured properties. They
 are not valid yet since control software has not set them yet. Control software
 will not perform property access until Initialize completes.

678 • Start:

- Transition to operational to doing the real work based on property values and data (at data interfaces).
- Must do any one-time initializations that depend on software-configured property values, since **Initialize** cannot do this (properties are not set yet).
 - Starting operation is based on property values set after Initialize completes
 - No OCP commands on **data** interfaces are allowed before this operation. Thus slaves must assert OCP SThreadBusy upon reset and not deassert it until **start**. Masters must not issue commands until **start**.

687 • Stop

- Make the worker inactive/paused/suspended, such that it can be resumed (via **Start**); maintain resources/state/properties for examination.
- When this operation is complete, data interfaces are "between messages". This is a "graceful" suspension, not an immediate destructive stop or abort.
- Worker is suspended, data interfaces can be reset by connected workers (if implementation is capable of it)

694 • Release

- Can be no-op if all un-initialization must be done under **Reset**: it returns failure in this case.
- Shut down/abort operations, discard any state (state is now undefined)
- If release fails, worker is unusable until reset.
- May be called after any operation, but not immediately after deassertion of reset.

OpenCPI Page 23 of 88

- 700 BeforeQuery
- After **Initialize**, **Start**, or **Stop**, informs worker that a group of related property queries (configuration reads) will be made and their values should be consistent.
- Used to enable coherent access to multiple property values.
 - Only necessary when property values depend on each other and need to be properly updated to be meaningful/correct.
- 706 AfterConfig
 - After **Initialize**, **Start**, or **Stop**, informs worker that a group of related property changes have been made.
 - Informs worker that changes to a set of interrelated property values can be processed.
- 711 Test

705

707

708

709

710

712

713

714

715

716 717

- After **Initialize**, used to run component-specific built-in tests, parameterized by current configuration property settings.
 - In a given system or application, the overall system built-in-test can be easily parameterized for each worker by specifying the configuration property settings prior to running "test", and the expected configuration property settings after running "test".
- Simple workers that have no tests can indicate it in metadata.
- 719 3.2.2.1 Simple workers can be very simple for control operations
- 720 For the simplest workers, only the **Start** operation is mandatory. The implications are:
- **Initialize** is not needed all initialization is performed during reset, and after reset is deasserted, the worker can accept configuration accesses.
- **Release** is not needed, and the implementation forces control software to reset the worker (which will propagate the reset to adjacent workers). This reduces system debugging and reloading flexibility, since this "software reset" is not possible.
- Stop is not implemented, and thus the worker cannot be paused/suspended at all.
 This forces whole applications to not be stoppable and thus degrades application and system-level debugging.
- 729 **Test** is not implemented: there is no built-in test capability.
- **BeforeQuery** and **AfterConfig** operations are not needed if there are no interdependent property values that must be used atomically and/or consistently.
- Thus simple, but useful, workers are only required to implement the **Start** operation; all others can be specified as unimplemented in metadata.
- 734 3.2.3 WCI States
- 735 Since control software is required to issue control operations correctly, in the
- appropriate sequence as defined above, these states are not normative, but are use to

737 further clarify the use of control operations.

OpenCPI Page 24 of 88

- State: Exists: after deassertion of reset or after successful **release** operation, ready for **initialize**.
 - The worker is loaded (if necessary), not necessarily fully initialized, configuration properties are not valid, property access is not valid, but reset is deasserted.
 - Only the **initialize** operation will be issued. If successful the worker is considered to be in the "initialized" state.
- State: Initialized: after successful initialize operation, ready to start (or release)
 - The worker has been completed any run-time initialization, doing whatever is necessary or appropriate after reset was deasserted.
 - The worker is in a known, stable, initial state "ready to start doing work", but not operational.
 - Configuration properties can be read and written (SW software can see the result of initialization, and can configure the worker prior to normal operation). Thus the **BeforeQuery** or **AfterConfig** operations maintain this state.
- State: **Operating:** after successful **Start** operation, ready to **Stop** (or **Release**)
 - The worker is doing normal work based on properties and data interfaces; it is "processing".
 - Configuration properties can be read or written, including BeforeQuery or AfterConfig operations
- State: **Suspended:** after successful **Stop** operation, ready to **Start** (or **Release**)
 - The worker is suspended; data interfaces can be reset by connected workers (if the implementation is capable of it).
 - Configuration properties can be read or written, including BeforeQuery or AfterConfig operations
- State: **Unusable**: after unsuccessful **Release** operation
- In this state the only action to take is to assert WCI reset.
- 764 3.2.4 WCI Errors

741

742

743

745

746 747

748

749 750

751

753

754

755

756

758

759

760

761

770

775

776

- 765 WCI errors are indicated via the OCP SResp signal taking the ERR value for control
- operations. Metadata indicates whether errors are transient whether retrying
- operations (other than **release**) makes any sense for an implementation.
- All **release** errors indicate unusable worker circuit state requiring reset before re-use
- If Initialize, Start, Stop, BeforeQuery or AfterConfig return an error
 - If metadata (the **Retry** attribute) says retries are possible, try again.
- If not, (or after unsuccessful retries) then **Release** may be attempted.
- After a successful **Start** operation, worker may assert the attention signal (see semantics for Sflag[0] below) to indicate that an error has occurred or attention is required
 - What this means is worker dependent, but generic software knows to inform users or invoke attention handlers for the worker.

OpenCPI Page 25 of 88

• Should be cleared by worker during **Release** operation (and reset).

778 3.3 WCI Attributes

- 779 Worker authors specify their WCI implementation choices via the following attributes,
- 780 from which all OCP configuration parameters and signals are derived.
- 781 Each attribute is labeled indicating whether the attribute value relates to the worker's
- interface (and thus applies to all implementations), or whether the attribute value is
- 783 specific to a particular implementation of the same interface common to all related
- 784 implementations. The metadata formats (XML Schema described below) separates
- attributes that are about high level interface behavior (e.g. properties) from those that
- 786 are implementation-specific.

789

787 The Clock and ClockSignal attributes, described in section 2.6, are applicable to WCI.

788 3.3.1 WCI Worker Attribute Summary

Table 5 – WCI Worker Canonical Attribute Table

Attribute Name	Type (per XML Schema)	<u>Int</u> erface vs. <u>Imp</u> le- mentation	Default Value	Description (OCP configuration parameters affected by this choice)
SizeOfConfigSpace	unsignedInt	Int	0	Size (in Bytes) of worker's configurable property space
WritableConfigProperties	boolean	Int	false	TRUE: there are writable configuration properties
ReadableConfigProperties	boolean	Int	false	TRUE: there are readable configuration properties
Sub32bitConfigProperties	boolean	Int	false	TRUE: there are properties that are smaller than 4-Byte values
ControlOperations	string	Imp	empty	List of supported control operations (start is assumed and mandatory)
ResetWhileSuspended	boolean	Imp	false	TRUE: the worker will remain functional when adjacent interface resets when SUSPENDED

790 3.3.2 WCI Worker Attribute Details

791 This subsection contains the per-attribute details of choices available for the WCI.

SizeOfConfigSpace	unsignedInt	Int	0	Size (in Bytes) of worker's configurable property space

- This attribute, when non-zero, indicates the size in bytes of the configuration property
- space. When this attribute is zero, it indicates that there are no configurable properties
- 794 on this worker.
- 795 Observation: Because the WCI physical OCP data path is 4 bytes wide, this value is
- typically a multiple of four. However, this is not a requirement; this attribute may be any
- 797 unsignedInt less than or equal to 2^16 (0x10000), 64KB.

WritableConfigProperties	boolean	Int	false	TRUE: there are writable configuration properties
--------------------------	---------	-----	-------	---

This attribute indicates the worker has writable configuration properties. If FALSE all configuration properties are read-only.

OpenCPI Page 26 of 88

814

815

816

817

818

819

820 821

826

ReadableConfigProperties	boolean	Int	false	TRUE: there are readable configuration properties
--------------------------	---------	-----	-------	---

This attribute indicates the worker has readable configuration properties. If FALSE, all configuration properties are only writable.

Sub32bitConfigProperties	boolean	Int	false	TRUE: there are properties that are smaller than 4-Byte values
				I SIIIAIICI UIAII 4-DVLC VAIUCS

This attribute indicates the worker contains configuration properties that are less than 32-bit (4-byte) values. When TRUE, OCP byte enable logic is provided to allow for 1-byte, and aligned 2-byte and 4-byte reads and writes. When FALSE, there is no byte enable logic and all accesses are 4-bytes.

The following attributes are metadata only and do not affect the OCP configuration

ControlOperations	string	Imp	empty	List of supported control operations (start is assumed and mandatory)
ResetWhileSuspended	boolean	Imp	false	TRUE: the worker will remain functional when adjacent interface resets when SUSPENDED

These two attributes provide information to the generic control software about the behavior of the workers in response to certain conditions. All default to FALSE to keep simple workers simple.

The ControlOperations attribute indicates (to control software) which of the optional control operations are implemented by this worker. Start is required, but all others are optional. Lack of support for **Stop** and **Release** degrades system debugging capability, and is thus not recommended.

The ResetWhileSuspended attribute indicates that the worker supports data interface resets when in the suspended state. This essentially means that the worker can be stopped/suspended, adjacent connected workers can be reset, and this worker can resume operation without itself requiring a complete WCI reset. The use-case is the ability to reset an adjacent broken worker without losing all the state and configuration of this worker. This attribute helps to define three levels of support for stoppable workers, with increasing value for system control and debugging:

- No support at all: "Stop" is not in the list in the ControlOperations attribute.
- Stoppable without supporting reset of adjacent workers: ResetWhileSuspended is
 FALSE
- Stoppable and able to remain configurable and resumable (via Start) when adjacent workers are reset.

3.4 WCI OCP Profile/Configuration Parameters

The WCI OCP profile is the aspect of the WCI that has to do with OCP configuration parameters and signal configuration. This section describes the concrete, complete, and unambiguous transformation from WCI WIP attributes described above, to the OCP configuration parameter inferred from those attributes. This transformation is implemented in automation tools.

The table below lists only those parameters that are different from the OCP configuration parameter defaults (per the OCP specification).

OpenCPI Page 27 of 88

Table 6 – WCI OCP Configuration Parameters

OCP Configuration Parameter	Value	Description (How OCP parameter is determined if not constant, and any tieoffs)
addr_wdth	[5N]	If SizeofConfigSpace <= 32, N = 5 Else N = ceil(log2(SizeofConfigSpace - 1))
addr_space addrspace_wdth	{0 1}	If SizeofConfigSpace > 0: 1 Else: 0
byteen	{0 1}	If Sub32BitConfigProperties = TRUE: 1 Else: 0
cmdaccept	0	
data_wdth	{0 32}	If SizeofConfigSpace > 0 : 32 Else: 0
force_aligned	{0 1}	If Sub32BitConfigProperties = TRUE: 1 Else: 0
mdata	{0 1}	If WritableConfigProperties = TRUE: 1 Else: 0
mflag	1	
mflag_wdth	2	
mreset	1	
sdata	{0 1}	If ReadableConfigProperties = TRUE: 1 Else: 0
sflag sflag_wdth	1	
sthreadbusy sthreadbusy_exact sthreadbusy_pipelined	1	Note: For pipelined, proactive flow control (backpressure) by way of the SThreadBusy signal
write_enable writeresp_enable	{0 1}	If WritableConfigProperties = TRUE: 1 Else: 0

MAddr[1:0] will always be zero (per OCP) and should be ignored. Sub-32bit write indication, when configured, is indicated only by the byte enables.

Observation: WCI is an exception among the four profiles listed herein in that it is the only one to define the OCP configuration parameter writeresp_enable to '1' (when there are writable properties). This is because WCI requires that configuration writes provide the capability for success versus failure indication. The use of the writeresp_enable OCP behavior provides this capability with the minimal implementation. All WCI writes require a SResp response, either accept/success (DVA) or error/failure (ERR).

- Accept (DVA) is interpreted as a worker configuration property being committed, with any side effects that might produce errors complete.
- Error (ERR) is interpreted as a worker explicitly failing to accept a configuration property write.

Each worker may define its own meaning of the write response beyond the indication of success or failure. This can be a range of behavior from "write value stored" to "side-effect of configuration property write action completed".

850 Observation: WCI is not pipelined (datahandshake=0) and is single threaded.

OpenCPI Page 28 of 88

3.5 WCI OCP Signals

851

852

853

854

855

856 857

858

859

860

861

862

863

864

865

866

867

868

Signal configuration is unambiguously determined by the OCP interface configuration parameters (derived from WIP attributes as defined above) and as called out in the "OCP Signal Configuration Parameter" table in the OCP specification. The tables below show the signals from master-to-slave and slave-to-master. The positional order of signals is alphabetical.

Light yellow shading of the description indicates where an OCP signal has added WCI semantics. Details described in following section.

Table 7 – WCI Signals Driven by the Master, to the Slave

OCP Signal	When included	Width	Usage
MAddr	always	If SizeofConfigSpace <= 32, N = 5 Else N = ceil(log2(SizeofConfigSpace-1))	Encodes control operation [4:2] and property word addr[x:2]. [1:0]==0, per OCP, and ignored
MAddrSpace	SizeofConfigSpace != 0	1	0=Control Transaction, 1=Config Transaction
MByteEn	Sub32BitConfigProperties == TRUE	4	Byte enables for configuration writes
MCmd	always	3	Read/write command: MCmd[2]==0
MData	WritableConfigProperties ==TRUE	32	Configuration write data
MFlag	always	2	MFlag[0] = 1: Force control operation to terminate with error MFlag[1]:0/1=Little/Big-Endian
MReset_n	always	1	0 = Reset Entire Worker

Table 8 - WCI Signals Driven by the Slave, to the Master

OCP Signal	When included	Width	Usage
SData	ReadableConfigProperties == TRUE	32	Configuration read data
SFlag	always	1	SFlag[0]:1 = Attention
SResp	always	2	Command response
SThreadBusy	always	1	0/1 = Ready/not-read for Cmd

In the simplest cases where a worker has no configurable properties, is fixed endian, does not assert "attention", and takes no significant time (clocks) for configuration or control operations, there are eight non-constant, non-ignored signals: MAddr[4:2], MCmd[1], MReset n, SResp[1:0], SThreadBusy.

3.6 WCI Semantics

This section describes specific semantic signal meanings in WCI that are layered on top of the fundamental OCP signals. They are organized by function and then the signals affected.

3.6.1 Indicating Control versus Configuration

WCI transactions are either "control" or "configuration" as described in a previous section. The signal MAddrSpace[0], when configured into the interface, indicates a

OpenCPI Page 29 of 88

- 872 "Control" versus "Configuration" command. The value 0 indicates control operations.
- The value 1 indicates configuration property accesses (when they are needed).
- Workers that do not advertise any properties would not have this signal in their interface
- 875 (SizeofConfigSpace == 0). They may assume all WCI transactions are control
- 876 transactions.

877 3.6.2 Encoding of Control

- 878 Control operations are invoked by OCP read commands qualified with
- 879 MAddrSpace[0]='0' as described previously. Writes to the control operation AddrSpace
- will never occur. The specific control operation is encoded on the MAddr[4:2] signals as
- 881 follows.

882

Table 9 – WCI Control Encoding (MCmd=Read; MAddrSpace='0')

Signal	Value	Control Operation
	B'000 (0)	Initialize
	B'001 (1)	Start
	B'010 (2)	Stop
MAddr[4:2]	B'011 (3)	Release
MAGGI[4.2]	B'100 (4)	Test
	B'101 (5)	BeforeQuery
	B'110 (6)	AfterConfig
	B'111 (7)	RESERVED

883 3.6.3 Control Response

- WCI control operations are implemented as OCP Read commands to enforce end-to-
- end signaling. There is no read data returned on SData for control operations. Note that
- the SData signals are not configured in workers that have no readable properties.
- However, the worker is always required to return either SResp=DVA for success or
- 888 SResp=ERR for error in response to a control (or configuration) operation.
- The worker's return on SResp of either DVA or ERR signals the completion of the
- 890 operation. In some cases these control responses may be immediate; in others there
- may be a delay, perhaps due to acquiring a resource or serially executing a long
- 892 sequence.
- 893 Workers should avoid having excessively long delays for control response. They are "in
- transition" until such time as either DVA or ERR are returned. Access to configuration
- 895 properties will not be issued during the time between control operation issuance and
- 896 response, owing to the single threaded interface. This is intentional: no configuration
- property changes are allowed during control operation execution.
- 898 Workers must return a response ERR in response to a Worker Control Operation
- 899 Interrupt (MFlag[0]) when that master-to-slave interrupt assertion is made while the
- 900 request response is pending (see below for details).
- Note that the "read side effect" aspect of this control scheme is defined only at the
- 902 boundary between the infrastructure IP of the control system, and the worker. This
- 903 does *not* imply that such a read operation is directly initiated by software on some
- 904 external bus or interconnect. The mechanism by which software invokes a control
- operation on a worker is determined by the infrastructure IP (e.g. CPIP), not this WCI
- 906 behavior. Thus the typical problems of read side effects (from bus retries or fetch-

OpenCPI Page 30 of 88

- ahead) are not relevant here. The design decision was based on worker
- 908 implementation simplicity and minimizing signal requirements.
- 909 *3.6.3.1 Retry*
- 910 If a worker's error response is a transient condition that could be resolved by repeating
- a command, the worker author may indicate as much in metadata by setting the Retry
- 912 attribute to TRUE.
- 913 3.6.4 Worker Control Operation Interrupt on the MFlag[0] signal
- To handle the potential for a worker not responding to a control operation, the signal
- 915 MFlag[0] is always configured in WCI. The rising edge of MFlag[0]='1' forces a timely
- 916 completion to an outstanding control operation. The WCI master sets MFlag[0]='1'
- 917 where it remains asserted. It is cleared sometime after a SResp (error or success) is
- 918 detected by system software. This allows a worker to be interruptible without
- 919 implementing any timeout scheme itself.
- 920 Rule: When processing a control operation, a worker must provide a response within 16
- 921 clock cycles from receiving MFlag[0]='1' (similar to the 16 cycle reset requirement of
- 922 OCP). This timely response may be either the normal response to the outstanding
- 923 control operation, or an error response. It must not cause an "extra" response.
- Observation: If a worker never takes longer than 16 clock cycles to respond to a control
- operation response, it has no reason to monitor MFlag[0] and can ignore it.
- 926 MFlag[0] is signaled synchronously with the WCI interface clock and is out-of-band with
- 927 respect to commands and responses, per the OCP specification, .
- 928 3.6.5 Worker "Endianness" Indicated on the MFlag[1] signal
- 929 Workers that have the capability of operating either little-endian or big-endian are called
- 930 *bi-endian* workers. The signal driven by the infrastructure on the MFlag[1] signal
- 931 indicates to such a worker if it is in a little- or big-endian environment. The worker only
- 932 has this signal if the global Endian attribute is set to the "dynamic".

WCI MFlag[1]	Description
0	Environment is Little-Endian
1	Environment is Big-Endian

- 933 3.6.6 Worker Attention on the SFlag[0] signal
- 934 The signal SFlag[0] provides the capability for a worker to ask for attention. Assertion of
- 935 SFlag[0]='1' alerts the control system that the worker requests attention. The worker
- 936 holds it asserted as a level. Worker attention is cleared by some worker-defined action.
- 937 The semantics of this attention (i.e. why a given worker would assert this) is worker-
- 938 specific, and thus generic controlling software would know what to do with it. A typical
- 939 response would be for a worker-specific handler to read certain configuration property
- 940 values to find out "what happened that requires attention". Otherwise generic software
- 941 can simply report the error condition. Examples include "a new high water mark to
- some measured value has been reached", or "an overrun condition has been detected".

OpenCPI Page 31 of 88

- 943 After this, some writable property might acknowledge receipt of the information causing
- 944 the attention indication and thus clear it.
- 945 SFlag[0] is signaled synchronously with the WCI interface clock, but "out of band" with
- 946 respect of commands and responses, per the OCP specification.
- 947 3.6.7 Configuration Property Access
- 948 "Configuration Properties" represent the collection of accessible locations inside a
- 949 worker that can be read or written. Hardware engineers may think of configuration
- 950 properties as the "control/status register description" of the worker IP. These locations
- don't necessarily have "register" storage. They can be anything abstracted though
- 952 load/store semantics and may have worker-specific side effects.
- The default choice is for all properties to be at least 32 bits in size, the full data width of
- 954 the WCI OCP interface. In the case where the worker provides sub-32-bit properties,
- individual 1-byte or 2 byte locations may be read or written, using the OCP byte enables
- 956 (note any low order address bits per OCP).
- 957 Access to configuration properties occurs when MCmd=RD or MCmd=WR and
- 958 MAddrSpace[0]='1'. In this case the word address of the configuration property is
- 959 signaled on MAddr[N:2]. Note that when configured, SData and/or MData must use
- 960 data wdth=32. The MAddr[1:0] shall always be zero, per OCP³.
- 961 3.6.8 Reset
- Reset has special meaning for WCI. It is described in section 2.9 on Reset Propagation
- 963 and Behavior

969

970

3.7 WCI Infrastructure Coping

The infrastructure is the master of the WCI interface, and must support the choices made by the worker implementing the WCI slave. The WCI attributes are largely used to add certain features as required by the implementer. The attribute choices that must be handled by the infrastructure IP acting as master of the WCI interface are:

- Presence or absence of configuration parameters, implying presence or absence of data and address space signals.
- Readability or writability of properties, implying presence or absence of the data signals in each direction.
- Presence of sub32bit properties, implying presence or absence of byte enables.
- Size of the usable configuration address space, determining the width of the address signals, and the range of value address values.
- 976 WCI masters, which are infrastructure IP, should include all the optional signals. For signals that are optional for the worker, the table below describes how the infrastructure

OpenCPI Page 32 of 88

³ MAddr is a byte address that must be aligned to the OCP word size (data_wdth). If the OCP word size is larger than a single byte, the aggregate is addressed at the OCP word-aligned address and the *lowest order address bits are hardwired to 0*. (from OCP specification, page 15)

(WCI master) accommodates their absence on the worker (or uses OCP tieoff rules to accommodate them):

Table 10 – Infrastructure Handling of Optional WCI Signals

OCP Signal	When Signal would be absent at the worker	How missing signals are handled
MAddr	High order [5+] may be missing, depending on SizeofConfigSpace	OCP Tieoff rules apply: No connection is made, extra MAddr bits are only driven to the default tieoff: 0. This should be checked in the test environment.
MAddrSpace	SizeofConfigSpace == 0	OCP Tieoff rules apply: No connection is made, MAddrSpace only driven to the default tieoff: 0 (indicating control). This should be checked in the test environment.
MByteEn	Sub32BitConfigProperties == FALSE	OCP Tieoff rules apply: No connection is made, MByteEn only driven to the default tieoff: all 1s (indicating full 32 bit words). This should be checked in the test environment.
MData	WritableConfigProperties ==FALSE	OCP Tieoff rules apply: No connection is made, MData will never be driven at all. This should be checked in the test environment.
SData	ReadableConfigProperties == FALSE	OCP Tieoff rules apply: No connection is made, SData will never be driven at all.

981

978

979

980

OpenCPI Page 33 of 88

4 Worker Data Interfaces

982

993

994 995

996

997

998

999

1004

- The Worker Streaming Interface (WSI) and Worker Message Interface (WMI) are both
- worker data interface profiles that enable message-oriented, data-plane communication.
- These interfaces are used by workers to produce or consume streams of data
- 986 messages to or from other workers, whether collocated in the same device or executing
- elsewhere (possibly in a different type of device, including other workers implemented in
- 988 software). This is the WIP data plane.
- 989 From the point of view of an application worker, it is talking to another worker in the
- 990 application or some source or sink I/O or network endpoint at the "edge" of the
- application. However, the other side of the interface may be infrastructure IP in these cases:
 - The other application worker is local, but needs an adapter for the two data interfaces to interoperate. Example: one worker producing on a WSI, and the other consuming on a WMI.
 - This worker is at the "edge" of the application, and the data is being sent to or received from some external source or I/O device. Example: a signal is being received from an A/D converter, and the worker is receiving the output of the A/D via the infrastructure IP that deals with the A/D hardware.
- The other worker is remote, in another device, requiring infrastructure IP to forward messages across some interconnect or fabric. Example: a worker is producing data for a consuming worker in a different processor connected by a fabric or bus attached to the local processor or FPGA.

4.1 Data Protocol between Workers: the Data Plane Protocol

- 1005 Worker Data Interfaces convey data content between workers according to a defined
- simple data protocol described by metadata attributes. Certain protocol aspects (e.g. explicit length, or message type) are supported and defined in this specification to
- 1008 "flatten" the overall protocol stack: simple protocol aspects that are efficiently
- 1009 implementable at this level of interface (based on OCP) are supported here. The
- 1010 definition and format of actual message payloads are not defined here. This data plane
- 1011 protocol is independent of:
- the actual width (in wires/signals) of the interface
- the chosen data interface profile (WSI or WMI)
- the implementation-specific attributes specified by the worker implementer.
- The protocol is defined as a sequence of fixed or variable size messages, each of which
- 1016 may have a "message type" or "payload type" called an opcode. Messages contain
- 1017 data values, which may or may not be same size within a message. When all the data
- values in all types of messages in the protocol are the same size, the infrastructure can
- 1019 provide interoperability support between diverse endianness. By knowing the message
- granularity (the least common multiple of all message sizes), the actual signal interface
- 1021 can be simplified to the minimum necessary (e.g. eliminate byte enables).

OpenCPI Page 34 of 88

- The simplest case of the "protocol" is a sequence of single-data-value messages of a single message type. This is the way to describe such a continuous stream of data values:
- There is one type of message (and thus no need for an explicit "opcode").
- The message length is fixed as the size of a single data value (and thus no need for an explicit message length, e.g. if the data values are single precision IEEE floats, all messages are 32 bits/4 bytes).
- 1029 In the more complex case all these attributes may be used to specify the "data protocol":
- Size in bits of the smallest data values in all messages (default to 8). Note that the width of the data path is never allowed to be less than this.
- Maximum message length in data values (default is 1).
- Whether messages are variable length or are all the same (maximum) length. (default is fixed length)
- The granularity of message sizes in number of data values (default: 1 data value, example of complex single float: 2 values).
- How many different message types (also called "opcodes") (default: 1)
- 1039 The concept of "data value" is used to specify interfaces that are not byte oriented. If
- the data message is byte oriented, then MaxMessageValues is simply the maximum
- 1041 message length in bytes. If all defaults are used, all messages are of the same type,
- and are one byte long. Streams of single values with no real message boundaries are
- specified simply by specifying the DataValueWidth attribute to the size of the data
- values (in bits). Thus the concept of "length" of messages is always in units of data
- 1045 values.

- 1046 These attributes are specified for each of the worker's data interfaces, independent of
- 1047 choices of WSI or WMI, or other implementation-specific attributes. A worker
- 1048 "implementer" then chooses either WSI (streaming, fifo-style) or WMI (buffered or more
- 1049 complex cases) to implement the (producer or consumer) data interface. Thus the
- message attributes above are about the messages produced or consumed, and not
- about the WIP profile used, or the implementation choices within that profile.

4.2 Worker Data Interfaces Attribute Summary

- 1053 The WIP data *protocol* attributes are described in the following table. While these
- attributes are valid for all data interface profiles (WSI and WMI), the way the attributes
- 1055 affect actual OCP signals in the interface are different and specified in the section for
- 1056 each profile. The "producer/consumer" role attribute of the interface is also here since it
- is also common to all data interface profiles. These attributes are repeated in the
- 1058 attribute tables for the data interface protocols.

OpenCPI Page 35 of 88

Table 11 - Worker Data Interface Protocol Attributes

Attribute Name	Type (per XML Schema)	Default Value	Description
DataValueWidth	unsignedInt	8 (octets)	Number of bits in the smallest data value in any message.
DataValueGranularity	unsignedInt	1	The number of data values in all messages are a multiple of this value.
DiverseDataSizes	boolean	false	TRUE: the data value sizes in messages vary, in which case automatic endian transformation is not possible. FALSE: the data values in all messages are all the same size: DataValueWidth
MaxMessageValues	unsignedInt	1	Maximum number of values transferred in the longest message over all opcodes.
NumberOfOpcodes	unsignedInt	1	The number of different message types in the protocol
Producer	boolean	false	TRUE: the interface role is PRODUCER; FALSE: it is CONSUMER
VariableMessageLength	boolean	false	TRUE: the message length may vary, FALSE: message length is fixed.
ZeroLengthMessages	boolean	false	TRUE: some message types may be zero length FALSE: all messages contain at least one data value.

4.3 Worker Data Interfaces Attribute Details

1061 This subsection contains the per-attribute details for data interfaces.

DataValueWidth	unsignedInt	8	Number of bits in the smallest data value in any
		(octets)	message.

This attribute indicates the smallest unit of data, in bits, in the message payloads, and thus is the "bit granularity" of the message payloads. When the actual interface width is known, this value helps in determining things like byte enables and endian packing. The default is 8 for typical byte oriented payloads. The actual width of the data interfaces are not allowed to be smaller than this. This term was used in preference to "ByteWidth" (used in WMemI) since it has more semantics than typically associated with the term "byte".

DataValueGranularity	unsignedInt	1	The number of data values in all messages are a multiple of this value.
----------------------	-------------	---	---

This attribute further constrains the length of messages, indicating that the size of all messages are this multiple of the basic data value size. This value also helps in byte enable and endian packing determination for interfaces.

An example might be that the data stream consists of pairs of 32 bit single float data values (thus the interface width cannot be less than 32), thus all messages are a multiple of two such values or 64 bits. The interface is allowed to be 32 bits or wider. If it is 64 bits wide, then all messages are full words. If it is 128 bits wide, then the last 128-bit word of a message may only be half full.

DiverseDataSizes	boolean	false	TRUE: the data value sizes in messages vary, in which case automatic endian transformation is not possible. FALSE: the data values in all messages are all the same size: DataValueWidth
------------------	---------	-------	--

This attribute indicates whether message payloads consist of different sized data values or not. Then false, it indicates uniform data value sizes and thus enables infrastructure-supported endian adaptation.

OpenCPI Page 36 of 88

	MaxMessageValues	unsignedInt	1	Maximum number of values transferred in the longest message over all opcodes.		
1080 1081 1082	The maximum (or fixed) size of messages, expressed in data values, each of which is DataValueWidth in size. If not specified, the default is that all messages are single data values. This value can be zero, indicating that all "messages" have no payload at all.					
	NumberOfOpcodes	unsignedInt	1	The number of different message types in the protocol		
1083 1084 1085 1086	This attribute specified the number of different message types in the protocol. Opcodes are conveyed separate from message data, to indicate the message type. Typically different message types have different payload layouts. The default value of 1 is used when there is only one type of message in the stream.					
	Producer	boolean	false	TRUE: the interface role is PRODUCER; FALSE: it is CONSUMER		
1087 1088	This attribute indicat consumer (FALSE).	es whether	the interf	ace of the worker is a producer (TRUE) or		
	VariableMessageLength	boolean	false	TRUE: the message length may vary, FALSE: message length is fixed.		
1089 1090	This attribute indicat whether they can ha			ages are the same size (FALSE, the default), or TRUE).		
	ZeroLengthMessages	boolean	false	TRUE: some message types may be zero length FALSE: all messages contain at least one data value.		
1091 1092 1093 1094 1095	This attribute, when TRUE, indicates that the stream of messages may contain messages of zero length, requiring support for this in the actual interface. If all messages are zero length, and there is one opcode, the protocol is simply a stream of events with no content. When this attribute is true, it forces byte enables to be included in WSI.					
1096 1097 1098 1099	4.4 Worker Data Interface OCP Profiles Beyond the attributes above, there are several aspects of the OCP configuration and signal semantics that are common across Worker Data Interfaces: reset behavior and flow control.					
1100 1101 1102 1103 1104 1105 1106 1107 1108 1109 1110	4.4.1 Worker Data Interface Reset Behavior Workers in the same FPGA communicate with each other via data (plane) interfaces. According to the reset propagation rules mentioned earlier, every worker must propagate its master reset (an input which is on its single WCI), to all of its data interfaces (as an output). Thus a worker that is being reset via its WCI asserts reset on all its data interfaces, using the master or slave OCP reset signal according to the master or slave role of its data interface. Conversely, a worker that is stoppable and suspended, or has just come out of reset itself (after its WCI reset has been deasserted), must accept a reset input on its data ports, indicating that its adjacent worker is being reset via its WCI. Such reset inputs at data interfaces will not be asserted when the worker's WCI commands it to initialize or start.					

OpenCPI Page 37 of 88

Worker Interface Profiles (WIP) Functional Specification

1112	4.4.2 Worker Data Interface Flow Control
1113	Worker data interfaces all use OCP pipelined, non-blocking flow control (see "Flow
1114	Control Options" in the OCP specification). Thus flow control is accomplished without
1115	combinatorial paths crossing the interface more than once in a cycle. It also means that
1116	when the interface is flow-controlled it is between transactions, not in the middle of a
1117	transaction. This allows a worker master to take unilateral actions (such as abandoning
1118	a transaction) based on being blocked (perhaps for some amount of time), without
1119	affecting the other side of the interface and without backing out of a transaction.

OpenCPI Page 38 of 88

1120 5 Data Widths and Byte Enables in WSI, WMI, and WMeml profiles

- In these three profiles, the width of the data path is defined in the WIP attributes by the
- implementer. This width is specified by setting the DataWidth attribute, whose default
- value (for WSI and WMI) is the value of the DataValueWidth protocol attribute described
- above. Also, all these profiles define a minimum unit of data such that the data path
- width must be a multiple of that minimum width. We call this minimum width the
- 1126 ByteWidth of the interface, which of course is commonly = 8 (for octets). For Worker
- Data Interfaces, we use a synonym: "DataValueWidth", to connote that this is related to
- message payloads (i.e. the width of the data values in the payload). Since the WMeml
- 1129 profile is not associated with message payloads, we simply use "ByteWidth" for it. Due
- to the requirements of OCP, and to keep simple cases simple for the implementer, we
- treat three cases differently for all these profiles:
- 1132 DataWidth is the same as ByteWidth
- DataWidth is a multiple of ByteWidth, and ByteWidth is 8 (bytes are octets)
- DataWidth is a multiple of ByteWidth, and ByteWidth is greater than 8
- 1135 There is no support for ByteWidths less than 8 when ByteWidth is not the same as
- 1136 DataWidth. Byte enables are only relevant to writes in these profiles.

1137 5.1 DataWidth equals ByteWidth

- 1138 This simple case sets the normal OCP data field (the data wdth configuration
- parameter for the MData and SData signals). There is no need for byte enables, and no
- 1140 need for the complexity of the OCP "datainfo" signals. There is no WIP or OCP
- 1141 constraint on the value of DataWidth.

1142 5.2 DataWidth is a multiple of ByteWidth, and ByteWidth is 8 (bytes are octets)

- 1143 This case is fairly simple and common, and well supported by OCP. Write byte enables
- are enabled in the interface unless, for WSI, the message size granularity implies that
- they would never be needed (i.e. all words are always "full", not partial).
- 1146 OCP dictates that each byte enable signal corresponds to exactly 8 bits of the OCP
- 1147 MData path, and that path must be a multiple of 8 bits if byte enables are used.

1148 5.3 DataWidth is a multiple of ByteWidth, and ByteWidth is greater than 8

- 1149 To properly handle this case, OCP dictates that the data be split into two separate
- signal fields, {M,S}data and {M,S}datainfo. 8 bits of each byte are packed into the OCP
- 1151 {M,S}Data field, and the remaining bits of each byte are packed into the {M,S}DataInfo
- field. For example, if the WIP logical DataWidth was 36, and ByteWidth was 9, then the
- 1153 OCP MData field would carry logical bits <34:27><25:18><16:9><7:0>. and the OCP
- 1154 MDataInfo path would carry logical bits <35><26><17><8>.
- 1155 Thus the worker implementer (and possibly automation tools) might map the MData and
- 1156 MDataInfo fields into a single 36 bit Data field internal to the implementation for clarity
- 1157 and convenience.

OpenCPI Page 39 of 88

1158 6 Worker Streaming Interface (WSI)

- 1159 See the section on Worker Data Interfaces for information that applies to all data-plane
- 1160 WIP.

1179

1180

1181

1182

1183

1184

1191 1192

1193

1161 **6.1 WSI Motivation**

- 1162 The most common and simple way for one data processing IP block to communicate
- with another (with flow control) is through a parallel interface with simple FIFO
- semantics, typically with data and data-strobe signals from the producer and "ready" or
- 1165 "accept" signal from the consumer. The WIP profiles must certainly support this
- 1166 common, lean, simple case. The WSI is intended to satisfy this requirement,
- 1167 configuring OCP to meet this objective.

1168 **6.2 WSI Overview**

- 1169 The worker streaming interface is designed to be a simple, FIFO sequential method for
- workers to exchange a stream of messages. In WSI, workers producing data are always
- 1171 OCP masters, while workers consuming data are always OCP slaves. In cases where
- the workers are collocated (in the same device), this allows the possibility of "glue-less"
- or "gasket-less" signal connection between workers when both implementers choose
- 1174 the same WIP attributes.
- 1175 WSI is purposefully "feature-constrained" for simplicity. In additional to the data protocol
- attributes described earlier, the worker implementer makes these choices:
- How wide (in bits) is the streaming data interface; i.e. how many bits does one
 wish to produce or consume in a single OCP clock cycle?
 - Does the worker wish to support precise bursts? (i.e. is the message length known at the start of the message?).
 - Do the message OCP requests need to come ahead of (in advance of) the OCP message data itself? (especially in the case of the first request for the first data word of the message).
 - Are idle cycles permitted in the middle of the message?
- Can a frame be aborted and discarded after it has started transmission?
- 1186 WSI uses basic OCP burst semantics to represent a message or "frame":
- The start of a burst is the start of a message
- Burst length is message length (in transfer words of the data width of the interface)
- Precise OCP bursts may be used when message length is known
 - Imprecise OCP burst may be used when the producer cannot indicate exact message length at the start of a message
 - The end of the burst is the end of a message
- 1194 While a "WIP Message" is an abstraction used in both the WSI and WMI profiles and an
- 1195 "OCP Burst" is defined by the OCP specification, WSI maps WIP messages to OCP
- 1196 bursts, 1-to-1. WMI does not.

OpenCPI Page 40 of 88

- 1197 Workers using the WSI may want the ability to signal as early as possible, before data,
- the impending arrival of a message. The EarlyRequest attribute is used to enable this
- optimal latency behavior. Masters (producers) are free to insert intra-message idle data
- 1200 cycles either by driving MCmd=IDLE or (when EarlyRequest = TRUE) by de-asserting
- 1201 MDataValid, unless the Continuous attribute is set.
- 1202 When ImpreciseBursts are being used, and the Abortable attribute is set, the
- 1203 producer/master can abort a frame, indicating to the slave that the message should be
- 1204 discarded. This enables the typical cut-through optimization in some cases.
- 1205 In all cases the default OCP burstsinglereq=0 semantics apply: there will be exactly as
- 1206 many valid request beats as there are valid data words. WSI only allows FIFO access
- 1207 to data. Use WMI when random or out-of-order access to message contents is
- 1208 required, either as producer or consumer.

6.3 WSI Attributes

1209

- 1210 Worker authors using a WSI specify their implementation choices via the following
- 1211 attributes (as well as the data protocol attributes above), from which all OCP
- 1212 configuration parameters and signals are derived.
- 1213 The Clock and ClockSignal attributes, described in section 2.6, are applicable to WSI.
- 1214 Since WSI is a data plane interface, the worker data interface protocol attributes are
- 1215 applicable, as described in section 4.2. These are: DataValueWidth,
- 1216 DataValueGranularity, DiverseDataSizes, MaxMessageValues, NumberOfOpcodes,
- 1217 Producer, VariableMessageLength, and ZeroLengthMessages.

1218 6.3.1 WSI Attribute Summary

1219 Table 12 – WSI Attribute Table

Attribute Name	Type (per XML Schema)	Default Value	Description
Continuous	boolean	false	TRUE: within a burst, there shall be no idle cycles. FALSE: there may be idle cycles within a burst
DataWidth	unsignedInt	DataValue- Width	Physical width in bits/wires of the data path.
ByteWidth:DERIVED FROM OTHER ATTRIBUTES	unsignedInt	none	Smallest data that the interface needs to handle: If DataValueWidth*DataValueGranularity is a multiple of DataWidth and ZeroLengthMessage = FALSE: ByteWidth = DataWidth (thus no byte enables) Else: ByteWidth = DataValueWidth
ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used
Abortable	boolean	false	TRUE: Unfinished messages can be aborted FALSE: All messages are transmitted in full.
EarlyRequest	boolean	false	TRUE: Start-of-message can occur before data FALSE: First data will accompany start of message.

1220 6.3.2 WSI Attribute Details

1221 This subsection contains the per-attribute details of choices available for a WSI.

OpenCPI Page 41 of 88

Continuous boolean false	TRUE: within a burst, there shall be no idle cycles. FALSE: there may be idle cycles within a burst
--------------------------	--

- 1222 The Continuous attribute indicates *continuous* data bursts between master and slave,
- meaning that once burst data transfer begins, data is transferred on every cycle without
- interruption, either by the master (no idle cycles) or the slave (no flow control via
- 1225 SThreadBusy). This attribute only refers to *intra*-burst continuity and implies nothing
- 1226 about inter-burst behavior.
- 1227 Continuous=TRUE indicates, for producers: "Once I get started and allowed by flow
- 1228 control at the start of a burst, I will produce all the data in one continuous burst with no
- idle cycles and cannot accept any flow control (backpressure)". For consumers: "Once I
- 1230 receive the first data in a burst, I require and will accept all the data in one continuous
- burst, without idle cycles, and without asserting SThreadBusy until after the last request
- 1232 in the burst."
- 1233 This attribute does not change the OCP configuration or any of the signals in the
- interface. It expresses two aspects of the data transfer: data will fill every cycle, and no
- data flow-control will occur within the burst. This attribute is common to the WSI, WMI,
- 1236 and WMeml profiles.

DataWidth	unsignedInt	DataValue- Width	Physical width in bits/wires of the data path.
-----------	-------------	---------------------	--

- 1237 The DataWidth attribute is the physical width (word size) of the interface in bits. It must
- be a multiple of the DataValueWidth attribute. If not specified, the default value is the
- 1239 DataValueWidth attribute of the protocol used over this interface. When the
- 1240 DataValueWidth*DataValueGranularity is smaller than the DataWidth, and not a multiple
- of 8, OCP requires the data path to be split between two OCP fields (MData and
- 1242 MDataInfo). Octet-oriented or word-oriented interfaces never have this complexity.
- 1243 When DataValueWidth*DataValueGranularity is smaller than DataWidth, byte enables
- 1244 are required in the interface.
- 1245 This attribute is common to the WSI, WMI, and WMemI profiles, except that for the
- 1246 WMeml profile, the default value is 8.

ByteWidth:DERIVED unsignedInt	none	Smallest data that the interface needs to handle: If DataValueWidth*DataValueGranularity is a multiple of DataWidth and ZeroLengthMessage = FALSE: ByteWidth = DataWidth (thus no byte enables) Else: ByteWidth = DataValueWidth
-------------------------------	------	--

- ByteWidth expresses the size in bits of the smallest data value that the interface needs
- to handle, and is used to enable byte enable functionality in WSI, WMI, and WMemI.
- 1249 For WSI, ByteWidth is a derived based on data protocol attributes. It is not specified
- directly. For WSI, when ByteWidth is less than DataWidth, byte enables are enabled to
- indicate the actual valid data in the last word messages (and, when
- 1252 ZeroLengthMessages = TRUE, that there is no data in the last word).
- 1253 Thus byte enables are only required in WSI when the messages may have zero length,
- or may contain a number of values that do not fill the last DataWidth word of the
- 1255 message.

OpenCPI Page 42 of 88

ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used

- 1256 These burst attributes indicate what sort of burst transactions will be issued by the
- worker, as OCP master, or accepted by the worker as OCP slave. These attributes are
- 1258 common to WSI, WMI and WMeml WIPs.
- 1259 For WSI and WMI, one, but not both of these attributes must be TRUE.

Abortablo	hooloan	falco	TRUE: Unfinished messages can be aborted
Abortable	boolean	false	FALSE: All messages are transmitted in full.

- 1260 Abortable specifies that the producer may abort a message before it is fully transmitted,
- and that the consumer can handle and respect such an action. This is an important
- optimization when both sides are able to do this without extra buffering. It is analogous
- 1263 to the cut-through routing optimization in switches. The semantic is similar to the
- 1264 "discontinue" action in the Xilinx LocalLink Interface. It is optional since it has a modest
- 1265 cost in interface complexity, and can only be TRUE when ImpreciseBurst is TRUE.

EarlyRequest	boolean	false	TRUE: Start-of-message can occur before data FALSE: First data will accompany the start of message.
, ,			I FALSE: FIRST data will accompany the start of message.

- 1266 The attribute EarlyRequest is an implementation choice that allows, when TRUE, the
- 1267 WSI to convey message arrival (a.k.a. "start of message") in advance of the first data in
- the message. In general, this is a latency improvement: you can start a message
- 1269 earlier.
- 1270 For consumers, use EarlyRequest=TRUE in situations where the early indication of
- message arrival has value, typically to reduce latency. For producers, pass along this
- 1272 information if it is available: i.e. of the producer knows about a message before it has
- the first data of the message, it should pass this potentially latency-improving
- 1274 information to the consumer.
- 1275 When EarlyRequest = FALSE, the first data word of a message is required to be
- 1276 available at the same time as the first OCP request of the message. Secondarily, data
- is supplied at the same time as the OCP request for *all* words of the message.
- 1278 When EarlyRequest=TRUE, the interface uses the OCP defined behavior of
- 1279 datahandshake=1 to decouple the request from the data. This allows the producing-
- master to send OCP requests ahead of (or at the same time as), the corresponding
- 1281 data.

- 1282 Since OCP datahandshake behavior is thus optional, single-request-multiple-data
- 1283 (SRMD) bursts are not allowed for WSI. All bursts are always MRMD.

6.4 WSI OCP Profile/Configuration Parameters

- 1285 The WSI OCP profile is the aspect of the WSI that has to do with OCP configuration
- 1286 parameters and signal configuration. This section describes the concrete, complete,
- 1287 and unambiguous transformation from WSI WIP attributes described above, to the OCP
- 1288 configuration parameters inferred from those attributes. This transformation is
- 1289 implemented in automation tools.
- 1290 The table below lists only those parameters that are different from the OCP
- 1291 configuration parameter defaults (per the OCP specification).

OpenCPI Page 43 of 88

1292 Table 13 – Worker Stream Interface OCP Configuration Parameters

OCP Configuration Value Parameter		Description		
		(How OCP parameter is determined if not constant, and any tieoffs)		
addr	0	Note: No addresses, FIFO-like		
burstlength	1	,		
burstlength_wdth	{P}	If $PreciseBurst = TRUE$: NWords = ceil(MaxMessageValues*DataValueWidth/DataWidth) $P = max(2, floor(log_2(N)) + 1)$ Else: P = 2;		
burstprecise	0	If PreciseBurst = FALSE: tieoff MPreciseBurst to 0 (OCP default tieoff is 1)		
cmdaccept	0	Note: The SThreadBusy signal is used for backpressure.		
datahandshake	{0 1}	If EarlyRequest = FALSE: 0, Else: 1		
datalast	{0 1}	If EarlyRequest = FALSE: 0, Else: 1		
reqlast	1			
data_wdth	{Q}	If ByteWidth != DataWidth and ByteWidth != 8: Q = 8 * DataWidth/ByteWidth Else: Q = DataWidth		
byteen	{0:1}	If ByteWidth != DataWidth ZeroLengthMessages = TRUE: 1, Else: 0		
mdatainfo	{0 1}	If ByteWidth != DataWidth and ByteWidth != 8: 1 Else: 0		
mdatainfo_wdth	{R}	If ByteWidth != DataWidth and ByteWidth != 8: R = DataWidth - (8 * DataWidth/ByteWidth) Else R = 0 If Abortable: R = R + 1		
mdatainfobyte_wdth	{S}	If ByteWidth != DataWidth and ByteWidth != 8: S = ByteWidth - 8		
mreset	1	Note: producer may reset the connection		
read_enable	0	Note: Push only stream - No reads		
sdata Vote: 1 ds		Note. I ush only sucall - No Icaus		
resp	0			
sreset	1	Note: consumer may reset the connection		
reginfo	{0 1}	If NumberOfOpcodes > 1: 1, Else: 0		
reginfo_wdth	{T}	$T = Ceil(log_2(NumberOfOpcodes))$		
sthreadbusy				
sthreadbusy_exact	1	Note: SThreadBusy signal supports pipelined, proactive, flow-control backpressure from slave to master.		
sthreadbusy_pipelined]	buckpicssuie nom slave to master.		

1293 **6.5 WSI OCP Signals**

1296

Signal configuration is determined by the above interface configuration parameters as called out in the "OCP Signal Configuration Parameter" table in the OCP specification.

The tables below show the signal from master-to-slave and slave-to-master. The

1297 positional order of signals is alphabetical.

1298 Light yellow shading of the description indicates where an OCP signal has added WSI

1299 semantics. Details described in following section.

OpenCPI Page 44 of 88

Table 14 - WSI OCP Signals Driven by the Producer/Master

OCP Signal	When Included	Width	Usage
MBurstLength	always	If PreciseBurst = TRUE: max(2,floor(log2(ceil(When PreciseBurst = TRUE, the number of words in the burst, constant over the burst (OCP Precise Burst). When PreciseBurst = FALSE, = b'01' for the last request of the burst, = b'10' otherwise (OCP Imprecise Burst)
MByteEn	ByteWidth != DataWidth ZeroLength- Messages= TRUE	DataWidth/ByteWidth	WSI Specific Semantics (if included): Must be all 1s in all requests but last one in the burst. When ZeroMessageLength= TRUE, then they can be all zeroes in the last or only request in the burst.
MCmd	always	3	Transfer Command; only writes allowed. Only one bit is not constant.
MData	If DataWidth != 0	If ByteWidth != DataWidth and ByteWidth != 8: 8 *DataWidth/ByteWidth Else: DataWidth	,
MDataInfo	If (ByteWidth != DataWidth and ByteWidth != 8) or Abortable	DataWidth - (8 * DataWidth/ByteWidth) + (Abortable ? 1 : 0)	Extra write data bits not allowed in MData per OCP WSI Specific Semantic: If Abortable, MSB indicates ABORT in last data of imprecise burst
MDataLast	EarlyRequest = TRUE	1	Indicates last beat of data
MDataValid	EarlyRequest = TRUE	1	Qualifies active data beats
MReqInfo	NumberOf- Opcodes > 1	Ceil(log₂(NumberOfOpcodes))	WSI Specific Semantics: Message Opcode indication
MReqLast	always	1	Indicates last request of bursts.
MReset_n	always	1	Push Reset Master-to-Slave, producer to consumer (Active Low)

1301

Table 15 - WSI OCP Signals Driven by the Consumer/Slave

OCP Signal	When included	Width	Usage
SReset_n	always	1	0 = Push Reset Slave-to-Master (Active Low)
SThreadBusy	always	1	Allows slave to provide backpressure, preventing new requests

1302 **6.6 WSI Semantics**

This section describes specific semantic signal meanings in WSI that are layered on top of the fundamental OCP signal semantics. The semantics stay within OCP compliance, so that even though they are additional behavioral constraints, they represent valid

1306 OCP-defined behavior.

1307 6.6.1 Opcode Indication on MRegInfo

When there is more than one message op-code, the MReqInfo signal is configured into the interface. This extra information about the message, its opcode, must be constant over the message/burst.

OpenCPI Page 45 of 88

- 1311 6.6.2 Messages (or "frames") are OCP Bursts
- 1312 Messages are transmitted as OCP bursts, with the start and end of a message being
- 1313 the first and last word of a burst. When PreciseBurst = TRUE, the interface is
- 1314 configured statically for precise bursts (MPreciseBurst tied off to 1 in the master the
- 1315 OCP default, ignored in the slave), otherwise it is configured for imprecise bursts
- 1316 (MPreciseBurst tied off to 0 in the master, ignored in the slave). In all cases the master
- 1317 asserts MRegLast with the last request of the burst. This means that slaves, whether
- 1318 precise or imprecise, can use this direct mechanism to determine the last request in the
- 1319 burst in all cases, without counting. The master of an imprecise burst must also drive
- the value of "0b01" in the MBurstLength field of the last request of the burst for OCP
- 1321 compliance, but this is in fact redundant with MReqLast.
- 1322 When the EarlyRequest attribute = TRUE, the end of a message can also be
- determined (precise or imprecise) with the MDataLast signal associated with the data.
- 1324 When EarlyReguest = TRUE, the first reguest can be supplied before the first data is
- available, to improve message startup latency in some cases.
- 1326 Interfaces configured with MaxMessageValues = 1 essentially have single word bursts,
- and the MBurstLength signal is constant (0b01).
- 1328 6.6.3 Byte enables
- 1329 Byte enables are configured and used (when necessary) to indicate partial word content
- in the last word of the message/burst. When they are included, they must be all ones
- for all words in the message except the last. They are only included when needed,
- when it is known from the data protocol attributes that messages may have lengths that
- 1333 are not a multiple of DataWidth or are zero.
- 1334 Also, the use of byte enables must be consistent with the endianness of the data
- interface. If the interface is big endian, then partial words will have low order byte
- 1336 enables set to zero as appropriate (e.g. if there is one valid byte, it must be the high
- order byte). If the interface is little endian, then partial words will have high order byte
- enables set to zero as appropriate (e.g. if there is one valid byte, it must be the low
- order byte). A typical example would be when input data was stored into an internal
- buffer, using the byte enables. At this point the worker's endianness would determine
- which bytes in memory are valid, since the byte enables are only valid during the write
- to internal memory, and are not necessarily captured anywhere.
- 1343 If the data protocol requires support for zero length messages (ZeroLengthMessages),
- byte enables are also included and may be all zero in the last or only word of a zero
- length message. Note that enabling ZeroLengthMessages in a WSI also enables the
- 1346 last word of non-zero-length messages to be empty. In particular, this allows a
- producer to signal the end of a message without data (and thus without knowing if any
- word is in fact the last one). This is useful for a producer what wants to pass every
- word of data to the consumer as soon as it is available, without needing to wait until it
- 1350 knows whether that word is in fact the last one or not (in the case of imprecise bursts).
- 1351 Thus the byte enable logic of a WSI is constrained beyond OCP, and all WSI
- 1352 transactions are OCP compliant.

OpenCPI Page 46 of 88

- 1353 6.6.4 Aborting Messages
- 1354 When the interface is using ImpreciseBursts, and the Abortable attribute is set, a feature
- is enabled allowing the master to terminate a burst and indicate that the message is
- being "aborted", which indicates to the slave that the message should not be processed,
- and should be discarded. This indication is placed on MDataInfo[N], which is sampled
- by the slave with the data (MData) in the last data beat of an imprecise burst. N is the
- 1359 MSB of this field.
- 1360 This feature is useful to reduce latency and buffering in some cases. An example is a
- 1361 "framer" worker that is extracting frames with CRC checks from a continuous stream. If
- it starts receiving a frame, it doesn't know whether the frame is valid until the CRC is
- 1363 checked. Since the common case is that the CRC is valid, it wants to forward the
- 1364 beginning of the frame to its output as soon as possible and not delay transmission (and
- avoid buffering) waiting until the CRC. In the rare case that the CRC is bad, it wants to
- 1366 abort the frame and start scanning for a new frame. If the downstream worker is
- already buffering the frame (e.g. when it is waiting to DMA a whole frame over a bus),
- then it can implement the "abort" feature with no extra buffering, since it is buffering
- 1369 already.
- 1370 If the downstream worker cannot handle aborting a message, then a buffer can be
- inserted between the two workers.

1372 6.7 WSI Infrastructure Coping

- 1373 Infrastructure IP supporting WSI interfaces (attached to application IP) falls into three categories:
- Adapter IP for interposing between workers that do not have directly interoperable data plane interfaces, but are otherwise logically, locally, connected.
- Communications IP when workers are not in the same device and need the data messages conveyed across some inter-chip interconnection or fabric (e.g. PCI, RapidIO, LVDS parallel, Aurora serial, XAUI serial, etc.
- I/O IP when workers are receiving or sending IP to an I/O device (sink or source of data) directly attached to the device (e.g. ADC/DAC).
- 1382 The first category (adapters) does the most "coping" as that is their job: to enable
- interoperability when worker developers make different attribute choices. Essentially
- 1384 adapters convert between choices like:
- 1385 Early Request or not
- 1386 Fixed or Variable size messages
- 1387 Precise or Imprecise Bursts
- 1388 Different width data paths
- 1389 Continuous data or not.
- 1390 Abortable or not.
- 1391 Different Endian
- Due to the design of the WIPs, interoperability is well defined in nearly all cases, and
- 1393 trivial to accomplish (by the infrastructure) in many cases. Burst conversions

OpenCPI Page 47 of 88

sometimes are simple logic, sometimes require counting, and sometimes require buffering.

Table 16 – WSI Slave Infrastructure Handling of Optional WSI Signals

OCP Signal	When Signal would be absent at the <u>master</u>	How missing signals are handled
MByteEn	ByteWidth = DataWidth	OCP Tieoff rules apply: No connection is made, MByteEn connected to the default tieoff: all 1s (indicating full words)
MDataLast	EarlyRequest==FALSE	Adapter: MDataLast = MReqLast
MDataValid	EarlyRequest==FALSE	Adapter: MDataValid = MCmd[0]
MDataInfo[MSB]	Abortable = FALSE	OCP Tieoff rules apply: Abort never happens, MDataInfo[MSB] = 0
MReqInfo	NumberOfOpcodes=1	OCP Tieoff rules apply: No connection is made, MReqInfo tied to the default tieof: 0 (indicating opcode == 0). Infrastructure slaves should generally support/convey 256 opcodes (8 bits).

Table 17 – WSI Master Infrastructure Handling of Optional WSI Signals

OCP Signal	When Signal would be absent at the <u>slave</u>	How missing signals are handled	
MByteEn	ByteWidth = DataWidth	OCP Tieoff rules apply: No connection is made, MByteEn always driven to the default tieoff: all 1s (indicating full words) This should be checked in test environment.	
MDataLast	EarlyRequest==FALSE Adapter: MDataLast is not connected		
MDataValid	EarlyRequest==FALSE	Adapter: Request info (MCmd[0], MReqLast, MBurstLength,MByteEn) must be captured and delayed until MDataValid. MDataValid is not connected	
MDataInfo[MSB]	Abortable = FALSE	OCP Tieoff tules apply: Abort never asserted, MDataInfo[MSB] = 0	
MReqInfo	NumberOfOpcodes=1	OCP Tieoff rules apply: No connection is made, MReqInfo tied to the default tieof: 0 (indicating opcode == 0). Infrastructure slaves should generally support 256 opcodes (8 bits).	

These tables above assume an infrastructure that supports all features (byte enables, early request/data handshake, and opcodes). Conversion between precise and imprecise burst lengths is slightly more complicated, but well defined.

Note that when infrastructure is conveying messages between application workers, interoperability can be determined even when the infrastructure supports features that the application worker does not. A good example is if an infrastructure master/producer generically supports 256 opcodes, but the application slave/consumer does not. Here interoperability checking is based on knowing that the upstream application worker (wherever it is), also doesn't produce opcodes, so the infrastructure master will never in fact drive the opcode signals to anything other than the tieoff. If the infrastructure was a data source rather than an interconnect between workers, then interoperability would be based on the infrastructure itself. If a application consumer did not support aborts, the infrastructure must be configured to never generate them.

OpenCPI Page 48 of 88

- 1411 6.7.1 Infrastructure Best Practice for Master/Producers
- 1412 Infrastructure IP acting as WSI producer/master should:
- 1413 use PreciseBurst = TRUE unless this adds buffering or latency.
- 1414 use EarlyRequest = FALSE unless this adds latency (i.e. when the infrastructure IP 1415 actually does know that a request should start before it has the data).
- 1416 use VariableMessageLength = FALSE when it knows that all messages it produces will be the same size. 1417
- 1418 Use Continuous = TRUE when it knows that bursts it produces will never have idle 1419 cycles.
- Use Abortable = TRUE if the data source supports aborting (defer buffering until 1420 1421 needed)
- 1422 6.7.2 Infrastructure Best Practice for Slave/Consumers
- 1423 Support both precise and imprecise bursts, use MReqLast rather than 1424
- MBurstLength, unless burst length is in fact required to be known early (in which case an adapter should add the imprecise-to-precise conversion when needed). 1425
- 1426 Using both precise and imprecise bursts is not legal for an application worker
- producer in any case, but an infrastructure consumer may indeed support both. 1427
- 1428 Support EarlyRequest = TRUE.
- 1429 Support VariableMessageLength = TRUE unless its function in fact requires fixed 1430 message sizes.
- 1431 Use Continuous = FALSE, allowing intra-burst idle cycles on input.
- 1432 Use Abortable = TRUE if the data sink does, or if buffering is already taking place

OpenCPI Page 49 of 88

1434 **7 Worker Message Interface (WMI)**

- 1435 See the earlier section on Worker Data Interfaces for information that applies to this and
- 1436 other data-plane WIPs.

1437 **7.1 WMI Motivation**

- 1438 A worker data interface more powerful than WSI, the Worker Message Interface (WMI)
- is a more complete and complex interface. It is used in preference to WSI only when the
- 1440 worker implementation needs its additional capabilities. Infrastructure supporting WIP
- should support workers whether they are implemented using WSI or WMI at any worker
- 1442 data interface.

1446

1447

1448

1449 1450

1451

1452

1453

1454 1455

1456

14571458

1459

1460 1461

1462


1443 This description is not really standalone; it builds on WSI and adds capabilities.

1444 **7.2 WMI Overview**

- 1445 Key features of the WMI beyond what WSI provides include:
 - The worker is always the OCP master, the active agent, whether consuming message input or producing message output.
 - WMI is not based on the "messages are bursts" model of WSI, since WMI provides random access to message contents, and each such access can be its own burst.
 - Random addressing within the content of a message is enabled. This generally implies message buffering by the infrastructure (slave).
 - Explicit indication that the worker has finished processing (consuming or producing) a message is available, independent of access to message contents.
 - Ability to configure a worker-consumer WMI for write-back, to allow the worker to write to (modify) received message in-place to allow in-place processing to reduce buffer requirements.
 - Ability to configure a worker-producer WMI to read-back, to allow the worker to read from (examine) outbound message in-place to allow in-place processing to reduce buffer requirements.
 - Ability to abort/discard an input message without accessing all of it.
 - Ability to abort/discard an output message without sending it.
- 1463 Workers that need any of these capabilities use WMI in preference to WSI, and thus
- 1464 generate addresses to access the contents of the message.
- 1465 WMI provides the worker, as an OCP master, with a view of the current buffer, whether
- 1466 producing or consuming. The slave interface on the other side is infrastructure that
- 1467 might be interfaced to local or remote memory and might include the logic for DMA
- 1468 buffer management.
- 1469 7.2.1 WMI Consuming versus Producing:
- 1470 With WMI, when a worker is a message-consumer, it is an OCP master and must read,
- or "pull", data from a slave. The infrastructure supplies this slave message-producer as
- shown below on the left side of the link marked 1.

OpenCPI Page 50 of 88

When a worker is a message-producer, it is always an OCP master and must write, or "push", data to a slave. The infrastructure supplies this slave message-consumer interface as shown below on the right side of the link marked 2.



1476 1477

1478

1479

1480

1481

1482

1483

1484

1485

1486

1487

1488

1489

1490

1491

1492 1493

1494

1473

1474

1475

Figure 6 - Signals on Worker with two WMI interfaces

For both worker-consuming and worker-producing, WMI provides the symmetric capabilities of slave buffer availability (to process on input, to fill on output) and a "done with message" indication.

For the worker-consumer:

- Slave/infrastructure indicates source buffer availability (source buffer ready to consume)
- Master/worker indicates "Done with Message" (discard/recycle the consumed source buffer)

For the worker-producer:

- Slave/infrastructure indicates target buffer availability (target buffer ready to fill with message)
- Master/worker indicates "Done with Message" (transmit the finalized contents of the output buffer)

Although the attributes are identical for consumer and producer, the OCP configuration parameters and signals differ owing to the fact that the worker is in an OCP Master role in both cases.

7.2.2 Indication of message length

Since in WMI messages are *not* bursts, the length of a message must be indicated independent of burst length (unless VariableMessageLength = FALSE). For a WMI consumer, both the opcode and the message length are supplied separately from data using the OCP SFlag signals. For the WMI producer, the opcode and message length are indicated on the OCP MFlag signals (again, unless VariableMessageLength = FALSE). The exact semantics are discussed below.

OpenCPI Page 51 of 88

- 1501 7.2.3 Indication of done-with-message
- 1502 Since the consumer can randomly access the contents of a message, there is no
- implicit way for the slave to know when the consumer is done processing the message.
- 1504 Thus, during any request to access the current message (input or output), the OCP
- 1505 MRegInfo[0] signal is used to indicate whether that access represents the last access
- 1506 required to complete the processing (input or output) of the message. This indicates,
- 1507 for input, that the message can be discarded and the buffer reused, and for output, that
- the buffer can be made available to transmit to the directly (locally) or indirectly (remote)
- 1509 consuming worker or output device ("downstream").
- 1510 Since the worker may not know that it is done processing a message until after it has
- performed all required data accesses for the contents of a message, there is a provision
- 1512 for making a request that accesses no data at all, but simply allows the done-with-
- message indication with no overhead for accessing memory. The exact semantics are
- 1514 discussed below. This indication is the same whether producing or consuming.
- 1515 This scheme enables two optimizations: no extra access (OCP transaction) is required
- 1516 to complete the message, and no data delay is required to wait until it is known that an
- 1517 access will be the last one. The mechanism is identical for consuming and producing.
- 1518 7.2.4 Indication of buffer available
- 1519 When the worker is "between" messages (before the first one, or after indicating "done"
- with the previously processed one), the OCP SThreadBusy signal acts as the indication
- that a buffer is available, for both consuming and producing. This indication is the same
- whether producing or consuming. It uses OCP semantics directly.
- 1523 7.2.5 Message content addressing
- 1524 WMI supports the worker, as OCP master, accessing message contents via random
- access reads and writes. Address 0 is always the first word of the "current" message.
- 1526 There is an additional "talkback" option, which allows the worker to write to input buffers
- or read from output buffers. This option enables read/write access to buffers (rather
- than read-only input buffers and write-only output buffers), with the associated hardware
- 1529 cost, but can reduce overall buffer requirements.

1530 7.3 WMI Worker Attributes

- Worker authors using a WMI specify their implementation choices via the following
- 1532 attributes (as well as the data protocol attributes above), from which all OCP
- 1533 configuration parameters and signals are derived. Light green shading of the description
- indicates where the attribute has the same meaning as in WSI.
- 1535 The Clock and ClockSignal attributes, described in section 2.6, are applicable to WMI.
- 1536 Since WMI is a data plane interface, the worker data interface protocol attributes are
- applicable, as described in section 4.2. These are: DataValueWidth,
- 1538 DataValueGranularity, DiverseDataSizes, MaxMessageValues, NumberOfOpcodes,
- 1539 Producer, VariableMessageLength, and ZeroLengthMessages.

OpenCPI Page 52 of 88

1540 7.3.1 WMI Attribute Summary

1541 Table 18 – WMI Attribute Table

Attribute Name	Type (per XML Schema)	Default Value	Description
Continuous	boolean	false	TRUE: within a burst, there shall be no idle cycles. FALSE: there may be idle cycles within a burst
DataWidth	unsigned Int	DataValue- Width	Physical width in bit/wires of data path
ByteWidth	unsigned Int	DataWidth	Set to non-default to have byte enables for writes to buffers
ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used
TalkBack	boolean	false	TRUE: Wants/needs to write input or read back output buffers FALSE: Will only read input or write output buffers

1542 7.3.2 WMI Worker Attribute Details

This subsection contains the per-attribute details of choices available for a WMI on a worker.

Continuous	boolean	false	TRUE: within a burst, there shall be no idle cycles. FALSE: there may be idle cycles within a burst
------------	---------	-------	---

1545 See WSI Attribute Details.

DataWidth	unsigned Int	DataValue- Width	Physical width in bit/wires of data path (same as WSI)
-----------	-----------------	---------------------	--

1546 See WSI Attribute Details.

ByteWidth	unsigned DataWidt	Set to non-default to have byte enables for writes to buffers
-----------	-------------------	---

- ByteWidth expresses the size in bits of the smallest data value that the interface needs to handle, and is used to enable byte enable functionality in WSI, WMI, and WMemI.
- 1549 If the WMI, when it is writing to buffers, requires byte enable support, set ByteWidth to a
- 1550 value that divides into DataWidth. Normally this would be DataValueWidth, but that is
- not required. Note that byte enables in WMI are never needed to express message
- 1552 lengths and are not used for reads.

ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used

1553 See WSI Attribute Details.

1554 For WMI:

OpenCPI Page 53 of 88

- There is no relationship between bursts and messages.
- One, but not both, of these attributes must be TRUE (same as WSI).
- Maximum message length determines maximum burst length, but bursts can be used to access any subset of the current message.

TalkBack boolean	false	TRUE: Wants/needs to write input or read back output buffers FALSE: Will only read input or write output buffers
------------------	-------	--

- When TRUE, this attribute configures a particular WMI interface to have both read and write data capability. For a consumer, this attribute enables write-back to the input
- buffer, in addition to the default message read capability. For a producer, this attribute
- enables read-back from the output buffer, in addition to the default message write
- capability. When FALSE, input buffers can only be read, and output buffers can only be
- 1564 written.
- This capability can obviate the need for workers to have extra internal buffers or use
- 1566 external memories.

1567 7.4 WMI OCP Profile/Configuration Parameters

- 1568 The WMI OCP profile is the aspect of the WMI that has to do with OCP configuration
- parameters and signal configuration. This section describes the concrete, complete,
- and unambiguous transformation from WMI WIP attributes described above, to the OCP
- 1571 configuration parameters inferred from those attributes. This transformation is
- 1572 implemented in automation tools.
- 1573 The table below lists only those parameters that are different from the OCP
- 1574 configuration parameter defaults (per the OCP specification).

OpenCPI Page 54 of 88

1575 Table 19 – Worker Message Interface OCP Configuration Parameters

OCP Configuration Val		Description		
Parameter	value	(How OCP parameter is determined if not constant, and any tieoffs)		
addr_wdth	{M}	N = ceil(MaxMessageValues*DataValueWidth/DataWidth) If (N <= 1) M = 0; $Else M = ceil(log2(N))) + max(0,ceil(log2(OCP data_wdth))-3)$		
addr_space, addrspace_wdth	1			
burstlength	1			
burstlength_wdth	{P}	If $PreciseBurst = TRUE$: $N = ceil(MaxMessageValues*DataValueWidth/DataWidth)$ If $(N < 4) P = 2$ $Else P = floor(log_2(N)) + 1$ $Else$: $P = 2$		
PreciseBurst	0	If ImpreciseBurst = TRUE, tieoff MPreciseBurst = 0 (OCP default tieoff is 1)		
cmdaccept	0	Note: The SThreadBusy signal is used everywhere for backpressure.		
datahandshake	1			
datalast	1			
data_wdth	{Q}	If ByteWidth != DataWidth and ByteWidth != 8: Q = 8 * DataWidth/ByteWidth Else: Q = DataWidth		
mdatabyteen	{0:1}	If (Producer = TRUE or Talkback = TRUE) and ByteWidth != DataWidth: 1, Else: 0		
mdata	{0 1}	If Producer = TRUE or TalkBack = TRUE: 1, Else: 0		
mdatainfo	{0 1}	If ByteWidth != DataWidth and ByteWidth != 8: 1 Else: 0		
mdatainfo_wdth	{R}	If ByteWidth != DataWidth and ByteWidth != 8: R = DataWidth - (8 * DataWidth/ByteWidth)		
mdatainfobyte_wdth	{S}	If ByteWidth $!=$ DataWidth and ByteWidth $!=$ 8: S = ByteWidth - 8		
mflag	1	If Producer = TRUE and (NumberOfOpcodes>1 or VariableMessageLength = TRUE): 1		
mflag_wdth	{T}	If Producer = TRUE and (NumberOfOpcodes>1 or VariableMessageLength = TRUE): 1 T = 8 + ceil(log2(MaxMessageValues))		
mreset	1			
read_enable	{0 1}	If Producer = FALSE or TalkBack = TRUE: 1, Else: 0		
reglast	1			
resp	{0 1}	If Producer = FALSE or TalkBack = TRUE: 1, Else: 0		
sdata	{0 1}	If Producer = FALSE or TalkBack = TRUE: 1, Else: 0		
sreset	1			
reqinfo	1			
reqinfo_wdth	1			
sflag	1	If Producer = FALSE and (NumberOfOpcodes > 1 or VariableMessageLength = TRUE): 1		
sflag_wdth	{U}	If Producer = FALSE and (NumberOfOpcodes > 1 or VariableMessageLength = TRUE): U = 8 + ceil(log2(MaxMessageValues))		
sthreadbusy_exact sthreadbusy_pipelined	1	Enables the SThreadBusy signal to support Request flow-control backpressure from slave to master.		
sdatathreadbusy sdatathreadbusy_exact sdatathreadbusy_pipelined	{0 1}	If Producer = TRUE or TalkBack = TRUE: 1 Else: 0		
write_enable	{1 0}	If Producer = TRUE or TalkBack = TRUE: 1, Else: 0		
		,		

1576 **7.5 WMI OCP Signals**

OpenCPI Page 55 of 88

Worker Interface Profiles (WIP) Functional Specification

Signal configuration is determined by the interface configuration parameters and as called out in the "OCP Signal Configuration Parameter" table in the OCP specification.
 The tables below show the signal from master-to-slave and slave-to-master. The positional order of signals is alphabetical.
 Light yellow shading of the description indicates where an OCP signal has had WMI semantics added. Details described in following section.

OpenCPI Page 56 of 88

Table 20 – WMI OCP Signals Driven by the Worker/Master

OCP Signal	When Included	Width	Usage
MAddr	always	See addr_wdth parameter above	Current message access address when MAddrSpace='1'
MAddrSpace	always	1	WMI Semantics Added: 0= Normal Transaction 1= No Data access for this command
MBurstLength	always	See burstlength_wdth parameter above	Standard OCP burst access: Constant burst length for Precise B'01' for last request for Imprecise
MCmd	always	3	Only one bit is not constant unless TalkBack= TRUE
MData	If Producer = TRUE or TalkBack = TRUE	If ByteWidth != DataWidth and ByteWidth != 8: 8 *DataWidth/ByteWidth Else: DataWidth	Write Data included when Producer=TRUE or MessageTalkBack = TRUE
MDataByteEn	If (Producer = TRUE or TalkBack = TRUE) and ByteWidth!= DataWidth	DataWidth/ ByteWidth	Qualify bytes in writes to current buffer
MDataInfo	If (Producer = TRUE or TalkBack = TRUE) and ByteWidth != DataWidth and ByteWidth != 8	DataWidth – (8 * DataWidth/ByteWidth)	Extra write data not allowed in MData per OCP
MDataLast	always	1	Indicates last word of data in burst
MDataValid	always	1	Qualifies active write-data
MFlag	If Producer = TRUE and (NumberOfOpcodes>1 or VariableMessageLength = TRUE)	8 + ceil(log2(MaxMessageValues+1))	WMI Specific Semantics: Opcode and Message Length
MReqInfo	always	1	WMI Semantics Added: Bit-0 = Done-with-Message (DWM) prevents SThreadBusy = FALSE
MReqLast	always	1	
MReset_n	always	1	0 = Reset Master-to-Slave. (Asserted in response to WCI reset)

1584 Table 21 – Worker Message Interface Signals Driven by the Infrastructure/Slave

	•		
OCP Signal	When Included	Width	Usage
SData	If Producer = FALSE or TalkBack = TRUE	DataWidth	Read Data
SDataThreadBusy	If Producer = TRUE or TalkBack = TRUE	1	Allows slave to provide pipelined, proactive write-data Datahandshake backpressure
SFlag	If Producer = FALSE and (NumberOfOpcodes > 1 or VariableMessageLength = TRUE)	8 + ceil(log2(MaxMessageValues+1))	WMI Specific Semantics: Opcode and Message Length
SReset_n	always	1	0 = Reset Slave-to-Master (Active Low)

OpenCPI Page 57 of 88

SResp	If Producer=FALSE or TalkBack = TRUE	FIXED	Qualifies active read-data transfer words within a message
SRespLast	If (ImpreciseBurst or PreciseBurst) and (Producer = FALSE or TalkBack = TRUE)	1	Indicates last beat of read data in a burst
SThreadBusy	always	1	WMI Specific Semantics: When between messages, when FALSE, it signifies: New Message Available

1585 7.6 WMI Semantics


- This section describes specific semantic signal meanings in WMI that are layered on top of the fundamental OCP signals. They are organized by function and then the signals affected.
- 1589 7.6.1 "Done with Message" (DWM) Indicated on MRegInfo[0]
- 1590 MRegInfo[0] adds information to the current OCP command request (to read or write
- message contents) to indicate that the data access associated with this command is the
- 1592 final access of the associated message. It is sent in this fashion to eliminate the need
- 1593 for an extra OCP request to indicate this.
- 1594 This mechanism is used for both consuming and producing workers. The associated
- data access can be suppressed (possibly reducing latency) by using the no-data
- 1596 indication via MAddrSpace[0] described next.
- 1597 7.6.2 No-Data Indication on MAddrSpace[0]
- 1598 WMI transactions initiated by a worker that include the DWM indication, either consumer
- or producer, may also indicate that the OCP command, read or write, has "No Data" by
- setting the MAddrSpace[0] signal to '1'. This allows a master to send to the slave the
- Done-with-Message (DWM) on MReqInfo[0] without any read or write side effects or
- overheads. Thus when the worker decides it is done with the current message, but
- requires no additional data accesses, it can issue the DWM request with no data access
- 1604 required by the infrastructure.
- Normal transactions to read and write "Data" require that MAddrSpace be set to '0'.
- 1606 Setting MAddrSpace[0] = 1 when MRegInfo[0] = 0 should not be done.
- 1607 7.6.3 Buffer Availability Indicated on SThreadBusy
- 1608 When between messages (either after reset or after the master indicates "done with
- message"), SThreadBusy is used to indicate the availability of a source data buffer to
- 1610 read (worker consumer) or an output data buffer to write (worker producer). An asserted
- 1611 SThreadBusy[0] signal blocks the worker from issuing an OCP request. When not
- between messages, SThreadBusy is simply the backpressure for reading or writing
- 1613 message data. For a consumer, the infrastructure side (slave) may allow access as data
- arrives (for improved latency), and thus latency could depend on the address of that first
- 1615 access to a (new) message.
- 1616 As an additional constraint on OCP, the master *cannot* assert a request in the cycle
- after the DWM is asserted, in order to allow the slave to assert the (pipelined)

OpenCPI Page 58 of 88

SThreadBusy for at least one cycle between messages. Thus the worker must not issue a request based on the normal pipelined SThreadBusy from the slave <u>or</u> the MReqInfo[0] in the previous cycle. For the purpose of this non-blocking flow control, both signals are sampled at the same clock: at the end of the cycle before the request is to be asserted.

7.6.4 Opcode and Message Size Move Downstream on {M|S}Flag

Opcodes and message size flow downstream. They are driven together on MFlag and SFlag as shown in the following diagram. A worker message-consumer *observes* these on SFlag and a worker message-producer *drives* them on MFlag. They are only configured when NumberOfOpcodes > 1 or VariableMessageLength = TRUE.



Encoding of Opcode and Message Length on both SFlag and Mflag:




Figure 7 WMI Use of SFlag/MFlag

When the field is configured, the opcode is driven on $\{S|M\}$ Flag[7:0]. When VariableMessageLength = TRUE the message length is driven on $\{S|M\}$ Flag[P:8], where P = ceil(log2(MaxMessageValues+1)) + 7.

For a worker *consumer*, this information is driven on SFlag by the infrastructure and the values will be valid for a given message starting in the first cycle when SThreadBusy is not asserted (after reset or the previous DWM), through the cycle when the worker asserts DWM (MReqInfo[0] = 1). Thus the worker may not need to capture them.

For a worker *producer*, this information is driven on MFlag by the worker and the values must be valid in the (single) same cycle as the request with DWM asserted.

OpenCPI Page 59 of 88

1639 7.7 WMI Infrastructure Coping

16431644

The key options chosen by the worker for WMI are data width, burst capabilities, and,

like WSI, the continuous attribute. Some of these attributes allow for infrastructure

optimization, such as when the TalkBack option is FALSE, more buffer sharing is

possible (multiple consumers could share the same input buffer).

Table 22 – WMI Slave Infrastructure Handling of Optional WMI Master Signals

OCP Signal	When Signal would be absent at the master	How missing signals are handled
MData	If Producer = FALSE and TalkBack = FALSE	No issue - infrastructure is prepared for TalkBack for a consumer, but worker doesn't use it. OCP tieoff rules apply, signals will never be driven.
<i>MDataByteEn</i>	If (ByteWidth = DataWidth or Producer = FALSE and Talkback = FALSE)	OCP Tieoff rules apply: No connection is made, MDataByteEn connected to the default tieoff: all 1s (indicating full words)
MFlag	NumberOfOpcodes=1 and VariableMessageLength = FALSE	OCP Tieoff rules apply: No connection is made, MFlag tied to the default tieof: 0 (indicating opcode == 0). Infrastructure slaves should generally support 256 opcodes (8 bits). Fixed message length would be the tieoff for bits [P:8]

- 1645 7.7.1 Infrastructure Best Practice for Slave Producers (feeding Worker Consumers)
- Support CONTINUOUS when the buffer memory can support it.
- Support both precise and imprecise bursts, use MReqLast rather than
 MBurstLength.
- Support Byte Enables on Writes.
- Support VariableMessageLength = TRUE.
- Support 8 bits of opcode.
- Have a variant IP to support TalkBack (since it might be costly)
- 1653 7.7.2 Infrastructure Best Practice for Slave Consumers (fed by Worker Producers)
- Support CONTINUOUS when the buffer memory can support it.
- Support both precise and imprecise bursts, use MReqLast rather than
 MBurstLength.
- Support Byte Enables on Writes.
- Support VariableMessageLength = TRUE.
- Support 8 bits of opcode.
- Have a variant IP to support TalkBack (since it might be costly)
- 1661 [Issue: packing non-power-of-two for DMA: map each byte to round up to 2^N?]

OpenCPI Page 60 of 88

1662 8 Worker Memory Interface (WMeml)

8.1 WMeml Motivation

1663


- 1664 WMeml is an interface that allows workers to access memory in a technology
- independent fashion, with enough choices to make workers simple and also allow for
- 1666 high performance use of local memories. It exists to enable workers to express their
- needs for FPGA-attached (or FPGA-internal) memory based on their own requirements
- and preferences. Since explicitly buffered data plane communication is handled by
- 1669 WMI, WMeml is focused on memory usage for non-communication purposes such as
- 1670 internal history buffers and LUTs.
- 1671 Since memory usage ranges from latency-optimized non-burst LUT-style random word
- access, to throughput optimized burst-style sequential access, the WMeml attribute
- 1673 choices enable this range of behavior.
- 1674 The intended purpose of WMeml is *not* for a worker to communicate via memory to any
- other worker, since that is the job of WSI or WMI, which may have underlying memory
- used for buffering. An example of this is shown earlier in the WMI section describing
- 1677 master-to-master adaptation.

1678 8.2 WMeml Overview

- 1679 Typical FPGA-attached memory scenarios include both SRAM and DRAM⁴. WMemI
- balances between abstracting enough away so that workers may be portable across
- heterogeneous memory architectures; vs. exposing enough of the micro-architectural
- 1682 details when "ultimate performance" is required.
- 1683 Workers may have zero or more WMemls, each with their own attributes.
- 1684 The figure below shows in isolation a (WMeml) interface (1) between Worker1 and
- 1685 MemController1. The worker specifies the WMeml attributes it desires at master
- interface (1M), such as data width and memory capacity. The infrastructure satisfies
- those requests on the other side on slave interface (1S). The worker side of a WMeml is
- 1688 always the OCP master.

OpenCPI Page 61 of 88

⁴ This memory might be "on-chip", such as rich memory (e.g. BRAM or MRAM) resource found on contemporary FPGAs. Or it may, most commonly, be "FPGA- attached", such as a SRAM or DRAM controller connected to a FPGA. It could also be a remote memory resource. Thus infrastructure can supply the type of memory that is available and appropriate, without the application worker making the choice explicit.



1691

1692

1693

Figure 8 - Master/Slave Roles for WMeml

The non-worker side of a WMeml interface does not have to be a direct connection to a memory controller; it could be other logic, such as a memory multiplexer that provides multiple memory views to multiple workers as shown below:

OpenCPI Page 62 of 88




Figure 9 - Memory Multiplexer with WMeml

Each of the workers shown above may have different FPGA-attached memory requirements, and would express those as unique WMeml attributes associated with each WMeml. Because of these differences the three WMeml interfaces may have different OCP configuration parameters. Thus, in the general case, the worker masters (1M, 2M, 3M) are loosely constrained for data-width and capacity; and the infrastructure slaves (1S, 2S, 3S) must conform or be adapted to them as the worker attributes are generating the OCP configuration parameters. Furthermore, the memory multiplexer must adapt these potentially disparate requests to a common access method for the memory controller.

OpenCPI Page 63 of 88

- 1705 The most significant choice made in specifying a WMeml is the use of bursts, which
- 1706 adds complexity to the interface (e.g. pipelined requests) and determines several
- 1707 significant differences in signal configuration (e.g. how byte enables are specified).
- 1708 The key choices made when a worker specifies a WMeml are:
- **Burst usage**: does the worker want burst-style (throughput optimized) access or SRAM-style latency-optimized single word access? How long will bursts be?
- Burst style: will the worker issue precise or imprecise bursts? Or both?
- *Intra-burst flow control*: will the worker handle flow control within a burst (after it is started)? Will it use (issue) flow control against the read data in a burst read?
- **Memory width and size**: how much memory is required, and how wide should it be? Should it support bytes of some width (byte enables on writes)?
- 1716 WMeml is specified using blocking request flow control (where the master issues the
- 1717 request and waits for it to be accepted) rather than the non-blocking flow control used in
- the other profiles (where the master waits for the not-busy indication before it can issue
- the request). This is because memory behavior (and the delay in processing requests)
- 1720 frequently depends on the address associated with the request (i.e. same bank/row or
- 1721 not).
- 1722 8.3 WMeml Worker Attributes
- 1723 Worker authors using a WMeml specify their implementation choices via the following
- 1724 attributes, from which all OCP configuration parameters and signals are derived. Light
- 1725 green shading of the description indicates where the attribute has the same meaning as
- 1726 in WMI.
- 1727 The Clock and ClockSignal attributes, described in section 2.6, are applicable to
- 1728 WMeml.

OpenCPI Page 64 of 88

1729 8.3.1 WMeml Attribute Summary

1730

Table 23 – WMeml Worker Canonical Attribute Table

Attribute Name	Type (per XML Schema)	Default value	Description (OCP configuration parameters affected by this choice)
DataWidth	unsignedInt	8	Physical width in bits/wires of data path similar to as WSI/WMI, must be a multiple of ByteWidth
ByteWidth	unsignedInt	8	Number of bits controlled by a write-byte-enable signal, must divide evenly into Data Width. If same as DataWidth, no byte enables are configured.
ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used
MemoryWords	unsignedInt	none	The amount of data memory (in words of DataWidth size) that are available, starting at address zero.
MaxBurstLength	unsignedInt	none	Maximum burst length, if either ImpreciseBurst or PreciseBurst is TRUE.
WriteDataFlowControl	boolean	false	TRUE: worker/master supports Write Data Flow Control from memory/slave during write bursts
ReadDataFlowControl	boolean	false	TRUE: worker/master requires memory/slave to support Read Data Flow Control during bursts

1731 8.3.2 WMeml Attribute Details

1732 This subsection contains the per-attribute details of choices available for a WMeml on a worker.

ImpreciseBurst	boolean	false	TRUE: Imprecise OCP bursts will be used FALSE: Imprecise OCP bursts will not be used
PreciseBurst	boolean	false	TRUE: Precise OCP bursts will be used FALSE: Precise OCP bursts will not be used
MaxBurstLength	unsignedInt	1	Maximum burst length, if either ImpreciseBurst or PreciseBurst are TRUE.

These attributes are as described under the WMI profile, except that it is allowed to configure a WMemI such that the master (worker) may issue <u>both</u> precise and imprecise bursts, or neither. MaxBurstLength (only for WMemI) is the maximum number of words that will be transmitted in a burst. (WMI infers this from the maximum message length).

DataWidth	unsignedInt	8	Physical width in bits/wires of data path similar to as WSI/WMI, must be a multiple of ByteWidth
ByteWidth	unsignedInt	8	Number of bits controlled by a write-byte-enable signal, must divide evenly into Data Width and be >= 8
MemoryWords	unsignedInt	none	The amount of data memory (in words of DataWidth size) that are available, starting at address zero.

DataWidth and ByteWidth are as in WSI and WMI (data path width in bits). ByteWidth expresses the byte enable capabilities for writes. There are no byte enable capabilities

in WSI, WMI or WMemI for reads. Memory is sized in words, with MemoryWords

1741 expressing the amount of memory available (or required), starting at address zero.

1742 MemoryWords implies the width of the address path. When ByteWidth equals

1743 DataWidth, no byte enables are used.

OpenCPI Page 65 of 88

WriteDataFlowControl	boolean	false	TRUE: worker/master supports Write Data Flow Control from memory/slave during write bursts
ReadDataFlowControl	boolean	false	TRUE: worker/master requires memory/slave to support Read Data Flow Control during bursts

- 1744 The WriteDataFlowControl attribute indicates if the worker will support and accept intra-
- burst flow control on memory writes. The default (FALSE) indicates that the worker
- 1746 cannot support any intra-burst backpressure, and that once a burst requests is
- accepted, all the data in the burst will be accepted. Only valid when bursts are used.
- 1748 The ReadDataFlowControl attribute indicates if the worker will assert intra-burst flow
- 1749 control on burst reads. The default (FALSE) indicates that the worker will not assert any
- intra-burst backpressure, and that it is prepared to accept all the data it requests. Only
- 1751 valid when bursts are used.

8.4 WMeml OCP Profile/Configuration Parameters

- 1753 The WMeml OCP profile is the aspect of the WMeml that has to do with OCP
- 1754 configuration parameters and signal configuration. This section describes the concrete,
- 1755 complete, and unambiguous transformation from WMeml WIP attributes described
- 1756 above, to the OCP configuration parameters inferred from those attributes. This
- 1757 transformation is implemented in automation tools.
- 1758 The table below lists only those parameters that are different from the OCP
- 1759 configuration parameter defaults (per the OCP specification).

OpenCPI Page 66 of 88

Table 24 – Worker Memory Interface OCP Configuration Parameter Settings

	'				
OCP Configuration	Value	Description			
Parameter		(How OCP parameter is determined if not constant, and any tieoffs)			
addr_wdth	{M}	M = ceil(log2(MemorWords)) + ceil(log2(DataWidth/ByteWidth))			
burstlength	{0 1}	If PreciseBurst = TRUE or ImpreciseBurst = TRUE: 1 Else: 0			
burstlength_wdth	{N}	If PreciseBurst = TRUE: $N = floor(log_2(max(2,MaxBurstLength))) + 1$ Else If ImpreciseBurst = TRUE: N = 2			
burstprecise	{0 1}	If PreciseBurst = TRUE and ImpreciseBurst = TRUE: 1 Else: 0 If PreciseBurst = FALSE and ImpreciseBurst = TRUE: {tie_off 0} (note OCP default tieoff is 1)			
burstsinglereq	{0 1}	If PreciseBurst = TRUE and ImpreciseBurst = TRUE: 1 Else: 0 If PrecisesBurst = TRUE and ImpreciseBurst = FALSE: {tie_off 1} (note OCP default tieoff is 0)			
dataaccept	{0 1}	If (PreciseBurst = TRUE or ImpreciseBurst = TRUE) and WriteDataFlowControl = TRUE: 1, Else: 0			
datahandshake	{0 1}	If PreciseBurst = TRUE or ImpreciseBurst = TRUE: 1, Else: 0			
datalast	{0 1}	If PreciseBurst = TRUE or ImpreciseBurst = TRUE: 1, Else: 0			
data_wdth	N	If ByteWidth = DataWidth or ByteWidth = 8 (no bytes or bytes=octets) N = DataWidth Else: N = DataWidth/ByteWidth * 8			
mbyteen	1	If PreciseBurst = FALSE and ImpreciseBurst = FALSE and ByteWidth != DataWidth: 1, Else: 0			
mdatabyteen	1	If (PreciseBurst = TRUE or ImpreciseBurst = TRUE) and ByteWidth != DataWidth: 1, Else: 0			
mdatainfo	{0 1}	If ByteWidth != DataWidth and ByteWidth != 8: 1, Else: 0			
mdatainfo_wdth	{Q}	If ByteWidth $!=$ DataWidth and ByteWidth $!=$ 8: Q = DataWidth - (8 * DataWidth/ByteWidth)			
mdatainfobyte_wdth	{R}	If ByteWidth != DataWidth and ByteWidth != 8: R = ByteWidth - 8			
mreset	1				
respaccept	{0 1}	If (PreciseBurst = TRUE or ImpreciseBurst = TRUE) and ReadDataFlowControl=TRUE: 1, Else: 0			
reglast	{0 1}	If PreciseBurst = TRUE or ImpreciseBurst = TRUE: 1, Else: 0			
resplast	{0 1}	If PreciseBurst = TRUE or ImpreciseBurst = TRUE: 1, Else: 0			
sdatainfo	{0 1}	If ByteWidth != DataWidth and ByteWidth != 8: 1, Else: 0			
sdatainfo_wdth	{S}	If ByteWidth != DataWidth and ByteWidth != 8: S = DataWidth - (8 * DataWidth/ByteWidth)			
sdatainfobyte_wdth	{T}	If ByteWidth $!=$ DataWidth and ByteWidth $!=$ 8: T = ByteWidth - 8			

8.5 WMeml OCP Signals

1761

1764

Signal configuration is determined by the interface configuration parameters and as called out in the "OCP Signal Configuration Parameter" table in the OCP specification.

The tables below show the signals from master-to-slave and slave-to-master. The

1765 positional order of signals is alphabetical.

OpenCPI Page 67 of 88

1766 Table 25 – Worker Memory Interface Signals Driven by the Master, to the Slave

OCP Signal	When Included	Width	Usage
MAddr	always	ceil(log2(MemorWords)) + ceil(log2(DataWidth/ByteWidth))	Memory Address, with byte address lines always 0
MBurstLength	If PreciseBurst <u>or</u> ImpreciseBurst	If PreciseBurst: floor(log ₂ (max(2, MaxBurstLength))) + 1 Else If ImpreciseBurst: 2	Burst Length
MPreciseBurst	If PreciseBurst <u>and</u> ImpreciseBurst	1	Indicates precise vs imprecise bursts.
MBurstSingleReq	If PreciseBurst <u>and</u> ImpreciseBurst	1	Indicates Single request for all data transfers in the burst
MCmd	always	3	Transfer Command, READ or WRITE
MData	always	If ByteWidth != DataWidth and ByteWidth != 8: 8 *DataWidth/ByteWidth Else: DataWidth	Write Data
MByteEn	!PreciseBurst <u>and</u> !ImpreciseBurst and ByteWidth != DataWidth	DataWidth/ByteWidth	Per-lane write byte enable when bursts and pipelining are not enabled: a request phase signal
MDataByteEn	(PreciseBurst <u>or</u> ImpreciseBurst) and ByteWidth != DataWidth	DataWidth/ByteWidth	Per-lane write byte enable when bursts and pipelining are enabled: a data handshake phase signal
MDataInfo	If ByteWidth != DataWidth and ByteWidth != 8	DataWidth – (8 * DataWidth/ByteWidth)	Extra write data not allowed in MData per OCP
MDataLast	PreciseBurst <u>or</u> ImpreciseBurst	1	Indicates last write data in a burst
MReqLast	PreciseBurst <u>or</u> ImpreciseBurst	1	Indicates last request in a burst
MDataValid	PreciseBurst or ImpreciseBurst	1	Qualifies active write-data within bursts
MReset_n	always	1	Reset Master-to-Slave. (Asserted in response to WCI reset asserted)
MRespAccept	(PreciseBurst <u>or</u> ImpreciseBurst) and ReadDataFlowControl	1	Indicates master has accepted the read data. Allows master to throttle read data it has requested.

1767 Table 26 – Worker Memory Interface Signals Driven by the Slave, to the Master

			_
OCP Signal	When Included	Width	Usage
SCmdAccept	always	1	Indicates slave has accepted the transfer command
SData	always	If ByteWidth != DataWidth and ByteWidth != 8: 8 *DataWidth/ByteWidth Else: DataWidth	Read Data
SDataAccept	(PreciseBurst <u>or</u> ImpreciseBurst) and WriteData- FlowControl	1	Indicates slave has accepted write data word.
SDataInfo	If ByteWidth != DataWidth and ByteWidth != 8	DataWidth – (8 * DataWidth/ByteWidth)	Extra read data not allowed in SData per OCP
SResp	always	1	Qualifies active read-data words

OpenCPI Page 68 of 88

SRespLast	PreciseBurst <u>or</u> ImpreciseBurst	1	Indicates last beat of read data in a burst
-----------	--	---	---

1768 8.6 WMeml Semantics

- 1769 This section describes specific semantic signal meanings in WMeml that are layered on
- 1770 top of the fundamental OCP signals. They are organized by function and then the
- 1771 signals affected.
- 1772 There are no special semantics with WMeml, but there are additional restrictions.
- 1773 8.6.1 Two basic modes of WMeml: bursts or not
- When neither type of burst is enabled by the WMeml attributes, the interface is
- 1775 simplified to have no data handshake phase, and thus no pipelining of requests before
- write data. The worker always presents data with the request, doesn't deal with bursts,
- and uses the MByteEn signals for write byte enables.
- 1778 When either type of burst is enabled by the WMeml attributes, the interface is
- 1779 configured with pipelined requests, bursts, and the (data handshake phase)
- 1780 MDataByteEn signals are used for write byte enables.
- 1781 8.6.2 Use only Single-Request Multiple-Data for Precise Bursts
- 1782 When the interface supports precise bursts, they must be issued with a single request,
- 1783 which is the semantic when the MBurstSingleReq signal is true (or tied true). Thus
- 1784 WMeml masters must not issue precise bursts with multiple requests. When the
- interface supports imprecise bursts, OCP requires using multiple-request-multiple-data
- 1786 bursts. When both precise bursts and imprecise bursts are supported, the
- 1787 MBurstSingleReq signal is configured (as well as the MPreciseBurst signal) and they
- both always have the same value: if the burst is precise, a single request is used, and if
- the burst is imprecise, multiple requests are used.
- 1790 8.6.3 Intra-burst write data flow control
- 1791 With WMeml, the SCmdAccept signal is always enabled and used to accept requests.
- 1792 The WriteDataFlowControl attribute, which can only be TRUE when bursts are used,
- enables the dataaccept OCP configuration parameter and thus the SDataAccept signal.
- 1794 In this case every data word asserted with MDataValid, must be held until accepted via
- the SDataAccept signal being asserted by the slave.
- 1796 When WriteDataFlowControl is FALSE, the dataaccept parameter is zero, and the
- 1797 MDataAccept signal is not in the interface. In this case, precise and imprecise bursts
- 1798 may work differently since imprecise may throttle write data via SCmdAccept within the
- 1799 burst
- 1800 Regardless of the setting of WriteDataFlowControl, if the first write data word in the
- burst (first data handshake phase in the burst) is presented (via MDataValid) before
- SCmdAccept is asserted (which indicates the end of the first request phase), that data
- 1803 (and the associated MDataValid) must be held constant until SCmdAccept is asserted.

OpenCPI Page 69 of 88

- 1804 8.6.3.1 Precise Bursts with no Write Flow Control.
- 1805 After SCmdAccept is asserted for the single request for the precise burst, any data
- 1806 words are simply presented in a single cycle with MDataValid asserted, and the slave
- 1807 must/will capture the data. Masters issuing precise bursts when WriteDataFlowControl
- 1808 is FALSE are assured that all data asserted after the cycle in which SCmdAccept is
- 1809 asserted will be accepted by the slave immediately.
- 1810 8.6.3.2 Imprecise Bursts with no Write Flow Control.
- 1811 In WMeml imprecise bursts use multiple requests for the burst. Thus, per OCP, the
- data associated with a request may be asserted starting in the same cycle as the
- reguest, but can also be arbitrarily delayed. As mentioned above, data asserted (with
- 1814 MDataValid) before the associated SCmdAccept must be held until SCmdAccept is
- 1815 asserted. Data asserted during or after the associated SCmdAccept assertion must/will
- 1816 be captured by the slave in that cycle.
- 1817 Masters issuing imprecise bursts must obey the SCmdAccept behavior for every
- 1818 request in the burst. Thus even when WriteDataFlowControl is FALSE, the master must
- 1819 support request flow control throughout the burst.
- 1820 8.6.4 Intra-burst read data flow control
- 1821 The WMeml ReadDataFlowControl attribute configures the interface to provide this
- 1822 feature by way of the MRespAccept signal, which causes the slave to hold read data
- until accepted by the master. This option is only used when bursts are enabled, and is
- 1824 typically only used for precise bursts, since intra-burst read flow control can be
- accomplished by the worker/master via throttling its own issuance of read requests.
- 1826 8.7 WMeml Infrastructure Issues
- 1827 WMeml infrastructure IP acts as a slave to worker interfaces specified with the WMeml
- 1828 attributes above. There are three significant issues in supporting worker choices: burst
- 1829 support (implying datahandshake), intra-burst flow control (for precise bursts), and
- 1830 data/byte widths.
- 1831 8.7.1 Burst support
- 1832 If memory IP supports both precise bursts and imprecise bursts then it will be able to
- 1833 satisfy any worker burst behavior. The major challenge/cost is in adding the dynamic
- 1834 behavior to optimize the imprecise case where the controller does not know how much
- data will be in the burst. In both cases, the memory IP does not know how many intra-
- burst idle cycles there will be (either in requests or data), and is usually optimized for
- 1837 the continuous case.
- 1838 When the worker has no burst support, and thus no data handshake phase, tie-offs on
- the burst-related signals (imprecise burst with burst length of 1) should suffice.
- 1840 If the memory IP has no burst support, then a slightly more complex adapter is required,
- to align request and data phases, and, for precise bursts, an address counter/generator
- 1842 is required.

OpenCPI Page 70 of 88

Worker Interface Profiles (WIP) Functional Specification

8.7.2 Intra-burst flow control 1843 1844 When a worker does not support write data flow control, all data in the burst must be 1845 captured in the cycle it is asserted (via MDataValid), up to the maximum burst size. 1846 This may require adding buffering to the memory IP (or adding an adapter with such memory). If the worker implements read data flow control, the memory IP may require 1847 extra buffering when it cannot apply backpressure to the underlying memory 1848 1849 mechanisms. 1850 When there are burst size mismatches, without flow control, extra buffering is also 1851 required (i.e. when the worker writes a burst without flow control, larger than the 1852 buffering available in the memory IP). 1853 8.7.3 Data/byte widths 1854 There are many cases of width mismatches, but a common one is when the memory 1855 itself has more bits in width than the worker requires or wants to use. The simple case is to simply ignore the extra bits (sometimes the extra bits-per-byte when memory bytes 1856 are actually > 8 bits wide). Most Memory IP should work when the worker wants simple 1857 1858 power-of-2 memory widths and 8-bit bytes.

OpenCPI Page 71 of 88

9 Worker Time Interface (WTI)

9.1 WTI Motivation

1859

1860

- WTI is an interface that allows workers to access the current system time (TOD, "now").
- 1862 This allows any worker in the system to know what time it is, to some system-defined
- 1863 accuracy (depending on the implementation of that service across the system). Many
- 1864 applications require accurate and precise timestamping, time measurement, and time
- scheduling. The interface must enable time to be provided as accurately as technically
- 1866 possible (depending on infrastructure capabilities), and be conveniently accessible from
- 1867 worker logic. The interface should also enable the time service to be controlled in order
- 1868 to reduce power when the worker does not need it.
- 1869 This interface should provide "time" as a service to workers, much like the WMeml
- provides memory as a service to workers. Implementations of this service are
- 1871 characterized by accuracy across the chip substrate (workers spread across a chip) as
- 1872 well as across chips on a circuit board or across circuit boards in a system or systems
- 1873 with GPS and/or network connections. The interface does not define accuracy, but
- 1874 allows workers to specify precision.
- 1875 Future versions of this specification may allow workers to indicate required accuracy as
- 1876 a quality of service.

1877 **9.2 WTI Overview**

- 1878 The format of the time value made available to the worker is a fixed point binary value
- 1879 corresponding to GPS time. When the worker's functionality requires access to time,
- the author specifies, via WIP attributes, the number of binary digits required on both
- sides of the radix point. With 32 bits to the right of the radix point, the low order bit
- would represent 0.23283 ns. This format, when using 32 bits on each side of the radix
- point, is the same as the format used in NTP (Network Time Protocol). GPS is a time
- 1884 scale based on atomic clocks that advances monotonically, unlike UTC or UNIX/POSIX
- 1885 time, which does not (due to handling of leap seconds). GPS time zero started at
- 1886 00:00:00 UTC on January 6, 1980. Conversion to UTC or UNIX/POSIX requires a table
- of leap seconds. GPS is chosen rather than UTC or POSIX so that workers will never
- deal with leap seconds when performing time calculations. There have been 24 leap
- 1889 seconds since 1972.
- 1890 This (OCP) profile specifies that the infrastructure is the master, and the worker is the
- 1891 slave, with the time constantly "written" from the infrastructure to the worker. Thus the
- 1892 time is constantly and trivially available as long as the worker requests it (via very
- 1893 simple flow control). Workers can ignore flow control and OCP signal tieoff rules will
- 1894 enable time to be always available.
- 1895 As in all WIP interfaces on a worker, the worker author chooses the clock domain in
- 1896 which the interface operates (the domain of the OCP clock signal associated with that
- interface). The worker author would typically choose the same clock domain as one of

OpenCPI Page 72 of 88

- its data input and/or output interfaces, but if it is specified to be in its own clock domain, it will likely be in a clock domain of the timekeeping infrastructure itself.
- 1900 The WTI is configured (per OCP) such that the time is delivered via (qualified by) an
- 1901 OCP "write" command on every clock cycle when the time value is valid and the worker
- 1902 allows, via flow control (SThreadBusy), the time value to be presented. This flow
- 1903 control aspect of WTI allows the worker to indicate to the infrastructure when it actually
- 1904 needs to know the time, enabling the infrastructure the possibility to make power
- 1905 optimizations when the worker does not need the time value. The presence of the OCP
- 1906 "write" command indicates valid time. The absence of the OCP "write" command
- 1907 indicates that time is not available (not valid).
- So to know time, the worker author specifies a WTI, and the number of data bits on both sides of the radix point.
- 1910 9.3 WTI Worker Attributes
- 1911 Worker authors using a WTI specify their implementation choices via the following
- 1912 attributes, from which all OCP configuration parameters and signals are derived.
- 1913 The Clock and ClockSignal attributes, described in section 2.6, are applicable to WTI.
- 1914 The default attribute settings provide GPS time in integer seconds.
- 1915 9.3.1 WTI Attribute Summary

Table 27 – WTI Worker Canonical Attribute Table

Attribute Name	Type (per XML Schema)	Default value	Description (OCP configuration parameters affected by this choice)
SecondsWidth	unsignedInt	32	Physical width in bits/wires of of the data path used to convey whole seconds of GPS time.
FractionWidth	unsignedInt	0	Physical width in bits/wires of of the data path used to convey fractional seconds of GPS time. The MSB is the first bit to the right of the radix point.
AllowUnavailable	boolean	false	Indicates, when true, that the worker is prepared to deal with the time value being unavailable.

- 1917 9.3.2 WTI Attribute Details
- 1918 This subsection contains the per-attribute details of choices available for a WTI on a
- 1919 worker.

1924

1916

- 1920 The two attributes, SecondsWidth, and FractionWidth, specify the number of bits to the
- 1921 left and right, respectively, of the radix point, of the fixed point binary value made
- 1922 available to the worker, on the OCP data signals (MData). The data path width is the
- 1923 sum of these two attributes.
 - 9.4 WTI OCP Profile/Configuration Parameters
- 1925 The WTI OCP profile is the aspect of the WTI that has to do with OCP configuration
- 1926 parameters and signal configuration. This section describes the concrete, complete,
- 1927 and unambiguous transformation from WTI WIP attributes described above, to the OCP

OpenCPI Page 73 of 88

1928 configuration parameters inferred from those attributes. This transformation is implemented in automation tools.

The table below lists only those parameters that are different from the OCP configuration parameter defaults (per the OCP specification).

Table 28 – Worker Time Interface OCP Configuration Parameter Settings

OCP Configuration Parameter	Value	Description (How OCP parameter is determined if not constant, and any tieoffs)
addr	0	
cmdaccept	0	
data_wdth	W	W = SecondsWidth + FractionWidth
mreset	0	
read_enable	0	
resp	0	
sdata	0	
sreset	1	Worker must propagate its WCI reset
sthreadbusy	1	Normal tieoff applies: signal is always deasserted
sthreadbusy_exact	1	Well defined sthreadbusy semantics per OCP
sthreadbusy_pipelined	1	SthreadBusy at a clock permits command in next cycle.

9.5 WTI OCP Signals

1930

1931 1932

1933

1934

1935 1936

1937

1938

1939

1940

Signal configuration is determined by the interface configuration parameters and as called out in the "OCP Signal Configuration Parameter" table in the OCP specification. The tables below show the signals from master-to-slave and slave-to-master. The positional order of signals is alphabetical.

Table 29 – Worker Time Interface Signals Driven by the Master, to the Slave

OCP Signal	When Included	Width	Usage
MCmd	always	3	MCmd == WRITE when time is available on MData, else IDLE. IDLE only before "start" or if AllowUnavailabe == true.
MData	always	SecondsWidth + FractionWidth	Time value, fixed point

Table 30 – Worker Time Interface Signals Driven by the Slave, to the Master

OCP Signal	When Included	Width	Usage
SReset_n	always	1	Indicates worker is in reset (from WCI). Must be propagated from WCI's MReset_n, in clock domain of this WTI.
SThreadBusy	always	1	Indicates when deasserted, that worker wants time in next cycle.

9.6 WTI Semantics

This section describes specific semantic signal meanings in WTI that are layered on top of the fundamental OCP signals. They are organized by function and then the signals affected.

OpenCPI Page 74 of 88

- 1944 9.6.1 Indicating to the worker when time is valid and available
- 1945 The MCmd signal field having the value "WRITE", indicates that the data is valid (on the
- 1946 MData signals), which in the case of WTI indicates when the time value is available and
- 1947 valid. A worker that has set the "AllowUnavailable" attribute to "false" (the default),
- 1948 indicates that it expects time to always be available before becoming operational
- 1949 (before the "start" control operation is issued to the worker via its WCI), and thus can
- 1950 assume this value is always "WRITE" before it receives the "start" control operation.
- 1951 9.6.2 Indicating to the infrastructure when time is not required
- 1952 If the worker would like to indicate to the infrastructure when a valid time value is *not*
- 1953 needed, it can assert the SThreadBusy signal. According to the OCP specification, this
- 1954 disallows a WRITE command. In the case of WTI, the infrastructure can use this
- 1955 indication to disable certain timekeeping activities to save power. The OCP tieoff for
- this signal is deasserted, so it can be ignored for workers that choose not to have such
- 1957 an indication.
- 1958 9.6.3 The simplest case
- 1959 With all attributes set to default values, and the worker not caring to indicate when it
- does not need the timevalue, the worker simple samples the MData signals with the
- 1961 clock indicated for the WTI. SThreadBusy will tie off to deasserted, and MCmd will
- 1962 always have the "WRITE" value. Other than sampling the MData signals, the worker
- 1963 must assert the SReset in signal (in the WTI's clock domain), when the MReset in
- 1964 signal is asserted on the worker's WCI.
- 1965 **9.7 WTI Infrastructure Issues**
- 1966 WTI infrastructure IP acts as a master to worker interfaces specified with the WTI
- 1967 attributes above. There are two significant issues in supporting worker behavior: time
- being unavailable, and the worker indicating that time is not needed.
- 1969 9.7.1 Time not needed
- 1970 The WTI infrastructure (master) must respect the SThreadBusy signal (with the exact,
- 1971 pipelined behavior per OCP) by not asserting the WRITE value on the MCmd signals
- unless the SThreadBusy signal from the worker is deasserted in the previous cycle.
- 1973 The infrastructure *may* take advantage of this indication of SThreadBusy to reduce
- 1974 activity/power in the infrastructure since the worker is explicitly indicating that it does not
- 1975 need a valid time value in the following cycle.
- 1976 9.7.2 Time not available
- 1977 When a worker cannot tolerate time being unavailable (when its AllowUnavailable
- 1978 attribute is false), then the control system will ensure that time is indeed available before
- 1979 issuing the "start" control operation to the worker's WCI interface. Furthermore, the
- 1980 infrastructure must be made aware (through implementation-defined mechanisms), that
- the worker cannot tolerate time becoming unavailable, and thus must inform the control
- 1982 system (again through implementation-defined mechanisms), when time becomes
- 1983 unavailable.

OpenCPI Page 75 of 88

1985

1997

1998

1999 2000

2001

2002

2003

20042005

2006

2010

2011

10 WIP XML Schema

1986 **10.1 Introduction**

- 1987 This section describes the WIP schema for users creating XML documents that
- 1988 describe WIP-based IP modules. It is the format of the WIP metadata.

1989 10.2 Quick XML Introduction

- 1990 XML documents are files that contain information formatted according to XML
- 1991 (Extensible Markup Language) syntax and structure according to a particular
- 1992 application-specific "XML schema". XML information itself is formatted into Elements,
- 1993 Attributes, and Textual Content. The WIP XML Schema does not allow Textual Content
- 1994 at this time. XML Elements take two forms. The simpler one is when an element has
- no child (embedded) elements and no Textual Content. It looks like this (for element of
- 1996 type, "xyz", with attribute "abc"):

```
<xyz abc="123"/>
```

Thus the element begins with the "<" character and the element type, and terminated with the "/>" characters. Attributes have values in double-quotes. Any white space, indentation, or new lines can be inserted for readability between the element name and attributes. Thus the above example could also be:

```
<xyz
abc="123"
/>
```

When the element has child elements (in this case element of type "ccc" with attribute "cat"), it looks like:

So, an XML Schema defines which Elements, Attributes, and child Elements the document may contain. Every XML document (in this context) has a single top level element that must be structured (attributes and sub-elements) according to the WIP

2013 XML schema.

An element can be entered directly (as above) or entered by referring to a separate file that contains that element. So the example above might have a file "ccc1.xml"

2016 containing:

```
2017 <ccc cat="345"/>
```

2018 And then a top level file called "xyz1.xml" containing:

However, the schema specifies which elements are allowed to be top-level elements in any file.

OpenCPI Page 76 of 88

2033

2034

2035

2044

2045

2046 2047

2048

2049

2050

2051

2052

2053 2054

2055

2056

2057

2058

2059

There are various built-in attributes that are part of the XML system itself and elements (such as the xi:include element above), and are required in certain cases. In particular, the top level element of a top level file (not an included file) must have these built-in, or "boilerplate" attributes:

2028 To specify the schema according to which this document is structured:

```
2029 xmlns:x="http://www.w3.org/2001/XMLSchema-instance"
2030 x:schemaLocation="http://www.mc.com/CPI WIP-schema1.xsd"
2031 xmlns="http://www.mc.com/CPI"
```

To allow the use of the "xi:include" feature above, the top level element that will have inclusions inside it must contain the attribute:

```
xmlns:xi="http://www.w3.org/2001/XInclude"
```

If all these boilerplate attributes were included in the example above, it would look like:

The schema reference attributes allow the files to be processed with very generic tools, since the files contain the reference to the schema they are following. If they are not included, then they must be supplied as command-line arguments on the tools that process these files. With these attributes included any XML processor can process the files without being told about the schema.

Note that the default value of all boolean attributes is false unless otherwise noted.

10.3 Top Level Element: Component Specification

A component specification is the XML element describing a component at a high level without implementation choices. It describes enough about how the component can be integrated into an application to ensure possible WIP-based interoperability and interchangeability among different implementations. Many such implementations are possible given this component specification. In particular, a component specification can usually be completely derived from a higher level component model such as that defined in the various software-defined radio component standards such as SCA and the OMG's "PIM/PSM for software-based communication", as well as the generic component standards such as the ones in UML v2 or CCM v4.

The component specification contains component-global attributes, control plane aspects and data plane aspects. A component specification is contained in the XML element whose type is "ComponentSpec", which should be a top level element in a file, structured as:

OpenCPI Page 77 of 88

- 2072 In the various examples below the boilerplate attributes will be omitted.
- 2073 10.3.1 Attributes of a Component Specification
- 2074 10.3.1.1 Name
- The "Name" attribute of the component specification is constrained to be acceptable as
- 2076 an identifier in several contexts, including VHDL. It identifies the component
- 2077 specification as a whole. It is case *insensitive*: when in a library or application, two
- 2078 different component specifications cannot have the same name, when compared in a
- 2079 case-insensitive way.
- 2080 10.3.1.2 NoControl
- 2081 The "NoControl" attribute of the component specification is a boolean attribute that
- 2082 indicates, when true, that components using this specification have no control
- 2083 plane/interface at all. This is not allowed for application components but is specified for
- 2084 certain infrastructure components.
- 2085 10.3.2 Control Plane Aspects of a Component Specification
- 2086 A component's control plane specification is essentially a description of its configuration
- 2087 properties used to parameterize its operation or to retrieve operational statistics and
- 2088 resulting scalar values based on the component's operation. There are two different
- 2089 ways to specify this: the summary or the details. The Properties element of a
- 2090 component specification enumerates the name and type and behavior of each
- 2091 configuration property supported by implementations of this specification. The
- 2092 alternative PropertySummary element simply provides the information necessary to
- define the (WCI) control interface for the component, without providing the details of
- 2094 individual configuration properties. If the Properties element is present, the property
- 2095 summary information is inferred from the enumerated property descriptions.
- 2096 Both the Properties and PropertySummary elements may be in separate files and
- referenced using the <xi:include href="<file>"/> syntax. This is common when
- 2098 PropertySummary or Properties elements are shared among multiple component
- 2099 specifications.
- 2100 10.3.2.1 Properties Element
- 2101 The Properties element has no attributes, but consists of a list of Property elements.
- 2102 The ordering of the Property elements is important: implementations are required to
- 2103 respect the order of the listed properties. Anywhere in the list of Property elements in
- 2104 the overall Properties element, you can be include additional Properties elements using

OpenCPI Page 78 of 88

- 2105 the <xi:include href="<file>"/> syntax. This allows a list of properties to be shared as a
- 2106 subset of the properties of different components.
- 2107 10.3.2.1.1 Property Element
- 2108 A Property element describes one configuration property. It has attributes, but no sub-
- 2109 elements. It always occurs as a sub-element of the Properties element. A Property
- 2110 element describes the name and data type of a configuration property, and there is a
- 2111 "struct" data type to allow properties to consist of a structure of simpler scalar data
- 2112 members. [As of the current WIP specification, there is no support for recursive
- 2113 structures] Furthermore, each property can be an array or sequence of its data type.
- 2114 Consistent with the CORBA IDL specification, the term "array" refers to a fixed number
- of data values of the specified type, whereas the term "sequence" refers to a variable
- 2116 number of data values, up to a specified maximum length. The attributes of the
- 2117 Property Element are listed here:
- **2118** *10.3.2.1.1.1 Name attribute*
- 2119 The Name attribute is the case insensitive name of the property. A set of properties
- 2120 cannot have properties whose names differ only in case. Mixed case property names
- 2121 can be used for readability. When a Properties element includes (via xi:include) other
- 2122 Properties elements there is still only one flat case-insensitive name space of properties
- 2123 for the component.
- **2124** *10.3.2.1.1.2 Type attribute*
- 2125 The Type property specifies the data type of the property. The legal types (case
- 2126 insensitive) are: Bool, Char, Double, Float, Short, Long, UChar, ULong, UShort,
- 2127 LongLong, ULongLong, and String. The "Char", "Short", "Long", and "LongLong" types
- represent 8, 16, 32, and 64 integer values respectively. The "Float" and "Double" types
- are consistent with 32 and 64 bit IEEE floating point types, and the "String" type is a null
- 2130 terminated string. When the "Type" attribute has the "String" value, the "StringLength"
- 2131 attribute must also be supplied, to indicate the maximum length of the string property
- values, excluding the terminating null character (consistent with the ISO-C strlen
- 2133 function). If no Type attribute is present in the Property element, the type "ULong" is
- 2134 used.
- 2135 The "ArrayLength" attribute is used when the property is a fixed length array of the
- 2136 indicated type. The "SequenceLength" attribute is used when the property is a variable
- 2137 length sequence of the indicated type.
- 2138 Then the type is "Struct", the Property element has Property sub-elements that indicate
- 2139 the types of the members of the struct value. No struct members can be of type
- 2140 "Struct". The SequenceLength and ArrayLength attributes do apply to "Struct"
- 2141 properties.
- 2142 Thus all types have a maximum length. There are no unbounded length property data
- 2143 types.
- 2144 *10.3.2.1.1.3 StringLength attribute*

OpenCPI Page 79 of 88

- 2145 The StringLength attribute is used when the Type attribute is "String", and indicates the
- 2146 maximum length null-terminated string value that this property can hold. The null is not
- 2147 included in the this length.
- 2148 *10.3.2.1.1.4 ArrayLength attribute*
- 2149 The presence of this attribute indicates that the property values are a fixed length array
- of the type specified in the Type attribute, and that fixed length is indicated in the value
- 2151 of this ArrayLength attribute.
- 2152 *10.3.2.1.1.5 SequenceLength attribute*
- 2153 The presence of this attribute indicates that the property values are a variable, but
- bounded, sequence of the type specified in the Type attribute, and that maximum length
- 2155 is indicated in the value of this SequenceLength attribute. Thus this property has the
- 2156 specified maximum length, and always contains a current length, up to that limit.
- **2157** *10.3.2.1.1.6 Readable attribute*
- 2158 This attribute, which defaults to true, indicates whether this property can be read by
- 2159 control software. If set to false, attempts to read the property value at any time after
- 2160 instantiation will result in an error.
- **2161** *10.3.2.1.1.7 Writable attribute*
- 2162 This attribute, which defaults to true, indicates whether this property can be written by
- 2163 control software. If set to false, attempts to write the property value at any time after
- 2164 instantiation will result in an error.
- **2165** *10.3.2.1.1.8 Initial attribute*
- 2166 This attribute, which defaults to true, indicates whether this property can be specified at
- 2167 the time of instantiation as an initial value, by control software. If set to false, attempts
- 2168 to specify the property at instantiation time will result in an error.
- **2169** *10.3.2.1.1.9 Volatile attribute*
- 2170 This attribute, which defaults to true, indicates whether this property's value will change
- as a consequence of the component's execution, without it being written by control
- 2172 software. When true, it indicates to control software that the values set at instantiation
- 2173 time or when the value is written, cannot be cached.
- 2174 10.3.2.2 Property Summary Element
- 2175 The property summary contains information about the configuration properties of the
- 2176 component that are relevant to the control interface, based on the WCI profile. It is
- 2177 called a "summary" since there is normally more information about configuration
- 2178 properties (the "details") that are neither relevant to nor required by the component's
- 2179 control interface. This property summary is expressed as an XML element whose type
- 2180 is "PropertySummary", and is a child element of a ComponentSpec. [A later version of
- 2181 this specification will include a PropertyDetails element that can be used in place of this
- 2182 when appropriate. The property detail will enumerate each configuration property value
- 2183 and its attributes to aid in generating more convenience items in the VHDL skeletons.]

OpenCPI Page 80 of 88

2184 The property summary includes the following attributes, as documented in the WIP WCI 2185 profile: 2186 10.3.2.2.1 SizeOfConfigSpace attribute 2187 The type of this attribute is of type unsigned of <= 2^20 with a default value of zero. 2188 10.3.2.2.2 WritableConfigProperties attribute of type boolean 2189 The type of this attribute is of type boolean. 2190 10.3.2.2.3 ReadableConfigProperties attribute 2191 The type of this attribute is of type boolean. 2192 Sub32BitConfigProperties attribute 10.3.2.2.4 2193 The type of this attribute is of type boolean. 2194 Thus an example is: 2195 <ComponentSpec 2196 ---attributes---2197 2198 <PropertySummary SizeOofConfigSpace="20"/> 2199 ---other child elements---2200 </ComponentSpec> 2201 If there is no PropertySummary, then all the related attributes take on default values for 2202 the ComponentSpec, as if "<PropertySummary/>" was included. This implies that the 2203 specified component has no configuration properties as all. 2204 10.3.3 Data Plane Aspects of a Component Specification 2205 10.3.3.1 Data Interface Specification Element 2206 The component specification defines data plane interfaces through the use of the "DataInterfaceSpec" element. It specifies the direction of the interface (producer or 2207 consumer) and the message-level protocol used at that interface. In particular it does 2208 not specify the WIP data profile (WSI, WMI) for that interface as that is an 2209 2210 implementation choice. 2211 The data interface specification element has several attributes and one child element: 2212 the Protocol Summary 2213 10.3.3.1.1 Name attribute

2218 10.3.3.1.2 Producer attribute

specification.

2214

2215

2216 2217

OpenCPI Page 81 of 88

This attribute specifies the name of the interface for this component. The value of the

name attribute is a string that is constrained to be valid in various languages like OCP configuration files and VHDL. It must be unique (case insensitive) within the component

- 2219 This boolean attribute is as specified in the WIP data plane profiles, and indicates
- 2220 whether data is produced at this worker interface or consumed at this interface. A value
- 2221 of "true", indicates a producer interface.
- 2222 10.3.3.2 Protocol Summary element
- 2223 The protocol summary element, which is a child element of the data interface
- 2224 specification element, specifies attributes of the message protocol used at this interface.
- 2225 We use the term "summary" since this element only contains the interface-related
- 2226 summary aspects of the message protocol, not the details (analogous to the
- 2227 PropertySummary above). [In a future version of this specification we will define a
- 2228 ProtocolDetails element that can be used in place of this]. The ProtocolSummary is a
- 2229 separate element since it will likely be reused across a variety of components and
- interfaces and thus may be referred to in a separate common file via the "xi:include"
- 2231 mechanism mentioned above.
- 2232 The attributes of the ProtocolSummary element are attributes defined for the data
- 2233 interfaces in the WIP profiles (WSI and WMI). They may be omitted if they have default
- values as defined in the WIP profiles. The attributes are described in the worker data
- 2235 interface section above.
- 2236 10.3.3.2.1 DataValueWidth
- The type of this attribute is of type unsignedInt.
- 2238 10.3.3.2.2 DataValueGranularity
- 2239 The type of this attribute is of type unsignedInt.
- 2240 10.3.3.2.3 DiverseDataSizes
- The type of this attribute is of type boolean.
- 2242 10.3.3.2.4 MaxMessageValues attribute
- The type of this attribute is of type unsignedInt.
- 2244 10.3.3.2.5 NumberOfOpcodes
- The type of this attribute is of type unsigned Int.
- 2246 10.3.3.2.6 VariableMessageLength
- The type of this attribute is of type boolean.
- 2248 10.3.3.2.7 ZeroLengthMessages
- The type of this attribute is of type boolean.

OpenCPI Page 82 of 88

2278

2279

2280

2281 2282

2283

2284

```
2250
       10.3.4 Component Specification Examples
2251
               <ComponentSpec Name="K1spec"</pre>
2252
                  <PropertySummary</pre>
2253
                     SizeofConfigSpace="8" WritableConfigProperties="true"/>
2254
                  <DataInterfaceSpec Name="lvds tx" Producer="true">
2255
                     <ProtocolSummary
2256
                        MaxMessageValues="1024" VariableMessageLength="true"/>
2257
                  </DataInterfaceSpec>
2258
                  <DataInterfaceSpec Name="lvds rx" Producer="false">
2259
                     <ProtocolSummary
                        MaxMessageValues="1024" VariableMessageLength="true"/>
2260
2261
                  </DataInterfaceSpec>
2262
               </ComponentSpec>
2263
               <ComponentSpec Name="S1spec"</pre>
2264
                  <PropertySummary</pre>
2265
                     SizeofConfigSpace="256"
2266
                     WritableConfigProperties="true"
2267
                     ReadableConfigProperties="true"/>
2268
                  <DataInterfaceSpec Name="sfpdp prod" Producer="true">
2269
                     <ProtocolSummary
2270
                        MaxMessageValues="1024" VariableMessageLength="true"/>
2271
                  </DataInterfaceSpec>
                  <DataInterfaceSpec Name="sfpdp cons" Producer="false">
2272
2273
                     <ProtocolSummary
2274
                        MaxMessageValues="1024" VariableMessageLength="true"/>
2275
                  </DataInterfaceSpec>
2276
               </ComponentSpec>
```

10.4 Top Level Element: Component Implementation Description

A component implementation description contains information provided by someone creating an implementation based on a component specification. It includes or references a component specification, and then describes implementation information about a particular implementation of that specification. Thus, after the attributes, it must either include as a child element a complete ComponentSpec, or include one by reference, for example, if the "fastcore" implementation of the "corespec1" specification referenced the component specification found in the "corespec1.xml" file:

```
2285
               <HdlImplementation
2286
                     xmlns:x="http://www.w3.org/2001/XMLSchema-instance"
2287
                     x:schemaLocation="http://www.omg.org/CPI WIP-schema1.xsd"
2288
                     xmlns="http://www.omg.org/CPI"
2289
                     xmlns:xi="http://www.w3.org/2001/XInclude"
2290
                  Name="fastcore"
2291
                  ---other attributes---
2292
2293
                  <xi:include href="corespec1.xml"/>
2294
                  ---other child elements---
2295
               </HdlImplementation>
```

OpenCPI Page 83 of 88

2331 2332

2296	10.4.1 Attributes of an HDL Component Implementation
2297	10.4.1.1 Nam e
2298 2299 2300	The "Name" attribute of the component implementation is constrained to be acceptable as an identifier in several contexts, including VHDL. It identifies the component specification as a whole. It is also used at the "core" name in OCP.
2301	10.4.2 Control Plane Aspects of an HDL Component Implementation
2302	10.4.2.1 Control Interface element
2303 2304 2305 2306 2307 2308 2309 2310	The control interface child element (ControlInterface) of the component implementation description (ComponentImplementation) specifies implementation aspects of the worker's control interface (its interface based on the WCI profile). If this element is not present, then the PropertySummary must also not be present in the referenced Component Specification, and indicates that this worker has no control interface at all. This is only allowed for infrastructure cores, not application cores. There can be zero or one control interface elements per component implementation. The attributes of the control interface are:
2311	10.4.2.1.1 Name attribute
2312 2313 2314	This attribute specifies the name used for this WCI-based interface, which defaults to "control" if not specified. The string value of this attribute is constrained to be a valid identifier in both OCP and VHDL.
2315	10.4.2.1.2 ControlOperations attribute
2316 2317 2318	This attribute is defined as a WCI profile attribute, and contains a comma-separated list of strings identifying the implemented control operations (the start operation must be included, and the default value is "start").
2319	10.4.2.1.3 ResetWhileSuspended attribute
2320	This boolean attribute is defined as a WCI profile attribute.
2321	10.4.2.1.4 Clock
2322 2323 2324 2325 2326 2327	This attribute specifies the name of the clock domain used at this interface. It must match the name of a clock child element of the component implementation. It may also refer to the name of another interface, in which case the clock for this interface will use the clock specified at that other interface. If not specified, the WCI has its own clock input signal, named according to the prefix rules, associated with the other signals at this interface.
2328	10.4.2.2 Clock element
2329 2330	The clock child element (Clock) of the component implementation description (ComponentImplementation) specifies a clock domain (clock input) to the

OpenCPI Page 84 of 88

interfaces. There can be zero or more clock elements in the component

implementation. It may be used by any interfaces, or be independent of any of those

- 2333 implementation. If there are none, then each interface (control or data) is assumed to
- have the same clock as the WCI, behaving per OCP. The attributes of the clock element
- 2335 are:
- 2336 10.4.2.2.1 Name attribute
- 2337 This attribute specifies the name used for this clock, which defaults to "clock" if not
- 2338 specified.
- 2339 10.4.2.2.2 Signal attribute
- 2340 This attribute specifies the name of the signal used inside the implementation for this
- 2341 clock. If the clock is "owned" by an interface (i.e. the "MyClock" attribute of that
- 2342 interface element is true), then this attribute must not be specified. The string value of
- 2343 this attribute is constrained to be a valid identifier in both OCP and VHDL.
- 2344 [future versions of this specification are expected to include constraints for the clocks
- 2345 required by an implementation]
- 2346 10.4.3 Data Plane Aspects of an HDL Component Implementation
- 2347 10.4.3.1 Stream Interface element
- 2348 The stream interface child element (StreamInterface) of the component implementation
- 2349 description (ComponentImplementation) specifies a data interface that uses the
- 2350 streaming WIP profile (WSI). It references a DataInterfaceSpec by its Name attribute.
- 2351 Thus the Name attribute of the StreamInterface element must match the Name attribute
- of a DataInterfaceSpec element of the ComponentSpec. The Stream Interface element
- 2353 adds implementation-specific information about the interface initially defined in that
- 2354 DataInterfaceSpec.
- 2355 10.4.3.1.1 Name attribute
- 2356 This attribute specifies the name used to reference the DataInterfaceSpec in the
- 2357 ComponentSpec.
- 2358 10.4.3.1.2 Clock attribute
- 2359 This attribute specifies the name of the clock domain used at this interface. It must
- 2360 match the name of a clock child element of the component implementation or refer to
- 2361 the name of another interface, in which case the clock for this interface will use the
- 2362 clock specified at that other interface. If not specified (and the MyClock attribute is not
- 2363 true), then this interface uses the same clock as the WCI.
- 2365 This Boolean attribute when true specifies that the clock used at this interface will be
- 2366 associated with the other OCP signals at this interface, and be named with the prefix
- rules for signals at this interface. It specifies that the clock is "owned" by this interface.
- 2368 If this attribute is true, and the "Clock" attribute is not specified, then this interface has
- 2369 its own clock, named with the other signals of this interface.

OpenCPI Page 85 of 88

- 2370 10.4.3.1.4 DataWidth attribute
- 2371 As specified for the WSI.
- 2372 10.4.3.1.5 PreciseBurst attribute
- 2373 As specified for the WSI.
- 2374 10.4.3.1.6 ImpreciseBurst attribute
- 2375 As specified for the WSI.
- 2376 10.4.3.1.7 Continuous attribute
- 2377 As specified for the WSI.
- 2378 10.4.3.1.8 Abortable attribute
- 2379 As specified for the WSI.
- 2380 10.4.3.1.9 EarlyRequest attribute
- 2381 As specified for the WSI.
- 2382 10.4.3.2 Message Interface element
- 2383 The message interface child element (MessageInterface) of the component
- 2384 implementation description (ComponentImplementation) specifies a data interface that
- 2385 uses the messaging WIP profile (WMI). It references a DataInterfaceSpec by its Name
- 2386 attribute. Thus the Name attribute of the MessageInterface element must match the
- 2387 Name attribute of a DataInterfaceSpec element of the ComponentSpec. The Message
- 2388 Interface element adds implementation-specific information about the interface initially
- 2389 defined in that DataInterfaceSpec.
- 2390 10.4.3.2.1 Name attribute
- 2391 This attribute specifies the name used to reference the DataInterfaceSpec in the
- 2392 ComponentSpec.
- 2393 10.4.3.2.2 Clock attribute
- 2394 See StreamInterface Clock attribute above.
- 2395 *10.4.3.2.3 MyClock attribute*
- 2396 See StreamInterface MyClock attribute above.
- 2397 10.4.3.2.4 DataWidth attribute
- 2398 As specified in the WIP data profiles.
- 2399 10.4.3.2.5 ByteWidth attribute
- 2400 As specified in the WIP data profiles.
- 2401 10.4.3.2.6 PreciseBurst attribute

OpenCPI Page 86 of 88

- 2402 As specified in the WIP data profiles.
- 2403 10.4.3.2.7 ImpreciseBurst attribute
- 2404 As specified in the WIP data profiles.
- 2405 10.4.3.2.8 Continuous attribute
- 2406 As specified in the WIP data profiles.
- 2407 10.4.3.2.9 TalkBack attribute
- 2408 As specified in the WIP data profiles.
- 2409 10.4.4 Memory Aspects of a Component Implementation
- 2410 10.4.4.1 Memory Interface element
- 2411 The memory interface child element (MemoryInterface) of the component
- 2412 implementation description (ComponentImplementation) specifies a memory interface
- 2413 that uses the memory WIP profile (WMeml).
- 2414 10.4.4.1.1 Name attribute
- 2415 This attribute specifies the name used for the memory interface (default is "memory").
- 2416 10.4.4.1.2 Clock attribute
- 2417 See StreamInterface Clock attribute above.
- 2418 10.4.4.1.3 MyClock attribute
- 2419 See StreamInterface MyClock attribute above.
- 2420 10.4.4.1.4 DataWidth attribute
- 2421 As specified in the WIP memory profiles.
- 2422 10.4.4.1.5 ByteWidth attribute
- 2423 As specified in the WIP memory profiles.
- 2424 10.4.4.1.6 PreciseBurst attribute
- 2425 As specified in the WIP data profiles.
- 2426 10.4.4.1.7 ImpreciseBurst attribute
- 2427 As specified in the WIP data profiles.
- 2428 10.4.4.1.8 MemoryWords
- 2429 As specified in the WIP data profiles.
- 2430 10.4.4.1.9 MaxBurstLength attribute
- 2431 As specified in the WIP data profiles.

OpenCPI Page 87 of 88

- 2432 *10.4.4.1.10 WriteDataFlowControl attribute* 2433 As specified in the WIP data profiles.
- 2434 10.4.4.1.11 ReadDataFlowControl attribute
- 2435 As specified in the WIP data profiles.
- 2436 10.4.5 Time Aspects of a Component Implementation
- 2437 10.4.5.1 Time Interface element
- 2438 The time interface child element (InterfaceInterface) of the component implementation
- 2439 description (ComponentImplementation) specifies a time interface that uses the time
- 2440 WIP profile (WTI).
- 2441 10.4.5.1.1 Name attribute
- 2442 This attribute specifies the name used for the time interface (default is "time").
- 2443 10.4.5.1.2 Clock attribute
- 2444 See StreamInterface Clock attribute above.
- 2445 10.4.5.1.3 MyClock attribute
- 2446 See StreamInterface MyClock attribute above.
- 2447 10.4.5.1.4 SecondsWidth attribute
- 2448 As specified in the WTI profile.
- 2449 10.4.5.1.5 FractionWidth attribute
- 2450 As specified in the WTI profile.
- 2451 10.4.5.1.6 AllowUnavailable attribute
- 2452 As specified in the WTI profile.

2453

OpenCPI Page 88 of 88