
Hund's law:

1°從低能階開始填=乱度最大

2° 考慮-最外層能量簡併執域

3°以 Si 為例,最外層 3P, ZET



electron spin Antisymmetric Antisymmetric

Singlet triplet Singlet

Output

Outpu

Lowest energy