

# Virtual I/O Device (VIRTIO) Version 1.2

# **Committee Specification Draft 01**

# 09 May 2022

#### This stage:

https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/tex/ (Authoritative) https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/virtio-v1.2-csd01.pdf https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/virtio-v1.2-csd01.html

#### **Previous stage:**

N/A

#### Latest stage:

https://docs.oasis-open.org/virtio/v1.2/virtio-v1.2.pdf https://docs.oasis-open.org/virtio/v1.2/virtio-v1.2.html

#### **Technical Committee:**

OASIS Virtual I/O Device (VIRTIO) TC

#### Chairs:

Michael S. Tsirkin (mst@redhat.com), Red Hat Cornelia Huck (cohuck@redhat.com), Red Hat

#### **Editors:**

Michael S. Tsirkin (mst@redhat.com), Red Hat Cornelia Huck (cohuck@redhat.com), Red Hat

#### **Additional artifacts:**

This prose specification is one component of a Work Product that also includes:

 Example Driver Listing: https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/listings/

#### **Related work:**

This specification replaces or supersedes:

- Virtual I/O Device (VIRTIO) Version 1.1. Edited by Michael S. Tsirkin and Cornelia Huck. Latest version:
  - https://docs.oasis-open.org/virtio/virtio/v1.1/virtio-v1.1.html
- Virtual I/O Device (VIRTIO) Version 1.0. Edited by Rusty Russell, Michael S. Tsirkin, Cornelia Huck, and Pawel Moll. Latest version:
- https://docs.oasis-open.org/virtio/virtio/v1.0/virtio-v1.0.html
- Virtio PCI Card Specification Version 0.9.5: http://ozlabs.org/~rusty/virtio-spec/virtio-0.9.5.pdf

#### Abstract:

This document describes the specifications of the "virtio" family of devices. These devices are found in virtual environments, yet by design they look like physical devices to the guest within the virtual machine - and this document treats them as such. This similarity allows the guest to use standard drivers and discovery mechanisms.

The purpose of virtio and this specification is that virtual environments and guests should have a straightforward, efficient, standard and extensible mechanism for virtual devices, rather than boutique per-environment or per-OS mechanisms.

#### Status:

This document was last revised or approved by the Virtual I/O Device (VIRTIO) TC on the above date. The level of approval is also listed above. Check the "Latest stage" location noted above for possible later revisions of this document. Any other numbered Versions and other technical work produced by the Technical Committee (TC) are listed at https://www.oasis-open.org/committees/tc home.php?wg abbrev=virtio#technical.

Technical Committee members should send comments on this specification to the Technical Committee's email list. Others should send comments to the Technical Committee by using the "Send A Comment" button on the Technical Committee's web page at https://www.oasis-open.org/committees/virtio/.

This specification is provided under the Non-Assertion Mode of the OASIS IPR Policy, the mode chosen when the Technical Committee was established. For information on whether any patents have been disclosed that may be essential to implementing this specification, and any offers of patent licensing terms, please refer to the Intellectual Property Rights page in the TC's GitHub repository (https://github.com/oasis-tcs/virtio-admin/blob/master/IPR.md).

Note that any machine-readable content (Computer Language Definitions) declared Normative for this Work Product is provided in separate plain text files. In the event of a discrepancy between any such plain text file and display content in the Work Product's prose narrative document(s), the content in the separate plain text file prevails.

#### **Citation format:**

When referencing this specification the following citation format should be used:

#### [VIRTIO-v1.2]

Virtual I/O Device (VIRTIO) Version 1.2. Edited by Michael S. Tsirkin and Cornelia Huck. 09 May 2022. OASIS Committee Specification Draft 01. https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/virtio-v1.2-csd01.html. Latest stage: https://docs.oasis-open.org/virtio/virtio/v1.2/virtio-v1.2.html.

# **Notices**

Copyright © OASIS Open 2022. All Rights Reserved.

All capitalized terms in the following text have the meanings assigned to them in the OASIS Intellectual Property Rights Policy (the "OASIS IPR Policy"). The full Policy may be found at the OASIS website.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published, and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this section are included on all such copies and derivative works. However, this document itself may not be modified in any way, including by removing the copyright notice or references to OASIS, except as needed for the purpose of developing any document or deliverable produced by an OASIS Technical Committee (in which case the rules applicable to copyrights, as set forth in the OASIS IPR Policy, must be followed) or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by OASIS or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and OASIS DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY OWNERSHIP RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. OASIS AND ITS MEMBERS WILL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF ANY USE OF THIS DOCUMENT OR ANY PART THEREOF.

As stated in the OASIS IPR Policy, the following three paragraphs in brackets apply to OASIS Standards Final Deliverable documents (Committee Specifications, OASIS Standards, or Approved Errata).

[OASIS requests that any OASIS Party or any other party that believes it has patent claims that would necessarily be infringed by implementations of this OASIS Committee Specification or OASIS Standard, to notify OASIS TC Administrator and provide an indication of its willingness to grant patent licenses to such patent claims in a manner consistent with the IPR Mode of the OASIS Technical Committee that produced this specification.]

[OASIS invites any party to contact the OASIS TC Administrator if it is aware of a claim of ownership of any patent claims that would necessarily be infringed by implementations of this specification by a patent holder that is not willing to provide a license to such patent claims in a manner consistent with the IPR Mode of the OASIS Technical Committee that produced this specification. OASIS may include such claims on its website, but disclaims any obligation to do so.]

[OASIS takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on OASIS' procedures with respect to rights in any document or deliverable produced by an OASIS Technical Committee can be found on the OASIS website. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this OASIS Committee Specification or OASIS Standard, can be obtained from the OASIS TC Administrator. OASIS makes no representation that any information or list of intellectual property rights will at any time be complete, or that any claims in such list are, in fact, Essential Claims.]

The name "OASIS" is a trademark of OASIS, the owner and developer of this specification, and should be used only to refer to the organization and its official outputs. OASIS welcomes reference to, and implementation and use of, specifications, while reserving the right to enforce its marks against misleading uses. Please see <a href="https://www.oasis-open.org/policies-guidelines/trademark/">https://www.oasis-open.org/policies-guidelines/trademark/</a> for above guidance.

# **Table of Contents**

1	Intro		1	
	1.1		/e References	7
	1.2	Non-Nor	mative References	8
	1.3		ogy	8
		1.3.1 L	egacy Interface: Terminology	8
			ransition from earlier specification drafts	9
	1.4		e Specifications	9
	1.5		t Specifications	
				•
2	Bas	ic Faciliti	es of a Virtio Device	1
	2.1		Status Field	1
		2.1.1	Priver Requirements: Device Status Field	1
			Device Requirements: Device Status Field	2
	2.2	Feature	Bits	2
			Priver Requirements: Feature Bits	2
			Device Requirements: Feature Bits	2
			egacy Interface: A Note on Feature Bits	2
	2.3		ons	3
	2.4		Reset	3
			Device Requirements: Device Reset	
			Priver Requirements: Device Reset	
	2.5		Configuration Space	
			Priver Requirements: Device Configuration Space	
			Device Requirements: Device Configuration Space	
			egacy Interface: A Note on Device Configuration Space endian-ness	
			egacy Interface: Device Configuration Space	
	2.6		es	
	2.0		irtqueue Reset	
			.6.1.1 Virtqueue Reset	
			2.6.1.1.1 Device Requirements: Virtqueue Reset	
			2.6.1.1.2 Driver Requirements: Virtqueue Reset	
		2	.6.1.2 Virtqueue Re-enable	
			2.6.1.2.1 Device Requirements: Virtqueue Re-enable	
			2.6.1.2.2 Driver Requirements: Virtqueue Re-enable	
	2.7	Split Virt	queues	
	2.1		priver Requirements: Virtqueues	
			egacy Interfaces: A Note on Virtqueue Layout	
			egacy Interfaces: A Note on Virtqueue Endianness	
			lessage Framing	
			.7.4.1 Device Requirements: Message Framing	
			·	
			.7.4.3 Legacy Interface: Message Framing	
			The Virtqueue Descriptor Table	
			.7.5.1 Device Requirements: The Virtqueue Descriptor Table	
			.7.5.2 Driver Requirements: The Virtqueue Descriptor Table	
		2	.7.5.3 Indirect Descriptors	
			2.7.5.3.1 Driver Requirements: Indirect Descriptors	9

	2.7.5.3.2 Device Requirements: Indirect Descriptors	
2.7.6	The Virtqueue Available Ring	
	2.7.6.1 Driver Requirements: The Virtqueue Available Ring	29
2.7.7	Used Buffer Notification Suppression	30
		30
		30
278	The state of the s	30
2.7.0		
		31
		31
2.7.10		
	2.7.10.1 Driver Requirements: Available Buffer Notification Suppression	
	2.7.10.2 Device Requirements: Available Buffer Notification Suppression	32
2.7.11		32
	2.7.13.4 Notifying The Device	34
Packed	d Virtqueues	35
2.8.1	Driver and Device Ring Wrap Counters	36
2.8.2		
	Novt Flag: Descriptor Chaining	37 27
2.8.10		
		39
2.8.13	The Virtqueue Descriptor Format	39
2.8.14	Event Suppression Structure Format	40
2.8.15	Device Requirements: The Virtqueue Descriptor Table	40
		40
		40
		40
	The state of the s	41
		41
		+ 1 41
2.8.21	0.004.4 Disable Aveilable Duffers Into The Descriptor Disa	
2.8.21		41
2.8.21	2.8.21.1.1 Driver Requirements: Updating flags	41 42
2.8.21	2.8.21.1 Driver Requirements: Updating flags	41 42 42
2.8.21	2.8.21.1.1 Driver Requirements: Updating flags	41 42 42 42
2.8.21	2.8.21.1.1 Driver Requirements: Updating flags	41 42 42 42
	2.8.21.1.1 Driver Requirements: Updating flags	41 42 42 43 43
2.8.22	2.8.21.1.1 Driver Requirements: Updating flags	41 42 42 42
2.8.22 Driver	2.8.21.1.1 Driver Requirements: Updating flags 2.8.21.2 Sending Available Buffer Notifications 2.8.21.3 Implementation Example 2.8.21.3.1 Driver Requirements: Sending Available Buffer Notifications Receiving Used Buffers From The Device Notifications	41 42 42 43 43
2.8.22 Driver Shared	2.8.21.1.1 Driver Requirements: Updating flags 2.8.21.2 Sending Available Buffer Notifications 2.8.21.3 Implementation Example 2.8.21.3.1 Driver Requirements: Sending Available Buffer Notifications Receiving Used Buffers From The Device Notifications Memory Regions	41 42 42 43 43
	2.7.8 2.7.9 2.7.10 2.7.11 2.7.12 2.7.13 2.7.14 Packed 2.8.1 2.8.3 2.8.4 2.8.5 2.8.6 2.8.7 2.8.8 2.8.9 2.8.10 2.8.11 2.8.12 2.8.13 2.8.14 2.8.15 2.8.16 2.8.17 2.8.18 2.8.17 2.8.18 2.8.19 2.8.19	2.7.7.1 Driver Requirements: Used Buffer Notification Suppression 2.7.7.2 Device Requirements: Used Buffer Notification Suppression 2.7.8.1 The Virtqueue Used Ring 2.7.8.1 Legacy Interface: The Virtqueue Used Ring 2.7.8.2 Device Requirements: The Virtqueue Used Ring 2.7.8.3 Driver Requirements: The Virtqueue Used Ring 2.7.8.3 Driver Requirements: The Virtqueue Used Ring 2.7.8.3 Driver Requirements: Suppose Suppose Suppression 2.7.10 Available Buffer Notification Suppression 2.7.10.1 Driver Requirements: Available Buffer Notification Suppression 2.7.10.2 Device Requirements: Available Buffer Notification Suppression 2.7.10.2 Device Requirements: Available Buffer Notification Suppression 2.7.13 Supplying Buffers to The Device 2.7.13 Supplying Buffers Into The Descriptor Table 2.7.13.2 Updating Buffers Into The Descriptor Table 2.7.13.3 Updating idx 2.7.13.3 Updating idx 2.7.13.4 Notifying The Device 2.7.13.4.1 Driver Requirements: Updating idx 2.7.13.4.1 Driver Requirements: Notifying The Device 2.7.13.4.1 Driver Requirements: Notifying The Device 2.7.13 Receiving Used Buffers From The Device Packed Virtqueues 2.8.1 Driver and Device Ring Wrap Counters 2.8.2 Polling of available and used descriptors 2.8.3 Write Flag 2.8.4 Element Address and Length 2.8.5 Scatter-Gather Support 2.8.6 Next Flag: Descriptor Chaining 2.8.7 Indirect Flag: Scatter-Gather Support 2.8.8 In-order use of descriptors 2.8.9 Multi-buffer requests 2.8.10 Driver and Device Event Suppression 2.8.10 Driver and Device Event Suppression 2.8.11 Driver Requirements: Virtqueue 2.8.12 Device Requirements: Virtqueue 2.8.13 The Virtqueue Descriptor Format 2.8.14 Event Suppression Structure Format 2.8.15 Device Requirements: The Virtqueue Descriptor Table 2.8.16 Driver Requirements: Scatter-Gather Support 2.8.8 Driver Requirements: Scatter-Gather Support 2.8.

	2.11	Export	ing Objec	ts 45
3	Gen	eral Ini	tializatio	n And Device Operation
				tion
				equirements: Device Initialization
				nterface: Device Initialization
	3.2			n
	·-			on of Device Configuration Changes
	3.3			
	0.0	3.3.1		equirements: Device Cleanup
4	Virti	o Trans	sport Opt	ions
				Bus
				Requirements: Virtio Over PCI Bus
				ce Discovery
			4.1.2.1	Device Requirements: PCI Device Discovery
				Driver Requirements: PCI Device Discovery
				Legacy Interfaces: A Note on PCI Device Discovery
		413		ce Layout
		1.1.0	4.1.3.1	Driver Requirements: PCI Device Layout
			4.1.3.2	
		111		ucture PCI Capabilities
		7.1.7	4.1.4.1	Driver Requirements: Virtio Structure PCI Capabilities
				Device Requirements: Virtio Structure PCI Capabilities
				Common configuration structure layout
				1.4.3.1 Device Requirements: Common configuration structure layout 52
				1.4.3.2 Driver Requirements: Common configuration structure layout 53
				Notification structure layout
				1.4.4.1 Device Requirements: Notification capability
				· · · · · · · · · · · · · · · · · · ·
				· · · · · · · · · · · · · · · · · · ·
				1.4.5.1 Device Requirements: ISR status capability
				Device-specific configuration
				1.4.6.1 Device Requirements: Device-specific configuration
			4.1.4.7	·
				1.4.7.1 Device Requirements: Shared memory capability
				Vendor data capability
				1.4.8.2 Driver Requirements: Vendor data capability
				PCI configuration access capability
				1.4.9.2 Driver Requirements: PCI configuration access capability 57 Legacy Interfaces: A Note on PCI Device Layout
		115		Non-transitional Device With Legacy Driver: A Note on PCI Device Layout . 58
		4.1.5		cific Initialization And Device Operation
			4.1.5.1	
				1.5.1.1 Virtio Device Configuration Layout Detection
				1.5.1.2 MSI-X Vector Configuration
				1.5.1.3 Virtqueue Configuration
				Available Buffer Notifications
				1.5.2.1 Driver Requirements: Available Buffer Notifications
				Used Buffer Notifications
				1.5.3.1 Device Requirements: Used Buffer Notifications
				Notification of Device Configuration Changes
				1.5.4.1 Device Requirements: Notification of Device Configuration Changes 61
				1.5.4.2 Driver Requirements: Notification of Device Configuration Changes 61
			4.1.5.5	Driver Handling Interrupts

4.2	Virtio (	Over MMIO	61
	4.2.1	MMIO Device Discovery	61
	4.2.2	MMIO Device Register Layout	62
		4.2.2.1 Device Requirements: MMIO Device Register Layout	
		4.2.2.2 Driver Requirements: MMIO Device Register Layout	
	4.2.3	MMIO-specific Initialization And Device Operation	
	7.2.0	4.2.3.1 Device Initialization	
		4.2.3.1.1 Driver Requirements: Device Initialization	
		4.2.3.2 Virtqueue Configuration	
		4.2.3.3 Available Buffer Notifications	
		4.2.3.4 Notifications From The Device	
		4.2.3.4.1 Driver Requirements: Notifications From The Device	
	4.2.4	Legacy interface	67
4.3	Virtio (	Over Channel I/O	69
	4.3.1	Basic Concepts	69
		4.3.1.1 Channel Commands for Virtio	
		4.3.1.2 Notifications	
		4.3.1.3 Device Requirements: Basic Concepts	
		4.3.1.4 Driver Requirements: Basic Concepts	70
	400		
	4.3.2	Device Initialization	70
		4.3.2.1 Setting the Virtio Revision	
		4.3.2.1.1 Device Requirements: Setting the Virtio Revision	
		4.3.2.1.2 Driver Requirements: Setting the Virtio Revision	
		4.3.2.1.3 Legacy Interfaces: A Note on Setting the Virtio Revision	
		4.3.2.2 Configuring a Virtqueue	71
		4.3.2.2.1 Device Requirements: Configuring a Virtqueue	72
		4.3.2.2.2 Legacy Interface: A Note on Configuring a Virtqueue	72
		4.3.2.3 Communicating Status Information	
		4.3.2.3.1 Driver Requirements: Communicating Status Information	
		4.3.2.3.2 Device Requirements: Communicating Status Information	72
		4.3.2.4 Handling Device Features	
		4.3.2.5 Device Configuration	
		4.3.2.6 Setting Up Indicators	
		4.3.2.6.1 Setting Up Classic Queue Indicators	
		4.3.2.6.2 Setting Up Configuration Change Indicators	
		4.3.2.6.3 Setting Up Two-Stage Queue Indicators	
		4.3.2.6.4 Legacy Interfaces: A Note on Setting Up Indicators	74
	4.3.3	Device Operation	74
		4.3.3.1 Host->Guest Notification	74
		4.3.3.1.1 Notification via Classic I/O Interrupts	74
		4.3.3.1.2 Notification via Adapter I/O Interrupts	75
		4.3.3.1.3 Legacy Interfaces: A Note on Host->Guest Notification	75
		4.3.3.2 Guest->Host Notification	75
		4.3.3.2.1 Device Requirements: Guest->Host Notification	76
		4.3.3.2.2 Driver Requirements: Guest->Host Notification	76
		·	
		4.3.3.3 Resetting Devices	76
		4.3.3.3.1 Device Requirements: Resetting Devices	76
		4.3.3.3.2 Driver Requirements: Resetting Devices	76
D	laa Too		
	ice Typ		77
5.1		ork Device	79
	5.1.1		79
		Virtqueues	79
	5.1.3		79
		5.1.3.1 Feature bit requirements	80
		5.1.3.2 Legacy Interface: Feature bits	81
	5.1.4	Device configuration layout	81

5

		5.1.4.1	Device I	Requirements: Device configuration layout					
		5.1.4.2		equirements: Device configuration layout					
		5.1.4.3		Interface: Device configuration layout					82
	5.1.5			n					83
	5.1.6								83
		5.1.6.1		Interface: Device Operation					84
		5.1.6.2		Fransmission					84
			1.6.2.1	Driver Requirements: Packet Transmission					85
			1.6.2.2	Device Requirements: Packet Transmission					86
			1.6.2.3	Packet Transmission Interrupt					86
				Jp Receive Buffers					86
			1.6.3.1	Driver Requirements: Setting Up Receive Buffers					86
			1.6.3.2	Device Requirements: Setting Up Receive Buffers					86
				ing of Incoming Packets					87
			1.6.4.1	Device Requirements: Processing of Incoming Packets					87
			1.6.4.2	Driver Requirements: Processing of Incoming Packets					88
			1.6.4.3	Hash calculation for incoming packets					88
			1.6.4.4	Hash reporting for incoming packets					91
				Virtqueue					91
			1.6.5.1	Packet Receive Filtering					92
			1.6.5.2	Setting MAC Address Filtering					93
			1.6.5.3	VLAN Filtering					94
			1.6.5.4	Gratuitous Packet Sending					94
		5.	1.6.5.5	Device operation in multiqueue mode					94
		5.	1.6.5.6	Automatic receive steering in multiqueue mode					95
		5.	1.6.5.7	Receive-side scaling (RSS)					96
		5.	1.6.5.8	Offloads State Configuration					97
		5.1.6.6	Legacy	Interface: Framing Requirements					98
5.2	Block								98
	5.2.1	Device II	D						98
	5.2.2	Virtqueu	es						98
	5.2.3	Feature	bits						98
		5.2.3.1	Legacy	Interface: Feature bits					99
	5.2.4	Device o	configurat	ion layout					99
		5.2.4.1	Legacy	Interface: Device configuration layout					100
	5.2.5	Device II	nitializatio	on					100
		5.2.5.1	Driver R	equirements: Device Initialization					
		5.2.5.2		Requirements: Device Initialization					
		5.2.5.3		Interface: Device Initialization					
	5.2.6	Device C							
		5.2.6.1	Driver R	equirements: Device Operation					102
		5.2.6.2		Requirements: Device Operation					
		5.2.6.3		Interface: Device Operation					
		5.2.6.4		Interface: Framing Requirements					
5.3	Conso	le Device							105
	5.3.1								106
	5.3.2								106
	5.3.3								106
	5.3.4			ion layout					106
	0.0	5.3.4.1	Legacy	Interface: Device configuration layout	•	•	•	•	106
	5.3.5	Device II							106
	0.0.0	5.3.5.1		Requirements: Device Initialization					107
	5.3.6								107
	0.0.0	5.3.6.1		equirements: Device Operation					107
		5.3.6.2		t Device Operation					107
			.3.6.2.1	Device Requirements: Multiport Device Operation					
			.3.6.2.2	Driver Requirements: Multiport Device Operation					
		J.	0.0.2.2	Briver requirements, muniport bevice operation				-	100

		5.3.6.3 Legacy Interface: Device Operation	
		5.3.6.4 Legacy Interface: Framing Requirements	
5.4		by Device	
	5.4.1		
	5.4.2	Virtqueues	
	5.4.3	Feature bits	
	5.4.4	Device configuration layout	
	5.4.5	Device Initialization	
	5.4.6	Device Operation	
		5.4.6.1 Driver Requirements: Device Operation	
		5.4.6.2 Device Requirements: Device Operation	09
5.5		onal Memory Balloon Device	09
	5.5.1	Device ID	
	5.5.2	Virtqueues	
	5.5.3	Feature bits	
		5.5.3.1 Driver Requirements: Feature bits	
		5.5.3.2 Device Requirements: Feature bits	
	5.5.4	Device configuration layout	10
	5.5.5	Device Initialization	
	5.5.6	Device Operation	11
		5.5.6.1 Driver Requirements: Device Operation	
		5.5.6.2 Device Requirements: Device Operation	
		5.5.6.2.1 Legacy Interface: Device Operation	
		5.5.6.3 Memory Statistics	
		5.5.6.3.1 Driver Requirements: Memory Statistics	
		5.5.6.3.2 Device Requirements: Memory Statistics	
		5.5.6.3.3 Legacy Interface: Memory Statistics	
		5.5.6.4 Memory Statistics Tags	
		5.5.6.5 Free Page Hinting	
		5.5.6.5.1 Driver Requirements: Free Page Hinting	
		5.5.6.5.2 Device Requirements: Free Page Hinting	
		5.5.6.6 Page Poison	
		5.5.6.6.1 Driver Requirements: Page Poison	
		5.5.6.6.2 Device Requirements: Page Poison	
		5.5.6.7 Free Page Reporting	
		5.5.6.7.1 Driver Requirements: Free Page Reporting	
		5.5.6.7.2 Device Requirements: Free Page Reporting	
5.6	SCSLI	Host Device	
0.0	5.6.1	Device ID	
	5.6.2	Virtqueues	
	5.6.3	Feature bits	
	5.6.4	Device configuration layout	
		5.6.4.1 Driver Requirements: Device configuration layout	
		5.6.4.2 Device Requirements: Device configuration layout	
		5.6.4.3 Legacy Interface: Device configuration layout	
	5.6.5	Device Requirements: Device Initialization	
	5.6.6	Device Operation	
		5.6.6.0.1 Legacy Interface: Device Operation	
		5.6.6.1 Device Operation: Request Queues	
		5.6.6.1.1 Device Requirements: Device Operation: Request Queues 12	
		5.6.6.1.2 Driver Requirements: Device Operation: Request Queues 12	
		5.6.6.1.3 Legacy Interface: Device Operation: Request Queues	
		5.6.6.2 Device Operation: controlq	
		5.6.6.2.1 Legacy Interface: Device Operation: controlq	
		5.6.6.3 Device Operation: eventq	
		5.6.6.3.1 Driver Requirements: Device Operation: eventg 12	25

		5.6.6.3.2 Device Requirements: Device Operation: eventq	
		5.6.6.3.3 Legacy Interface: Device Operation: eventq	
		5.6.6.4 Legacy Interface: Framing Requirements	
5.7	GPU [	Device	126
	5.7.1	Device ID	126
	5.7.2	Virtqueues	126
	5.7.3	Feature bits	126
	5.7.4	Device configuration layout	126
		5.7.4.1 Device configuration fields	
		5.7.4.2 Events	
	5.7.5	Device Requirements: Device Initialization	
	5.7.6	Device Operation	
	0.7.0	5.7.6.1 Device Operation: Create a framebuffer and configure scanout	127
		5.7.6.2 Device Operation: Update a framebuffer and scanout	
		5.7.6.3 Device Operation: Using pageflip	
		5.7.6.5 Device Requirements: Device Operation: Command lifecycle and fencing .	
		5.7.6.6 Device Operation: Configure mouse cursor	
		5.7.6.7 Device Operation: Request header	
		5.7.6.8 Device Operation: controlq	
		5.7.6.9 Device Operation: controlq (3d)	
		5.7.6.10 Device Operation: cursorq	
		VGA Compatibility	
5.8	Input D	Device	
	5.8.1	Device ID	136
	5.8.2	Virtqueues	136
	5.8.3	Feature bits	136
	5.8.4	Device configuration layout	
	5.8.5	Device Initialization	
		5.8.5.1 Driver Requirements: Device Initialization	
		5.8.5.2 Device Requirements: Device Initialization	
	5.8.6	Device Operation	
	0.0.0	5.8.6.1 Driver Requirements: Device Operation	
		5.8.6.2 Device Requirements: Device Operation	
5.9	Crypto	Device	
5.9	5.9.1	Device ID	
	5.9.1		
		Virtqueues	
	5.9.3	Feature bits	
	<b>504</b>	5.9.3.1 Feature bit requirements	
	5.9.4	Supported crypto services	
		5.9.4.1 CIPHER services	
		5.9.4.2 HASH services	
		5.9.4.3 MAC services	
		5.9.4.4 AEAD services	
	5.9.5	Device configuration layout	
		5.9.5.1 Device Requirements: Device configuration layout	
		5.9.5.2 Driver Requirements: Device configuration layout	142
	5.9.6	Device Initialization	142
		5.9.6.1 Driver Requirements: Device Initialization	142
	5.9.7	Device Operation	
		5.9.7.1 Operation Status	
		5.9.7.2 Control Virtqueue	
		5.9.7.2.1 Session operation	
		5.9.7.3 Data Virtqueue	148
		5.9.7.4 HASH Service Operation	_
		5.9.7.4.1 Driver Requirements: HASH Service Operation	
		5.9.7.4.2 Device Requirements: HASH Service Operation	
		O.O.T.T.Z DOVICE REQUIREMENTS. HAZIF OF VICE OPERATION	100

		5.9.7.5 MAC Service Operation	
		5.9.7.5.1 Driver Requirements: MAC Service Operation	152
		5.9.7.5.2 Device Requirements: MAC Service Operation	152
		5.9.7.6 Symmetric algorithms Operation	
		5.9.7.6.1 Driver Requirements: Symmetric algorithms Operation	
		5.9.7.6.2 Device Requirements: Symmetric algorithms Operation	
		5.9.7.7 AEAD Service Operation	
		5.9.7.7.1 Driver Requirements: AEAD Service Operation	
- 40		5.9.7.7.2 Device Requirements: AEAD Service Operation	
5.10		Device	
		Device ID	
		Virtqueues	
	5.10.3	Feature bits	159
	5.10.4	Device configuration layout	159
		Device Initialization	
		Device Operation	
	0	5.10.6.1 Virtqueue Flow Control	
		5.10.6.1.1 Driver Requirements: Device Operation: Virtqueue Flow Control	
		5.10.6.1.2 Device Requirements: Device Operation: Virtqueue Flow Control	
		5.10.6.2 Addressing	
		5.10.6.3 Buffer Space Management	
		5.10.6.3.1 Driver Requirements: Device Operation: Buffer Space Management	
		5.10.6.3.2 Device Requirements: Device Operation: Buffer Space Management	
		5.10.6.4 Receive and Transmit	161
		5.10.6.4.1 Driver Requirements: Device Operation: Receive and Transmit	161
		5.10.6.4.2 Device Requirements: Device Operation: Receive and Transmit	161
		5.10.6.5 Stream Sockets	
		5.10.6.6 Segpacket Sockets	
		5.10.6.6.1 Message and record boundaries	
		5.10.6.7 Device Events	
		5.10.6.7.1 Driver Requirements: Device Operation: Device Events	
E 44	Ella Cu		
5.11		rstem Device	
		Device ID	
		Virtqueues	
		Feature bits	
	5.11.4	Device configuration layout	
		5.11.4.1 Driver Requirements: Device configuration layout	163
		5.11.4.2 Device Requirements: Device configuration layout	
	5 11 5		164
	0.11.0	Device Initialization	-
		Device Initialization	164
		Device Operation	164 164
		Device Operation	164 164 164
		Device Operation	164 164 164 165
		Device Operation	164 164 164 165 165
		Device Operation	164 164 164 165 165
		Device Operation	164 164 165 165 165 165
		Device Operation	164 164 165 165 165 165 166
		Device Operation	164 164 165 165 165 165 166
		Device Operation	164 164 165 165 165 166 166
		Device Operation	164 164 165 165 165 166 166
		Device Operation	164 164 165 165 165 166 166 166
		Device Operation	164 164 165 165 165 166 166 166 166
5.12	5.11.6	Device Operation	164 164 165 165 165 166 166 166 167
5.12	5.11.6 RPMB	Device Operation .  5.11.6.1 Device Operation: Request Queues 5.11.6.2 Device Operation: High Priority Queue 5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue 5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue 5.11.6.3 Device Operation: Notification Queue 5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue 5.11.6.4 Device Operation: DAX Window 5.11.6.4.1 Device Requirements: Device Operation: DAX Window 5.11.6.4.2 Driver Requirements: Device Operation: DAX Window 5.11.6.5 Security Considerations 5.11.6.6 Live migration considerations Device	164 164 164 165 165 165 166 166 166 167 167
5.12	5.11.6 RPMB 5.12.1	Device Operation .  5.11.6.1 Device Operation: Request Queues .  5.11.6.2 Device Operation: High Priority Queue .  5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue .  5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue .  5.11.6.3 Device Operation: Notification Queue .  5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue .  5.11.6.4 Device Operation: DAX Window .  5.11.6.4.1 Device Requirements: Device Operation: DAX Window .  5.11.6.5 Security Considerations .  5.11.6.6 Live migration considerations .  Device ID .	164 164 165 165 165 166 166 166 167 167 167
5.12	5.11.6 RPMB 5.12.1 5.12.2	Device Operation .  5.11.6.1 Device Operation: Request Queues .  5.11.6.2 Device Operation: High Priority Queue .  5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue .  5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue .  5.11.6.3 Device Operation: Notification Queue .  5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue .  5.11.6.4 Device Operation: DAX Window .  5.11.6.4.1 Device Requirements: Device Operation: DAX Window .  5.11.6.4.2 Driver Requirements: Device Operation: DAX Window .  5.11.6.5 Security Considerations .  5.11.6.6 Live migration considerations .  Device .  Device ID .  Virtqueues .	164 164 165 165 165 166 166 166 167 167 167
5.12	5.11.6 RPMB 5.12.1 5.12.2 5.12.3	Device Operation .  5.11.6.1 Device Operation: Request Queues .  5.11.6.2 Device Operation: High Priority Queue .  5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue .  5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue .  5.11.6.3 Device Operation: Notification Queue .  5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue .  5.11.6.4 Device Operation: DAX Window .  5.11.6.4.1 Device Requirements: Device Operation: DAX Window .  5.11.6.4.2 Driver Requirements: Device Operation: DAX Window .  5.11.6.5 Security Considerations .  5.11.6.6 Live migration considerations .  Device .  Device ID .  Virtqueues .  Feature bits .	164 164 165 165 165 166 166 166 167 167 167 167
5.12	5.11.6 RPMB 5.12.1 5.12.2 5.12.3 5.12.4	Device Operation .  5.11.6.1 Device Operation: Request Queues .  5.11.6.2 Device Operation: High Priority Queue .  5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue .  5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue .  5.11.6.3 Device Operation: Notification Queue .  5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue .  5.11.6.4 Device Operation: DAX Window .  5.11.6.4.1 Device Requirements: Device Operation: DAX Window .  5.11.6.4.2 Driver Requirements: Device Operation: DAX Window .  5.11.6.5 Security Considerations .  5.11.6.6 Live migration considerations .  Device .  Device ID .  Virtqueues .	164 164 165 165 165 166 166 166 167 167 167 167 168 168

	5.12.6	Device Operation	
		5.12.6.1 Device Operation: Request Queue	169
		5.12.6.1.1 Device Requirements: Device Operation: Program Key	169
		5.12.6.1.2 Device Requirements: Device Operation: Get Write Counter	170
		5.12.6.1.3 Device Requirements: Device Operation: Data Write	170
		5.12.6.1.4 Device Requirements: Device Operation: Data Read	170
		5.12.6.1.5 Device Requirements: Device Operation: Result Read	
		5.12.6.2 Driver Requirements: Device Operation	
		5.12.6.3 Device Requirements: Device Operation	
5.13	IOMMI	J device	
		Device ID	
		Virtqueues	
		Feature bits	
	0.10.0	5.13.3.1 Driver Requirements: Feature bits	
		5.13.3.2 Device Requirements: Feature bits	
	5 13 /	Device configuration layout	
	J. 1J. <del>T</del>	5.13.4.1 Driver Requirements: Device configuration layout	
		5.13.4.2 Device Requirements: Device configuration layout	
	E 12 E	Device initialization	
	5.13.5		
	E 40.0	5.13.5.1 Driver Requirements: Device Initialization	
	5.13.0	Device operations	
		5.13.6.1 Driver Requirements: Device operations	
		5.13.6.2 Device Requirements: Device operations	
		5.13.6.3 ATTACH request	
		5.13.6.3.1 Driver Requirements: ATTACH request	
		5.13.6.3.2 Device Requirements: ATTACH request	
		5.13.6.4 DETACH request	
		5.13.6.4.1 Driver Requirements: DETACH request	
		5.13.6.4.2 Device Requirements: DETACH request	
		5.13.6.5 MAP request	
		5.13.6.5.1 Driver Requirements: MAP request	177
		5.13.6.5.2 Device Requirements: MAP request	178
		5.13.6.6 UNMAP request	178
		5.13.6.6.1 Driver Requirements: UNMAP request	179
		5.13.6.6.2 Device Requirements: UNMAP request	179
		5.13.6.7 PROBE request	
		5.13.6.7.1 Driver Requirements: PROBE request	
		5.13.6.7.2 Device Requirements: PROBE request	
		5.13.6.8 PROBE properties	
		5.13.6.8.1 Property RESV_MEM	
		5.13.6.9 Fault reporting	
		5.13.6.9.1 Driver Requirements: Fault reporting	
		5.13.6.9.2 Device Requirements: Fault reporting	
5 14	Sound	Device	
J. 14		Device ID	
		Virtqueues	
		Feature Bits	
		Device Configuration Layout	
		Device Initialization	
	5.14.5		
	E 14.0	5.14.5.1 Driver Requirements: Device Initialization	
	5.14.6	Device Operation	
		5.14.6.1 Item Information Request	
		5.14.6.2 Driver Requirements: Item Information Request	
		5.14.6.3 Relationships with the High Definition Audio Specification	
		5.14.6.4 Jack Control Messages	
		5.14.6.4.1 VIRTIO_SND_R_JACK_INFO	
		5.14.6.4.2 VIRTIO_SND_R_JACK_REMAP	186

		5.14.6.5 Jack Notifications	
		5.14.6.6 PCM Control Messages	
		5.14.6.6.1 PCM Command Lifecycle	37
		5.14.6.6.2 VIRTIO_SND_R_PCM_INFO	
		5.14.6.6.3 VIRTIO_SND_R_PCM_SET_PARAMS	39
		5.14.6.6.4 VIRTIO_SND_R_PCM_PREPARE	<b>)</b> 0
		5.14.6.6.5 VIRTIO_SND_R_PCM_RELEASE	<b>9</b> 0
		5.14.6.6.6 VIRTIO_SND_R_PCM_START	<b>3</b> 0
		5.14.6.6.7 VIRTIO_SND_R_PCM_STOP	<b>9</b> 0
		5.14.6.7 PCM Notifications	
		5.14.6.8 PCM I/O Messages	
		5.14.6.8.1 Output Stream	
		5.14.6.8.2 Input Stream	<u>}</u> 2
		5.14.6.9 Channel Map Control Messages	
		5.14.6.9.1 VIRTIO_SND_R_CHMAP_INFO	
5.15	Memo	y Device	
		Device ID	
	5 15 2	Virtqueues	14
		Feature bits	
		Device configuration layout	
	0.10.4	5.15.4.1 Driver Requirements: Device configuration layout	
		5.15.4.2 Device Requirements: Device configuration layout	
	5 15 5	Device Initialization	)5 )5
	5.15.5	5.15.5.1 Driver Requirements: Device Initialization	
		5.15.5.2 Device Requirements: Device Initialization	
	5 15 6	Device Operation	
	5.15.0	5.15.6.1 Driver Requirements: Device Operation	
		5.15.6.2 Device Requirements: Device Operation	
		5.15.6.3 PLUG request	
		5.15.6.3.1 Driver Requirements: PLUG request	
		5.15.6.3.2 Device Requirements: PLUG request	
		5.15.6.4 UNPLUG request	
		5.15.6.4.1 Driver Requirements: UNPLUG request	
		5.15.6.4.2 Device Requirements: UNPLUG request	
		5.15.6.5 UNPLUG ALL request	
		5.15.6.5.1 Driver Requirements: UNPLUG request	
		5.15.6.5.2 Device Requirements: UNPLUG request	
		5.15.6.6 STATE request	
		5.15.6.6.1 Driver Requirements: STATE request	
		5.15.6.6.2 Device Requirements: STATE request	
5.16		apter Device	
		Device ID	
		Virtqueues	
		Feature bits	
		Device configuration layout	
		Device Initialization	
	5.16.6	Device Operation	)()
		5.16.6.1 Device Operation: Request Queue	)()
		5.16.6.2 Device Operation: Operation Status	)1
		5.16.6.3 Driver Requirements: Device Operation	)1
		5.16.6.4 Device Requirements: Device Operation	)2
5.17	SCMI	Device	)2
		Device ID	
		Virtqueues	)2
		Feature bits	)2
		5.17.3.1 Device Requirements: Feature bits	)3
	5.17.4	Device configuration layout	)3

		7.5 Device Initialization	
	5.1	7.6 Device Operation	
		5.17.6.1 cmdq Operation	
		5.17.6.1.1 Device Requirements: cmdq Operation	
		5.17.6.1.2 Driver Requirements: cmdq Operation	204
		5.17.6.2 Setting Up eventq Buffers	204
		5.17.6.2.1 Driver Requirements: Setting Up eventq Buffers	204
		5.17.6.3 eventq Operation	
		5.17.6.3.1 Device Requirements: eventq Operation	
		5.17.6.4 Shared Memory Operation	
	E 40 OF	5.17.6.4.1 Device Requirements: Shared Memory Operation	
		PIO Device	
		8.2 Virtqueues	
		8.3 Feature bits	
		8.4 Device configuration layout	
		8.5 Device Initialization	
		8.6 Device Operation: requestq	
	0.1	5.18.6.1 requestq Operation: Get Line Names	
		5.18.6.2 requestq Operation: Get Direction	208
		5.18.6.3 requestq Operation: Set Direction	208
		5.18.6.4 requestq Operation: Get Value	
		5.18.6.5 requestq Operation: Set Value	
		5.18.6.6 requestq Operation: Set IRQ Type	
		5.18.6.7 requestq Operation: Message Flow	
		5.18.6.8 Driver Requirements: requestq Operation	
		5.18.6.9 Device Requirements: requestq Operation	
	5.1	8.7 Device Operation: eventq	
		5.18.7.1 eventq Operation: Message Flow	
		5.18.7.2 Driver Requirements: eventq Operation	212
		5.18.7.3 Device Requirements: eventq Operation	
		MEM Device	
		9.1 Device ID	
		9.2 Virtqueues	
		9.3 Feature bits	
		9.4 Device configuration layout	
	5.1	9.5 Device Initialization	
		5.19.5.1 Device Requirements: Device Initialization	
		5.19.5.2 Driver Requirements: Device Initialization	
		9.6 Driver Operations	
	5.1	9.7 Device Operations	
		5.19.7.1 Device Requirements: Device Operation: Virtqueue flush	
		5.19.7.2 Device Operations	
	E 1	5.19.7.3 Device Requirements: Device Operation: Virtqueue return	
		9.8 Possible security implications	
	J. I	5.19.9.1 With SHARED mapping	
		5.19.9.2 With PRIVATE mapping	
		5.19.9.3 Workload specific mapping	
		5.19.9.4 Prevent cache eviction	
		C. C	<u> </u>
6	Reserve	ed Feature Bits	215
		ver Requirements: Reserved Feature Bits	
		vice Requirements: Reserved Feature Bits	
	6.3 Le	gacy Interface: Reserved Feature Bits	216
_			
7	Confort	mance	218

7.1		
7.2	Clause 1: Driver Conformance	218
	7.2.1 Clause 2: PCI Driver Conformance	219
	7.2.2 Clause 3: MMIO Driver Conformance	219
	7.2.3 Clause 4: Channel I/O Driver Conformance	219
	7.2.4 Clause 5: Network Driver Conformance	220
	7.2.5 Clause 6: Block Driver Conformance	220
	7.2.6 Clause 7: Console Driver Conformance	220
	7.2.7 Clause 8: Entropy Driver Conformance	220
	7.2.8 Clause 9: Traditional Memory Balloon Driver Conformance	220
	7.2.9 Clause 10: SCSI Host Driver Conformance	
	7.2.10 Clause 11: Input Driver Conformance	
	7.2.11 Clause 12: Crypto Driver Conformance	
	7.2.12 Clause 13: Socket Driver Conformance	
	7.2.13 Clause 14: File System Driver Conformance	
	7.2.14 Clause 15: RPMB Driver Conformance	
	7.2.15 Clause 16: IOMMU Driver Conformance	
	7.2.16 Clause 17: Sound Driver Conformance	
	7.2.17 Clause 18: Memory Driver Conformance	
	7.2.17 Clause 10: Memory Driver Conformance	
	7.2.19 Clause 20: SCMI Driver Conformance	
	7.2.19 Clause 20. SCMI Driver Conformance	
	7.2.20 Clause 21: GFIO Driver Conformance	
7.3	Clause 23: Device Conformance	
1.3		
	7.3.3 Clause 26: Channel I/O Device Conformance	
	7.3.4 Clause 27: Network Device Conformance	
	7.3.5 Clause 28: Block Device Conformance	
	7.3.6 Clause 29: Console Device Conformance	
	7.3.7 Clause 30: Entropy Device Conformance	
	7.3.8 Clause 31: Traditional Memory Balloon Device Conformance	
	7.3.9 Clause 32: SCSI Host Device Conformance	
	7.3.10 Clause 33: GPU Device Conformance	
	7.3.11 Clause 34: Input Device Conformance	
	7.3.12 Clause 35: Crypto Device Conformance	
	7.3.13 Clause 36: Socket Device Conformance	
	7.3.14 Clause 37: File System Device Conformance	
	7.3.15 Clause 38: RPMB Device Conformance	
	7.3.16 Clause 39: IOMMU Device Conformance	
	7.3.17 Clause 40: Sound Device Conformance	
	7.3.18 Clause 41: Memory Device Conformance	
	7.3.19 Clause 42: I2C Adapter Device Conformance	
	7.3.20 Clause 43: SCMI Device Conformance	
	7.3.21 Clause 44: GPIO Device Conformance	
	7.3.22 Clause 45: PMEM Device Conformance	
7.4	Clause 46: Legacy Interface: Transitional Device and Transitional Driver Conformance	227
virti	o_queue.h	229
Crea	ating New Device Types	231
	How Many Virtqueues?	
	What Device Configuration Space Layout?	
	What Device Number?	
	How many MSI-X vectors? (for PCI)	
	Device Improvements	231

Α

В

С	Acknowledgements			 			-												-		. :	23	2
D	Revision History	 		 																	. :	23	7

# 1 Introduction

This document describes the specifications of the "virtio" family of devices. These devices are found in virtual environments, yet by design they look like physical devices to the guest within the virtual machine - and this document treats them as such. This similarity allows the guest to use standard drivers and discovery mechanisms.

The purpose of virtio and this specification is that virtual environments and guests should have a straightforward, efficient, standard and extensible mechanism for virtual devices, rather than boutique per-environment or per-OS mechanisms.

**Straightforward:** Virtio devices use normal bus mechanisms of interrupts and DMA which should be familiar to any device driver author. There is no exotic page-flipping or COW mechanism: it's just a normal device.<sup>1</sup>

**Efficient:** Virtio devices consist of rings of descriptors for both input and output, which are neatly laid out to avoid cache effects from both driver and device writing to the same cache lines.

**Standard:** Virtio makes no assumptions about the environment in which it operates, beyond supporting the bus to which device is attached. In this specification, virtio devices are implemented over MMIO, Channel I/O and PCI bus transports <sup>2</sup>, earlier drafts have been implemented on other buses not included here.

**Extensible:** Virtio devices contain feature bits which are acknowledged by the guest operating system during device setup. This allows forwards and backwards compatibility: the device offers all the features it knows about, and the driver acknowledges those it understands and wishes to use.

# 1.1 Normative References

[RFC2119]	Bradner S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14,
	Didutie O., INEV WOLUS IOLUSE IILINI OS IO IIIUICAIE NEUUITEITEITI LEVEIS , DOI 17.

RFC 2119, March 1997.

http://www.ietf.org/rfc/rfc2119.txt

[RFC4122] Leach, P., Mealling, M., and R. Salz, "A Universally Unique IDentifier (UUID) URN

Namespace", RFC 4122, DOI 10.17487/RFC4122, July 2005.

http://www.ietf.org/rfc/rfc4122.txt

[S390 PoP] z/Architecture Principles of Operation, IBM Publication SA22-7832,

http://publibfi.boulder.ibm.com/epubs/pdf/dz9zr009.pdf, and any future revisions

[S390 Common I/O] ESA/390 Common I/O-Device and Self-Description, IBM Publication SA22-7204,

http://publibfp.dhe.ibm.com/cgi-bin/bookmgr/BOOKS/dz9ar501/CCONTENTS,

and any future revisions

[PCI] Conventional PCI Specifications,

http://www.pcisig.com/specifications/conventional/, PCI-SIG

[PCIe] PCI Express Specifications

http://www.pcisig.com/specifications/pciexpress/, PCI-SIG

<sup>&</sup>lt;sup>1</sup>This lack of page-sharing implies that the implementation of the device (e.g. the hypervisor or host) needs full access to the guest memory. Communication with untrusted parties (i.e. inter-guest communication) requires copying.

<sup>&</sup>lt;sup>2</sup>The Linux implementation further separates the virtio transport code from the specific virtio drivers: these drivers are shared between different transports.

[IEEE 802] IEEE Standard for Local and Metropolitan Area Networks: Overview and Architec-

ture.

http://www.ieee802.org/, IEEE

[SAM] SCSI Architectural Model,

http://www.t10.org/cgi-bin/ac.pl?t=f&f=sam4r05.pdf

[SCSI MMC] SCSI Multimedia Commands,

http://www.t10.org/cgi-bin/ac.pl?t=f&f=mmc6r00.pdf

**[FUSE]** Linux FUSE interface,

https://git.kernel.org/pub/scm/linux/kernel/git/torvalds/linux.git/tree/include/uapi/

linux/fuse.h

**[eMMC]** eMMC Electrical Standard (5.1), JESD84-B51,

http://www.jedec.org/sites/default/files/docs/JESD84-B51.pdf

[HDA] High Definition Audio Specification,

https://www.intel.com/content/dam/www/public/us/en/documents/

product-specifications/high-definition-audio-specification.pdf

[12C] I2C-bus specification and user manual,

https://www.nxp.com/docs/en/user-guide/UM10204.pdf

[SCMI] Arm System Control and Management Interface, DEN0056,

https://developer.arm.com/docs/den0056/c, version C and any future revisions

# 1.2 Non-Normative References

[Virtio PCI Draft] Virtio PCI Draft Specification

http://ozlabs.org/~rusty/virtio-spec/virtio-0.9.5.pdf

# 1.3 Terminology

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC2119].

## 1.3.1 Legacy Interface: Terminology

Specification drafts preceding version 1.0 of this specification (e.g. see [Virtio PCI Draft]) defined a similar, but different interface between the driver and the device. Since these are widely deployed, this specification accommodates OPTIONAL features to simplify transition from these earlier draft interfaces.

Specifically devices and drivers MAY support:

Legacy Interface is an interface specified by an earlier draft of this specification (before 1.0)

**Legacy Device** is a device implemented before this specification was released, and implementing a legacy interface on the host side

**Legacy Driver** is a driver implemented before this specification was released, and implementing a legacy interface on the guest side

Legacy devices and legacy drivers are not compliant with this specification.

To simplify transition from these earlier draft interfaces, a device MAY implement:

**Transitional Device** a device supporting both drivers conforming to this specification, and allowing legacy drivers.

Similarly, a driver MAY implement:

Transitional Driver a driver supporting both devices conforming to this specification, and legacy devices.

**Note:** Legacy interfaces are not required; ie. don't implement them unless you have a need for backwards compatibility!

Devices or drivers with no legacy compatibility are referred to as non-transitional devices and drivers, respectively.

# 1.3.2 Transition from earlier specification drafts

For devices and drivers already implementing the legacy interface, some changes will have to be made to support this specification.

In this case, it might be beneficial for the reader to focus on sections tagged "Legacy Interface" in the section title. These highlight the changes made since the earlier drafts.

# 1.4 Structure Specifications

Many device and driver in-memory structure layouts are documented using the C struct syntax. All structures are assumed to be without additional padding. To stress this, cases where common C compilers are known to insert extra padding within structures are tagged using the GNU C \_\_attribute\_\_((packed)) syntax.

For the integer data types used in the structure definitions, the following conventions are used:

u8, u16, u32, u64 An unsigned integer of the specified length in bits.

le16, le32, le64 An unsigned integer of the specified length in bits, in little-endian byte order.

be16, be32, be64 An unsigned integer of the specified length in bits, in big-endian byte order.

Some of the fields to be defined in this specification don't start or don't end on a byte boundary. Such fields are called bit-fields. A set of bit-fields is always a sub-division of an integer typed field.

Bit-fields within integer fields are always listed in order, from the least significant to the most significant bit. The bit-fields are considered unsigned integers of the specified width with the next in significance relationship of the bits preserved.

For example:

documents the value A stored in the low 15 bit of x and the value B stored in the high bit of x, the 16-bit integer x in turn stored using the big-endian byte order at the beginning of the structure S, and being followed immediately by an unsigned integer y stored in big-endian byte order at an offset of 2 bytes (16 bits) from the beginning of the structure.

Note that this notation somewhat resembles the C bitfield syntax but should not be naively converted to a bitfield notation for portable code: it matches the way bitfields are packed by C compilers on little-endian architectures but not the way bitfields are packed by C compilers on big-endian architectures.

Assuming that CPU\_TO\_BE16 converts a 16-bit integer from a native CPU to the big-endian byte order, the following is the equivalent portable C code to generate a value to be stored into *x*:

```
CPU_TO_BE16(B << 15 | A)
```

# 1.5 Constant Specifications

In many cases, numeric values used in the interface between the device and the driver are documented using the C #define and /\* \*/ comment syntax. Multiple related values are grouped together with a common name as a prefix, using \_ as a separator. Using \_XXX as a suffix refers to all values in a group. For example:

```
/* Field Fld value A description */
#define VIRTIO_FLD_A (1 << 0)
/* Field Fld value B description */
#define VIRTIO_FLD_B (1 << 1)
```

documents two numeric values for a field *Fld*, with *Fld* having value 1 referring to *A* and *Fld* having value 2 referring to *B*. Note that << refers to the shift-left operation.

Further, in this case VIRTIO\_FLD\_A and VIRTIO\_FLD\_B refer to values 1 and 2 of Fld respectively. Further, VIRTIO\_FLD\_XXX refers to either VIRTIO\_FLD\_A or VIRTIO\_FLD\_B.

# 2 Basic Facilities of a Virtio Device

A virtio device is discovered and identified by a bus-specific method (see the bus specific sections: 4.1 Virtio Over PCI Bus, 4.2 Virtio Over MMIO and 4.3 Virtio Over Channel I/O). Each device consists of the following parts:

- · Device status field
- · Feature bits
- Notifications
- Device Configuration space
- · One or more virtqueues

# 2.1 Device Status Field

During device initialization by a driver, the driver follows the sequence of steps specified in 3.1.

The *device status* field provides a simple low-level indication of the completed steps of this sequence. It's most useful to imagine it hooked up to traffic lights on the console indicating the status of each device. The following bits are defined (listed below in the order in which they would be typically set):

**ACKNOWLEDGE (1)** Indicates that the guest OS has found the device and recognized it as a valid virtio device.

**DRIVER (2)** Indicates that the guest OS knows how to drive the device.

**Note:** There could be a significant (or infinite) delay before setting this bit. For example, under Linux, drivers can be loadable modules.

**FAILED (128)** Indicates that something went wrong in the guest, and it has given up on the device. This could be an internal error, or the driver didn't like the device for some reason, or even a fatal error during device operation.

**FEATURES\_OK (8)** Indicates that the driver has acknowledged all the features it understands, and feature negotiation is complete.

**DRIVER OK (4)** Indicates that the driver is set up and ready to drive the device.

**DEVICE\_NEEDS\_RESET (64)** Indicates that the device has experienced an error from which it can't recover.

The device status field starts out as 0, and is reinitialized to 0 by the device during reset.

# 2.1.1 Driver Requirements: Device Status Field

The driver MUST update *device status*, setting bits to indicate the completed steps of the driver initialization sequence specified in 3.1. The driver MUST NOT clear a *device status* bit. If the driver sets the FAILED bit, the driver MUST later reset the device before attempting to re-initialize.

The driver SHOULD NOT rely on completion of operations of a device if DEVICE NEEDS RESET is set.

**Note:** For example, the driver can't assume requests in flight will be completed if DEVICE\_NEEDS\_RESET is set, nor can it assume that they have not been completed. A good implementation will try to recover by issuing a reset.

# 2.1.2 Device Requirements: Device Status Field

The device MUST NOT consume buffers or send any used buffer notifications to the driver before DRIVER\_-

The device SHOULD set DEVICE\_NEEDS\_RESET when it enters an error state that a reset is needed. If DRIVER\_OK is set, after it sets DEVICE\_NEEDS\_RESET, the device MUST send a device configuration change notification to the driver.

# 2.2 Feature Bits

Each virtio device offers all the features it understands. During device initialization, the driver reads this and tells the device the subset that it accepts. The only way to renegotiate is to reset the device.

This allows for forwards and backwards compatibility: if the device is enhanced with a new feature bit, older drivers will not write that feature bit back to the device. Similarly, if a driver is enhanced with a feature that the device doesn't support, it see the new feature is not offered.

Feature bits are allocated as follows:

0 to 23, and 50 to 127 Feature bits for the specific device type

24 to 40 Feature bits reserved for extensions to the queue and feature negotiation mechanisms

**41 to 49, and 128 and above** Feature bits reserved for future extensions.

**Note:** For example, feature bit 0 for a network device (i.e. Device ID 1) indicates that the device supports checksumming of packets.

In particular, new fields in the device configuration space are indicated by offering a new feature bit.

# 2.2.1 Driver Requirements: Feature Bits

The driver MUST NOT accept a feature which the device did not offer, and MUST NOT accept a feature which requires another feature which was not accepted.

The driver SHOULD go into backwards compatibility mode if the device does not offer a feature it understands, otherwise MUST set the FAILED *device status* bit and cease initialization.

# 2.2.2 Device Requirements: Feature Bits

The device MUST NOT offer a feature which requires another feature which was not offered. The device SHOULD accept any valid subset of features the driver accepts, otherwise it MUST fail to set the FEATURES\_OK *device status* bit when the driver writes it.

If a device has successfully negotiated a set of features at least once (by accepting the FEATURES\_OK device status bit during device initialization), then it SHOULD NOT fail re-negotiation of the same set of features after a device or system reset. Failure to do so would interfere with resuming from suspend and error recovery.

# 2.2.3 Legacy Interface: A Note on Feature Bits

Transitional Drivers MUST detect Legacy Devices by detecting that the feature bit VIRTIO\_F\_VERSION\_1 is not offered. Transitional devices MUST detect Legacy drivers by detecting that VIRTIO\_F\_VERSION\_1 has not been acknowledged by the driver.

In this case device is used through the legacy interface.

Legacy interface support is OPTIONAL. Thus, both transitional and non-transitional devices and drivers are compliant with this specification.

Requirements pertaining to transitional devices and drivers is contained in sections named 'Legacy Interface' like this one.

When device is used through the legacy interface, transitional devices and transitional drivers MUST operate according to the requirements documented within these legacy interface sections. Specification text within these sections generally does not apply to non-transitional devices.

# 2.3 Notifications

The notion of sending a notification (driver to device or device to driver) plays an important role in this specification. The modus operandi of the notifications is transport specific.

There are three types of notifications:

- · configuration change notification
- · available buffer notification
- · used buffer notification.

Configuration change notifications and used buffer notifications are sent by the device, the recipient is the driver. A configuration change notification indicates that the device configuration space has changed; a used buffer notification indicates that a buffer may have been made used on the virtqueue designated by the notification.

Available buffer notifications are sent by the driver, the recipient is the device. This type of notification indicates that a buffer may have been made available on the virtqueue designated by the notification.

The semantics, the transport-specific implementations, and other important aspects of the different notifications are specified in detail in the following chapters.

Most transports implement notifications sent by the device to the driver using interrupts. Therefore, in previous versions of this specification, these notifications were often called interrupts. Some names defined in this specification still retain this interrupt terminology. Occasionally, the term event is used to refer to a notification or a receipt of a notification.

# 2.4 Device Reset

The driver may want to initiate a device reset at various times; notably, it is required to do so during device initialization and device cleanup.

The mechanism used by the driver to initiate the reset is transport specific.

## 2.4.1 Device Requirements: Device Reset

A device MUST reinitialize device status to 0 after receiving a reset.

A device MUST NOT send notifications or interact with the queues after indicating completion of the reset by reinitializing *device status* to 0, until the driver re-initializes the device.

#### 2.4.2 Driver Requirements: Device Reset

The driver SHOULD consider a driver-initiated reset complete when it reads device status as 0.

# 2.5 Device Configuration Space

Device configuration space is generally used for rarely-changing or initialization-time parameters. Where configuration fields are optional, their existence is indicated by feature bits: Future versions of this specification will likely extend the device configuration space by adding extra fields at the tail.

Note: The device configuration space uses the little-endian format for multi-byte fields.

Each transport also provides a generation count for the device configuration space, which will change whenever there is a possibility that two accesses to the device configuration space can see different versions of that space.

# 2.5.1 Driver Requirements: Device Configuration Space

Drivers MUST NOT assume reads from fields greater than 32 bits wide are atomic, nor are reads from multiple fields: drivers SHOULD read device configuration space fields like so:

```
u32 before, after;
do {
         before = get_config_generation(device);
         // read config entry/entries.
         after = get_config_generation(device);
} while (after != before);
```

For optional configuration space fields, the driver MUST check that the corresponding feature is offered before accessing that part of the configuration space.

**Note:** See section 3.1 for details on feature negotiation.

Drivers MUST NOT limit structure size and device configuration space size. Instead, drivers SHOULD only check that device configuration space is *large enough* to contain the fields necessary for device operation.

**Note:** For example, if the specification states that device configuration space 'includes a single 8-bit field' drivers should understand this to mean that the device configuration space might also include an arbitrary amount of tail padding, and accept any device configuration space size equal to or greater than the specified 8-bit size.

# 2.5.2 Device Requirements: Device Configuration Space

The device MUST allow reading of any device-specific configuration field before FEATURES\_OK is set by the driver. This includes fields which are conditional on feature bits, as long as those feature bits are offered by the device.

# 2.5.3 Legacy Interface: A Note on Device Configuration Space endian-ness

Note that for legacy interfaces, device configuration space is generally the guest's native endian, rather than PCI's little-endian. The correct endian-ness is documented for each device.

# 2.5.4 Legacy Interface: Device Configuration Space

Legacy devices did not have a configuration generation field, thus are susceptible to race conditions if configuration is updated. This affects the block *capacity* (see 5.2.4) and network *mac* (see 5.1.4) fields; when using the legacy interface, drivers SHOULD read these fields multiple times until two reads generate a consistent result.

# 2.6 Virtqueues

The mechanism for bulk data transport on virtio devices is pretentiously called a virtqueue. Each device can have zero or more virtqueues<sup>1</sup>.

Driver makes requests available to device by adding an available buffer to the queue, i.e., adding a buffer describing the request to a virtqueue, and optionally triggering a driver event, i.e., sending an available buffer notification to the device.

Device executes the requests and - when complete - adds a used buffer to the queue, i.e., lets the driver know by marking the buffer as used. Device can then trigger a device event, i.e., send a used buffer notification to the driver.

<sup>&</sup>lt;sup>1</sup>For example, the simplest network device has one virtqueue for transmit and one for receive.

Device reports the number of bytes it has written to memory for each buffer it uses. This is referred to as "used length".

Device is not generally required to use buffers in the same order in which they have been made available by the driver.

Some devices always use descriptors in the same order in which they have been made available. These devices can offer the VIRTIO\_F\_IN\_ORDER feature. If negotiated, this knowledge might allow optimizations or simplify driver and/or device code.

Each virtqueue can consist of up to 3 parts:

- Descriptor Area used for describing buffers
- · Driver Area extra data supplied by driver to the device
- Device Area extra data supplied by device to driver

**Note:** Note that previous versions of this spec used different names for these parts (following 2.7):

- · Descriptor Table for the Descriptor Area
- Available Ring for the Driver Area
- · Used Ring for the Device Area

Two formats are supported: Split Virtqueues (see 2.7 Split Virtqueues) and Packed Virtqueues (see 2.8 Packed Virtqueues).

Every driver and device supports either the Packed or the Split Virtqueue format, or both.

## 2.6.1 Virtqueue Reset

When VIRTIO\_F\_RING\_RESET is negotiated, the driver can reset a virtqueue individually. The way to reset the virtqueue is transport specific.

Virtqueue reset is divided into two parts. The driver first resets a queue and can afterwards optionally reenable it.

#### 2.6.1.1 Virtqueue Reset

#### 2.6.1.1.1 Device Requirements: Virtqueue Reset

After a queue has been reset by the driver, the device MUST NOT execute any requests from that virtqueue, or notify the driver for it.

The device MUST reset any state of a virtqueue to the default state, including the available state and the used state.

#### 2.6.1.1.2 Driver Requirements: Virtqueue Reset

After the driver tells the device to reset a queue, the driver MUST verify that the queue has actually been reset.

After the queue has been successfully reset, the driver MAY release any resource associated with that virtqueue.

#### 2.6.1.2 Virtgueue Re-enable

This process is the same as the initialization process of a single queue during the initialization of the entire device.

## 2.6.1.2.1 Device Requirements: Virtqueue Re-enable

The device MUST observe any queue configuration that may have been changed by the driver, like the maximum queue size.

#### 2.6.1.2.2 Driver Requirements: Virtqueue Re-enable

When re-enabling a queue, the driver MUST configure the queue resources as during initial virtqueue discovery, but optionally with different parameters.

# 2.7 Split Virtqueues

The split virtqueue format was the only format supported by the version 1.0 (and earlier) of this standard.

The split virtqueue format separates the virtqueue into several parts, where each part is write-able by either the driver or the device, but not both. Multiple parts and/or locations within a part need to be updated when making a buffer available and when marking it as used.

Each queue has a 16-bit queue size parameter, which sets the number of entries and implies the total size of the queue.

Each virtqueue consists of three parts:

- · Descriptor Table occupies the Descriptor Area
- Available Ring occupies the Driver Area
- · Used Ring occupies the Device Area

where each part is physically-contiguous in guest memory, and has different alignment requirements.

The memory alignment and size requirements, in bytes, of each part of the virtqueue are summarized in the following table:

Virtqueue Part	Alignment	Size							
Descriptor Table	16	16*(Queue Size)							
Available Ring	2	6 + 2*(Queue Size)							
Used Ring	4	6 + 8*(Queue Size)							

The Alignment column gives the minimum alignment for each part of the virtqueue.

The Size column gives the total number of bytes for each part of the virtqueue.

Queue Size corresponds to the maximum number of buffers in the virtqueue<sup>2</sup>. Queue Size value is always a power of 2. The maximum Queue Size value is 32768. This value is specified in a bus-specific way.

When the driver wants to send a buffer to the device, it fills in a slot in the descriptor table (or chains several together), and writes the descriptor index into the available ring. It then notifies the device. When the device has finished a buffer, it writes the descriptor index into the used ring, and sends a used buffer notification.

# 2.7.1 Driver Requirements: Virtqueues

The driver MUST ensure that the physical address of the first byte of each virtqueue part is a multiple of the specified alignment value in the above table.

# 2.7.2 Legacy Interfaces: A Note on Virtqueue Layout

For Legacy Interfaces, several additional restrictions are placed on the virtqueue layout:

Each virtqueue occupies two or more physically-contiguous pages (usually defined as 4096 bytes, but depending on the transport; henceforth referred to as Queue Align) and consists of three parts:

The bus-specific Queue Size field controls the total number of bytes for the virtqueue. When using the legacy interface, the transitional driver MUST retrieve the Queue Size field from the device and MUST allocate the

<sup>&</sup>lt;sup>2</sup>For example, if Queue Size is 4 then at most 4 buffers can be queued at any given time.

total number of bytes for the virtqueue according to the following formula (Queue Align given in qalign and Queue Size given in qsz):

This wastes some space with padding. When using the legacy interface, both transitional devices and drivers MUST use the following virtgueue layout structure to locate elements of the virtgueue:

```
struct virtq {
    // The actual descriptors (16 bytes each)
    struct virtq_desc desc[ Queue Size ];

    // A ring of available descriptor heads with free-running index.
    struct virtq_avail avail;

    // Padding to the next Queue Align boundary.
    u8 pad[ Padding ];

    // A ring of used descriptor heads with free-running index.
    struct virtq_used used;
};
```

# 2.7.3 Legacy Interfaces: A Note on Virtqueue Endianness

Note that when using the legacy interface, transitional devices and drivers MUST use the native endian of the guest as the endian of fields and in the virtqueue. This is opposed to little-endian for non-legacy interface as specified by this standard. It is assumed that the host is already aware of the guest endian.

# 2.7.4 Message Framing

The framing of messages with descriptors is independent of the contents of the buffers. For example, a network transmit buffer consists of a 12 byte header followed by the network packet. This could be most simply placed in the descriptor table as a 12 byte output descriptor followed by a 1514 byte output descriptor, but it could also consist of a single 1526 byte output descriptor in the case where the header and packet are adjacent, or even three or more descriptors (possibly with loss of efficiency in that case).

Note that, some device implementations have large-but-reasonable restrictions on total descriptor size (such as based on IOV\_MAX in the host OS). This has not been a problem in practice: little sympathy will be given to drivers which create unreasonably-sized descriptors such as by dividing a network packet into 1500 single-byte descriptors!

#### 2.7.4.1 Device Requirements: Message Framing

The device MUST NOT make assumptions about the particular arrangement of descriptors. The device MAY have a reasonable limit of descriptors it will allow in a chain.

#### 2.7.4.2 Driver Requirements: Message Framing

The driver MUST place any device-writable descriptor elements after any device-readable descriptor elements.

The driver SHOULD NOT use an excessive number of descriptors to describe a buffer.

#### 2.7.4.3 Legacy Interface: Message Framing

Regrettably, initial driver implementations used simple layouts, and devices came to rely on it, despite this specification wording. In addition, the specification for virtio\_blk SCSI commands required intuiting field lengths from frame boundaries (see 5.2.6.3 Legacy Interface: Device Operation)

Thus when using the legacy interface, the VIRTIO\_F\_ANY\_LAYOUT feature indicates to both the device and the driver that no assumptions were made about framing. Requirements for transitional drivers when this is not negotiated are included in each device section.

# 2.7.5 The Virtqueue Descriptor Table

The descriptor table refers to the buffers the driver is using for the device. *addr* is a physical address, and the buffers can be chained via *next*. Each descriptor describes a buffer which is read-only for the device ("device-readable") or write-only for the device ("device-writable"), but a chain of descriptors can contain both device-readable and device-writable buffers.

The actual contents of the memory offered to the device depends on the device type. Most common is to begin the data with a header (containing little-endian fields) for the device to read, and postfix it with a status tailer for the device to write.

```
struct virtq_desc {
       /* Address (guest-physical). */
       le64 addr;
       /* Length. */
       le32 len;
/* This marks a buffer as continuing via the next field. */
#define VIRTQ DESC F NEXT 1
/* This marks a buffer as device write-only (otherwise device read-only). */
#define VIRTQ DESC F WRITE 2
/* This means the buffer contains a list of buffer descriptors. */
#define VIRTQ DESC F INDIRECT 4
       /* The flags as indicated above. */
       le16 flags;
       /* Next field if flags & NEXT */
       le16 next;
};
```

The number of descriptors in the table is defined by the queue size for this virtqueue: this is the maximum possible descriptor chain length.

If VIRTIO\_F\_IN\_ORDER has been negotiated, driver uses descriptors in ring order: starting from offset 0 in the table, and wrapping around at the end of the table.

**Note:** The legacy [Virtio PCI Draft] referred to this structure as vring\_desc, and the constants as VRING\_-DESC\_F\_NEXT, etc, but the layout and values were identical.

#### 2.7.5.1 Device Requirements: The Virtqueue Descriptor Table

A device MUST NOT write to a device-readable buffer, and a device SHOULD NOT read a device-writable buffer (it MAY do so for debugging or diagnostic purposes). A device MUST NOT write to any descriptor table entry.

#### 2.7.5.2 Driver Requirements: The Virtqueue Descriptor Table

Drivers MUST NOT add a descriptor chain longer than  $2^{32}$  bytes in total; this implies that loops in the descriptor chain are forbidden!

If VIRTIO\_F\_IN\_ORDER has been negotiated, and when making a descriptor with VRING\_DESC\_F\_NEXT set in *flags* at offset x in the table available to the device, driver MUST set next to 0 for the last descriptor in the table (where  $x = queue\_size - 1$ ) and to x + 1 for the rest of the descriptors.

#### 2.7.5.3 Indirect Descriptors

Some devices benefit by concurrently dispatching a large number of large requests. The VIRTIO\_F\_INDI-RECT\_DESC feature allows this (see A virtio\_queue.h). To increase ring capacity the driver can store a table of indirect descriptors anywhere in memory, and insert a descriptor in main virtqueue (with flags&VIRTQ\_-DESC\_F\_INDIRECT on) that refers to memory buffer containing this indirect descriptor table; addr and len refer to the indirect table address and length in bytes, respectively.

The indirect table layout structure looks like this (*len* is the length of the descriptor that refers to this table, which is a variable, so this code won't compile):

```
struct indirect_descriptor_table {
    /* The actual descriptors (16 bytes each) */
    struct virtq_desc desc[len / 16];
};
```

The first indirect descriptor is located at start of the indirect descriptor table (index 0), additional indirect descriptors are chained by *next*. An indirect descriptor without a valid *next* (with *flags*&VIRTQ\_DESC\_-F\_NEXT off) signals the end of the descriptor. A single indirect descriptor table can include both device-readable and device-writable descriptors.

If VIRTIO\_F\_IN\_ORDER has been negotiated, indirect descriptors use sequential indices, in-order: index 0 followed by index 1 followed by index 2, etc.

#### 2.7.5.3.1 Driver Requirements: Indirect Descriptors

The driver MUST NOT set the VIRTQ\_DESC\_F\_INDIRECT flag unless the VIRTIO\_F\_INDIRECT\_DESC feature was negotiated. The driver MUST NOT set the VIRTQ\_DESC\_F\_INDIRECT flag within an indirect descriptor (ie. only one table per descriptor).

A driver MUST NOT create a descriptor chain longer than the Queue Size of the device.

A driver MUST NOT set both VIRTQ DESC F INDIRECT and VIRTQ DESC F NEXT in flags.

If VIRTIO\_F\_IN\_ORDER has been negotiated, indirect descriptors MUST appear sequentially, with *next* taking the value of 1 for the 1st descriptor, 2 for the 2nd one, etc.

## 2.7.5.3.2 Device Requirements: Indirect Descriptors

The device MUST ignore the write-only flag (*flags*&VIRTQ\_DESC\_F\_WRITE) in the descriptor that refers to an indirect table.

The device MUST handle the case of zero or more normal chained descriptors followed by a single descriptor with flags&VIRTQ\_DESC\_F\_INDIRECT.

**Note:** While unusual (most implementations either create a chain solely using non-indirect descriptors, or use a single indirect element), such a layout is valid.

#### 2.7.6 The Virtqueue Available Ring

The available ring has the following layout structure:

The driver uses the available ring to offer buffers to the device: each ring entry refers to the head of a descriptor chain. It is only written by the driver and read by the device.

*idx* field indicates where the driver would put the next descriptor entry in the ring (modulo the queue size). This starts at 0, and increases.

**Note:** The legacy [Virtio PCI Draft] referred to this structure as vring\_avail, and the constant as VRING\_-AVAIL\_F\_NO\_INTERRUPT, but the layout and value were identical.

#### 2.7.6.1 Driver Requirements: The Virtqueue Available Ring

A driver MUST NOT decrement the available idx on a virtqueue (ie. there is no way to "unexpose" buffers).

# 2.7.7 Used Buffer Notification Suppression

If the VIRTIO\_F\_EVENT\_IDX feature bit is not negotiated, the *flags* field in the available ring offers a crude mechanism for the driver to inform the device that it doesn't want notifications when buffers are used. Otherwise *used\_event* is a more performant alternative where the driver specifies how far the device can progress before a notification is required.

Neither of these notification suppression methods are reliable, as they are not synchronized with the device, but they serve as useful optimizations.

#### 2.7.7.1 Driver Requirements: Used Buffer Notification Suppression

If the VIRTIO F EVENT IDX feature bit is not negotiated:

- The driver MUST set flags to 0 or 1.
- The driver MAY set *flags* to 1 to advise the device that notifications are not needed.

Otherwise, if the VIRTIO F EVENT IDX feature bit is negotiated:

- The driver MUST set flags to 0.
- The driver MAY use *used\_event* to advise the device that notifications are unnecessary until the device writes an entry with an index specified by *used\_event* into the used ring (equivalently, until *idx* in the used ring will reach the value *used\_event* + 1).

The driver MUST handle spurious notifications from the device.

#### 2.7.7.2 Device Requirements: Used Buffer Notification Suppression

If the VIRTIO\_F\_EVENT\_IDX feature bit is not negotiated:

- The device MUST ignore the used\_event value.
- After the device writes a descriptor index into the used ring:
  - If flags is 1, the device SHOULD NOT send a notification.
  - If flags is 0, the device MUST send a notification.

Otherwise, if the VIRTIO F EVENT IDX feature bit is negotiated:

- The device MUST ignore the lower bit of flags.
- After the device writes a descriptor index into the used ring:
  - If the idx field in the used ring (which determined where that descriptor index was placed) was equal to used event, the device MUST send a notification.
  - Otherwise the device SHOULD NOT send a notification.

**Note:** For example, if *used\_event* is 0, then a device using

VIRTIO\_F\_EVENT\_IDX would send a used buffer notification to the driver after the first buffer is used (and again after the 65536th buffer, etc).

#### 2.7.8 The Virtqueue Used Ring

The used ring has the following layout structure:

```
struct virtq_used {
#define VIRTQ_USED_F_NO_NOTIFY 1
    le16 flags;
    le16 idx;
    struct virtq_used_elem ring[ /* Queue Size */];
    le16 avail_event; /* Only if VIRTIO_F_EVENT_IDX */
};

/* le32 is used here for ids for padding reasons. */
struct virtq_used_elem {
```

```
/* Index of start of used descriptor chain. */
le32 id;
/*
    * The number of bytes written into the device writable portion of
    * the buffer described by the descriptor chain.
    */
le32 len;
};
```

The used ring is where the device returns buffers once it is done with them: it is only written to by the device, and read by the driver.

Each entry in the ring is a pair: *id* indicates the head entry of the descriptor chain describing the buffer (this matches an entry placed in the available ring by the guest earlier), and *len* the total of bytes written into the buffer.

**Note:** *len* is particularly useful for drivers using untrusted buffers: if a driver does not know exactly how much has been written by the device, the driver would have to zero the buffer in advance to ensure no data leakage occurs.

For example, a network driver may hand a received buffer directly to an unprivileged userspace application. If the network device has not overwritten the bytes which were in that buffer, this could leak the contents of freed memory from other processes to the application.

*idx* field indicates where the device would put the next descriptor entry in the ring (modulo the queue size). This starts at 0, and increases.

**Note:** The legacy [Virtio PCI Draft] referred to these structures as vring\_used and vring\_used\_elem, and the constant as VRING\_USED\_F\_NO\_NOTIFY, but the layout and value were identical.

# 2.7.8.1 Legacy Interface: The Virtqueue Used Ring

Historically, many drivers ignored the *len* value, as a result, many devices set *len* incorrectly. Thus, when using the legacy interface, it is generally a good idea to ignore the *len* value in used ring entries if possible. Specific known issues are listed per device type.

#### 2.7.8.2 Device Requirements: The Virtqueue Used Ring

The device MUST set *len* prior to updating the used *idx*.

The device MUST write at least *len* bytes to descriptor, beginning at the first device-writable buffer, prior to updating the used *idx*.

The device MAY write more than *len* bytes to descriptor.

**Note:** There are potential error cases where a device might not know what parts of the buffers have been written. This is why *len* is permitted to be an underestimate: that's preferable to the driver believing that uninitialized memory has been overwritten when it has not.

## 2.7.8.3 Driver Requirements: The Virtqueue Used Ring

The driver MUST NOT make assumptions about data in device-writable buffers beyond the first *len* bytes, and SHOULD ignore this data.

#### 2.7.9 In-order use of descriptors

Some devices always use descriptors in the same order in which they have been made available. These devices can offer the VIRTIO\_F\_IN\_ORDER feature. If negotiated, this knowledge allows devices to notify the use of a batch of buffers to the driver by only writing out a single used ring entry with the *id* corresponding to the head entry of the descriptor chain describing the last buffer in the batch.

The device then skips forward in the ring according to the size of the batch. Accordingly, it increments the used *idx* by the size of the batch.

The driver needs to look up the used *id* and calculate the batch size to be able to advance to where the next used ring entry will be written by the device.

This will result in the used ring entry at an offset matching the first available ring entry in the batch, the used ring entry for the next batch at an offset matching the first available ring entry in the next batch, etc.

The skipped buffers (for which no used ring entry was written) are assumed to have been used (read or written) by the device completely.

# 2.7.10 Available Buffer Notification Suppression

The device can suppress available buffer notifications in a manner analogous to the way drivers can suppress used buffer notifications as detailed in section 2.7.7. The device manipulates *flags* or *avail\_event* in the used ring the same way the driver manipulates *flags* or *used\_event* in the available ring.

## 2.7.10.1 Driver Requirements: Available Buffer Notification Suppression

The driver MUST initialize *flags* in the used ring to 0 when allocating the used ring.

If the VIRTIO F EVENT IDX feature bit is not negotiated:

- The driver MUST ignore the avail\_event value.
- · After the driver writes a descriptor index into the available ring:
  - If flags is 1, the driver SHOULD NOT send a notification.
  - If flags is 0, the driver MUST send a notification.

Otherwise, if the VIRTIO\_F\_EVENT\_IDX feature bit is negotiated:

- The driver MUST ignore the lower bit of flags.
- After the driver writes a descriptor index into the available ring:
  - If the idx field in the available ring (which determined where that descriptor index was placed) was equal to avail\_event, the driver MUST send a notification.
  - Otherwise the driver SHOULD NOT send a notification.

#### 2.7.10.2 Device Requirements: Available Buffer Notification Suppression

If the VIRTIO F EVENT IDX feature bit is not negotiated:

- The device MUST set flags to 0 or 1.
- The device MAY set flags to 1 to advise the driver that notifications are not needed.

Otherwise, if the VIRTIO F EVENT IDX feature bit is negotiated:

- The device MUST set flags to 0.
- The device MAY use *avail\_event* to advise the driver that notifications are unnecessary until the driver writes entry with an index specified by *avail\_event* into the available ring (equivalently, until *idx* in the available ring will reach the value *avail\_event* + 1).

The device MUST handle spurious notifications from the driver.

# 2.7.11 Helpers for Operating Virtqueues

The Linux Kernel Source code contains the definitions above and helper routines in a more usable form, in include/uapi/linux/virtio\_ring.h. This was explicitly licensed by IBM and Red Hat under the (3-clause) BSD license so that it can be freely used by all other projects, and is reproduced (with slight variation) in A virtio queue.h.

# 2.7.12 Virtqueue Operation

There are two parts to virtqueue operation: supplying new available buffers to the device, and processing used buffers from the device.

**Note:** As an example, the simplest virtio network device has two virtqueues: the transmit virtqueue and the receive virtqueue. The driver adds outgoing (device-readable) packets to the transmit virtqueue, and then frees them after they are used. Similarly, incoming (device-writable) buffers are added to the receive virtqueue, and processed after they are used.

What follows is the requirements of each of these two parts when using the split virtqueue format in more detail.

# 2.7.13 Supplying Buffers to The Device

The driver offers buffers to one of the device's virtqueues as follows:

- 1. The driver places the buffer into free descriptor(s) in the descriptor table, chaining as necessary (see 2.7.5 The Virtqueue Descriptor Table).
- 2. The driver places the index of the head of the descriptor chain into the next ring entry of the available ring.
- 3. Steps 1 and 2 MAY be performed repeatedly if batching is possible.
- 4. The driver performs a suitable memory barrier to ensure the device sees the updated descriptor table and available ring before the next step.
- 5. The available idx is increased by the number of descriptor chain heads added to the available ring.
- 6. The driver performs a suitable memory barrier to ensure that it updates the *idx* field before checking for notification suppression.
- 7. The driver sends an available buffer notification to the device if such notifications are not suppressed.

Note that the above code does not take precautions against the available ring buffer wrapping around: this is not possible since the ring buffer is the same size as the descriptor table, so step (1) will prevent such a condition.

In addition, the maximum queue size is 32768 (the highest power of 2 which fits in 16 bits), so the 16-bit *idx* value can always distinguish between a full and empty buffer.

What follows is the requirements of each stage in more detail.

#### 2.7.13.1 Placing Buffers Into The Descriptor Table

A buffer consists of zero or more device-readable physically-contiguous elements followed by zero or more physically-contiguous device-writable elements (each has at least one element). This algorithm maps it into the descriptor table to form a descriptor chain:

for each buffer element, b:

- 1. Get the next free descriptor table entry, d
- 2. Set d.addr to the physical address of the start of b
- 3. Set d.len to the length of b.
- 4. If b is device-writable, set *d.flags* to VIRTQ\_DESC\_F\_WRITE, otherwise 0.
- 5. If there is a buffer element after this:
  - (a) Set d.next to the index of the next free descriptor element.
  - (b) Set the VIRTQ\_DESC\_F\_NEXT bit in d.flags.

In practice, *d.next* is usually used to chain free descriptors, and a separate count kept to check there are enough free descriptors before beginning the mappings.

#### 2.7.13.2 Updating The Available Ring

The descriptor chain head is the first d in the algorithm above, ie. the index of the descriptor table entry referring to the first part of the buffer. A naive driver implementation MAY do the following (with the appropriate conversion to-and-from little-endian assumed):

```
avail->ring[avail->idx % qsz] = head;
```

However, in general the driver MAY add many descriptor chains before it updates *idx* (at which point they become visible to the device), so it is common to keep a counter of how many the driver has added:

```
avail->ring[(avail->idx + added++) % qsz] = head;
```

#### 2.7.13.3 Updating *idx*

idx always increments, and wraps naturally at 65536:

```
avail->idx += added;
```

Once available *idx* is updated by the driver, this exposes the descriptor and its contents. The device MAY access the descriptor chains the driver created and the memory they refer to immediately.

#### 2.7.13.3.1 Driver Requirements: Updating idx

The driver MUST perform a suitable memory barrier before the *idx* update, to ensure the device sees the most up-to-date copy.

## 2.7.13.4 Notifying The Device

The actual method of device notification is bus-specific, but generally it can be expensive. So the device MAY suppress such notifications if it doesn't need them, as detailed in section 2.7.10.

The driver has to be careful to expose the new idx value before checking if notifications are suppressed.

### 2.7.13.4.1 Driver Requirements: Notifying The Device

The driver MUST perform a suitable memory barrier before reading *flags* or *avail\_event*, to avoid missing a notification.

### 2.7.14 Receiving Used Buffers From The Device

Once the device has used buffers referred to by a descriptor (read from or written to them, or parts of both, depending on the nature of the virtqueue and the device), it sends a used buffer notification to the driver as detailed in section 2.7.7.

**Note:** For optimal performance, a driver MAY disable used buffer notifications while processing the used ring, but beware the problem of missing notifications between emptying the ring and reenabling notifications. This is usually handled by re-checking for more used buffers after notifications are reenabled:

```
virtq_disable_used_buffer_notifications(vq);

for (;;) {
    if (vq->last_seen_used != le16_to_cpu(virtq->used.idx)) {
        virtq_enable_used_buffer_notifications(vq);
        mb();

    if (vq->last_seen_used != le16_to_cpu(virtq->used.idx))
        break;

    virtq_disable_used_buffer_notifications(vq);
}
```

```
struct virtq_used_elem *e = virtq.used->ring[vq->last_seen_used%vsz];
process_buffer(e);
vq->last_seen_used++;
}
```

# 2.8 Packed Virtqueues

Packed virtqueues is an alternative compact virtqueue layout using read-write memory, that is memory that is both read and written by both host and guest.

Use of packed virtqueues is negotiated by the VIRTIO\_F\_RING\_PACKED feature bit.

Packed virtgueues support up to  $2^{15}$  entries each.

With current transports, virtqueues are located in guest memory allocated by the driver. Each packed virtqueue consists of three parts:

- · Descriptor Ring occupies the Descriptor Area
- · Driver Event Suppression occupies the Driver Area
- Device Event Suppression occupies the Device Area

Where the Descriptor Ring in turn consists of descriptors, and where each descriptor can contain the following parts:

- · Buffer ID
- · Element Address
- · Element Length
- Flags

A buffer consists of zero or more device-readable physically-contiguous elements followed by zero or more physically-contiguous device-writable elements (each buffer has at least one element).

When the driver wants to send such a buffer to the device, it writes at least one available descriptor describing elements of the buffer into the Descriptor Ring. The descriptor(s) are associated with a buffer by means of a Buffer ID stored within the descriptor.

The driver then notifies the device. When the device has finished processing the buffer, it writes a used device descriptor including the Buffer ID into the Descriptor Ring (overwriting a driver descriptor previously made available), and sends a used event notification.

The Descriptor Ring is used in a circular manner: the driver writes descriptors into the ring in order. After reaching the end of the ring, the next descriptor is placed at the head of the ring. Once the ring is full of driver descriptors, the driver stops sending new requests and waits for the device to start processing descriptors and to write out some used descriptors before making new driver descriptors available.

Similarly, the device reads descriptors from the ring in order and detects that a driver descriptor has been made available. As processing of descriptors is completed, used descriptors are written by the device back into the ring.

Note: after reading driver descriptors and starting their processing in order, the device might complete their processing out of order. Used device descriptors are written in the order in which their processing is complete.

The Device Event Suppression data structure is write-only by the device. It includes information for reducing the number of device events, i.e., sending fewer available buffer notifications to the device.

The Driver Event Suppression data structure is read-only by the device. It includes information for reducing the number of driver events, i.e., sending fewer used buffer notifications to the driver.

# 2.8.1 Driver and Device Ring Wrap Counters

Each of the driver and the device are expected to maintain, internally, a single-bit ring wrap counter initialized to 1.

The counter maintained by the driver is called the Driver Ring Wrap Counter. The driver changes the value of this counter each time it makes available the last descriptor in the ring (after making the last descriptor available).

The counter maintained by the device is called the Device Ring Wrap Counter. The device changes the value of this counter each time it uses the last descriptor in the ring (after marking the last descriptor used).

It is easy to see that the Driver Ring Wrap Counter in the driver matches the Device Ring Wrap Counter in the device when both are processing the same descriptor, or when all available descriptors have been used.

To mark a descriptor as available and used, both the driver and the device use the following two flags:

```
#define VIRTQ_DESC_F_AVAIL (1 << 7)
#define VIRTQ_DESC_F_USED (1 << 15)</pre>
```

To mark a descriptor as available, the driver sets the VIRTQ\_DESC\_F\_AVAIL bit in Flags to match the internal Driver Ring Wrap Counter. It also sets the VIRTQ\_DESC\_F\_USED bit to match the *inverse* value (i.e. to not match the internal Driver Ring Wrap Counter).

To mark a descriptor as used, the device sets the VIRTQ\_DESC\_F\_USED bit in Flags to match the internal Device Ring Wrap Counter. It also sets the VIRTQ\_DESC\_F\_AVAIL bit to match the *same* value.

Thus VIRTQ\_DESC\_F\_AVAIL and VIRTQ\_DESC\_F\_USED bits are different for an available descriptor and equal for a used descriptor.

Note that this observation is mostly useful for sanity-checking as these are necessary but not sufficient conditions - for example, all descriptors are zero-initialized. To detect used and available descriptors it is possible for drivers and devices to keep track of the last observed value of VIRTQ\_DESC\_F\_USED/VIRTQ\_DESC\_F\_USED/VIRTQ\_DESC\_F\_USED bit changes might also be possible.

# 2.8.2 Polling of available and used descriptors

Writes of device and driver descriptors can generally be reordered, but each side (driver and device) are only required to poll (or test) a single location in memory: the next device descriptor after the one they processed previously, in circular order.

Sometimes the device needs to only write out a single used descriptor after processing a batch of multiple available descriptors. As described in more detail below, this can happen when using descriptor chaining or with in-order use of descriptors. In this case, the device writes out a used descriptor with the buffer id of the last descriptor in the group. After processing the used descriptor, both device and driver then skip forward in the ring the number of the remaining descriptors in the group until processing (reading for the driver and writing for the device) the next used descriptor.

## 2.8.3 Write Flag

In an available descriptor, the VIRTQ\_DESC\_F\_WRITE bit within Flags is used to mark a descriptor as corresponding to a write-only or read-only element of a buffer.

```
/* This marks a descriptor as device write-only (otherwise device read-only). */
#define VIRTQ_DESC_F_WRITE 2
```

In a used descriptor, this bit is used to specify whether any data has been written by the device into any parts of the buffer.

## 2.8.4 Element Address and Length

In an available descriptor, Element Address corresponds to the physical address of the buffer element. The length of the element assumed to be physically contiguous is stored in Element Length.

In a used descriptor, Element Address is unused. Element Length specifies the length of the buffer that has been initialized (written to) by the device.

Element Length is reserved for used descriptors without the VIRTQ\_DESC\_F\_WRITE flag, and is ignored by drivers.

## 2.8.5 Scatter-Gather Support

Some drivers need an ability to supply a list of multiple buffer elements (also known as a scatter/gather list) with a request. Two features support this: descriptor chaining and indirect descriptors.

If neither feature is in use by the driver, each buffer is physically-contiguous, either read-only or write-only and is described completely by a single descriptor.

While unusual (most implementations either create all lists solely using non-indirect descriptors, or always use a single indirect element), if both features have been negotiated, mixing indirect and non-indirect descriptors in a ring is valid, as long as each list only contains descriptors of a given type.

Scatter/gather lists only apply to available descriptors. A single used descriptor corresponds to the whole list.

The device limits the number of descriptors in a list through a transport-specific and/or device-specific value. If not limited, the maximum number of descriptors in a list is the virt queue size.

## 2.8.6 Next Flag: Descriptor Chaining

The packed ring format allows the driver to supply a scatter/gather list to the device by using multiple descriptors, and setting the VIRTQ\_DESC\_F\_NEXT bit in Flags for all but the last available descriptor.

```
/* This marks a buffer as continuing. */
#define VIRTQ_DESC_F_NEXT 1
```

Buffer ID is included in the last descriptor in the list.

The driver always makes the first descriptor in the list available after the rest of the list has been written out into the ring. This guarantees that the device will never observe a partial scatter/gather list in the ring.

Note: all flags, including VIRTQ\_DESC\_F\_AVAIL, VIRTQ\_DESC\_F\_USED, VIRTQ\_DESC\_F\_WRITE must be set/cleared correctly in all descriptors in the list, not just the first one.

The device only writes out a single used descriptor for the whole list. It then skips forward according to the number of descriptors in the list. The driver needs to keep track of the size of the list corresponding to each buffer ID, to be able to skip to where the next used descriptor is written by the device.

For example, if descriptors are used in the same order in which they are made available, this will result in the used descriptor overwriting the first available descriptor in the list, the used descriptor for the next list overwriting the first available descriptor in the next list, etc.

VIRTQ DESC F NEXT is reserved in used descriptors, and should be ignored by drivers.

## 2.8.7 Indirect Flag: Scatter-Gather Support

Some devices benefit by concurrently dispatching a large number of large requests. The VIRTIO\_F\_INDI-RECT\_DESC feature allows this. To increase ring capacity the driver can store a (read-only by the device) table of indirect descriptors anywhere in memory, and insert a descriptor in the main virtqueue (with Flags bit VIRTQ\_DESC\_F\_INDIRECT on) that refers to a buffer element containing this indirect descriptor table; addr and len refer to the indirect table address and length in bytes, respectively.

```
/* This means the element contains a table of descriptors. */
#define VIRTQ_DESC_F_INDIRECT 4
```

The indirect table layout structure looks like this (*len* is the Buffer Length of the descriptor that refers to this table, which is a variable):

```
struct pvirtq_indirect_descriptor_table {
    /* The actual descriptor structures (struct pvirtq_desc each) */
    struct pvirtq_desc desc[len / sizeof(struct pvirtq_desc)];
};
```

The first descriptor is located at the start of the indirect descriptor table, additional indirect descriptors come immediately afterwards. The VIRTQ\_DESC\_F\_WRITE *flags* bit is the only valid flag for descriptors in the indirect table. Others are reserved and are ignored by the device. Buffer ID is also reserved and is ignored by the device.

In descriptors with VIRTQ\_DESC\_F\_INDIRECT set VIRTQ\_DESC\_F\_WRITE is reserved and is ignored by the device.

## 2.8.8 In-order use of descriptors

Some devices always use descriptors in the same order in which they have been made available. These devices can offer the VIRTIO\_F\_IN\_ORDER feature. If negotiated, this knowledge allows devices to notify the use of a batch of buffers to the driver by only writing out a single used descriptor with the Buffer ID corresponding to the last descriptor in the batch.

The device then skips forward in the ring according to the size of the batch. The driver needs to look up the used Buffer ID and calculate the batch size to be able to advance to where the next used descriptor will be written by the device.

This will result in the used descriptor overwriting the first available descriptor in the batch, the used descriptor for the next batch overwriting the first available descriptor in the next batch, etc.

The skipped buffers (for which no used descriptor was written) are assumed to have been used (read or written) by the device completely.

## 2.8.9 Multi-buffer requests

Some devices combine multiple buffers as part of processing of a single request. These devices always mark the descriptor corresponding to the first buffer in the request used after the rest of the descriptors (corresponding to rest of the buffers) in the request - which follow the first descriptor in ring order - has been marked used and written out into the ring. This guarantees that the driver will never observe a partial request in the ring.

## 2.8.10 Driver and Device Event Suppression

In many systems used and available buffer notifications involve significant overhead. To mitigate this overhead, each virtqueue includes two identical structures used for controlling notifications between the device and the driver.

The Driver Event Suppression structure is read-only by the device and controls the used buffer notifications sent by the device to the driver.

The Device Event Suppression structure is read-only by the driver and controls the available buffer notifications sent by the driver to the device.

Each of these Event Suppression structures includes the following fields:

## **Descriptor Ring Change Event Flags** Takes values:

```
/* Enable events */
#define RING_EVENT_FLAGS_ENABLE 0x0
/* Disable events */
#define RING_EVENT_FLAGS_DISABLE 0x1
/*
    * Enable events for a specific descriptor
    * (as specified by Descriptor Ring Change Event Offset/Wrap Counter).
```

```
* Only valid if VIRTIO_F_EVENT_IDX has been negotiated.

*/
#define RING_EVENT_FLAGS_DESC 0x2
/* The value 0x3 is reserved */
```

**Descriptor Ring Change Event Offset** If Event Flags set to descriptor specific event: offset within the ring (in units of descriptor size). Event will only trigger when this descriptor is made available/used respectively.

**Descriptor Ring Change Event Wrap Counter** If Event Flags set to descriptor specific event: offset within the ring (in units of descriptor size). Event will only trigger when Ring Wrap Counter matches this value and a descriptor is made available/used respectively.

After writing out some descriptors, both the device and the driver are expected to consult the relevant structure to find out whether a used respectively an available buffer notification should be sent.

## 2.8.10.1 Structure Size and Alignment

Each part of the virtqueue is physically-contiguous in guest memory, and has different alignment requirements.

The memory alignment and size requirements, in bytes, of each part of the virtqueue are summarized in the following table:

Virtqueue Part	Alignment	Size
Descriptor Ring	16	16*(Queue Size)
Device Event Suppression	4	4
Driver Event Suppression	4	4

The Alignment column gives the minimum alignment for each part of the virtqueue.

The Size column gives the total number of bytes for each part of the virtqueue.

Queue Size corresponds to the maximum number of descriptors in the virtqueue<sup>3</sup>. The Queue Size value does not have to be a power of 2.

## 2.8.11 Driver Requirements: Virtqueues

The driver MUST ensure that the physical address of the first byte of each virtqueue part is a multiple of the specified alignment value in the above table.

## 2.8.12 Device Requirements: Virtqueues

The device MUST start processing driver descriptors in the order in which they appear in the ring. The device MUST start writing device descriptors into the ring in the order in which they complete. The device MAY reorder descriptor writes once they are started.

## 2.8.13 The Virtqueue Descriptor Format

The available descriptor refers to the buffers the driver is sending to the device. *addr* is a physical address, and the descriptor is identified with a buffer using the *id* field.

```
struct pvirtq_desc {
    /* Buffer Address. */
    le64 addr;
    /* Buffer Length. */
    le32 len;
    /* Buffer ID. */
    le16 id;
    /* The flags depending on descriptor type. */
    le16 flags;
```

<sup>&</sup>lt;sup>3</sup>For example, if Queue Size is 4 then at most 4 buffers can be queued at any given time.

The descriptor ring is zero-initialized.

## 2.8.14 Event Suppression Structure Format

The following structure is used to reduce the number of notifications sent between driver and device.

```
struct pvirtq_event_suppress {
    le16 {
        desc_event_off : 15; /* Descriptor Ring Change Event Offset */
        desc_event_wrap : 1; /* Descriptor Ring Change Event Wrap Counter */
    } desc; /* If desc_event_flags set to RING_EVENT_FLAGS_DESC */
    le16 {
        desc_event_flags : 2, /* Descriptor Ring Change Event Flags */
        reserved : 14; /* Reserved, set to 0 */
    } flags;
};
```

## 2.8.15 Device Requirements: The Virtqueue Descriptor Table

A device MUST NOT write to a device-readable buffer, and a device SHOULD NOT read a device-writable buffer. A device MUST NOT use a descriptor unless it observes the VIRTQ\_DESC\_F\_AVAIL bit in its flags being changed (e.g. as compared to the initial zero value). A device MUST NOT change a descriptor after changing it's the VIRTQ\_DESC\_F\_USED bit in its flags.

## 2.8.16 Driver Requirements: The Virtqueue Descriptor Table

A driver MUST NOT change a descriptor unless it observes the VIRTQ\_DESC\_F\_USED bit in its *flags* being changed. A driver MUST NOT change a descriptor after changing the VIRTQ\_DESC\_F\_AVAIL bit in its *flags*. When notifying the device, driver MUST set *next\_off* and *next\_wrap* to match the next descriptor not yet made available to the device. A driver MAY send multiple available buffer notifications without making any new descriptors available to the device.

## 2.8.17 Driver Requirements: Scatter-Gather Support

A driver MUST NOT create a descriptor list longer than allowed by the device.

A driver MUST NOT create a descriptor list longer than the Queue Size.

This implies that loops in the descriptor list are forbidden!

The driver MUST place any device-writable descriptor elements after any device-readable descriptor elements.

A driver MUST NOT depend on the device to use more descriptors to be able to write out all descriptors in a list. A driver MUST make sure there's enough space in the ring for the whole list before making the first descriptor in the list available to the device.

A driver MUST NOT make the first descriptor in the list available before all subsequent descriptors comprising the list are made available.

## 2.8.18 Device Requirements: Scatter-Gather Support

The device MUST use descriptors in a list chained by the VIRTQ\_DESC\_F\_NEXT flag in the same order that they were made available by the driver.

The device MAY limit the number of buffers it will allow in a list.

## 2.8.19 Driver Requirements: Indirect Descriptors

The driver MUST NOT set the VIRTQ\_DESC\_F\_INDIRECT flag unless the VIRTIO\_F\_INDIRECT\_DESC feature was negotiated. The driver MUST NOT set any flags except DESC\_F\_WRITE within an indirect descriptor.

A driver MUST NOT create a descriptor chain longer than allowed by the device.

A driver MUST NOT write direct descriptors with VIRTQ\_DESC\_F\_INDIRECT set in a scatter-gather list linked by VIRTQ\_DESC\_F\_NEXT. *flags*.

## 2.8.20 Virtqueue Operation

There are two parts to virtqueue operation: supplying new available buffers to the device, and processing used buffers from the device.

What follows is the requirements of each of these two parts when using the packed virtqueue format in more detail.

## 2.8.21 Supplying Buffers to The Device

The driver offers buffers to one of the device's virtqueues as follows:

- 1. The driver places the buffer into free descriptor(s) in the Descriptor Ring.
- 2. The driver performs a suitable memory barrier to ensure that it updates the descriptor(s) before checking for notification suppression.
- 3. If notifications are not suppressed, the driver notifies the device of the new available buffers.

What follows are the requirements of each stage in more detail.

## 2.8.21.1 Placing Available Buffers Into The Descriptor Ring

For each buffer element, b:

- 1. Get the next descriptor table entry, d
- 2. Get the next free buffer id value
- 3. Set d.addr to the physical address of the start of b
- 4. Set d.len to the length of b.
- 5. Set d.id to the buffer id
- 6. Calculate the flags as follows:
  - (a) If b is device-writable, set the VIRTQ\_DESC\_F\_WRITE bit to 1, otherwise 0
  - (b) Set the VIRTQ DESC F AVAIL bit to the current value of the Driver Ring Wrap Counter
  - (c) Set the VIRTQ\_DESC\_F\_USED bit to inverse value
- 7. Perform a memory barrier to ensure that the descriptor has been initialized
- 8. Set d.flags to the calculated flags value
- 9. If d is the last descriptor in the ring, toggle the Driver Ring Wrap Counter
- 10. Otherwise, increment d to point at the next descriptor

This makes a single descriptor buffer available. However, in general the driver MAY make use of a batch of descriptors as part of a single request. In that case, it defers updating the descriptor flags for the first descriptor (and the previous memory barrier) until after the rest of the descriptors have been initialized.

Once the descriptor *flags* field is updated by the driver, this exposes the descriptor and its contents. The device MAY access the descriptor and any following descriptors the driver created and the memory they refer to immediately.

#### 2.8.21.1.1 Driver Requirements: Updating flags

The driver MUST perform a suitable memory barrier before the *flags* update, to ensure the device sees the most up-to-date copy.

#### 2.8.21.2 Sending Available Buffer Notifications

The actual method of device notification is bus-specific, but generally it can be expensive. So the device MAY suppress such notifications if it doesn't need them, using the Event Suppression structure comprising the Device Area as detailed in section 2.8.14.

The driver has to be careful to expose the new *flags* value before checking if notifications are suppressed.

#### 2.8.21.3 Implementation Example

Below is a driver code example. It does not attempt to reduce the number of available buffer notifications, neither does it support the VIRTIO F EVENT IDX feature.

```
/* Note: vg->avail wrap count is initialized to 1 */
/* Note: vq->sgs is an array same size as the ring */
id = alloc id(vq);
first = vq->next avail;
sgs = 0;
for (each buffer element b) {
        sas++;
       vq \rightarrow ids[vq \rightarrow next avail] = -1;
        vq->desc[vq->next_avail].address = get_addr(b);
        vq->desc[vq->next avail].len = get len(b);
        avail = vq->avail_wrap_count ? VIRTQ DESC F AVAIL : 0;
        used = !vq->avail wrap count ? VIRTQ DESC F USED : 0;
        f = get flags(b) | avail | used;
        if (b is not the last buffer element) {
                f |= VIRTQ DESC F NEXT;
        /\star Don't mark the 1st descriptor available until all of them are ready. \star/
        if (vq->next avail == first) {
                flags = f;
        } else {
                vq->desc[vq->next avail].flags = f;
        last = vq->next avail;
        vq->next avail++;
        if (vq->next avail >= vq->size) {
                vq->next avail = 0;
                vq->avail wrap count ^= 1;
        }
vq->sqs[id] = sqs;
^{\prime} ID included in the last descriptor in the list */
vq->desc[last].id = id;
write memory barrier();
vq->desc[first].flags = flags;
memory barrier();
if (vq->device_event.flags != RING_EVENT_FLAGS_DISABLE) {
       notify device(vq);
```

#### 2.8.21.3.1 Driver Requirements: Sending Available Buffer Notifications

The driver MUST perform a suitable memory barrier before reading the Event Suppression structure occupying the Device Area. Failing to do so could result in mandatory available buffer notifications not being sent.

## 2.8.22 Receiving Used Buffers From The Device

Once the device has used buffers referred to by a descriptor (read from or written to them, or parts of both, depending on the nature of the virtqueue and the device), it sends a used buffer notification to the driver as detailed in section 2.8.14.

**Note:** For optimal performance, a driver MAY disable used buffer notifications while processing the used buffers, but beware the problem of missing notifications between emptying the ring and reenabling used buffer notifications. This is usually handled by re-checking for more used buffers after notifications are re-enabled:

```
/* Note: vq->used wrap count is initialized to 1 */
vq->driver event.flags = RING EVENT FLAGS DISABLE;
for (;;) {
        struct pvirtq desc *d = vq->desc[vq->next used];
        * Check that
         * 1. Descriptor has been made available. This check is necessary
             if the driver is making new descriptors available in parallel
             with this processing of used descriptors (e.g. from another thread).
             Note: there are many other ways to check this, e.g.
            track the number of outstanding available descriptors or buffers
             and check that it's not 0.
        ^{\star} 2. Descriptor has been used by the device.
        flags = d->flags;
       bool avail = flags & VIRTO DESC F AVAIL;
       bool used = flags & VIRTQ DESC F USED;
       if (avail != vq->used_wrap_count || used != vq->used wrap count) {
                vq->driver event.flags = RING EVENT FLAGS ENABLE;
                memory barrier();
                 \mbox{\scriptsize \star} Re-test in case the driver made more descriptors available in
                 * parallel with the used descriptor processing (e.g. from another
                 ^{\star} thread) and/or the device used more descriptors before the driver
                 * enabled events.
                */
                flags = d->flags;
                bool avail = flags & VIRTQ DESC F AVAIL;
                bool used = flags & VIRTQ DESC F USED;
                if (avail != vq->used wrap count || used != vq->used wrap count) {
                vq->driver event.flags = RING EVENT FLAGS DISABLE;
       read memory barrier();
        /* skip descriptors until the next buffer */
       id = d->id;
       assert(id < vq->size);
        sgs = vq->sgs[id];
        vq->next used += sgs;
       if (vq->next_used >= vq->size) {
              vq->next used -= vq->size;
               vq->used_wrap_count ^= 1;
        }
```

```
free_id(vq, id);

process_buffer(d);
}
```

## 2.9 Driver Notifications

The driver is sometimes required to send an available buffer notification to the device.

When VIRTIO\_F\_NOTIFICATION\_DATA has not been negotiated, this notification involves sending the virtqueue number to the device (method depending on the transport).

However, some devices benefit from the ability to find out the amount of available data in the queue without accessing the virtgueue in memory: for efficiency or as a debugging aid.

To help with these optimizations, when VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, driver notifications to the device include the following information:

vqn VQ number to be notified.

- **next\_off** Offset within the ring where the next available ring entry will be written. When VIRTIO\_F\_RING\_-PACKED has not been negotiated this refers to the 15 least significant bits of the available index. When VIRTIO\_F\_RING\_PACKED has been negotiated this refers to the offset (in units of descriptor entries) within the descriptor ring where the next available descriptor will be written.
- **next\_wrap** Wrap Counter. With VIRTIO\_F\_RING\_PACKED this is the wrap counter referring to the next available descriptor. Without VIRTIO\_F\_RING\_PACKED this is the most significant bit (bit 15) of the available index.

Note that the driver can send multiple notifications even without making any more buffers available. When VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, these notifications would then have identical *next\_-off* and *next\_wrap* values.

# 2.10 Shared Memory Regions

Shared memory regions are an additional facility available to devices that need a region of memory that's continuously shared between the device and the driver, rather than passed between them in the way virtqueue elements are.

Example uses include shared caches and version pools for versioned data structures.

The memory region is allocated by the device and presented to the driver. Where the device is implemented in software on a host, this arrangement allows the memory region to be allocated by a library on the host, which the device may not have full control over.

A device may have multiple shared memory regions associated with it. Each region has a *shmid* to identify it, the meaning of which is device-specific.

Enumeration and location of shared memory regions is performed in a transport-specific way.

Memory consistency rules vary depending on the region and the device and they will be specified as required by each device.

## 2.10.1 Addressing within regions

References into shared memory regions are represented as offsets from the beginning of the region instead of absolute memory addresses. Offsets are used both for references between structures stored within shared memory and for requests placed in virtqueues that refer to shared memory. The *shmid* may be explicit or may be inferred from the context of the reference.

## 2.10.2 Device Requirements: Shared Memory Regions

Shared memory regions MUST NOT expose shared memory regions which are used to control the operation of the device, nor to stream data.

# 2.11 Exporting Objects

When an object created by one virtio device needs to be shared with a seperate virtio device, the first device can export the object by generating a UUID which can then be passed to the second device to identify the object.

What constitutes an object, how to export objects, and how to import objects are defined by the individual device types. It is RECOMMENDED that devices generate version 4 UUIDs as specified by [RFC4122].

# 3 General Initialization And Device Operation

We start with an overview of device initialization, then expand on the details of the device and how each step is preformed. This section is best read along with the bus-specific section which describes how to communicate with the specific device.

## 3.1 Device Initialization

## 3.1.1 Driver Requirements: Device Initialization

The driver MUST follow this sequence to initialize a device:

- 1. Reset the device.
- 2. Set the ACKNOWLEDGE status bit: the guest OS has noticed the device.
- 3. Set the DRIVER status bit: the guest OS knows how to drive the device.
- 4. Read device feature bits, and write the subset of feature bits understood by the OS and driver to the device. During this step the driver MAY read (but MUST NOT write) the device-specific configuration fields to check that it can support the device before accepting it.
- 5. Set the FEATURES OK status bit. The driver MUST NOT accept new feature bits after this step.
- 6. Re-read *device status* to ensure the FEATURES\_OK bit is still set: otherwise, the device does not support our subset of features and the device is unusable.
- 7. Perform device-specific setup, including discovery of virtqueues for the device, optional per-bus setup, reading and possibly writing the device's virtio configuration space, and population of virtqueues.
- 8. Set the DRIVER\_OK status bit. At this point the device is "live".

If any of these steps go irrecoverably wrong, the driver SHOULD set the FAILED status bit to indicate that it has given up on the device (it can reset the device later to restart if desired). The driver MUST NOT continue initialization in that case.

The driver MUST NOT send any buffer available notifications to the device before setting DRIVER\_OK.

## 3.1.2 Legacy Interface: Device Initialization

Legacy devices did not support the FEATURES\_OK status bit, and thus did not have a graceful way for the device to indicate unsupported feature combinations. They also did not provide a clear mechanism to end feature negotiation, which meant that devices finalized features on first-use, and no features could be introduced which radically changed the initial operation of the device.

Legacy driver implementations often used the device before setting the DRIVER\_OK bit, and sometimes even before writing the feature bits to the device.

The result was the steps 5 and 6 were omitted, and steps 4, 7 and 8 were conflated.

Therefore, when using the legacy interface:

- The transitional driver MUST execute the initialization sequence as described in 3.1 but omitting the steps 5 and 6.
- The transitional device MUST support the driver writing device configuration fields before the step 4.
- The transitional device MUST support the driver using the device before the step 8.

## 3.2 Device Operation

When operating the device, each field in the device configuration space can be changed by either the driver or the device.

Whenever such a configuration change is triggered by the device, driver is notified. This makes it possible for drivers to cache device configuration, avoiding expensive configuration reads unless notified.

## 3.2.1 Notification of Device Configuration Changes

For devices where the device-specific configuration information can be changed, a configuration change notification is sent when a device-specific configuration change occurs.

In addition, this notification is triggered by the device setting DEVICE\_NEEDS\_RESET (see 2.1.2).

# 3.3 Device Cleanup

Once the driver has set the DRIVER\_OK status bit, all the configured virtqueue of the device are considered live. None of the virtqueues of a device are live once the device has been reset.

## 3.3.1 Driver Requirements: Device Cleanup

A driver MUST NOT alter virtqueue entries for exposed buffers, i.e., buffers which have been made available to the device (and not been used by the device) of a live virtqueue.

Thus a driver MUST ensure a virtqueue isn't live (by device reset) before removing exposed buffers.

# **4 Virtio Transport Options**

Virtio can use various different buses, thus the standard is split into virtio general and bus-specific sections.

## 4.1 Virtio Over PCI Bus

Virtio devices are commonly implemented as PCI devices.

A Virtio device can be implemented as any kind of PCI device: a Conventional PCI device or a PCI Express device. To assure designs meet the latest level requirements, see the PCI-SIG home page at http://www.pcisig.com for any approved changes.

## 4.1.1 Device Requirements: Virtio Over PCI Bus

A Virtio device using Virtio Over PCI Bus MUST expose to guest an interface that meets the specification requirements of the appropriate PCI specification: [PCI] and [PCIe] respectively.

## 4.1.2 PCI Device Discovery

Any PCI device with PCI Vendor ID 0x1AF4, and PCI Device ID 0x1000 through 0x107F inclusive is a virtio device. The actual value within this range indicates which virtio device is supported by the device. The PCI Device ID is calculated by adding 0x1040 to the Virtio Device ID, as indicated in section 5. Additionally, devices MAY utilize a Transitional PCI Device ID range, 0x1000 to 0x103F depending on the device type.

#### 4.1.2.1 Device Requirements: PCI Device Discovery

Devices MUST have the PCI Vendor ID 0x1AF4. Devices MUST either have the PCI Device ID calculated by adding 0x1040 to the Virtio Device ID, as indicated in section 5 or have the Transitional PCI Device ID depending on the device type, as follows:

Transitional PCI Device ID	Virtio Device
0x1000	network card
0x1001	block device
0x1002	memory ballooning (traditional)
0x1003	console
0x1004	SCSI host
0x1005	entropy source
0x1009	9P transport

For example, the network card device with the Virtio Device ID 1 has the PCI Device ID 0x1041 or the Transitional PCI Device ID 0x1000.

The PCI Subsystem Vendor ID and the PCI Subsystem Device ID MAY reflect the PCI Vendor and Device ID of the environment (for informational purposes by the driver).

Non-transitional devices SHOULD have a PCI Device ID in the range 0x1040 to 0x107f. Non-transitional devices SHOULD have a PCI Revision ID of 1 or higher. Non-transitional devices SHOULD have a PCI Subsystem Device ID of 0x40 or higher.

This is to reduce the chance of a legacy driver attempting to drive the device.

#### 4.1.2.2 Driver Requirements: PCI Device Discovery

Drivers MUST match devices with the PCI Vendor ID 0x1AF4 and the PCI Device ID in the range 0x1040 to 0x107f, calculated by adding 0x1040 to the Virtio Device ID, as indicated in section 5. Drivers for device types listed in section 4.1.2 MUST match devices with the PCI Vendor ID 0x1AF4 and the Transitional PCI Device ID indicated in section 4.1.2.

Drivers MUST match any PCI Revision ID value. Drivers MAY match any PCI Subsystem Vendor ID and any PCI Subsystem Device ID value.

#### 4.1.2.3 Legacy Interfaces: A Note on PCI Device Discovery

Transitional devices MUST have a PCI Revision ID of 0. Transitional devices MUST have the PCI Subsystem Device ID matching the Virtio Device ID, as indicated in section 5. Transitional devices MUST have the Transitional PCI Device ID in the range 0x1000 to 0x103f.

This is to match legacy drivers.

## 4.1.3 PCI Device Layout

The device is configured via I/O and/or memory regions (though see 4.1.4.9 for access via the PCI configuration space), as specified by Virtio Structure PCI Capabilities.

Fields of different sizes are present in the device configuration regions. All 64-bit, 32-bit and 16-bit fields are little-endian. 64-bit fields are to be treated as two 32-bit fields, with low 32 bit part followed by the high 32 bit part.

#### 4.1.3.1 Driver Requirements: PCI Device Layout

For device configuration access, the driver MUST use 8-bit wide accesses for 8-bit wide fields, 16-bit wide and aligned accesses for 16-bit wide fields and 32-bit wide and aligned accesses for 32-bit and 64-bit wide fields. For 64-bit fields, the driver MAY access each of the high and low 32-bit parts of the field independently.

#### 4.1.3.2 Device Requirements: PCI Device Layout

For 64-bit device configuration fields, the device MUST allow driver independent access to high and low 32-bit parts of the field.

## 4.1.4 Virtio Structure PCI Capabilities

The virtio device configuration layout includes several structures:

- · Common configuration
- Notifications
- ISR Status
- Device-specific configuration (optional)
- · PCI configuration access

Each structure can be mapped by a Base Address register (BAR) belonging to the function, or accessed via the special VIRTIO\_PCI\_CAP\_PCI\_CFG field in the PCI configuration space.

The location of each structure is specified using a vendor-specific PCI capability located on the capability list in PCI configuration space of the device. This virtio structure capability uses little-endian format; all fields are read-only for the driver unless stated otherwise:

This structure can be followed by extra data, depending on cfg\_type, as documented below.

The fields are interpreted as follows:

cap vndr 0x09; Identifies a vendor-specific capability.

cap next Link to next capability in the capability list in the PCI configuration space.

cap\_len Length of this capability structure, including the whole of struct virtio\_pci\_cap, and extra data if any. This length MAY include padding, or fields unused by the driver.

**cfg\_type** identifies the structure, according to the following table:

```
/* Common configuration */
#define VIRTIO PCI CAP COMMON CFG
                                         1
/* Notifications */
#define VIRTIO PCI CAP NOTIFY CFG
                                         2
/* ISR Status */
#define VIRTIO PCI CAP ISR CFG
                                         3
/* Device specific configuration */
#define VIRTIO PCI CAP DEVICE CFG
/* PCI configuration access */
#define VIRTIO PCI CAP PCI CFG
/* Shared memory region */
#define VIRTIO PCI CAP SHARED MEMORY CFG 8
/* Vendor-specific data */
#define VIRTIO PCI CAP VENDOR CFG
                                         9
```

Any other value is reserved for future use.

Each structure is detailed individually below.

The device MAY offer more than one structure of any type - this makes it possible for the device to expose multiple interfaces to drivers. The order of the capabilities in the capability list specifies the order of preference suggested by the device. A device may specify that this ordering mechanism be overridden by the use of the *id* field.

**Note:** For example, on some hypervisors, notifications using IO accesses are faster than memory accesses. In this case, the device would expose two capabilities with *cfg\_type* set to VIRTIO\_-PCI\_CAP\_NOTIFY\_CFG: the first one addressing an I/O BAR, the second one addressing a memory BAR. In this example, the driver would use the I/O BAR if I/O resources are available, and fall back on memory BAR when I/O resources are unavailable.

bar values 0x0 to 0x5 specify a Base Address register (BAR) belonging to the function located beginning at 10h in PCI Configuration Space and used to map the structure into Memory or I/O Space. The BAR is permitted to be either 32-bit or 64-bit, it can map Memory Space or I/O Space.

Any other value is reserved for future use.

id Used by some device types to uniquely identify multiple capabilities of a certain type. If the device type does not specify the meaning of this field, its contents are undefined.

**offset** indicates where the structure begins relative to the base address associated with the BAR. The alignment requirements of *offset* are indicated in each structure-specific section below.

length indicates the length of the structure.

length MAY include padding, or fields unused by the driver, or future extensions.

**Note:** For example, a future device might present a large structure size of several MBytes. As current devices never utilize structures larger than 4KBytes in size, driver MAY limit the mapped structure size to e.g. 4KBytes (thus ignoring parts of structure after the first 4KBytes) to allow forward compatibility with such devices without loss of functionality and without wasting resources.

A variant of this type, struct virtio\_pci\_cap64, is defined for those capabilities that require offsets or lengths larger than 4GiB:

```
struct virtio_pci_cap64 {
    struct virtio_pci_cap cap;
    u32 offset_hi;
    u32 length_hi;
};
```

Given that the *cap.length* and *cap.offset* fields are only 32 bit, the additional *offset\_hi* and *length\_hi* fields provide the most significant 32 bits of a total 64 bit offset and length within the BAR specified by *cap.bar*.

#### 4.1.4.1 Driver Requirements: Virtio Structure PCI Capabilities

The driver MUST ignore any vendor-specific capability structure which has a reserved *cfg\_type* value.

The driver SHOULD use the first instance of each virtio structure type they can support.

The driver MUST accept a *cap\_len* value which is larger than specified here.

The driver MUST ignore any vendor-specific capability structure which has a reserved bar value.

The drivers SHOULD only map part of configuration structure large enough for device operation. The drivers MUST handle an unexpectedly large *length*, but MAY check that *length* is large enough for device operation.

The driver MUST NOT write into any field of the capability structure, with the exception of those with *cap\_type* VIRTIO PCI CAP PCI CFG as detailed in 4.1.4.9.2.

## 4.1.4.2 Device Requirements: Virtio Structure PCI Capabilities

The device MUST include any extra data (from the beginning of the *cap\_vndr* field through end of the extra data fields if any) in *cap\_len*. The device MAY append extra data or padding to any structure beyond that.

If the device presents multiple structures of the same type, it SHOULD order them from optimal (first) to least-optimal (last).

#### 4.1.4.3 Common configuration structure layout

The common configuration structure is found at the *bar* and *offset* within the VIRTIO\_PCI\_CAP\_COMMON\_-CFG capability; its layout is below.

**device\_feature\_select** The driver uses this to select which feature bits **device\_feature** shows. Value 0x0 selects Feature Bits 0 to 31, 0x1 selects Feature Bits 32 to 63, etc.

- **device\_feature** The device uses this to report which feature bits it is offering to the driver: the driver writes to *device feature select* to select which feature bits are presented.
- **driver\_feature\_select** The driver uses this to select which feature bits *driver\_feature* shows. Value 0x0 selects Feature Bits 0 to 31, 0x1 selects Feature Bits 32 to 63, etc.
- **driver\_feature** The driver writes this to accept feature bits offered by the device. Driver Feature Bits selected by *driver\_feature\_select*.
- config\_msix\_vector The driver sets the Configuration Vector for MSI-X.
- num\_queues The device specifies the maximum number of virtqueues supported here.
- device status The driver writes the device status here (see 2.1). Writing 0 into this field resets the device.
- **config\_generation** Configuration atomicity value. The device changes this every time the configuration noticeably changes.
- queue\_select Queue Select. The driver selects which virtqueue the following fields refer to.
- **queue\_size** Queue Size. On reset, specifies the maximum queue size supported by the device. This can be modified by the driver to reduce memory requirements. A 0 means the queue is unavailable.
- **queue\_msix\_vector** The driver uses this to specify the queue vector for MSI-X.
- **queue\_enable** The driver uses this to selectively prevent the device from executing requests from this virtqueue. 1 enabled; 0 disabled.
- **queue\_notify\_off** The driver reads this to calculate the offset from start of Notification structure at which this virtqueue is located.
  - **Note:** this is not an offset in bytes. See 4.1.4.4 below.
- **queue\_desc** The driver writes the physical address of Descriptor Area here. See section 2.6.
- queue\_driver The driver writes the physical address of Driver Area here. See section 2.6.
- queue\_device The driver writes the physical address of Device Area here. See section 2.6.
- queue\_notify\_data This field exists only if VIRTIO\_F\_NOTIF\_CONFIG\_DATA has been negotiated. The driver will use this value to put it in the 'virtqueue number' field in the available buffer notification structure. See section 4.1.5.2.
  - **Note:** This field provides the device with flexibility to determine how virtqueues will be referred to in available buffer notifications. In a trivial case the device can set *queue\_notify\_data=*vqn. Some devices may benefit from providing another value, for example an internal virtqueue identifier, or an internal offset related to the virtqueue number.
- **queue\_reset** The driver uses this to selectively reset the queue. This field exists only if VIRTIO\_F\_RING\_-RESET has been negotiated. (see 2.6.1).

## 4.1.4.3.1 Device Requirements: Common configuration structure layout

offset MUST be 4-byte aligned.

The device MUST present at least one common configuration capability.

The device MUST present the feature bits it is offering in *device\_feature*, starting at bit *device\_feature\_select* \* 32 for any *device\_feature\_select* written by the driver.

**Note:** This means that it will present 0 for any *device\_feature\_select* other than 0 or 1, since no feature defined here exceeds 63.

The device MUST present any valid feature bits the driver has written in *driver\_feature*, starting at bit *driver\_feature\_select* \* 32 for any *driver\_feature\_select* written by the driver. Valid feature bits are those which are subset of the corresponding *device feature* bits. The device MAY present invalid bits written by the driver.

**Note:** This means that a device can ignore writes for feature bits it never offers, and simply present 0 on reads. Or it can just mirror what the driver wrote (but it will still have to check them when the driver sets FEATURES OK).

Note: A driver shouldn't write invalid bits anyway, as per 3.1.1, but this attempts to handle it.

The device MUST present a changed *config\_generation* after the driver has read a device-specific configuration value which has changed since any part of the device-specific configuration was last read.

**Note:** As *config\_generation* is an 8-bit value, simply incrementing it on every configuration change could violate this requirement due to wrap. Better would be to set an internal flag when it has changed, and if that flag is set when the driver reads from the device-specific configuration, increment *config\_generation* and clear the flag.

The device MUST reset when 0 is written to device\_status, and present a 0 in device\_status once that is done.

The device MUST present a 0 in queue\_enable on reset.

If VIRTIO\_F\_RING\_RESET has been negotiated, the device MUST present a 0 in queue\_reset on reset.

If VIRTIO\_F\_RING\_RESET has been negotiated, the device MUST present a 0 in *queue\_reset* after the virtqueue is enabled with *queue\_enable*.

The device MUST reset the queue when 1 is written to *queue\_reset*. The device MUST continue to present 1 in *queue\_reset* as long as the queue reset is ongoing. The device MUST present 0 in both *queue\_reset* and *queue\_enable* when queue reset has completed. (see 2.6.1).

The device MUST present a 0 in *queue\_size* if the virtqueue corresponding to the current *queue\_select* is unavailable.

If VIRTIO\_F\_RING\_PACKED has not been negotiated, the device MUST present either a value of 0 or a power of 2 in *queue\_size*.

#### 4.1.4.3.2 Driver Requirements: Common configuration structure layout

The driver MUST NOT write to device\_feature, num\_queues, config\_generation, queue\_notify\_off or queue\_notify\_data.

If VIRTIO\_F\_RING\_PACKED has been negotiated, the driver MUST NOT write the value 0 to *queue\_size*. If VIRTIO\_F\_RING\_PACKED has not been negotiated, the driver MUST NOT write a value which is not a power of 2 to *queue\_size*.

The driver MUST configure the other virtqueue fields before enabling the virtqueue with queue\_enable.

After writing 0 to *device\_status*, the driver MUST wait for a read of *device\_status* to return 0 before reinitializing the device.

The driver MUST NOT write a 0 to queue enable.

If VIRTIO\_F\_RING\_RESET has been negotiated, after the driver writes 1 to *queue\_reset* to reset the queue, the driver MUST NOT consider queue reset to be complete until it reads back 0 in *queue\_reset*. The driver MAY re-enable the queue by writing 1 to *queue\_enable* after ensuring that other virtqueue fields have been set up correctly. The driver MAY set driver-writeable queue configuration values to different values than those that were used before the queue reset. (see 2.6.1).

#### 4.1.4.4 Notification structure layout

The notification location is found using the VIRTIO\_PCI\_CAP\_NOTIFY\_CFG capability. This capability is immediately followed by an additional field, like so:

```
struct virtio_pci_notify_cap {
    struct virtio_pci_cap cap;
    le32 notify_off_multiplier; /* Multiplier for queue_notify_off. */
};
```

notify\_off\_multiplier is combined with the queue\_notify\_off to derive the Queue Notify address within a BAR for a virtqueue:

```
cap.offset + queue_notify_off * notify_off_multiplier
```

The *cap.offset* and *notify\_off\_multiplier* are taken from the notification capability structure above, and the *queue\_notify\_off* is taken from the common configuration structure.

**Note:** For example, if *notifier\_off\_multiplier* is 0, the device uses the same Queue Notify address for all queues.

## 4.1.4.4.1 Device Requirements: Notification capability

The device MUST present at least one notification capability.

For devices not offering VIRTIO\_F\_NOTIFICATION\_DATA:

The cap.offset MUST be 2-byte aligned.

The device MUST either present *notify\_off\_multiplier* as an even power of 2, or present *notify\_off\_multiplier* as 0.

The value *cap.length* presented by the device MUST be at least 2 and MUST be large enough to support queue notification offsets for all supported queues in all possible configurations.

For all queues, the value cap.length presented by the device MUST satisfy:

```
cap.length >= queue_notify_off * notify_off_multiplier + 2
```

For devices offering VIRTIO\_F\_NOTIFICATION\_DATA:

The device MUST either present *notify\_off\_multiplier* as a number that is a power of 2 that is also a multiple 4, or present *notify\_off\_multiplier* as 0.

The cap.offset MUST be 4-byte aligned.

The value *cap.length* presented by the device MUST be at least 4 and MUST be large enough to support queue notification offsets for all supported queues in all possible configurations.

For all queues, the value cap.length presented by the device MUST satisfy:

```
cap.length >= queue_notify_off * notify_off_multiplier + 4
```

#### 4.1.4.5 ISR status capability

The VIRTIO\_PCI\_CAP\_ISR\_CFG capability refers to at least a single byte, which contains the 8-bit ISR status field to be used for INT#x interrupt handling.

The offset for the ISR status has no alignment requirements.

The ISR bits allow the driver to distinguish between device-specific configuration change interrupts and normal virtqueue interrupts:

Bits	0	1	2 to 31
Purpose	Queue Interrupt	Device Configuration Interrupt	Reserved

To avoid an extra access, simply reading this register resets it to 0 and causes the device to de-assert the interrupt.

In this way, driver read of ISR status causes the device to de-assert an interrupt.

See sections 4.1.5.3 and 4.1.5.4 for how this is used.

## 4.1.4.5.1 Device Requirements: ISR status capability

The device MUST present at least one VIRTIO PCI CAP ISR CFG capability.

The device MUST set the Device Configuration Interrupt bit in *ISR* status before sending a device configuration change notification to the driver.

If MSI-X capability is disabled, the device MUST set the Queue Interrupt bit in *ISR status* before sending a virtqueue notification to the driver.

If MSI-X capability is disabled, the device MUST set the Interrupt Status bit in the PCI Status register in the PCI Configuration Header of the device to the logical OR of all bits in *ISR status* of the device. The device then asserts/deasserts INT#x interrupts unless masked according to standard PCI rules [PCI].

The device MUST reset ISR status to 0 on driver read.

## 4.1.4.5.2 Driver Requirements: ISR status capability

If MSI-X capability is enabled, the driver SHOULD NOT access ISR status upon detecting a Queue Interrupt.

#### 4.1.4.6 Device-specific configuration

The device MUST present at least one VIRTIO\_PCI\_CAP\_DEVICE\_CFG capability for any device type which has a device-specific configuration.

#### 4.1.4.6.1 Device Requirements: Device-specific configuration

The offset for the device-specific configuration MUST be 4-byte aligned.

## 4.1.4.7 Shared memory capability

Shared memory regions 2.10 are enumerated on the PCI transport as a sequence of VIRTIO\_PCI\_CAP\_-SHARED\_MEMORY\_CFG capabilities, one per region.

The capability is defined by a struct virtio\_pci\_cap64 and utilises the *cap.id* to allow multiple shared memory regions per device. The identifier in *cap.id* does not denote a certain order of preference; it is only used to uniquely identify a region.

#### 4.1.4.7.1 Device Requirements: Shared memory capability

The region defined by the combination of the *cap.offset*, *offset\_hi*, and *cap.length*, *length\_hi* fields MUST be contained within the BAR specified by *cap.bar*.

The *cap.id* MUST be unique for any one device instance.

#### 4.1.4.8 Vendor data capability

The optional Vendor data capability allows the device to present vendor-specific data to the driver, without conflicts, for debugging and/or reporting purposes, and without conflicting with standard functionality.

This capability augments but does not replace the standard subsystem ID and subsystem vendor ID fields (offsets 0x2C and 0x2E in the PCI configuration space header) as specified by [PCI].

Vendor data capability is enumerated on the PCI transport as a VIRTIO\_PCI\_CAP\_VENDOR\_CFG capability.

The capability has the following structure:

```
/* For Vendor Definition */
/* Pads structure to a multiple of 4 bytes */
/* Reads must not have side effects */
};
```

Where vendor\_id identifies the PCI-SIG assigned Vendor ID as specified by [PCI].

Note that the capability size is required to be a multiple of 4.

To make it safe for a generic driver to access the capability, reads from this capability MUST NOT have any side effects.

## 4.1.4.8.1 Device Requirements: Vendor data capability

Devices CAN present *vendor\_id* that does not match either the PCI Vendor ID or the PCI Subsystem Vendor ID.

Devices CAN present multiple Vendor data capabilities with either different or identical vendor\_id values.

The value *vendor\_id* MUST NOT equal 0x1AF4.

The size of the Vendor data capability MUST be a multiple of 4 bytes.

Reads of the Vendor data capability by the driver MUST NOT have any side effects.

## 4.1.4.8.2 Driver Requirements: Vendor data capability

The driver SHOULD NOT use the Vendor data capability except for debugging and reporting purposes.

The driver MUST qualify the vendor\_id before interpreting or writing into the Vendor data capability.

#### 4.1.4.9 PCI configuration access capability

The VIRTIO\_PCI\_CAP\_PCI\_CFG capability creates an alternative (and likely suboptimal) access method to the common configuration, notification, ISR and device-specific configuration regions.

The capability is immediately followed by an additional field like so:

```
struct virtio_pci_cfg_cap {
    struct virtio_pci_cap cap;
    u8 pci_cfg_data[4]; /* Data for BAR access. */
};
```

The fields cap.bar, cap.length, cap.offset and pci\_cfg\_data are read-write (RW) for the driver.

To access a device region, the driver writes into the capability structure (ie. within the PCI configuration space) as follows:

- The driver sets the BAR to access by writing to cap.bar.
- The driver sets the size of the access by writing 1, 2 or 4 to cap.length.
- The driver sets the offset within the BAR by writing to cap.offset.

At that point, pci\_cfg\_data will provide a window of size cap.length into the given cap.bar at offset cap.offset.

#### 4.1.4.9.1 Device Requirements: PCI configuration access capability

The device MUST present at least one VIRTIO\_PCI\_CAP\_PCI\_CFG capability.

Upon detecting driver write access to *pci\_cfg\_data*, the device MUST execute a write access at offset *cap.offset* at BAR selected by *cap.bar* using the first *cap.length* bytes from *pci\_cfg\_data*.

Upon detecting driver read access to *pci\_cfg\_data*, the device MUST execute a read access of length cap.length at offset *cap.offset* at BAR selected by *cap.bar* and store the first *cap.length* bytes in *pci\_cfg\_data*.

#### 4.1.4.9.2 Driver Requirements: PCI configuration access capability

The driver MUST NOT write a *cap.offset* which is not a multiple of *cap.length* (ie. all accesses MUST be aligned).

The driver MUST NOT read or write *pci\_cfg\_data* unless *cap.bar*, *cap.length* and *cap.offset* address *cap.length* bytes within a BAR range specified by some other Virtio Structure PCI Capability of type other than *VIR-TIO\_PCI\_CAP\_PCI\_CFG*.

## 4.1.4.10 Legacy Interfaces: A Note on PCI Device Layout

Transitional devices MUST present part of configuration registers in a legacy configuration structure in BAR0 in the first I/O region of the PCI device, as documented below. When using the legacy interface, transitional drivers MUST use the legacy configuration structure in BAR0 in the first I/O region of the PCI device, as documented below.

When using the legacy interface the driver MAY access the device-specific configuration region using any width accesses, and a transitional device MUST present driver with the same results as when accessed using the "natural" access method (i.e. 32-bit accesses for 32-bit fields, etc).

Note that this is possible because while the virtio common configuration structure is PCI (i.e. little) endian, when using the legacy interface the device-specific configuration region is encoded in the native endian of the guest (where such distinction is applicable).

When used through the legacy interface, the virtio common configuration structure looks as follows:

Bits	32	32	32	16	16	16	8	8
Read / Write	R	R+W	R+W	R	R+W	R+W	R+W	R
Purpose	Device Features bits 0:31	Driver Features bits 0:31	Queue Address	queue size	queue select	Queue Notify	Device Status	ISR Status

If MSI-X is enabled for the device, two additional fields immediately follow this header:

Bits	16	16
Read/Write	R+W	R+W
Purpose (MSI-X)	config_msix_vector	queue_msix_vector

Note: When MSI-X capability is enabled, device-specific configuration starts at byte offset 24 in virtio common configuration structure structure. When MSI-X capability is not enabled, device-specific configuration starts at byte offset 20 in virtio header. ie. once you enable MSI-X on the device, the other fields move. If you turn it off again, they move back!

Any device-specific configuration space immediately follows these general headers:

Bits	Device Specific	
Read / Write	Device Specific	
Purpose	Device Specific	

When accessing the device-specific configuration space using the legacy interface, transitional drivers MUST access the device-specific configuration space at an offset immediately following the general headers.

When using the legacy interface, transitional devices MUST present the device-specific configuration space if any at an offset immediately following the general headers.

Note that only Feature Bits 0 to 31 are accessible through the Legacy Interface. When used through the Legacy Interface, Transitional Devices MUST assume that Feature Bits 32 to 63 are not acknowledged by Driver.

As legacy devices had no *config\_generation* field, see 2.5.4 Legacy Interface: Device Configuration Space for workarounds.

#### 4.1.4.11 Non-transitional Device With Legacy Driver: A Note on PCI Device Layout

All known legacy drivers check either the PCI Revision or the Device and Vendor IDs, and thus won't attempt to drive a non-transitional device.

A buggy legacy driver might mistakenly attempt to drive a non-transitional device. If support for such drivers is required (as opposed to fixing the bug), the following would be the recommended way to detect and handle them.

**Note:** Such buggy drivers are not currently known to be used in production.

#### 4.1.4.11.0.1 Device Requirements: Non-transitional Device With Legacy Driver

Non-transitional devices, on a platform where a legacy driver for a legacy device with the same ID (including PCI Revision, Device and Vendor IDs) is known to have previously existed, SHOULD take the following steps to cause the legacy driver to fail gracefully when it attempts to drive them:

- 1. Present an I/O BAR in BAR0, and
- 2. Respond to a single-byte zero write to offset 18 (corresponding to Device Status register in the legacy layout) of BAR0 by presenting zeroes on every BAR and ignoring writes.

## 4.1.5 PCI-specific Initialization And Device Operation

#### 4.1.5.1 Device Initialization

This documents PCI-specific steps executed during Device Initialization.

#### 4.1.5.1.1 Virtio Device Configuration Layout Detection

As a prerequisite to device initialization, the driver scans the PCI capability list, detecting virtio configuration layout using Virtio Structure PCI capabilities as detailed in 4.1.4

## 4.1.5.1.1.1 Legacy Interface: A Note on Device Layout Detection

Legacy drivers skipped the Device Layout Detection step, assuming legacy device configuration space in BAR0 in I/O space unconditionally.

Legacy devices did not have the Virtio PCI Capability in their capability list.

Therefore:

Transitional devices MUST expose the Legacy Interface in I/O space in BAR0.

Transitional drivers MUST look for the Virtio PCI Capabilities on the capability list. If these are not present, driver MUST assume a legacy device, and use it through the legacy interface.

Non-transitional drivers MUST look for the Virtio PCI Capabilities on the capability list. If these are not present, driver MUST assume a legacy device, and fail gracefully.

## 4.1.5.1.2 MSI-X Vector Configuration

When MSI-X capability is present and enabled in the device (through standard PCI configuration space) config\_msix\_vector and queue\_msix\_vector are used to map configuration change and queue interrupts to MSI-X vectors. In this case, the ISR Status is unused.

Writing a valid MSI-X Table entry number, 0 to 0x7FF, to config\_msix\_vector/queue\_msix\_vector maps interrupts triggered by the configuration change/selected queue events respectively to the corresponding MSI-X vector. To disable interrupts for an event type, the driver unmaps this event by writing a special NO VECTOR value:

Note that mapping an event to vector might require device to allocate internal device resources, and thus could fail.

## 4.1.5.1.2.1 Device Requirements: MSI-X Vector Configuration

A device that has an MSI-X capability SHOULD support at least 2 and at most 0x800 MSI-X vectors. Device MUST report the number of vectors supported in *Table Size* in the MSI-X Capability as specified in [PCI]. The device SHOULD restrict the reported MSI-X Table Size field to a value that might benefit system performance.

**Note:** For example, a device which does not expect to send interrupts at a high rate might only specify 2 MSI-X vectors.

Device MUST support mapping any event type to any valid vector 0 to MSI-X *Table Size*. Device MUST support unmapping any event type.

The device MUST return vector mapped to a given event, (NO\_VECTOR if unmapped) on read of *config\_-msix\_vector/queue\_msix\_vector*. The device MUST have all queue and configuration change events are unmapped upon reset.

Devices SHOULD NOT cause mapping an event to vector to fail unless it is impossible for the device to satisfy the mapping request. Devices MUST report mapping failures by returning the NO\_VECTOR value when the relevant *config\_msix\_vector/queue\_msix\_vector* field is read.

#### 4.1.5.1.2.2 Driver Requirements: MSI-X Vector Configuration

Driver MUST support device with any MSI-X Table Size 0 to 0x7FF. Driver MAY fall back on using INT#x interrupts for a device which only supports one MSI-X vector (MSI-X Table Size = 0).

Driver MAY intepret the Table Size as a hint from the device for the suggested number of MSI-X vectors to use.

Driver MUST NOT attempt to map an event to a vector outside the MSI-X Table supported by the device, as reported by *Table Size* in the MSI-X Capability.

After mapping an event to vector, the driver MUST verify success by reading the Vector field value: on success, the previously written value is returned, and on failure, NO\_VECTOR is returned. If a mapping failure is detected, the driver MAY retry mapping with fewer vectors, disable MSI-X or report device failure.

#### 4.1.5.1.3 Virtqueue Configuration

As a device can have zero or more virtqueues for bulk data transport<sup>1</sup>, the driver needs to configure them as part of the device-specific configuration.

The driver typically does this as follows, for each virtqueue a device has:

- 1. Write the virtqueue index (first queue is 0) to *queue\_select*.
- 2. Read the virtqueue size from *queue\_size*. This controls how big the virtqueue is (see 2.6 Virtqueues). If this field is 0, the virtqueue does not exist.
- 3. Optionally, select a smaller virtqueue size and write it to *queue\_size*.
- 4. Allocate and zero Descriptor Table, Available and Used rings for the virtqueue in contiguous physical memory.
- 5. Optionally, if MSI-X capability is present and enabled on the device, select a vector to use to request interrupts triggered by virtqueue events. Write the MSI-X Table entry number corresponding to this

<sup>&</sup>lt;sup>1</sup>For example, the simplest network device has two virtqueues.

vector into *queue\_msix\_vector*. Read *queue\_msix\_vector*: on success, previously written value is returned; on failure, NO VECTOR value is returned.

#### 4.1.5.1.3.1 Legacy Interface: A Note on Virtgueue Configuration

When using the legacy interface, the queue layout follows 2.7.2 Legacy Interfaces: A Note on Virtqueue Layout with an alignment of 4096. Driver writes the physical address, divided by 4096 to the Queue Address field<sup>2</sup>. There was no mechanism to negotiate the queue size.

#### 4.1.5.2 Available Buffer Notifications

When VIRTIO\_F\_NOTIFICATION\_DATA has not been negotiated, the driver sends an available buffer notification to the device by writing the 16-bit virtqueue index of this virtqueue to the Queue Notify address.

When VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, the driver sends an available buffer notification to the device by writing the following 32-bit value to the Queue Notify address:

```
le32 {
  vqn : 16;
  next_off : 15;
  next_wrap : 1;
};
```

See 2.9 Driver Notifications for the definition of the components.

See 4.1.4.4 for how to calculate the Queue Notify address.

## 4.1.5.2.1 Driver Requirements: Available Buffer Notifications

If VIRTIO\_F\_NOTIF\_CONFIG\_DATA has been negotiated:

- If VIRTIO\_F\_NOTIFICATION\_DATA has not been negotiated, the driver MUST use the queue\_notify\_data value instead of the virtqueue index.
- If VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, the driver MUST set the *vqn* field to the *queue\_notify\_data* value.

## 4.1.5.3 Used Buffer Notifications

If a used buffer notification is necessary for a virtqueue, the device would typically act as follows:

- If MSI-X capability is disabled:
  - 1. Set the lower bit of the ISR Status field for the device.
  - 2. Send the appropriate PCI interrupt for the device.
- If MSI-X capability is enabled:
  - 1. If *queue\_msix\_vector* is not NO\_VECTOR, request the appropriate MSI-X interrupt message for the device, *queue\_msix\_vector* sets the MSI-X Table entry number.

#### 4.1.5.3.1 Device Requirements: Used Buffer Notifications

If MSI-X capability is enabled and *queue\_msix\_vector* is NO\_VECTOR for a virtqueue, the device MUST NOT deliver an interrupt for that virtqueue.

<sup>&</sup>lt;sup>2</sup>The 4096 is based on the x86 page size, but it's also large enough to ensure that the separate parts of the virtqueue are on separate cache lines.

#### 4.1.5.4 Notification of Device Configuration Changes

Some virtio PCI devices can change the device configuration state, as reflected in the device-specific configuration region of the device. In this case:

- If MSI-X capability is disabled:
  - 1. Set the second lower bit of the ISR Status field for the device.
  - 2. Send the appropriate PCI interrupt for the device.
- · If MSI-X capability is enabled:
  - 1. If *config\_msix\_vector* is not NO\_VECTOR, request the appropriate MSI-X interrupt message for the device, *config\_msix\_vector* sets the MSI-X Table entry number.

A single interrupt MAY indicate both that one or more virtqueue has been used and that the configuration space has changed.

## 4.1.5.4.1 Device Requirements: Notification of Device Configuration Changes

If MSI-X capability is enabled and *config\_msix\_vector* is NO\_VECTOR, the device MUST NOT deliver an interrupt for device configuration space changes.

#### 4.1.5.4.2 Driver Requirements: Notification of Device Configuration Changes

A driver MUST handle the case where the same interrupt is used to indicate both device configuration space change and one or more virtgueues being used.

#### 4.1.5.5 Driver Handling Interrupts

The driver interrupt handler would typically:

- If MSI-X capability is disabled:
  - Read the ISR Status field, which will reset it to zero.
  - If the lower bit is set: look through all virtqueues for the device, to see if any progress has been made by the device which requires servicing.
  - If the second lower bit is set: re-examine the configuration space to see what changed.
- · If MSI-X capability is enabled:
  - Look through all virtqueues mapped to that MSI-X vector for the device, to see if any progress
    has been made by the device which requires servicing.
  - If the MSI-X vector is equal to config\_msix\_vector, re-examine the configuration space to see what changed.

## 4.2 Virtio Over MMIO

Virtual environments without PCI support (a common situation in embedded devices models) might use simple memory mapped device ("virtio-mmio") instead of the PCI device.

The memory mapped virtio device behaviour is based on the PCI device specification. Therefore most operations including device initialization, queues configuration and buffer transfers are nearly identical. Existing differences are described in the following sections.

## 4.2.1 MMIO Device Discovery

Unlike PCI, MMIO provides no generic device discovery mechanism. For each device, the guest OS will need to know the location of the registers and interrupt(s) used. The suggested binding for systems using flattened device trees is shown in this example:

```
// EXAMPLE: virtio_block device taking 512 bytes at 0x1e000, interrupt 42.
virtio_block@1e000 {
    compatible = "virtio,mmio";
    reg = <0x1e000 0x200>;
    interrupts = <42>;
}
```

## 4.2.2 MMIO Device Register Layout

MMIO virtio devices provide a set of memory mapped control registers followed by a device-specific configuration space, described in the table 4.1.

All register values are organized as Little Endian.

Table 4.1: MMIO Device Register Layout

Name Offset from base Direction	Function Description
MagicValue 0x000 R	Magic value 0x74726976 (a Little Endian equivalent of the "virt" string).
Version 0x004 R	Device version number 0x2.  Note: Legacy devices (see 4.2.4 Legacy interface) used 0x1.
DeviceID 0x008 R	Virtio Subsystem Device ID  See 5 Device Types for possible values. Value zero (0x0) is used to define a system memory map with placeholder devices at static, well known addresses, assigning functions to them depending on user's needs.
VendorID 0x00c R	Virtio Subsystem Vendor ID
DeviceFeatures 0x010 R	Flags representing features the device supports Reading from this register returns 32 consecutive flag bits, the least significant bit depending on the last value written to DeviceFeaturesSel. Access to this register returns bits DeviceFeaturesSel * 32 to (DeviceFeaturesSel * 32)+31, eg. feature bits 0 to 31 if DeviceFeaturesSel is set to 0 and features bits 32 to 63 if DeviceFeaturesSel is set to 1. Also see 2.2 Feature Bits.
DeviceFeaturesSel 0x014 W	<b>Device (host) features word selection.</b> Writing to this register selects a set of 32 device feature bits accessible by reading from <i>DeviceFeatures</i> .
DriverFeatures 0x020 W	Flags representing device features understood and activated by the driver  Writing to this register sets 32 consecutive flag bits, the least significant bit depending on the last value written to DriverFeaturesSel. Access to this register sets bits DriverFeaturesSel * 32 to (DriverFeaturesSel * 32) + 31, eg. feature bits 0 to 31 if DriverFeaturesSel is set to 0 and features bits 32 to 63 if DriverFeaturesSel is set to 1. Also see 2.2 Feature Bits.
<i>DriverFeaturesSel</i> 0x024 W	Activated (guest) features word selection Writing to this register selects a set of 32 activated feature bits accessible by writing to <i>DriverFeatures</i> .

Name Offset from the base Direction	Function Description
QueueSel 0x030 W	Virtual queue index Writing to this register selects the virtual queue that the following operations on QueueNumMax, QueueNum, QueueReady, QueueDescLow, QueueDescHigh, QueueDriverlLow, QueueDriverHigh, QueueDeviceLow, QueueDeviceHigh and QueueReset apply to. The index number of the first queue is zero (0x0).
QueueNumMax 0x034 R	Maximum virtual queue size Reading from the register returns the maximum size (number of elements) of the queue the device is ready to process or zero (0x0) if the queue is not available. This applies to the queue selected by writing to QueueSel.
QueueNum 0x038 W	Virtual queue size  Queue size is the number of elements in the queue. Writing to this register notifies the device what size of the queue the driver will use. This applies to the queue selected by writing to QueueSel.
QueueReady 0x044 RW	Virtual queue ready bit Writing one (0x1) to this register notifies the device that it can execute requests from this virtual queue. Reading from this register returns the last value written to it. Both read and write accesses apply to the queue selected by writing to QueueSel.
QueueNotify 0x050 W	Queue notifier Writing a value to this register notifies the device that there are new buffers to process in a queue. When VIRTIO_F_NOTIFICATION_DATA has not been negotiated, the value written is the queue index. When VIRTIO_F_NOTIFICATION_DATA has been negotiated, the Notification data value has the following format:
	<pre>le32 {    vqn : 16;    next_off : 15;    next_wrap : 1; };</pre>
	See 2.9 Driver Notifications for the definition of the components.
InterruptStatus 0x60 R	Interrupt status Reading from this register returns a bit mask of events that caused the device interrupt to be asserted. The following events are possible:  Used Buffer Notification - bit 0 - the interrupt was asserted because the device has used a buffer in at least one of the active virtual queues.  Configuration Change Notification - bit 1 - the interrupt was asserted because the configuration of the device has changed.
InterruptACK 0x064 W	Interrupt acknowledge Writing a value with bits set as defined in InterruptStatus to this register notifies the device that events causing the interrupt have been handled.
Status 0x070 RW	<b>Device status</b> Reading from this register returns the current device status flags. Writing non-zero values to this register sets the status flags, indicating the driver progress. Writing zero (0x0) to this register triggers a device reset. See also p. 4.2.3.1 Device Initialization.

Name Offset from the base Direction	Function Description
QueueDescLow 0x080 QueueDescHigh 0x084 W	Virtual queue's Descriptor Area 64 bit long physical address Writing to these two registers (lower 32 bits of the address to QueueDescLow, higher 32 bits to QueueDescHigh) notifies the device about location of the Descriptor Area of the queue selected by writing to QueueSel register.
QueueDriverLow 0x090 QueueDriverHigh 0x094 W	Virtual queue's Driver Area 64 bit long physical address Writing to these two registers (lower 32 bits of the address to QueueDriver-Low, higher 32 bits to QueueDriverHigh) notifies the device about location of the Driver Area of the queue selected by writing to QueueSel.
QueueDeviceLow 0x0a0 QueueDeviceHigh 0x0a4 W	Virtual queue's Device Area 64 bit long physical address Writing to these two registers (lower 32 bits of the address to QueueDeviceLow, higher 32 bits to QueueDeviceHigh) notifies the device about location of the Device Area of the queue selected by writing to QueueSel.
SHMSel 0x0ac W	Shared memory id Writing to this register selects the shared memory region 2.10 following operations on SHMLenLow, SHMLenHigh, SHMBaseLow and SHMBaseHigh apply to.
SHMLenLow 0x0b0 SHMLenHigh 0x0b4 R	Shared memory region 64 bit long length These registers return the length of the shared memory region in bytes, as defined by the device for the region selected by the SHMSel register. The lower 32 bits of the length are read from SHMLenLow and the higher 32 bits from SHMLenHigh. Reading from a non-existent region (i.e. where the ID written to SHMSel is unused) results in a length of -1.
SHMBaseLow 0x0b8 SHMBaseHigh 0x0bc R	Shared memory region 64 bit long physical address The driver reads these registers to discover the base address of the region in physical address space. This address is chosen by the device (or other part of the VMM). The lower 32 bits of the address are read from SHMBaseLow with the higher 32 bits from SHMBaseHigh. Reading from a non-existent region (i.e. where the ID written to SHMSel is unused) results in a base address of 0xfffffffffffff.
QueueReset 0x0c0 RW	Virtual queue reset bit  If VIRTIO_F_RING_RESET has been negotiated, writing one (0x1) to this register selectively resets the queue. Both read and write accesses apply to the queue selected by writing to QueueSel.
ConfigGeneration 0x0fc R	Configuration atomicity value Reading from this register returns a value describing a version of the device- specific configuration space (see <i>Config</i> ). The driver can then access the configuration space and, when finished, read <i>ConfigGeneration</i> again. If no part of the configuration space has changed between these two <i>ConfigGeneration</i> reads, the returned values are identical. If the values are different, the configuration space accesses were not atomic and the driver has to perform the operations again. See also 2.5.
Config 0x100+ RW	Configuration space Device-specific configuration space starts at the offset 0x100 and is accessed with byte alignment. Its meaning and size depend on the device and the driver.

#### 4.2.2.1 Device Requirements: MMIO Device Register Layout

The device MUST return 0x74726976 in MagicValue.

The device MUST return value 0x2 in Version.

The device MUST present each event by setting the corresponding bit in *InterruptStatus* from the moment it takes place, until the driver acknowledges the interrupt by writing a corresponding bit mask to the *InterruptACK* register. Bits which do not represent events which took place MUST be zero.

Upon reset, the device MUST clear all bits in *InterruptStatus* and ready bits in the *QueueReady* register for all queues in the device.

The device MUST change value returned in *ConfigGeneration* if there is any risk of a driver seeing an inconsistent configuration state.

The device MUST NOT access virtual queue contents when QueueReady is zero (0x0).

If VIRTIO\_F\_RING\_RESET has been negotiated, the device MUST present a 0 in QueueReset on reset.

If VIRTIO\_F\_RING\_RESET has been negotiated, The device MUST present a 0 in *QueueReset* after the virtqueue is enabled with *QueueReady*.

The device MUST reset the queue when 1 is written to *QueueReset*. The device MUST continue to present 1 in *QueueReset* as long as the queue reset is ongoing. The device MUST present 0 in both *QueueReset* and *QueueReady* when queue reset has completed. (see 2.6.1).

#### 4.2.2.2 Driver Requirements: MMIO Device Register Layout

The driver MUST NOT access memory locations not described in the table 4.1 (or, in case of the configuration space, described in the device specification), MUST NOT write to the read-only registers (direction R) and MUST NOT read from the write-only registers (direction W).

The driver MUST only use 32 bit wide and aligned reads and writes to access the control registers described in table 4.1. For the device-specific configuration space, the driver MUST use 8 bit wide accesses for 8 bit wide fields, 16 bit wide and aligned accesses for 16 bit wide fields and 32 bit wide and aligned accesses for 32 and 64 bit wide fields.

The driver MUST ignore a device with Magic Value which is not 0x74726976, although it MAY report an error.

The driver MUST ignore a device with *Version* which is not 0x2, although it MAY report an error.

The driver MUST ignore a device with DeviceID 0x0, but MUST NOT report any error.

Before reading from DeviceFeatures, the driver MUST write a value to DeviceFeaturesSel.

Before writing to the *DriverFeatures* register, the driver MUST write a value to the *DriverFeaturesSel* register.

The driver MUST write a value to *QueueNum* which is less than or equal to the value presented by the device in *QueueNumMax*.

When QueueReady is not zero, the driver MUST NOT access QueueNum, QueueDescLow, QueueDescHigh, QueueDriverLow, QueueDriverHigh, QueueDeviceLow, QueueDeviceHigh.

To stop using the queue the driver MUST write zero (0x0) to this *QueueReady* and MUST read the value back to ensure synchronization.

The driver MUST ignore undefined bits in *InterruptStatus*.

The driver MUST write a value with a bit mask describing events it handled into *InterruptACK* when it finishes handling an interrupt and MUST NOT set any of the undefined bits in the value.

If VIRTIO\_F\_RING\_RESET has been negotiated, after the driver writes 1 to *QueueReset* to reset the queue, the driver MUST NOT consider queue reset to be complete until it reads back 0 in *QueueReset*. The driver MAY re-enable the queue by writing 1 to *QueueReady* after ensuring that other virtqueue fields have been set up correctly. The driver MAY set driver-writeable queue configuration values to different values than those that were used before the queue reset. (see 2.6.1).

## 4.2.3 MMIO-specific Initialization And Device Operation

#### 4.2.3.1 Device Initialization

#### 4.2.3.1.1 Driver Requirements: Device Initialization

The driver MUST start the device initialization by reading and checking values from *MagicValue* and *Version*. If both values are valid, it MUST read *DeviceID* and if its value is zero (0x0) MUST abort initialization and MUST NOT access any other register.

Drivers not expecting shared memory MUST NOT use the shared memory registers.

Further initialization MUST follow the procedure described in 3.1 Device Initialization.

#### 4.2.3.2 Virtqueue Configuration

The driver will typically initialize the virtual queue in the following way:

- 1. Select the queue writing its index (first queue is 0) to QueueSel.
- 2. Check if the queue is not already in use: read QueueReady, and expect a returned value of zero (0x0).
- 3. Read maximum queue size (number of elements) from *QueueNumMax*. If the returned value is zero (0x0) the queue is not available.
- 4. Allocate and zero the queue memory, making sure the memory is physically contiguous.
- 5. Notify the device about the queue size by writing the size to QueueNum.
- 6. Write physical addresses of the queue's Descriptor Area, Driver Area and Device Area to (respectively) the QueueDescLow/QueueDescHigh, QueueDriverLow/QueueDriverHigh and QueueDeviceLow/QueueDeviceHigh register pairs.
- 7. Write 0x1 to QueueReady.

#### 4.2.3.3 Available Buffer Notifications

When VIRTIO\_F\_NOTIFICATION\_DATA has not been negotiated, the driver sends an available buffer notification to the device by writing the 16-bit virtqueue index of the queue to be notified to *QueueNotify*.

When VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, the driver sends an available buffer notification to the device by writing the following 32-bit value to *QueueNotify*:

```
le32 {
  vqn : 16;
  next_off : 15;
  next_wrap : 1;
};
```

See 2.9 Driver Notifications for the definition of the components.

#### 4.2.3.4 Notifications From The Device

The memory mapped virtio device is using a single, dedicated interrupt signal, which is asserted when at least one of the bits described in the description of *InterruptStatus* is set. This is how the device sends a used buffer notification or a configuration change notification to the device.

## 4.2.3.4.1 Driver Requirements: Notifications From The Device

After receiving an interrupt, the driver MUST read *InterruptStatus* to check what caused the interrupt (see the register description). The used buffer notification bit being set SHOULD be interpreted as a used buffer notification for each active virtqueue. After the interrupt is handled, the driver MUST acknowledge it by writing a bit mask corresponding to the handled events to the InterruptACK register.

## 4.2.4 Legacy interface

The legacy MMIO transport used page-based addressing, resulting in a slightly different control register layout, the device initialization and the virtual queue configuration procedure.

Table 4.2 presents control registers layout, omitting descriptions of registers which did not change their function nor behaviour:

Table 4.2: MMIO Device Legacy Register Layout

Name Offset from base Direction	Function Description
MagicValue 0x000 R	Magic value
Version 0x004 R	Device version number Legacy device returns value 0x1.
DeviceID 0x008 R	Virtio Subsystem Device ID
VendorID 0x00c R	Virtio Subsystem Vendor ID
HostFeatures 0x010 R	Flags representing features the device supports
HostFeaturesSel 0x014 W	Device (host) features word selection.
GuestFeatures 0x020 W	Flags representing device features understood and activated by the driver
GuestFeaturesSel 0x024 W	Activated (guest) features word selection
GuestPageSize 0x028 W	Guest page size  The driver writes the guest page size in bytes to the register during initialization, before any queues are used. This value should be a power of 2 and is used by the device to calculate the Guest address of the first queue page (see QueuePFN).
QueueSel 0x030 W	Virtual queue index Writing to this register selects the virtual queue that the following operations on the QueueNumMax, QueueNum, QueueAlign and QueuePFN registers apply to. The index number of the first queue is zero (0x0).
QueueNumMax 0x034 R	Maximum virtual queue size Reading from the register returns the maximum size of the queue the device is ready to process or zero (0x0) if the queue is not available. This applies to the queue selected by writing to QueueSel and is allowed only when QueuePFN is set to zero (0x0), so when the queue is not actively used.

Name Offset from the base Direction	Function Description
QueueNum 0x038 W	Virtual queue size  Queue size is the number of elements in the queue. Writing to this register notifies the device what size of the queue the driver will use. This applies to the queue selected by writing to QueueSel.
QueueAlign 0x03c W	Used Ring alignment in the virtual queue Writing to this register notifies the device about alignment boundary of the Used Ring in bytes. This value should be a power of 2 and applies to the queue selected by writing to QueueSel.
QueuePFN 0x040 RW	Guest physical page number of the virtual queue Writing to this register notifies the device about location of the virtual queue in the Guest's physical address space. This value is the index number of a page starting with the queue Descriptor Table. Value zero (0x0) means physical address zero (0x00000000) and is illegal. When the driver stops using the queue it writes zero (0x0) to this register. Reading from this register returns the currently used page number of the queue, therefore a value other than zero (0x0) means that the queue is in use. Both read and write accesses apply to the queue selected by writing to <i>QueueSel</i> .
QueueNotify 0x050 W	Queue notifier
InterruptStatus 0x60 R	Interrupt status
InterruptACK 0x064 W	Interrupt acknowledge
Status 0x070 RW	<b>Device status</b> Reading from this register returns the current device status flags. Writing non-zero values to this register sets the status flags, indicating the OS/driver progress. Writing zero (0x0) to this register triggers a device reset. The device sets <i>QueuePFN</i> to zero (0x0) for all queues in the device. Also see 3.1 Device Initialization.
Config 0x100+ RW	Configuration space

The virtual queue page size is defined by writing to *GuestPageSize*, as written by the guest. The driver does this before the virtual queues are configured.

The virtual queue layout follows p. 2.7.2 Legacy Interfaces: A Note on Virtqueue Layout, with the alignment defined in *QueueAlign*.

The virtual queue is configured as follows:

- 1. Select the queue writing its index (first queue is 0) to QueueSel.
- 2. Check if the queue is not already in use: read QueuePFN, expecting a returned value of zero (0x0).
- 3. Read maximum queue size (number of elements) from *QueueNumMax*. If the returned value is zero (0x0) the queue is not available.
- 4. Allocate and zero the queue pages in contiguous virtual memory, aligning the Used Ring to an optimal boundary (usually page size). The driver should choose a queue size smaller than or equal to

QueueNumMax.

- 5. Notify the device about the queue size by writing the size to QueueNum.
- 6. Notify the device about the used alignment by writing its value in bytes to QueueAlign.
- 7. Write the physical number of the first page of the queue to the QueuePFN register.

Notification mechanisms did not change.

## 4.3 Virtio Over Channel I/O

S/390 based virtual machines support neither PCI nor MMIO, so a different transport is needed there.

virtio-ccw uses the standard channel I/O based mechanism used for the majority of devices on S/390. A virtual channel device with a special control unit type acts as proxy to the virtio device (similar to the way virtio-pci uses a PCI device) and configuration and operation of the virtio device is accomplished (mostly) via channel commands. This means virtio devices are discoverable via standard operating system algorithms, and adding virtio support is mainly a question of supporting a new control unit type.

As the S/390 is a big endian machine, the data structures transmitted via channel commands are big-endian: this is made clear by use of the types be16, be32 and be64.

## 4.3.1 Basic Concepts

As a proxy device, virtio-ccw uses a channel-attached I/O control unit with a special control unit type (0x3832) and a control unit model corresponding to the attached virtio device's subsystem device ID, accessed via a virtual I/O subchannel and a virtual channel path of type 0x32. This proxy device is discoverable via normal channel subsystem device discovery (usually a STORE SUBCHANNEL loop) and answers to the basic channel commands:

- NO-OPERATION (0x03)
- BASIC SENSE (0x04)
- TRANSFER IN CHANNEL (0x08)
- SENSE ID (0xe4)

For a virtio-ccw proxy device, SENSE ID will return the following information:

Bytes	Description	Contents
0	reserved	0xff
1-2	control unit type	0x3832
3	control unit model	<virtio device="" id=""></virtio>
4-5	device type	zeroes (unset)
6	device model	zeroes (unset)
7-255	extended Senseld data	zeroes (unset)

A virtio-ccw proxy device facilitates:

- Discovery and attachment of virtio devices (as described above).
- Initialization of virtqueues and transport-specific facilities (using virtio-specific channel commands).
- Notifications (via hypercall and a combination of I/O interrupts and indicator bits).

#### 4.3.1.1 Channel Commands for Virtio

In addition to the basic channel commands, virtio-ccw defines a set of channel commands related to configuration and operation of virtio:

```
#define CCW_CMD_SET_VQ 0x13
#define CCW_CMD_VDEV_RESET 0x33
#define CCW_CMD_SET_IND 0x43
#define CCW_CMD_SET_CONF_IND 0x53
#define CCW_CMD_SET_IND_ADAPTER 0x73
#define CCW_CMD_READ_FEAT 0x12
#define CCW_CMD_WRITE_FEAT 0x11
#define CCW_CMD_WRITE_FEAT 0x11
#define CCW_CMD_READ_CONF 0x22
#define CCW_CMD_WRITE_CONF 0x21
#define CCW_CMD_WRITE_STATUS 0x31
#define CCW_CMD_READ_VQ_CONF 0x32
#define CCW_CMD_SET_VIRTIO_REV 0x83
#define CCW_CMD_READ_STATUS 0x72
```

#### 4.3.1.2 Notifications

Available buffer notifications are realized as a hypercall. No additional setup by the driver is needed. The operation of available buffer notifications is described in section 4.3.3.2.

Used buffer notifications are realized either as so-called classic or adapter I/O interrupts depending on a transport level negotiation. The initialization is described in sections 4.3.2.6.1 and 4.3.2.6.3 respectively. The operation of each flavor is described in sections 4.3.3.1.1 and 4.3.3.1.2 respectively.

Configuration change notifications are done using so-called classic I/O interrupts. The initialization is described in section 4.3.2.6.2 and the operation in section 4.3.3.1.1.

#### 4.3.1.3 Device Requirements: Basic Concepts

The virtio-ccw device acts like a normal channel device, as specified in [S390 PoP] and [S390 Common I/O]. In particular:

- · A device MUST post a unit check with command reject for any command it does not support.
- If a driver did not suppress length checks for a channel command, the device MUST present a subchannel status as detailed in the architecture when the actual length did not match the expected length.
- If a driver did suppress length checks for a channel command, the device MUST present a check
  condition if the transmitted data does not contain enough data to process the command. If the driver
  submitted a buffer that was too long, the device SHOULD accept the command.

#### 4.3.1.4 Driver Requirements: Basic Concepts

A driver for virtio-ccw devices MUST check for a control unit type of 0x3832 and MUST ignore the device type and model.

A driver SHOULD attempt to provide the correct length in a channel command even if it suppresses length checks for that command.

#### 4.3.2 Device Initialization

virtio-ccw uses several channel commands to set up a device.

#### 4.3.2.1 Setting the Virtio Revision

CCW\_CMD\_SET\_VIRTIO\_REV is issued by the driver to set the revision of the virtio-ccw transport it intends to drive the device with. It uses the following communication structure:

```
struct virtio_rev_info {
    bel6 revision;
    bel6 length;
    u8 data[];
};
```

revision contains the desired revision id, *length* the length of the data portion and *data* revision-dependent additional desired options.

The following values are supported:

revision	length	data	remarks
0	0	<empty></empty>	legacy interface; transitional devices only
1	0	<empty></empty>	Virtio 1
2	0	<empty></empty>	CCW_CMD_READ_STATUS support
3-n			reserved for later revisions

Note that a change in the virtio standard does not necessarily correspond to a change in the virtio-ccw revision.

## 4.3.2.1.1 Device Requirements: Setting the Virtio Revision

A device MUST post a unit check with command reject for any *revision* it does not support. For any invalid combination of *revision*, *length* and *data*, it MUST post a unit check with command reject as well. A non-transitional device MUST reject revision id 0.

A device SHOULD answer with command reject to any virtio-ccw specific channel command that is not contained in the revision selected by the driver.

A device MUST answer with command reject to any attempt to select a different revision after a revision has been successfully selected by the driver.

A device MUST treat the revision as unset from the time the associated subchannel has been enabled until a revision has been successfully set by the driver. This implies that revisions are not persistent across disabling and enabling of the associated subchannel.

#### 4.3.2.1.2 Driver Requirements: Setting the Virtio Revision

A driver SHOULD start with trying to set the highest revision it supports and continue with lower revisions if it gets a command reject.

A driver MUST NOT issue any other virtio-ccw specific channel commands prior to setting the revision.

After a revision has been successfully selected by the driver, it MUST NOT attempt to select a different revision.

## 4.3.2.1.3 Legacy Interfaces: A Note on Setting the Virtio Revision

A legacy device will not support the CCW\_CMD\_SET\_VIRTIO\_REV and answer with a command reject. A non-transitional driver MUST stop trying to operate this device in that case. A transitional driver MUST operate the device as if it had been able to set revision 0.

A legacy driver will not issue the CCW\_CMD\_SET\_VIRTIO\_REV prior to issuing other virtio-ccw specific channel commands. A non-transitional device therefore MUST answer any such attempts with a command reject. A transitional device MUST assume in this case that the driver is a legacy driver and continue as if the driver selected revision 0. This implies that the device MUST reject any command not valid for revision 0, including a subsequent CCW\_CMD\_SET\_VIRTIO\_REV.

#### 4.3.2.2 Configuring a Virtqueue

CCW\_CMD\_READ\_VQ\_CONF is issued by the driver to obtain information about a queue. It uses the following structure for communicating:

```
struct vq_config_block {
    be16 index;
    be16 max_num;
};
```

The requested number of buffers for queue *index* is returned in *max\_num*.

Afterwards, CCW\_CMD\_SET\_VQ is issued by the driver to inform the device about the location used for its queue. The transmitted structure is

```
struct vq_info_block {
    be64 desc;
    be32 res0;
    be16 index;
    be16 num;
    be64 driver;
    be64 device;
};
```

desc, driver and device contain the guest addresses for the descriptor area, available area and used area for gueue index, respectively. The actual virtqueue size (number of allocated buffers) is transmitted in num.

#### 4.3.2.2.1 Device Requirements: Configuring a Virtqueue

res0 is reserved and MUST be ignored by the device.

#### 4.3.2.2.2 Legacy Interface: A Note on Configuring a Virtqueue

For a legacy driver or for a driver that selected revision 0, CCW\_CMD\_SET\_VQ uses the following communication block:

```
struct vq_info_block_legacy {
    be64 queue;
    be32 align;
    be16 index;
    be16 num;
};
```

queue contains the guest address for queue *index*, *num* the number of buffers and *align* the alignment. The queue layout follows 2.7.2 Legacy Interfaces: A Note on Virtqueue Layout.

## 4.3.2.3 Communicating Status Information

The driver changes the status of a device via the CCW\_CMD\_WRITE\_STATUS command, which transmits an 8 bit status value.

As described in 2.2.2, a device sometimes fails to set the *device status* field: For example, it might fail to accept the FEATURES\_OK status bit during device initialization.

With revision 2, CCW\_CMD\_READ\_STATUS is defined: It reads an 8 bit status value from the device and acts as a reverse operation to CCW\_CMD\_WRITE\_STATUS.

#### 4.3.2.3.1 Driver Requirements: Communicating Status Information

If the device posts a unit check with command reject in response to the CCW\_CMD\_WRITE\_STATUS command, the driver MUST assume that the device failed to set the status and the *device status* field retained its previous value.

If at least revision 2 has been negotiated, the driver SHOULD use the CCW\_CMD\_READ\_STATUS command to retrieve the *device status* field after a configuration change has been detected.

If not at least revision 2 has been negotiated, the driver MUST NOT attempt to issue the CCW\_CMD\_-READ\_STATUS command.

## 4.3.2.3.2 Device Requirements: Communicating Status Information

If the device fails to set the *device status* field to the value written by the driver, the device MUST assure that the *device status* field is left unchanged and MUST post a unit check with command reject.

If at least revision 2 has been negotiated, the device MUST return the current *device status* field if the CCW CMD READ STATUS command is issued.

#### 4.3.2.4 Handling Device Features

Feature bits are arranged in an array of 32 bit values, making for a total of 8192 feature bits. Feature bits are in little-endian byte order.

The CCW commands dealing with features use the following communication block:

```
struct virtio_feature_desc {
    le32 features;
    u8 index;
};
```

features are the 32 bits of features currently accessed, while *index* describes which of the feature bit values is to be accessed. No padding is added at the end of the structure, it is exactly 5 bytes in length.

The guest obtains the device's device feature set via the CCW\_CMD\_READ\_FEAT command. The device stores the features at *index* to *features*.

For communicating its supported features to the device, the driver uses the CCW\_CMD\_WRITE\_FEAT command, denoting a *features/index* combination.

# 4.3.2.5 Device Configuration

The device's configuration space is located in host memory.

To obtain information from the configuration space, the driver uses CCW\_CMD\_READ\_CONF, specifying the guest memory for the device to write to.

For changing configuration information, the driver uses CCW\_CMD\_WRITE\_CONF, specifying the guest memory for the device to read from.

In both cases, the complete configuration space is transmitted. This allows the driver to compare the new configuration space with the old version, and keep a generation count internally whenever it changes.

## 4.3.2.6 Setting Up Indicators

In order to set up the indicator bits for host->guest notification, the driver uses different channel commands depending on whether it wishes to use traditional I/O interrupts tied to a subchannel or adapter I/O interrupts for virtqueue notifications. For any given device, the two mechanisms are mutually exclusive.

For the configuration change indicators, only a mechanism using traditional I/O interrupts is provided, regardless of whether traditional or adapter I/O interrupts are used for virtqueue notifications.

## 4.3.2.6.1 Setting Up Classic Queue Indicators

Indicators for notification via classic I/O interrupts are contained in a 64 bit value per virtio-ccw proxy device.

To communicate the location of the indicator bits for host->guest notification, the driver uses the CCW\_-CMD\_SET\_IND command, pointing to a location containing the guest address of the indicators in a 64 bit value.

If the driver has already set up two-staged queue indicators via the CCW\_CMD\_SET\_IND\_ADAPTER command, the device MUST post a unit check with command reject to any subsequent CCW\_CMD\_SET\_IND command.

## 4.3.2.6.2 Setting Up Configuration Change Indicators

Indicators for configuration change host->guest notification are contained in a 64 bit value per virtio-ccw proxy device.

To communicate the location of the indicator bits used in the configuration change host->guest notification, the driver issues the CCW\_CMD\_SET\_CONF\_IND command, pointing to a location containing the guest address of the indicators in a 64 bit value.

## 4.3.2.6.3 Setting Up Two-Stage Queue Indicators

Indicators for notification via adapter I/O interrupts consist of two stages:

- a summary indicator byte covering the virtqueues for one or more virtio-ccw proxy devices
- · a set of contigous indicator bits for the virtqueues for a virtio-ccw proxy device

To communicate the location of the summary and queue indicator bits, the driver uses the CCW\_CMD\_-SET\_IND\_ADAPTER command with the following payload:

```
struct virtio_thinint_area {
    be64 summary_indicator;
    be64 indicator;
    be64 bit_nr;
    u8 isc;
} __attribute__ ((packed));
```

summary\_indicator contains the guest address of the 8 bit summary indicator. indicator contains the guest address of an area wherein the indicators for the devices are contained, starting at bit\_nr, one bit per virtqueue of the device. Bit numbers start at the left, i.e. the most significant bit in the first byte is assigned the bit number 0. isc contains the I/O interruption subclass to be used for the adapter I/O interrupt. It MAY be different from the isc used by the proxy virtio-ccw device's subchannel. No padding is added at the end of the structure, it is exactly 25 bytes in length.

## 4.3.2.6.3.1 Device Requirements: Setting Up Two-Stage Queue Indicators

If the driver has already set up classic queue indicators via the CCW\_CMD\_SET\_IND command, the device MUST post a unit check with command reject to any subsequent CCW\_CMD\_SET\_IND\_ADAPTER command.

## 4.3.2.6.4 Legacy Interfaces: A Note on Setting Up Indicators

In some cases, legacy devices will only support classic queue indicators; in that case, they will reject CCW\_-CMD\_SET\_IND\_ADAPTER as they don't know that command. Some legacy devices will support two-stage queue indicators, though, and a driver will be able to successfully use CCW\_CMD\_SET\_IND\_ADAPTER to set them up.

## 4.3.3 Device Operation

## 4.3.3.1 Host->Guest Notification

There are two modes of operation regarding host->guest notification, classic I/O interrupts and adapter I/O interrupts. The mode to be used is determined by the driver by using CCW\_CMD\_SET\_IND respectively CCW\_CMD\_SET\_IND ADAPTER to set up queue indicators.

For configuration changes, the driver always uses classic I/O interrupts.

## 4.3.3.1.1 Notification via Classic I/O Interrupts

If the driver used the CCW\_CMD\_SET\_IND command to set up queue indicators, the device will use classic I/O interrupts for host->guest notification about virtqueue activity.

For notifying the driver of virtqueue buffers, the device sets the corresponding bit in the guest-provided indicators. If an interrupt is not already pending for the subchannel, the device generates an unsolicited I/O interrupt.

If the device wants to notify the driver about configuration changes, it sets bit 0 in the configuration indicators and generates an unsolicited I/O interrupt, if needed. This also applies if adapter I/O interrupts are used for queue notifications.

## 4.3.3.1.2 Notification via Adapter I/O Interrupts

If the driver used the CCW\_CMD\_SET\_IND\_ADAPTER command to set up queue indicators, the device will use adapter I/O interrupts for host->guest notification about virtqueue activity.

For notifying the driver of virtqueue buffers, the device sets the bit in the guest-provided indicator area at the corresponding offset. The guest-provided summary indicator is set to 0x01. An adapter I/O interrupt for the corresponding interruption subclass is generated.

The recommended way to process an adapter I/O interrupt by the driver is as follows:

- Process all queue indicator bits associated with the summary indicator.
- · Clear the summary indicator, performing a synchronization (memory barrier) afterwards.
- · Process all queue indicator bits associated with the summary indicator again.

## 4.3.3.1.2.1 Device Requirements: Notification via Adapter I/O Interrupts

The device SHOULD only generate an adapter I/O interrupt if the summary indicator had not been set prior to notification.

#### 4.3.3.1.2.2 Driver Requirements: Notification via Adapter I/O Interrupts

The driver MUST clear the summary indicator after receiving an adapter I/O interrupt before it processes the queue indicators.

#### 4.3.3.1.3 Legacy Interfaces: A Note on Host->Guest Notification

As legacy devices and drivers support only classic queue indicators, host->guest notification will always be done via classic I/O interrupts.

## 4.3.3.2 Guest->Host Notification

For notifying the device of virtqueue buffers, the driver unfortunately can't use a channel command (the asynchronous characteristics of channel I/O interact badly with the host block I/O backend). Instead, it uses a diagnose 0x500 call with subcode 3 specifying the queue, as follows:

GPR	Input Value	Output Value
1	0x3	
2	Subchannel ID	Host Cookie
3	Notification data	
4	Host Cookie	

When VIRTIO\_F\_NOTIFICATION\_DATA has not been negotiated, the *Notification data* contains the Virtqueue number.

When VIRTIO\_F\_NOTIFICATION\_DATA has been negotiated, the value has the following format:

```
be32 {
  vqn : 16;
  next_off : 15;
  next_wrap : 1;
};
```

See 2.9 Driver Notifications for the definition of the components.

# 4.3.3.2.1 Device Requirements: Guest->Host Notification

The device MUST ignore bits 0-31 (counting from the left) of GPR2. This aligns passing the subchannel ID with the way it is passed for the existing I/O instructions.

The device MAY return a 64-bit host cookie in GPR2 to speed up the notification execution.

#### 4.3.3.2.2 Driver Requirements: Guest->Host Notification

For each notification, the driver SHOULD use GPR4 to pass the host cookie received in GPR2 from the previous notication.

Note: For example:

# 4.3.3.3 Resetting Devices

In order to reset a device, a driver sends the CCW\_CMD\_VDEV\_RESET command. This command does not carry any payload.

The device signals completion of the virtio reset operation through successful conclusion of the CCW\_-CMD\_VDEV\_RESET channel command. In particular, the command not only triggers the reset operation, but the reset operation is already completed when the operation concludes successfully.

## 4.3.3.3.1 Device Requirements: Resetting Devices

The device MUST finish the virtio reset operation and reinitialize *device status* to zero before it concludes the CCW\_CMD\_VDEV\_RESET command successfully.

The device MUST NOT send notifications or interact with the queues after it signaled successful conclusion of the CCW\_CMD\_VDEV\_RESET command.

#### 4.3.3.3.2 Driver Requirements: Resetting Devices

The driver MAY consider the virtio reset operation to be complete already after successful conclusion of the CCW\_CMD\_VDEV\_RESET channel command, although it MAY also choose to verify reset completion by reading *device status* via CCW\_CMD\_READ\_STATUS and checking whether it is 0 afterwards.

# **5 Device Types**

On top of the queues, config space and feature negotiation facilities built into virtio, several devices are defined.

The following device IDs are used to identify different types of virtio devices. Some device IDs are reserved for devices which are not currently defined in this standard.

Discovering what devices are available and their type is bus-dependent.

Device ID	Virtio Device	
0	reserved (invalid)	
1	network card	
2	block device	
3	console	
4	entropy source	
5	memory ballooning (traditional)	
6	ioMemory	
7	rpmsg	
8	SCSI host	
9	9P transport	
10	mac80211 wlan	
11	rproc serial	
12	virtio CAIF	
13	memory balloon	
16	GPU device	
17	Timer/Clock device	
18	Input device	
19	Socket device	
20	Crypto device	
21	Signal Distribution Module	
22	pstore device	
23	IOMMU device	
24	Memory device	
25	Audio device	
26	file system device	
27	PMEM device	
28	RPMB device	
29	mac80211 hwsim wireless simulation device	
30	Video encoder device	
31	Video decoder device	
32	SCMI device	
33	NitroSecureModule	
34	I2C adapter	
35	Watchdog	
36	CAN device	
38	Parameter Server	
39	Audio policy device	
40	Bluetooth device	
41	GPIO device	
42	RDMA device	

Some of the devices above are unspecified by this document, because they are seen as immature or especially niche. Be warned that some are only specified by the sole existing implementation; they could become

part of a future specification, be abandoned entirely, or live on outside this standard. We shall speak of them no further.

# 5.1 Network Device

The virtio network device is a virtual ethernet card, and is the most complex of the devices supported so far by virtio. It has enhanced rapidly and demonstrates clearly how support for new features are added to an existing device. Empty buffers are placed in one virtqueue for receiving packets, and outgoing packets are enqueued into another for transmission in that order. A third command queue is used to control advanced filtering features.

#### 5.1.1 Device ID

1

# 5.1.2 Virtqueues

0 receiveq1

1 transmitq1

. . .

2(N-1) receiveqN

2(N-1)+1 transmitqN

2N controlq

N=1 if neither VIRTIO\_NET\_F\_MQ nor VIRTIO\_NET\_F\_RSS are negotiated, otherwise N is set by *max\_-virtqueue\_pairs*.

controlg only exists if VIRTIO NET F CTRL VQ set.

#### 5.1.3 Feature bits

**VIRTIO\_NET\_F\_CSUM (0)** Device handles packets with partial checksum. This "checksum offload" is a common feature on modern network cards.

VIRTIO\_NET\_F\_GUEST\_CSUM (1) Driver handles packets with partial checksum.

VIRTIO\_NET\_F\_CTRL\_GUEST\_OFFLOADS (2) Control channel offloads reconfiguration support.

**VIRTIO\_NET\_F\_MTU(3)** Device maximum MTU reporting is supported. If offered by the device, device advises driver about the value of its maximum MTU. If negotiated, the driver uses *mtu* as the maximum MTU value.

VIRTIO NET F MAC (5) Device has given MAC address.

VIRTIO NET F GUEST TSO4 (7) Driver can receive TSOv4.

VIRTIO\_NET\_F\_GUEST\_TSO6 (8) Driver can receive TSOv6.

VIRTIO\_NET\_F\_GUEST\_ECN (9) Driver can receive TSO with ECN.

VIRTIO\_NET\_F\_GUEST\_UFO (10) Driver can receive UFO.

VIRTIO\_NET\_F\_HOST\_TSO4 (11) Device can receive TSOv4.

VIRTIO\_NET\_F\_HOST\_TSO6 (12) Device can receive TSOv6.

VIRTIO\_NET\_F\_HOST\_ECN (13) Device can receive TSO with ECN.

VIRTIO\_NET\_F\_HOST\_UFO (14) Device can receive UFO.

**VIRTIO\_NET\_F\_MRG\_RXBUF (15)** Driver can merge receive buffers.

- VIRTIO\_NET\_F\_STATUS (16) Configuration status field is available.
- VIRTIO\_NET\_F\_CTRL\_VQ (17) Control channel is available.
- VIRTIO\_NET\_F\_CTRL\_RX (18) Control channel RX mode support.
- VIRTIO\_NET\_F\_CTRL\_VLAN (19) Control channel VLAN filtering.
- VIRTIO\_NET\_F\_GUEST\_ANNOUNCE(21) Driver can send gratuitous packets.
- VIRTIO\_NET\_F\_MQ(22) Device supports multiqueue with automatic receive steering.
- VIRTIO\_NET\_F\_CTRL\_MAC\_ADDR(23) Set MAC address through control channel.
- VIRTIO\_NET\_F\_HOST\_USO (56) Device can receive USO packets. Unlike UFO (fragmenting the packet) the USO splits large UDP packet to several segments when each of these smaller packets has UDP header.
- **VIRTIO\_NET\_F\_HASH\_REPORT(57)** Device can report per-packet hash value and a type of calculated hash.
- **VIRTIO\_NET\_F\_GUEST\_HDRLEN(59)** Driver can provide the exact *hdr\_len* value. Device benefits from knowing the exact header length.
- **VIRTIO\_NET\_F\_RSS(60)** Device supports RSS (receive-side scaling) with Toeplitz hash calculation and configurable hash parameters for receive steering.
- **VIRTIO\_NET\_F\_RSC\_EXT(61)** Device can process duplicated ACKs and report number of coalesced segments and duplicated ACKs.
- VIRTIO\_NET\_F\_STANDBY(62) Device may act as a standby for a primary device with the same MAC address.
- VIRTIO\_NET\_F\_SPEED\_DUPLEX(63) Device reports speed and duplex.

## 5.1.3.1 Feature bit requirements

Some networking feature bits require other networking feature bits (see 2.2.1):

VIRTIO NET F GUEST TSO4 Requires VIRTIO NET F GUEST CSUM.

VIRTIO\_NET\_F\_GUEST\_TSO6 Requires VIRTIO NET F GUEST CSUM.

VIRTIO\_NET\_F\_GUEST\_ECN Requires VIRTIO\_NET\_F\_GUEST\_TSO4 or VIRTIO\_NET\_F\_GUEST\_TSO6.

VIRTIO\_NET\_F\_GUEST\_UFO Requires VIRTIO\_NET\_F\_GUEST\_CSUM.

VIRTIO\_NET\_F\_HOST\_TSO4 Requires VIRTIO NET F CSUM.

VIRTIO\_NET\_F\_HOST\_TSO6 Requires VIRTIO NET F CSUM.

VIRTIO\_NET\_F\_HOST\_ECN Requires VIRTIO\_NET\_F\_HOST\_TSO4 or VIRTIO\_NET\_F\_HOST\_TSO6.

VIRTIO\_NET\_F\_HOST\_UFO Requires VIRTIO\_NET\_F\_CSUM.

VIRTIO NET F HOST USO Requires VIRTIO NET F CSUM.

VIRTIO\_NET\_F\_CTRL\_RX Requires VIRTIO\_NET F CTRL VQ.

VIRTIO\_NET\_F\_CTRL\_VLAN Requires VIRTIO\_NET\_F\_CTRL\_VQ.

VIRTIO NET F GUEST ANNOUNCE Requires VIRTIO NET F CTRL VQ.

VIRTIO\_NET\_F\_MQ Requires VIRTIO\_NET\_F\_CTRL\_VQ.

VIRTIO\_NET\_F\_CTRL\_MAC\_ADDR Requires VIRTIO NET F CTRL VQ.

VIRTIO\_NET\_F\_RSC\_EXT Requires VIRTIO\_NET\_F\_HOST\_TSO4 or VIRTIO\_NET\_F\_HOST\_TSO6.

VIRTIO\_NET\_F\_RSS Requires VIRTIO NET F CTRL VQ.

#### 5.1.3.2 Legacy Interface: Feature bits

- **VIRTIO\_NET\_F\_GSO (6)** Device handles packets with any GSO type. This was supposed to indicate segmentation offload support, but upon further investigation it became clear that multiple bits were needed.
- **VIRTIO\_NET\_F\_GUEST\_RSC4 (41)** Device coalesces TCPIP v4 packets. This was implemented by hypervisor patch for certification purposes and current Windows driver depends on it. It will not function if virtio-net device reports this feature.
- **VIRTIO\_NET\_F\_GUEST\_RSC6 (42)** Device coalesces TCPIP v6 packets. Similar to VIRTIO\_NET\_F\_-GUEST\_RSC4.

# 5.1.4 Device configuration layout

Device configuration fields are listed below, they are read-only for a driver. The *mac* address field always exists (though is only valid if VIRTIO\_NET\_F\_MAC is set), and *status* only exists if VIRTIO\_NET\_F\_STATUS is set. Two read-only bits (for the driver) are currently defined for the status field: VIRTIO\_NET\_S\_LINK\_UP and VIRTIO\_NET\_S\_ANNOUNCE.

```
#define VIRTIO_NET_S_LINK_UP 1
#define VIRTIO_NET_S_ANNOUNCE 2
```

The following driver-read-only field, <code>max\_virtqueue\_pairs</code> only exists if VIRTIO\_NET\_F\_MQ or VIRTIO\_NET\_F\_RSS is set. This field specifies the maximum number of each of transmit and receive virtqueues (receiveq1...receiveqN and transmitq1...transmitqN respectively) that can be configured once at least one of these features is negotiated.

The following driver-read-only field, *mtu* only exists if VIRTIO\_NET\_F\_MTU is set. This field specifies the maximum MTU for the driver to use.

The following two fields, speed and duplex, only exist if VIRTIO\_NET\_F\_SPEED\_DUPLEX is set.

speed contains the device speed, in units of 1 MBit per second, 0 to 0x7fffffff, or 0xffffffff for unknown speed.

duplex has the values of 0x01 for full duplex, 0x00 for half duplex and 0xff for unknown duplex state.

Both *speed* and *duplex* can change, thus the driver is expected to re-read these values after receiving a configuration change notification.

```
struct virtio_net_config {
    u8 mac[6];
    le16 status;
    le16 max_virtqueue_pairs;
    le16 mtu;
    le32 speed;
    u8 duplex;
    u8 rss_max_key_size;
    le16 rss_max_indirection_table_length;
    le32 supported_hash_types;
};
```

The following field, *rss\_max\_key\_size* only exists if VIRTIO\_NET\_F\_RSS or VIRTIO\_NET\_F\_HASH\_RE-PORT is set. It specifies the maximum supported length of RSS key in bytes.

The following field, *rss\_max\_indirection\_table\_length* only exists if VIRTIO\_NET\_F\_RSS is set. It specifies the maximum number of 16-bit entries in RSS indirection table.

The next field, *supported\_hash\_types* only exists if the device supports hash calculation, i.e. if VIRTIO\_-NET\_F\_RSS or VIRTIO\_NET\_F\_HASH\_REPORT is set.

Field *supported\_hash\_types* contains the bitmask of supported hash types. See 5.1.6.4.3.1 for details of supported hash types.

#### 5.1.4.1 Device Requirements: Device configuration layout

The device MUST set *max\_virtqueue\_pairs* to between 1 and 0x8000 inclusive, if it offers VIRTIO\_NET\_-F\_MQ.

The device MUST set mtu to between 68 and 65535 inclusive, if it offers VIRTIO\_NET\_F\_MTU.

The device SHOULD set mtu to at least 1280, if it offers VIRTIO NET F MTU.

The device MUST NOT modify mtu once it has been set.

The device MUST NOT pass received packets that exceed *mtu* (plus low level ethernet header length) size with *gso\_type* NONE or ECN after VIRTIO\_NET\_F\_MTU has been successfully negotiated.

The device MUST forward transmitted packets of up to *mtu* (plus low level ethernet header length) size with *gso\_type* NONE or ECN, and do so without fragmentation, after VIRTIO\_NET\_F\_MTU has been successfully negotiated.

The device MUST set rss\_max\_key\_size to at least 40, if it offers VIRTIO\_NET\_F\_RSS or VIRTIO\_NET\_-F\_HASH\_REPORT.

The device MUST set rss\_max\_indirection\_table\_length to at least 128, if it offers VIRTIO\_NET\_F\_RSS.

If the driver negotiates the VIRTIO\_NET\_F\_STANDBY feature, the device MAY act as a standby device for a primary device with the same MAC address.

If VIRTIO\_NET\_F\_SPEED\_DUPLEX has been negotiated, *speed* MUST contain the device speed, in units of 1 MBit per second, 0 to 0x7ffffffff, or 0xffffffff for unknown.

If VIRTIO\_NET\_F\_SPEED\_DUPLEX has been negotiated, *duplex* MUST have the values of 0x00 for full duplex, 0x01 for half duplex, or 0xff for unknown.

If VIRTIO\_NET\_F\_SPEED\_DUPLEX and VIRTIO\_NET\_F\_STATUS have both been negotiated, the device SHOULD NOT change the *speed* and *duplex* fields as long as VIRTIO\_NET\_S\_LINK\_UP is set in the *status*.

## 5.1.4.2 Driver Requirements: Device configuration layout

A driver SHOULD negotiate VIRTIO\_NET\_F\_MAC if the device offers it. If the driver negotiates the VIRTIO\_-NET\_F\_MAC feature, the driver MUST set the physical address of the NIC to *mac*. Otherwise, it SHOULD use a locally-administered MAC address (see IEEE 802, "9.2 48-bit universal LAN MAC addresses").

If the driver does not negotiate the VIRTIO\_NET\_F\_STATUS feature, it SHOULD assume the link is active, otherwise it SHOULD read the link status from the bottom bit of *status*.

A driver SHOULD negotiate VIRTIO\_NET\_F\_MTU if the device offers it.

If the driver negotiates VIRTIO\_NET\_F\_MTU, it MUST supply enough receive buffers to receive at least one receive packet of size *mtu* (plus low level ethernet header length) with *qso\_type* NONE or ECN.

If the driver negotiates VIRTIO\_NET\_F\_MTU, it MUST NOT transmit packets of size exceeding the value of *mtu* (plus low level ethernet header length) with *gso\_type* NONE or ECN.

A driver SHOULD negotiate the VIRTIO\_NET\_F\_STANDBY feature if the device offers it.

If VIRTIO\_NET\_F\_SPEED\_DUPLEX has been negotiated, the driver MUST treat any value of *speed* above 0x7fffffff as well as any value of *duplex* not matching 0x00 or 0x01 as an unknown value.

If VIRTIO\_NET\_F\_SPEED\_DUPLEX has been negotiated, the driver SHOULD re-read *speed* and *duplex* after a configuration change notification.

#### 5.1.4.3 Legacy Interface: Device configuration layout

When using the legacy interface, transitional devices and drivers MUST format *status* and *max\_virtqueue\_pairs* in struct virtio\_net\_config according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

When using the legacy interface, *mac* is driver-writable which provided a way for drivers to update the MAC without negotiating VIRTIO\_NET\_F\_CTRL\_MAC\_ADDR.

## 5.1.5 Device Initialization

A driver would perform a typical initialization routine like so:

- 1. Identify and initialize the receive and transmission virtqueues, up to N of each kind. If VIRTIO\_NET\_-F\_MQ feature bit is negotiated, N=max\_virtqueue\_pairs, otherwise identify N=1.
- 2. If the VIRTIO NET F CTRL VQ feature bit is negotiated, identify the control virtqueue.
- 3. Fill the receive queues with buffers: see 5.1.6.3.
- 4. Even with VIRTIO\_NET\_F\_MQ, only receiveq1, transmitq1 and controlq are used by default. The driver would send the VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET command specifying the number of the transmit and receive queues to use.
- If the VIRTIO\_NET\_F\_MAC feature bit is set, the configuration space mac entry indicates the "physical" address of the network card, otherwise the driver would typically generate a random local MAC address.
- 6. If the VIRTIO\_NET\_F\_STATUS feature bit is negotiated, the link status comes from the bottom bit of *status*. Otherwise, the driver assumes it's active.
- A performant driver would indicate that it will generate checksumless packets by negotating the VIR-TIO\_NET\_F\_CSUM feature.
- 8. If that feature is negotiated, a driver can use TCP segmentation or UDP segmentation/fragmentation offload by negotiating the VIRTIO\_NET\_F\_HOST\_TSO4 (IPv4 TCP), VIRTIO\_NET\_F\_HOST\_TSO6 (IPv6 TCP), VIRTIO\_NET\_F\_HOST\_UFO (UDP fragmentation) and VIRTIO\_NET\_F\_HOST\_USO (UDP segmentation) features.
- 9. The converse features are also available: a driver can save the virtual device some work by negotiating these features.

Note: For example, a network packet transported between two guests on the same system might not need checksumming at all, nor segmentation, if both guests are amenable. The VIRTIO\_-NET\_F\_GUEST\_CSUM feature indicates that partially checksummed packets can be received, and if it can do that then the VIRTIO\_NET\_F\_GUEST\_TSO4, VIRTIO\_NET\_F\_GUEST\_TSO6, VIRTIO\_NET\_F\_GUEST\_UFO and VIRTIO\_NET\_F\_GUEST\_ECN are the input equivalents of the features described above. See 5.1.6.3 Setting Up Receive Buffers and 5.1.6.4 Processing of Incoming Packets below.

A truly minimal driver would only accept VIRTIO\_NET\_F\_MAC and ignore everything else.

## 5.1.6 Device Operation

Packets are transmitted by placing them in the transmitq1...transmitqN, and buffers for incoming packets are placed in the receiveq1...receiveqN. In each case, the packet itself is preceded by a header:

```
struct virtio net hdr {
#define VIRTIO NET HDR F NEEDS CSUM
                                         1
#define VIRTIO_NET_HDR_F_DATA_VALID
                                          2
#define VIRTIO NET HDR F RSC INFO
                                          4
       u8 flags;
#define VIRTIO NET HDR GSO NONE
#define VIRTIO NET HDR GSO TCPV4
                                         1
#define VIRTIO NET HDR GSO UDP
                                         3
#define VIRTIO NET HDR GSO TCPV6
                                          4
#define VIRTIO NET HDR GSO UDP L4
                                         5
#define VIRTIO NET HDR GSO ECN
                                      0×80
        u8 gso type;
        le16 hdr_len;
        le16 gso size;
        le16 csum start;
        le16 csum offset;
        le32 hash_value; (Only if VIRTIO_NET_F_HASH_REPORT negotiated)
le16 hash_report; (Only if VIRTIO_NET_E_UBOUTED)
        le16 num buffers;
        le16 padding_reserved; (Only if VIRTIO_NET_F_HASH_REPORT negotiated)
```

The control g is used to control device features such as filtering.

#### 5.1.6.1 Legacy Interface: Device Operation

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_net\_-hdr according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

The legacy driver only presented *num\_buffers* in the struct virtio\_net\_hdr when VIRTIO\_NET\_F\_MRG\_-RXBUF was negotiated; without that feature the structure was 2 bytes shorter.

When using the legacy interface, the driver SHOULD ignore the used length for the transmit queues and the controlq queue.

**Note:** Historically, some devices put the total descriptor length there, even though no data was actually written.

#### 5.1.6.2 Packet Transmission

Transmitting a single packet is simple, but varies depending on the different features the driver negotiated.

- 1. The driver can send a completely checksummed packet. In this case, *flags* will be zero, and *gso\_type* will be VIRTIO\_NET\_HDR\_GSO\_NONE.
- 2. If the driver negotiated VIRTIO NET F CSUM, it can skip checksumming the packet:
  - flags has the VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM set,
  - csum start is set to the offset within the packet to begin checksumming, and
  - csum\_offset indicates how many bytes after the csum\_start the new (16 bit ones' complement) checksum is placed by the device.
  - The TCP checksum field in the packet is set to the sum of the TCP pseudo header, so that replacing it by the ones' complement checksum of the TCP header and body will give the correct result.
  - **Note:** For example, consider a partially checksummed TCP (IPv4) packet. It will have a 14 byte ethernet header and 20 byte IP header followed by the TCP header (with the TCP checksum field 16 bytes into that header). *csum\_start* will be 14+20 = 34 (the TCP checksum includes the header), and *csum\_offset* will be 16.
- 3. If the driver negotiated VIRTIO\_NET\_F\_HOST\_TSO4, TSO6, USO or UFO, and the packet requires TCP segmentation, UDP segmentation or fragmentation, then *gso\_type* is set to VIRTIO\_NET\_HDR\_GSO\_TCPV4, TCPV6, UDP\_L4 or UDP. (Otherwise, it is set to VIRTIO\_NET\_HDR\_GSO\_NONE). In this case, packets larger than 1514 bytes can be transmitted: the metadata indicates how to replicate the packet header to cut it into smaller packets. The other gso fields are set:
  - If the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature has been negotiated, *hdr\_len* indicates the header length that needs to be replicated for each packet. It's the number of bytes from the beginning of the packet to the beginning of the transport payload. Otherwise, if the VIRTIO\_NET\_F\_GUEST\_-HDRLEN feature has not been negotiated, *hdr\_len* is a hint to the device as to how much of the header needs to be kept to copy into each packet, usually set to the length of the headers, including the transport header<sup>1</sup>.

**Note:** Some devices benefit from knowledge of the exact header length.

- gso size is the maximum size of each packet beyond that header (ie. MSS).
- If the driver negotiated the VIRTIO\_NET\_F\_HOST\_ECN feature, the VIRTIO\_NET\_HDR\_GSO\_-ECN bit in gso\_type indicates that the TCP packet has the ECN bit set<sup>2</sup>.

<sup>&</sup>lt;sup>1</sup>Due to various bugs in implementations, this field is not useful as a guarantee of the transport header size.

<sup>&</sup>lt;sup>2</sup>This case is not handled by some older hardware, so is called out specifically in the protocol.

- 4. num buffers is set to zero. This field is unused on transmitted packets.
- 5. The header and packet are added as one output descriptor to the transmitq, and the device is notified of the new entry (see 5.1.5 Device Initialization).

#### 5.1.6.2.1 Driver Requirements: Packet Transmission

The driver MUST set num buffers to zero.

If VIRTIO\_NET\_F\_CSUM is not negotiated, the driver MUST set *flags* to zero and SHOULD supply a fully checksummed packet to the device.

If VIRTIO\_NET\_F\_HOST\_TSO4 is negotiated, the driver MAY set *gso\_type* to VIRTIO\_NET\_HDR\_GSO\_-TCPV4 to request TCPv4 segmentation, otherwise the driver MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR\_GSO\_TCPV4.

If VIRTIO\_NET\_F\_HOST\_TSO6 is negotiated, the driver MAY set *gso\_type* to VIRTIO\_NET\_HDR\_GSO\_-TCPV6 to request TCPv6 segmentation, otherwise the driver MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR\_GSO\_TCPV6.

If VIRTIO\_NET\_F\_HOST\_UFO is negotiated, the driver MAY set *gso\_type* to VIRTIO\_NET\_HDR\_GSO\_-UDP to request UDP fragmentation, otherwise the driver MUST NOT set *gso\_type* to VIRTIO\_NET\_HDR\_-GSO\_UDP.

If VIRTIO\_NET\_F\_HOST\_USO is negotiated, the driver MAY set *gso\_type* to VIRTIO\_NET\_HDR\_GSO\_-UDP\_L4 to request UDP segmentation, otherwise the driver MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR\_GSO\_UDP\_L4.

The driver SHOULD NOT send to the device TCP packets requiring segmentation offload which have the Explicit Congestion Notification bit set, unless the VIRTIO\_NET\_F\_HOST\_ECN feature is negotiated, in which case the driver MUST set the VIRTIO\_NET\_HDR\_GSO\_ECN bit in *gso\_type*.

If the VIRTIO\_NET\_F\_CSUM feature has been negotiated, the driver MAY set the VIRTIO\_NET\_HDR\_F\_-NEEDS\_CSUM bit in *flags*, if so:

- the driver MUST validate the packet checksum at offset csum\_offset from csum\_start as well as all preceding offsets;
- 2. the driver MUST set the packet checksum stored in the buffer to the TCP/UDP pseudo header;
- the driver MUST set csum\_start and csum\_offset such that calculating a ones' complement checksum from csum\_start up until the end of the packet and storing the result at offset csum\_offset from csum\_start will result in a fully checksummed packet;

If none of the VIRTIO\_NET\_F\_HOST\_TSO4, TSO6, USO or UFO options have been negotiated, the driver MUST set *gso type* to VIRTIO NET HDR GSO NONE.

If gso\_type differs from VIRTIO\_NET\_HDR\_GSO\_NONE, then the driver MUST also set the VIRTIO\_NET\_-HDR\_F NEEDS CSUM bit in flags and MUST set gso\_size to indicate the desired MSS.

If one of the VIRTIO\_NET\_F\_HOST\_TSO4, TSO6, USO or UFO options have been negotiated:

- If the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature has been negotiated, and gso\_type differs from VIR-TIO\_NET\_HDR\_GSO\_NONE, the driver MUST set hdr\_len to a value equal to the length of the headers, including the transport header.
- If the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature has not been negotiated, or gso\_type is VIRTIO\_-NET\_HDR\_GSO\_NONE, the driver SHOULD set hdr\_len to a value not less than the length of the headers, including the transport header.

The driver SHOULD accept the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature if it has been offered, and if it's able to provide the exact header length.

The driver MUST NOT set the VIRTIO\_NET\_HDR\_F\_DATA\_VALID and VIRTIO\_NET\_HDR\_F\_RSC\_INFO bits in *flags*.

# 5.1.6.2.2 Device Requirements: Packet Transmission

The device MUST ignore *flag* bits that it does not recognize.

If VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM bit in *flags* is not set, the device MUST NOT use the *csum\_start* and *csum\_offset*.

If one of the VIRTIO\_NET\_F\_HOST\_TSO4, TSO6, USO or UFO options have been negotiated:

• If the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature has been negotiated, and *gso\_type* differs from VIR-TIO\_NET\_HDR\_GSO\_NONE, the device MAY use *hdr\_len* as the transport header size.

**Note:** Caution should be taken by the implementation so as to prevent a malicious driver from attacking the device by setting an incorrect hdr\_len.

• If the VIRTIO\_NET\_F\_GUEST\_HDRLEN feature has not been negotiated, or *gso\_type* is VIRTIO\_-NET\_HDR\_GSO\_NONE, the device MAY use *hdr\_len* only as a hint about the transport header size. The device MUST NOT rely on *hdr\_len* to be correct.

Note: This is due to various bugs in implementations.

If VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM is not set, the device MUST NOT rely on the packet checksum being correct.

## 5.1.6.2.3 Packet Transmission Interrupt

Often a driver will suppress transmission virtqueue interrupts and check for used packets in the transmit path of following packets.

The normal behavior in this interrupt handler is to retrieve used buffers from the virtqueue and free the corresponding headers and packets.

## 5.1.6.3 Setting Up Receive Buffers

It is generally a good idea to keep the receive virtqueue as fully populated as possible: if it runs out, network performance will suffer.

If the VIRTIO\_NET\_F\_GUEST\_TSO4, VIRTIO\_NET\_F\_GUEST\_TSO6 or VIRTIO\_NET\_F\_GUEST\_UFO features are used, the maximum incoming packet will be to 65550 bytes long (the maximum size of a TCP or UDP packet, plus the 14 byte ethernet header), otherwise 1514 bytes. The 12-byte struct virtio\_net\_hdr is prepended to this, making for 65562 or 1526 bytes.

# 5.1.6.3.1 Driver Requirements: Setting Up Receive Buffers

- If VIRTIO\_NET\_F\_MRG\_RXBUF is not negotiated:
  - If VIRTIO\_NET\_F\_GUEST\_TSO4, VIRTIO\_NET\_F\_GUEST\_TSO6 or VIRTIO\_NET\_F\_GUEST\_-UFO are negotiated, the driver SHOULD populate the receive queue(s) with buffers of at least 65562 bytes.
  - Otherwise, the driver SHOULD populate the receive queue(s) with buffers of at least 1526 bytes.
- If VIRTIO\_NET\_F\_MRG\_RXBUF is negotiated, each buffer MUST be at least the size of the struct virtio\_net\_hdr.

**Note:** Obviously each buffer can be split across multiple descriptor elements.

If VIRTIO\_NET\_F\_MQ is negotiated, each of receiveq1...receiveqN that will be used SHOULD be populated with receive buffers.

## 5.1.6.3.2 Device Requirements: Setting Up Receive Buffers

The device MUST set *num\_buffers* to the number of descriptors used to hold the incoming packet.

The device MUST use only a single descriptor if VIRTIO NET F MRG RXBUF was not negotiated.

Note: This means that num buffers will always be 1 if VIRTIO NET F MRG RXBUF is not negotiated.

## **5.1.6.4** Processing of Incoming Packets

When a packet is copied into a buffer in the received, the optimal path is to disable further used buffer notifications for the received and process packets until no more are found, then re-enable them.

Processing incoming packets involves:

- 1. num\_buffers indicates how many descriptors this packet is spread over (including this one): this will always be 1 if VIRTIO\_NET\_F\_MRG\_RXBUF was not negotiated. This allows receipt of large packets without having to allocate large buffers: a packet that does not fit in a single buffer can flow over to the next buffer, and so on. In this case, there will be at least num\_buffers used buffers in the virtqueue, and the device chains them together to form a single packet in a way similar to how it would store it in a single buffer spread over multiple descriptors. The other buffers will not begin with a struct virtio net hdr.
- 2. If *num\_buffers* is one, then the entire packet will be contained within this buffer, immediately following the struct virtio\_net\_hdr.
- 3. If the VIRTIO\_NET\_F\_GUEST\_CSUM feature was negotiated, the VIRTIO\_NET\_HDR\_F\_DATA\_VALID bit in *flags* can be set: if so, device has validated the packet checksum. In case of multiple encapsulated protocols, one level of checksums has been validated.

Additionally, VIRTIO\_NET\_F\_GUEST\_CSUM, TSO4, TSO6, UDP and ECN features enable receive checksum, large receive offload and ECN support which are the input equivalents of the transmit checksum, transmit segmentation offloading and ECN features, as described in 5.1.6.2:

- If the VIRTIO\_NET\_F\_GUEST\_TSO4, TSO6 or UFO options were negotiated, then gso\_type MAY be something other than VIRTIO\_NET\_HDR\_GSO\_NONE, and gso\_size field indicates the desired MSS (see Packet Transmission point 2).
- If the VIRTIO\_NET\_F\_RSC\_EXT option was negotiated (this implies one of VIRTIO\_NET\_F\_GUEST\_-TSO4, TSO6), the device processes also duplicated ACK segments, reports number of coalesced TCP segments in *csum\_start* field and number of duplicated ACK segments in *csum\_offset* field and sets bit VIRTIO\_NET\_HDR\_F\_RSC\_INFO in *flags*.
- 3. If the VIRTIO\_NET\_F\_GUEST\_CSUM feature was negotiated, the VIRTIO\_NET\_HDR\_F\_NEEDS\_-CSUM bit in flags can be set: if so, the packet checksum at offset csum\_offset from csum\_start and any preceding checksums have been validated. The checksum on the packet is incomplete and if bit VIRTIO\_NET\_HDR\_F\_RSC\_INFO is not set in flags, then csum\_start and csum\_offset indicate how to calculate it (see Packet Transmission point 1).

If applicable, the device calculates per-packet hash for incoming packets as defined in 5.1.6.4.3.

If applicable, the device reports hash information for incoming packets as defined in 5.1.6.4.4.

## 5.1.6.4.1 Device Requirements: Processing of Incoming Packets

If VIRTIO\_NET\_F\_MRG\_RXBUF has not been negotiated, the device MUST set num\_buffers to 1.

If VIRTIO\_NET\_F\_MRG\_RXBUF has been negotiated, the device MUST set *num\_buffers* to indicate the number of buffers the packet (including the header) is spread over.

If a receive packet is spread over multiple buffers, the device MUST use all buffers but the last (i.e. the first num\_buffers - 1 buffers) completely up to the full length of each buffer supplied by the driver.

The device MUST use all buffers used by a single receive packet together, such that at least *num\_buffers* are observed by driver as used.

If VIRTIO\_NET\_F\_GUEST\_CSUM is not negotiated, the device MUST set *flags* to zero and SHOULD supply a fully checksummed packet to the driver.

If VIRTIO\_NET\_F\_GUEST\_TSO4 is not negotiated, the device MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR\_GSO\_TCPV4.

If VIRTIO\_NET\_F\_GUEST\_UDP is not negotiated, the device MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR GSO UDP.

If VIRTIO\_NET\_F\_GUEST\_TSO6 is not negotiated, the device MUST NOT set *gso\_type* to VIRTIO\_NET\_-HDR\_GSO\_TCPV6.

The device SHOULD NOT send to the driver TCP packets requiring segmentation offload which have the Explicit Congestion Notification bit set, unless the VIRTIO\_NET\_F\_GUEST\_ECN feature is negotiated, in which case the device MUST set the VIRTIO\_NET\_HDR\_GSO\_ECN bit in *gso\_type*.

If the VIRTIO\_NET\_F\_GUEST\_CSUM feature has been negotiated, the device MAY set the VIRTIO\_NET\_-HDR\_F\_NEEDS\_CSUM bit in *flags*, if so:

- 1. the device MUST validate the packet checksum at offset csum\_offset from csum\_start as well as all preceding offsets;
- 2. the device MUST set the packet checksum stored in the receive buffer to the TCP/UDP pseudo header;
- the device MUST set csum\_start and csum\_offset such that calculating a ones' complement checksum from csum\_start up until the end of the packet and storing the result at offset csum\_offset from csum\_start will result in a fully checksummed packet;

If none of the VIRTIO\_NET\_F\_GUEST\_TSO4, TSO6 or UFO options have been negotiated, the device MUST set *gso\_type* to VIRTIO\_NET\_HDR\_GSO\_NONE.

If gso\_type differs from VIRTIO\_NET\_HDR\_GSO\_NONE, then the device MUST also set the VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM bit in flags MUST set gso\_size to indicate the desired MSS. If VIRTIO\_NET\_F\_RSC\_EXT was negotiated, the device MUST also set VIRTIO\_NET\_HDR\_F\_RSC\_INFO bit in flags, set csum\_start to number of coalesced TCP segments and set csum\_offset to number of received duplicated ACK segments.

If VIRTIO\_NET\_F\_RSC\_EXT was not negotiated, the device MUST not set VIRTIO\_NET\_HDR\_F\_RSC\_-INFO bit in *flags*.

If one of the VIRTIO\_NET\_F\_GUEST\_TSO4, TSO6 or UFO options have been negotiated, the device SHOULD set *hdr\_len* to a value not less than the length of the headers, including the transport header.

If the VIRTIO\_NET\_F\_GUEST\_CSUM feature has been negotiated, the device MAY set the VIRTIO\_NET\_-HDR\_F\_DATA\_VALID bit in *flags*, if so, the device MUST validate the packet checksum (in case of multiple encapsulated protocols, one level of checksums is validated).

## 5.1.6.4.2 Driver Requirements: Processing of Incoming Packets

The driver MUST ignore *flag* bits that it does not recognize.

If VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM bit in *flags* is not set or if VIRTIO\_NET\_HDR\_F\_RSC\_INFO bit *flags* is set, the driver MUST NOT use the *csum start* and *csum offset*.

If one of the VIRTIO\_NET\_F\_GUEST\_TSO4, TSO6 or UFO options have been negotiated, the driver MAY use *hdr\_len* only as a hint about the transport header size. The driver MUST NOT rely on *hdr\_len* to be correct.

Note: This is due to various bugs in implementations.

If neither VIRTIO\_NET\_HDR\_F\_NEEDS\_CSUM nor VIRTIO\_NET\_HDR\_F\_DATA\_VALID is set, the driver MUST NOT rely on the packet checksum being correct.

# 5.1.6.4.3 Hash calculation for incoming packets

A device attempts to calculate a per-packet hash in the following cases:

• The feature VIRTIO\_NET\_F\_RSS was negotiated. The device uses the hash to determine the receive virtqueue to place incoming packets.

• The feature VIRTIO\_NET\_F\_HASH\_REPORT was negotiated. The device reports the hash value and the hash type with the packet.

If the feature VIRTIO\_NET\_F\_RSS was negotiated:

- The device uses hash\_types of the virtio\_net\_rss\_config structure as 'Enabled hash types' bitmask.
- The device uses a key as defined in hash\_key\_data and hash\_key\_length of the virtio\_net\_rss\_config structure (see 5.1.6.5.7.1).

If the feature VIRTIO\_NET\_F\_RSS was not negotiated:

- The device uses <code>hash\_types</code> of the virtio\_net\_hash\_config structure as 'Enabled hash types' bitmask.
- The device uses a key as defined in hash\_key\_data and hash\_key\_length of the virtio\_net\_hash\_config structure (see 5.1.6.5.6.4).

Note that if the device offers VIRTIO\_NET\_F\_HASH\_REPORT, even if it supports only one pair of virtqueues, it MUST support at least one of commands of VIRTIO\_NET\_CTRL\_MQ class to configure reported hash parameters:

- If the device offers VIRTIO\_NET\_F\_RSS, it MUST support VIRTIO\_NET\_CTRL\_MQ\_RSS\_CONFIG command per 5.1.6.5.7.1.
- Otherwise the device MUST support VIRTIO\_NET\_CTRL\_MQ\_HASH\_CONFIG command per 5.1.6.5.6.4.

## 5.1.6.4.3.1 Supported/enabled hash types

Hash types applicable for IPv4 packets:

```
#define VIRTIO_NET_HASH_TYPE_IPv4 (1 << 0)
#define VIRTIO_NET_HASH_TYPE_TCPv4 (1 << 1)
#define VIRTIO_NET_HASH_TYPE_UDPv4 (1 << 2)
```

## Hash types applicable for IPv6 packets without extension headers

```
#define VIRTIO_NET_HASH_TYPE_IPv6 (1 << 3)
#define VIRTIO_NET_HASH_TYPE_TCPv6 (1 << 4)
#define VIRTIO_NET_HASH_TYPE_UDPv6 (1 << 5)
```

#### Hash types applicable for IPv6 packets with extension headers

```
#define VIRTIO_NET_HASH_TYPE_IP_EX (1 << 6)
#define VIRTIO_NET_HASH_TYPE_TCP_EX (1 << 7)
#define VIRTIO_NET_HASH_TYPE_UDP_EX (1 << 8)
```

#### 5.1.6.4.3.2 IPv4 packets

The device calculates the hash on IPv4 packets according to 'Enabled hash types' bitmask as follows:

- If VIRTIO\_NET\_HASH\_TYPE\_TCPv4 is set and the packet has a TCP header, the hash is calculated over the following fields:
  - Source IP address
  - Destination IP address
  - Source TCP port
  - Destination TCP port
- Else if VIRTIO\_NET\_HASH\_TYPE\_UDPv4 is set and the packet has a UDP header, the hash is calculated over the following fields:
  - Source IP address
  - Destination IP address

- Source UDP port
- Destination UDP port
- Else if VIRTIO\_NET\_HASH\_TYPE\_IPv4 is set, the hash is calculated over the following fields:
  - Source IP address
  - Destination IP address
- Else the device does not calculate the hash

#### 5.1.6.4.3.3 IPv6 packets without extension header

The device calculates the hash on IPv6 packets without extension headers according to 'Enabled hash types' bitmask as follows:

- If VIRTIO\_NET\_HASH\_TYPE\_TCPv6 is set and the packet has a TCPv6 header, the hash is calculated over the following fields:
  - Source IPv6 address
  - Destination IPv6 address
  - Source TCP port
  - Destination TCP port
- Else if VIRTIO\_NET\_HASH\_TYPE\_UDPv6 is set and the packet has a UDPv6 header, the hash is calculated over the following fields:
  - Source IPv6 address
  - Destination IPv6 address
  - Source UDP port
  - Destination UDP port
- Else if VIRTIO NET HASH TYPE IPv6 is set, the hash is calculated over the following fields:
  - Source IPv6 address
  - Destination IPv6 address
- · Else the device does not calculate the hash

#### 5.1.6.4.3.4 IPv6 packets with extension header

The device calculates the hash on IPv6 packets with extension headers according to 'Enabled hash types' bitmask as follows:

- If VIRTIO\_NET\_HASH\_TYPE\_TCP\_EX is set and the packet has a TCPv6 header, the hash is calculated over the following fields:
  - Home address from the home address option in the IPv6 destination options header. If the extension header is not present, use the Source IPv6 address.
  - IPv6 address that is contained in the Routing-Header-Type-2 from the associated extension header.
     If the extension header is not present, use the Destination IPv6 address.
  - Source TCP port
  - Destination TCP port
- Else if VIRTIO\_NET\_HASH\_TYPE\_UDP\_EX is set and the packet has a UDPv6 header, the hash is calculated over the following fields:
  - Home address from the home address option in the IPv6 destination options header. If the extension header is not present, use the Source IPv6 address.

- IPv6 address that is contained in the Routing-Header-Type-2 from the associated extension header.
   If the extension header is not present, use the Destination IPv6 address.
- Source UDP port
- Destination UDP port
- Else if VIRTIO\_NET\_HASH\_TYPE\_IP\_EX is set, the hash is calculated over the following fields:
  - Home address from the home address option in the IPv6 destination options header. If the extension header is not present, use the Source IPv6 address.
  - IPv6 address that is contained in the Routing-Header-Type-2 from the associated extension header.
     If the extension header is not present, use the Destination IPv6 address.
- Else skip IPv6 extension headers and calculate the hash as defined for an IPv6 packet without extension headers (see 5.1.6.4.3.3).

## 5.1.6.4.4 Hash reporting for incoming packets

If VIRTIO\_NET\_F\_HASH\_REPORT was negotiated and the device has calculated the hash for the packet, the device fills <code>hash\_report</code> with the report type of calculated hash and <code>hash\_value</code> with the value of calculated hash.

If VIRTIO\_NET\_F\_HASH\_REPORT was negotiated but due to any reason the hash was not calculated, the device sets <code>hash\_report</code> to VIRTIO\_NET\_HASH\_REPORT\_NONE.

Possible values that the device can report in *hash\_report* are defined below. They correspond to supported hash types defined in 5.1.6.4.3.1 as follows:

VIRTIO\_NET\_HASH\_TYPE\_XXX = 1 « (VIRTIO\_NET\_HASH\_REPORT\_XXX - 1)

```
#define VIRTIO NET HASH REPORT NONE
#define VIRTIO NET HASH REPORT IPv4
                                               1
#define VIRTIO NET HASH REPORT TCPv4
#define VIRTIO NET HASH REPORT UDPv4
                                               3
#define VIRTIO_NET_HASH_REPORT_IPv6
                                               4
#define VIRTIO NET HASH REPORT TCPv6
                                               5
#define VIRTIO NET HASH REPORT UDPv6
                                               6
#define VIRTIO NET HASH REPORT IPv6 EX
#define VIRTIO NET HASH REPORT TCPv6 EX
                                               8
#define VIRTIO NET HASH REPORT UDPv6 EX
```

# 5.1.6.5 Control Virtqueue

The driver uses the control virtqueue (if VIRTIO\_NET\_F\_CTRL\_VQ is negotiated) to send commands to manipulate various features of the device which would not easily map into the configuration space.

All commands are of the following form:

The *class*, *command* and command-specific-data are set by the driver, and the device sets the *ack* byte. There is little it can do except issue a diagnostic if *ack* is not VIRTIO\_NET\_OK.

## 5.1.6.5.1 Packet Receive Filtering

If the VIRTIO\_NET\_F\_CTRL\_RX and VIRTIO\_NET\_F\_CTRL\_RX\_EXTRA features are negotiated, the driver can send control commands for promiscuous mode, multicast, unicast and broadcast receiving.

Note: In general, these commands are best-effort: unwanted packets could still arrive.

```
#define VIRTIO_NET_CTRL_RX 0

#define VIRTIO_NET_CTRL_RX_PROMISC 0

#define VIRTIO_NET_CTRL_RX_ALLMULTI 1

#define VIRTIO_NET_CTRL_RX_ALLUNI 2

#define VIRTIO_NET_CTRL_RX_NOMULTI 3

#define VIRTIO_NET_CTRL_RX_NOUNI 4

#define VIRTIO_NET_CTRL_RX_NOBCAST 5
```

## 5.1.6.5.1.1 Device Requirements: Packet Receive Filtering

If the VIRTIO\_NET\_F\_CTRL\_RX feature has been negotiated, the device MUST support the following VIRTIO NET CTRL RX class commands:

- VIRTIO\_NET\_CTRL\_RX\_PROMISC turns promiscuous mode on and off. The command-specific-data
  is one byte containing 0 (off) or 1 (on). If promiscous mode is on, the device SHOULD receive all
  incoming packets. This SHOULD take effect even if one of the other modes set by a VIRTIO\_NET\_CTRL\_RX class command is on.
- VIRTIO\_NET\_CTRL\_RX\_ALLMULTI turns all-multicast receive on and off. The command-specificdata is one byte containing 0 (off) or 1 (on). When all-multicast receive is on the device SHOULD allow all incoming multicast packets.

If the VIRTIO\_NET\_F\_CTRL\_RX\_EXTRA feature has been negotiated, the device MUST support the following VIRTIO\_NET\_CTRL\_RX class commands:

- VIRTIO\_NET\_CTRL\_RX\_ALLUNI turns all-unicast receive on and off. The command-specific-data is
  one byte containing 0 (off) or 1 (on). When all-unicast receive is on the device SHOULD allow all
  incoming unicast packets.
- VIRTIO\_NET\_CTRL\_RX\_NOMULTI suppresses multicast receive. The command-specific-data is one
  byte containing 0 (multicast receive allowed) or 1 (multicast receive suppressed). When multicast receive is suppressed, the device SHOULD NOT send multicast packets to the driver. This SHOULD take
  effect even if VIRTIO\_NET\_CTRL\_RX\_ALLMULTI is on. This filter SHOULD NOT apply to broadcast
  packets.
- VIRTIO\_NET\_CTRL\_RX\_NOUNI suppresses unicast receive. The command-specific-data is one byte
  containing 0 (unicast receive allowed) or 1 (unicast receive suppressed). When unicast receive is
  suppressed, the device SHOULD NOT send unicast packets to the driver. This SHOULD take effect
  even if VIRTIO\_NET\_CTRL\_RX\_ALLUNI is on.
- VIRTIO\_NET\_CTRL\_RX\_NOBCAST suppresses broadcast receive. The command-specific-data is
  one byte containing 0 (broadcast receive allowed) or 1 (broadcast receive suppressed). When broadcast receive is suppressed, the device SHOULD NOT send broadcast packets to the driver. This
  SHOULD take effect even if VIRTIO\_NET\_CTRL\_RX\_ALLMULTI is on.

#### 5.1.6.5.1.2 Driver Requirements: Packet Receive Filtering

If the VIRTIO\_NET\_F\_CTRL\_RX feature has not been negotiated, the driver MUST NOT issue commands VIRTIO\_NET\_CTRL\_RX\_PROMISC or VIRTIO\_NET\_CTRL\_RX\_ALLMULTI.

If the VIRTIO\_NET\_F\_CTRL\_RX\_EXTRA feature has not been negotiated, the driver MUST NOT issue commands VIRTIO\_NET\_CTRL\_RX\_ALLUNI, VIRTIO\_NET\_CTRL\_RX\_NOMULTI, VIRTIO\_NET\_CTRL\_-RX\_NOUNI or VIRTIO\_NET\_CTRL\_RX\_NOBCAST.

## 5.1.6.5.2 Setting MAC Address Filtering

If the VIRTIO\_NET\_F\_CTRL\_RX feature is negotiated, the driver can send control commands for MAC address filtering.

The device can filter incoming packets by any number of destination MAC addresses<sup>3</sup>. This table is set using the class VIRTIO\_NET\_CTRL\_MAC and the command VIRTIO\_NET\_CTRL\_MAC\_TABLE\_SET. The command-specific-data is two variable length tables of 6-byte MAC addresses (as described in struct virtio\_net ctrl mac). The first table contains unicast addresses, and the second contains multicast addresses.

The VIRTIO\_NET\_CTRL\_MAC\_ADDR\_SET command is used to set the default MAC address which rx filtering accepts (and if VIRTIO\_NET\_F\_MAC has been negotiated, this will be reflected in *mac* in config space).

The command-specific-data for VIRTIO\_NET\_CTRL\_MAC\_ADDR\_SET is the 6-byte MAC address.

## 5.1.6.5.2.1 Device Requirements: Setting MAC Address Filtering

The device MUST have an empty MAC filtering table on reset.

The device MUST update the MAC filtering table before it consumes the VIRTIO\_NET\_CTRL\_MAC\_TA-BLE SET command.

The device MUST update *mac* in config space before it consumes the VIRTIO\_NET\_CTRL\_MAC\_ADDR\_-SET command, if VIRTIO\_NET\_F\_MAC has been negotiated.

The device SHOULD drop incoming packets which have a destination MAC which matches neither the *mac* (or that set with VIRTIO\_NET\_CTRL\_MAC\_ADDR\_SET) nor the MAC filtering table.

#### 5.1.6.5.2.2 Driver Requirements: Setting MAC Address Filtering

If VIRTIO\_NET\_F\_CTRL\_RX has not been negotiated, the driver MUST NOT issue VIRTIO\_NET\_CTRL\_-MAC class commands.

If VIRTIO\_NET\_F\_CTRL\_RX has been negotiated, the driver SHOULD issue VIRTIO\_NET\_CTRL\_MAC\_-ADDR\_SET to set the default mac if it is different from *mac*.

The driver MUST follow the VIRTIO\_NET\_CTRL\_MAC\_TABLE\_SET command by a le32 number, followed by that number of non-multicast MAC addresses, followed by another le32 number, followed by that number of multicast addresses. Either number MAY be 0.

# 5.1.6.5.2.3 Legacy Interface: Setting MAC Address Filtering

When using the legacy interface, transitional devices and drivers MUST format *entries* in struct virtio\_net\_-ctrl\_mac according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

Legacy drivers that didn't negotiate VIRTIO\_NET\_F\_CTRL\_MAC\_ADDR changed *mac* in config space when NIC is accepting incoming packets. These drivers always wrote the mac value from first to last byte, therefore after detecting such drivers, a transitional device MAY defer MAC update, or MAY defer processing incoming packets until driver writes the last byte of *mac* in the config space.

<sup>&</sup>lt;sup>3</sup>Since there are no guarantees, it can use a hash filter or silently switch to allmulti or promiscuous mode if it is given too many addresses.

#### 5.1.6.5.3 VLAN Filtering

If the driver negotiates the VIRTIO\_NET\_F\_CTRL\_VLAN feature, it can control a VLAN filter table in the device.

**Note:** Similar to the MAC address based filtering, the VLAN filtering is also best-effort: unwanted packets could still arrive.

```
#define VIRTIO_NET_CTRL_VLAN 2
#define VIRTIO_NET_CTRL_VLAN_ADD 0
#define VIRTIO_NET_CTRL_VLAN_DEL 1
```

Both the VIRTIO\_NET\_CTRL\_VLAN\_ADD and VIRTIO\_NET\_CTRL\_VLAN\_DEL command take a little-endian 16-bit VLAN id as the command-specific-data.

## 5.1.6.5.3.1 Legacy Interface: VLAN Filtering

When using the legacy interface, transitional devices and drivers MUST format the VLAN id according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.1.6.5.4 Gratuitous Packet Sending

If the driver negotiates the VIRTIO\_NET\_F\_GUEST\_ANNOUNCE (depends on VIRTIO\_NET\_F\_CTRL\_-VQ), the device can ask the driver to send gratuitous packets; this is usually done after the guest has been physically migrated, and needs to announce its presence on the new network links. (As hypervisor does not have the knowledge of guest network configuration (eg. tagged vlan) it is simplest to prod the guest in this way).

```
#define VIRTIO_NET_CTRL_ANNOUNCE 3
#define VIRTIO_NET_CTRL_ANNOUNCE_ACK 0
```

The driver checks VIRTIO\_NET\_S\_ANNOUNCE bit in the device configuration *status* field when it notices the changes of device configuration. The command VIRTIO\_NET\_CTRL\_ANNOUNCE\_ACK is used to indicate that driver has received the notification and device clears the VIRTIO\_NET\_S\_ANNOUNCE bit in *status*.

Processing this notification involves:

- 1. Sending the gratuitous packets (eg. ARP) or marking there are pending gratuitous packets to be sent and letting deferred routine to send them.
- 2. Sending VIRTIO\_NET\_CTRL\_ANNOUNCE\_ACK command through control vq.

#### 5.1.6.5.4.1 Driver Requirements: Gratuitous Packet Sending

If the driver negotiates VIRTIO\_NET\_F\_GUEST\_ANNOUNCE, it SHOULD notify network peers of its new location after it sees the VIRTIO\_NET\_S\_ANNOUNCE bit in *status*. The driver MUST send a command on the command queue with class VIRTIO\_NET\_CTRL\_ANNOUNCE and command VIRTIO\_NET\_CTRL\_-ANNOUNCE\_ACK.

#### 5.1.6.5.4.2 Device Requirements: Gratuitous Packet Sending

If VIRTIO\_NET\_F\_GUEST\_ANNOUNCE is negotiated, the device MUST clear the VIRTIO\_NET\_S\_ANNOUNCE bit in *status* upon receipt of a command buffer with class VIRTIO\_NET\_CTRL\_ANNOUNCE and command VIRTIO\_NET\_CTRL\_ANNOUNCE\_ACK before marking the buffer as used.

#### 5.1.6.5.5 Device operation in multiqueue mode

This specification defines the following modes that a device MAY implement for operation with multiple transmit/receive virtqueues:

- Automatic receive steering as defined in 5.1.6.5.6. If a device supports this mode, it offers the VIRTIO\_-NET F MQ feature bit.
- Receive-side scaling as defined in 5.1.6.5.7.3. If a device supports this mode, it offers the VIRTIO\_-NET\_F\_RSS feature bit.

A device MAY support one of these features or both. The driver MAY negotiate any set of these features that the device supports.

Multiqueue is disabled by default.

The driver enables multiqueue by sending a command using *class* VIRTIO\_NET\_CTRL\_MQ. The *command* selects the mode of multiqueue operation, as follows:

```
#define VIRTIO_NET_CTRL_MQ 4

#define VIRTIO_NET_CTRL_MQ_VQ_PAIRS_SET 0 (for automatic receive steering)

#define VIRTIO_NET_CTRL_MQ_RSS_CONFIG 1 (for configurable receive steering)

#define VIRTIO_NET_CTRL_MQ_HASH_CONFIG 2 (for configurable hash calculation)
```

If more than one multiqueue mode is negotiated, the resulting device configuration is defined by the last command sent by the driver.

## 5.1.6.5.6 Automatic receive steering in multiqueue mode

If the driver negotiates the VIRTIO\_NET\_F\_MQ feature bit (depends on VIRTIO\_NET\_F\_CTRL\_VQ), it MAY transmit outgoing packets on one of the multiple transmitq1...transmitqN and ask the device to queue incoming packets into one of the multiple receiveq1...receiveqN depending on the packet flow.

The driver enables multiqueue by sending the VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET command, specifying the number of the transmit and receive queues to be used up to *max\_virtqueue\_pairs*; subsequently, transmitq1...transmitqn and receiveq1...receiveqn where n=*virtqueue\_pairs* MAY be used.

When multiqueue is enabled by VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET command, the device MUST use automatic receive steering based on packet flow. Programming of the receive steering classificator is implicit. After the driver transmitted a packet of a flow on transmitqX, the device SHOULD cause incoming packets for that flow to be steered to receiveqX. For uni-directional protocols, or where no packets have been transmitted yet, the device MAY steer a packet to a random gueue out of the specified receiveg1...receivegn.

Multiqueue is disabled by VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET with *virtqueue\_pairs* to 1 (this is the default) and waiting for the device to use the command buffer.

#### 5.1.6.5.6.1 Driver Requirements: Automatic receive steering in multiqueue mode

The driver MUST configure the virtqueues before enabling them with the VIRTIO\_NET\_CTRL\_MQ\_VQ\_-PAIRS\_SET command.

The driver MUST NOT request a *virtqueue\_pairs* of 0 or greater than *max\_virtqueue\_pairs* in the device configuration space.

The driver MUST queue packets only on any transmitq1 before the VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_-SET command.

The driver MUST NOT queue packets on transmit queues greater than *virtqueue\_pairs* once it has placed the VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET command in the available ring.

#### 5.1.6.5.6.2 Device Requirements: Automatic receive steering in multiqueue mode

After initialization of reset, the device MUST gueue packets only on receiveg1.

The device MUST NOT queue packets on receive queues greater than *virtqueue\_pairs* once it has placed the VIRTIO\_NET\_CTRL\_MQ\_VQ\_PAIRS\_SET command in a used buffer.

#### 5.1.6.5.6.3 Legacy Interface: Automatic receive steering in multiqueue mode

When using the legacy interface, transitional devices and drivers MUST format *virtqueue\_pairs* according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

#### 5.1.6.5.6.4 Hash calculation

If VIRTIO\_NET\_F\_HASH\_REPORT was negotiated and the device uses automatic receive steering, the device MUST support a command to configure hash calculation parameters.

The driver provides parameters for hash calculation as follows:

class VIRTIO\_NET\_CTRL\_MQ, command VIRTIO\_NET\_CTRL\_MQ\_HASH\_CONFIG.

The command-specific-data has following format:

```
struct virtio_net_hash_config {
   le32 hash_types;
   le16 reserved[4];
   u8 hash_key_length;
   u8 hash_key_data[hash_key_length];
};
```

Field *hash\_types* contains a bitmask of allowed hash types as defined in 5.1.6.4.3.1. Initially the device has all hash types disabled and reports only VIRTIO\_NET\_HASH\_REPORT\_NONE.

Field *reserved* MUST contain zeroes. It is defined to make the structure to match the layout of virtio\_net\_rss config structure, defined in 5.1.6.5.7.

Fields hash key length and hash key data define the key to be used in hash calculation.

## 5.1.6.5.7 Receive-side scaling (RSS)

A device offers the feature VIRTIO\_NET\_F\_RSS if it supports RSS receive steering with Toeplitz hash calculation and configurable parameters.

A driver queries RSS capabilities of the device by reading device configuration as defined in 5.1.4

# 5.1.6.5.7.1 Setting RSS parameters

Driver sends a VIRTIO\_NET\_CTRL\_MQ\_RSS\_CONFIG command using the following format for *command-specific-data*:

```
struct virtio_net_rss_config {
   le32 hash_types;
   le16 indirection_table_mask;
   le16 unclassified_queue;
   le16 indirection_table[indirection_table_length];
   le16 max_tx_vq;
   u8 hash_key_length;
   u8 hash_key_data[hash_key_length];
};
```

Field hash types contains a bitmask of allowed hash types as defined in 5.1.6.4.3.1.

Field *indirection\_table\_mask* is a mask to be applied to the calculated hash to produce an index in the *indirection\_table* array. Number of entries in *indirection\_table* is (*indirection\_table\_mask* + 1).

Field *unclassified\_queue* contains the 0-based index of the receive virtqueue to place unclassified packets in. Index 0 corresponds to receiveq1.

Field *indirection\_table* contains an array of 0-based indices of receive virtqueus. Index 0 corresponds to receiveq1.

A driver sets  $max\_tx\_vq$  to inform a device how many transmit virtqueues it may use (transmitq1...transmitq  $max\_tx\_vq$ ).

Fields hash\_key\_length and hash\_key\_data define the key to be used in hash calculation.

#### 5.1.6.5.7.2 Driver Requirements: Setting RSS parameters

A driver MUST NOT send the VIRTIO\_NET\_CTRL\_MQ\_RSS\_CONFIG command if the feature VIRTIO\_-NET\_F\_RSS has not been negotiated.

A driver MUST fill the *indirection\_table* array only with indices of enabled queues. Index 0 corresponds to receiveq1.

The number of entries in *indirection\_table* (*indirection\_table\_mask* + 1) MUST be a power of two.

A driver MUST use indirection\_table\_mask values that are less than rss\_max\_indirection\_table\_length reported by a device.

A driver MUST NOT set any VIRTIO\_NET\_HASH\_TYPE\_ flags that are not supported by a device.

## 5.1.6.5.7.3 Device Requirements: RSS processing

The device MUST determine the destination queue for a network packet as follows:

- Calculate the hash of the packet as defined in 5.1.6.4.3.
- If the device did not calculate the hash for the specific packet, the device directs the packet to the
  received specified by unclassified\_queue of virtio\_net\_rss\_config structure (value of 0 corresponds to
  received1).
- Apply *indirection\_table\_mask* to the calculated hash and use the result as the index in the indirection table to get 0-based number of destination receiveg (value of 0 corresponds to receiveg1).

## **5.1.6.5.8 Offloads State Configuration**

If the VIRTIO\_NET\_F\_CTRL\_GUEST\_OFFLOADS feature is negotiated, the driver can send control commands for dynamic offloads state configuration.

#### 5.1.6.5.8.1 Setting Offloads State

To configure the offloads, the following layout structure and definitions are used:

```
#define VIRTIO_NET_F_GUEST_CSUM 1
#define VIRTIO_NET_F_GUEST_TSO4 7
#define VIRTIO_NET_F_GUEST_TSO6 8
#define VIRTIO_NET_F_GUEST_ECN 9
#define VIRTIO_NET_F_GUEST_UFO 10

#define VIRTIO_NET_CTRL_GUEST_OFFLOADS 5
#define VIRTIO_NET_CTRL_GUEST_OFFLOADS_SET 0
```

The class VIRTIO\_NET\_CTRL\_GUEST\_OFFLOADS has one command: VIRTIO\_NET\_CTRL\_GUEST\_-OFFLOADS\_SET applies the new offloads configuration.

le64 value passed as command data is a bitmask, bits set define offloads to be enabled, bits cleared - offloads to be disabled.

There is a corresponding device feature for each offload. Upon feature negotiation corresponding offload gets enabled to preserve backward compatibility.

#### 5.1.6.5.8.2 Driver Requirements: Setting Offloads State

A driver MUST NOT enable an offload for which the appropriate feature has not been negotiated.

#### 5.1.6.5.8.3 Legacy Interface: Setting Offloads State

When using the legacy interface, transitional devices and drivers MUST format *offloads* according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.1.6.6 Legacy Interface: Framing Requirements

When using legacy interfaces, transitional drivers which have not negotiated VIRTIO\_F\_ANY\_LAYOUT MUST use a single descriptor for the struct virtio\_net\_hdr on both transmit and receive, with the network data in the following descriptors.

Additionally, when using the control virtqueue (see 5.1.6.5), transitional drivers which have not negotiated VIRTIO\_F\_ANY\_LAYOUT MUST:

- · for all commands, use a single 2-byte descriptor including the first two fields: class and command
- for all commands except VIRTIO\_NET\_CTRL\_MAC\_TABLE\_SET use a single descriptor including command-specific-data with no padding.
- for the VIRTIO\_NET\_CTRL\_MAC\_TABLE\_SET command use exactly two descriptors including commandspecific-data with no padding: the first of these descriptors MUST include the virtio\_net\_ctrl\_mac table structure for the unicast addresses with no padding, the second of these descriptors MUST include the virtio\_net\_ctrl\_mac table structure for the multicast addresses with no padding.
- for all commands, use a single 1-byte descriptor for the ack field

See 2.7.4.

## 5.2 Block Device

The virtio block device is a simple virtual block device (ie. disk). Read and write requests (and other exotic requests) are placed in one of its queues, and serviced (probably out of order) by the device except where noted.

#### 5.2.1 Device ID

2

## 5.2.2 Virtqueues

0 requestq1

. . .

N-1 requestqN

N=1 if VIRTIO\_BLK\_F\_MQ is not negotiated, otherwise N is set by *num\_queues*.

#### 5.2.3 Feature bits

**VIRTIO\_BLK\_F\_SIZE\_MAX (1)** Maximum size of any single segment is in *size\_max*.

VIRTIO\_BLK\_F\_SEG\_MAX (2) Maximum number of segments in a request is in seg\_max.

VIRTIO\_BLK\_F\_GEOMETRY (4) Disk-style geometry specified in geometry.

VIRTIO\_BLK\_F\_RO (5) Device is read-only.

VIRTIO\_BLK\_F\_BLK\_SIZE (6) Block size of disk is in blk\_size.

VIRTIO\_BLK\_F\_FLUSH (9) Cache flush command support.

VIRTIO\_BLK\_F\_TOPOLOGY (10) Device exports information on optimal I/O alignment.

VIRTIO\_BLK\_F\_CONFIG\_WCE (11) Device can toggle its cache between writeback and writethrough modes.

**VIRTIO\_BLK\_F\_MQ (12)** Device supports multiqueue.

**VIRTIO\_BLK\_F\_DISCARD (13)** Device can support discard command, maximum discard sectors size in *max\_discard\_sectors* and maximum discard segment number in *max\_discard\_seg*.

**VIRTIO\_BLK\_F\_WRITE\_ZEROES (14)** Device can support write zeroes command, maximum write zeroes sectors size in *max\_write\_zeroes\_sectors* and maximum write zeroes segment number in *max\_write\_zeroes\_seg*.

VIRTIO\_BLK\_F\_LIFETIME (15) Device supports providing storage lifetime information.

**VIRTIO\_BLK\_F\_SECURE\_ERASE (16)** Device supports secure erase command, maximum erase sectors count in *max\_secure\_erase\_sectors* and maximum erase segment number in *max\_secure\_erase\_seg*.

#### 5.2.3.1 Legacy Interface: Feature bits

VIRTIO\_BLK\_F\_BARRIER (0) Device supports request barriers.

**VIRTIO\_BLK\_F\_SCSI** (7) Device supports scsi packet commands.

**Note:** In the legacy interface, VIRTIO\_BLK\_F\_FLUSH was also called VIRTIO\_BLK\_F\_WCE.

# 5.2.4 Device configuration layout

The *capacity* of the device (expressed in 512-byte sectors) is always present. The availability of the others all depend on various feature bits as indicated above.

The field *num\_queues* only exists if VIRTIO\_BLK\_F\_MQ is set. This field specifies the number of queues.

The parameters in the configuration space of the device <code>max\_discard\_sectors discard\_sector\_alignment</code> are expressed in 512-byte units if the VIRTIO\_BLK\_F\_DISCARD feature bit is negotiated. The <code>max\_write\_-zeroes\_sectors</code> is expressed in 512-byte units if the VIRTIO\_BLK\_F\_WRITE\_ZEROES feature bit is negotiated. The parameters in the configuration space of the device <code>max\_secure\_erase\_sectors secure\_erase\_sector\_alignment</code> are expressed in 512-byte units if the VIRTIO\_BLK\_F\_SECURE\_ERASE feature bit is negotiated.

```
struct virtio blk config {
        le64 capacity;
       le32 size max;
       le32 seg max;
       struct virtio blk geometry {
               le16 cylinders;
               u8 heads;
               u8 sectors;
       } geometry;
        le32 blk size;
        struct virtio blk topology {
                // # of logical blocks per physical block (log2)
               u8 physical block exp;
                // offset of first aligned logical block
                u8 alignment offset;
                // suggested minimum I/O size in blocks
                le16 min io size;
                // optimal (suggested maximum) I/O size in blocks
                le32 opt io size;
        } topology;
       u8 writeback;
       u8 unused0;
       u16 num queues;
```

```
le32 max_discard_sectors;
le32 max_discard_seg;
le32 discard_sector_alignment;
le32 max_write_zeroes_sectors;
le32 max_write_zeroes_seg;
u8 write_zeroes_may_unmap;
u8 unused1[3];
le32 max_secure_erase_sectors;
le32 max_secure_erase_seg;
le32 secure_erase_sector_alignment;
};
```

## 5.2.4.1 Legacy Interface: Device configuration layout

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_blk\_config according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

#### 5.2.5 Device Initialization

- 1. The device size can be read from capacity.
- 2. If the VIRTIO\_BLK\_F\_BLK\_SIZE feature is negotiated, *blk\_size* can be read to determine the optimal sector size for the driver to use. This does not affect the units used in the protocol (always 512 bytes), but awareness of the correct value can affect performance.
- 3. If the VIRTIO\_BLK\_F\_RO feature is set by the device, any write requests will fail.
- 4. If the VIRTIO\_BLK\_F\_TOPOLOGY feature is negotiated, the fields in the *topology* struct can be read to determine the physical block size and optimal I/O lengths for the driver to use. This also does not affect the units in the protocol, only performance.
- 5. If the VIRTIO\_BLK\_F\_CONFIG\_WCE feature is negotiated, the cache mode can be read or set through the writeback field. 0 corresponds to a writethrough cache, 1 to a writeback cache<sup>4</sup>. The cache mode after reset can be either writeback or writethrough. The actual mode can be determined by reading writeback after feature negotiation.
- 6. If the VIRTIO\_BLK\_F\_DISCARD feature is negotiated, max\_discard\_sectors and max\_discard\_seg can be read to determine the maximum discard sectors and maximum number of discard segments for the block driver to use. discard\_sector\_alignment can be used by OS when splitting a request based on alignment.
- If the VIRTIO\_BLK\_F\_WRITE\_ZEROES feature is negotiated, max\_write\_zeroes\_sectors and max\_write\_zeroes\_seg can be read to determine the maximum write zeroes sectors and maximum number of write zeroes segments for the block driver to use.
- 8. If the VIRTIO\_BLK\_F\_MQ feature is negotiated, *num\_queues* field can be read to determine the number of queues.
- 9. If the VIRTIO\_BLK\_F\_SECURE\_ERASE feature is negotiated, max\_secure\_erase\_sectors and max\_secure\_erase\_seg can be read to determine the maximum secure erase sectors and maximum number of secure erase segments for the block driver to use. secure\_erase\_sector\_alignment can be used by OS when splitting a request based on alignment.

## 5.2.5.1 Driver Requirements: Device Initialization

Drivers SHOULD NOT negotiate VIRTIO\_BLK\_F\_FLUSH if they are incapable of sending VIRTIO\_BLK\_-T\_FLUSH commands.

<sup>&</sup>lt;sup>4</sup>Consistent with 5.2.6.2, a writethrough cache can be defined broadly as a cache that commits writes to persistent device backend storage before reporting their completion. For example, a battery-backed writeback cache actually counts as writethrough according to this definition.

If neither VIRTIO\_BLK\_F\_CONFIG\_WCE nor VIRTIO\_BLK\_F\_FLUSH are negotiated, the driver MAY deduce the presence of a writethrough cache. If VIRTIO\_BLK\_F\_CONFIG\_WCE was not negotiated but VIRTIO\_BLK\_F\_LUSH was, the driver SHOULD assume presence of a writeback cache.

The driver MUST NOT read writeback before setting the FEATURES\_OK device status bit.

## 5.2.5.2 Device Requirements: Device Initialization

Devices SHOULD always offer VIRTIO\_BLK\_F\_FLUSH, and MUST offer it if they offer VIRTIO\_BLK\_F\_-CONFIG WCE.

If VIRTIO\_BLK\_F\_CONFIG\_WCE is negotiated but VIRTIO\_BLK\_F\_FLUSH is not, the device MUST initialize *writeback* to 0.

The device MUST initialize padding bytes unused0 and unused1 to 0.

## 5.2.5.3 Legacy Interface: Device Initialization

Because legacy devices do not have FEATURES\_OK, transitional devices MUST implement slightly different behavior around feature negotiation when used through the legacy interface. In particular, when using the legacy interface:

- the driver MAY read or write writeback before setting the DRIVER or DRIVER OK device status bit
- the device MUST NOT modify the cache mode (and writeback) as a result of a driver setting a status bit, unless the DRIVER\_OK bit is being set and the driver has not set the VIRTIO\_BLK\_F\_CONFIG\_WCE driver feature bit.
- the device MUST NOT modify the cache mode (and *writeback*) as a result of a driver modifying the driver feature bits, for example if the driver sets the VIRTIO\_BLK\_F\_CONFIG\_WCE driver feature bit but does not set the VIRTIO\_BLK\_F\_FLUSH bit.

# 5.2.6 Device Operation

The driver queues requests to the virtqueues, and they are used by the device (not necessarily in order). Each request is of form:

```
struct virtio_blk_req {
    le32 type;
    le32 reserved;
    le64 sector;
    u8 data[];
    u8 status;
};
```

The type of the request is either a read (VIRTIO\_BLK\_T\_IN), a write (VIRTIO\_BLK\_T\_OUT), a discard (VIRTIO\_BLK\_T\_DISCARD), a write zeroes (VIRTIO\_BLK\_T\_WRITE\_ZEROES), a flush (VIRTIO\_BLK\_T\_FLUSH), a get device ID string command (VIRTIO\_BLK\_T\_GET\_ID), a secure erase (VIRTIO\_BLK\_T\_SECURE\_ERASE), or a get device lifetime command (VIRTIO\_BLK\_T\_GET\_LIFETIME).

```
#define VIRTIO_BLK_T_IN 0
#define VIRTIO_BLK_T_OUT 1
#define VIRTIO_BLK_T_FLUSH 4
#define VIRTIO_BLK_T_GET_ID 8
#define VIRTIO_BLK_T_GET_LIFETIME 10
#define VIRTIO_BLK_T_DISCARD 11
#define VIRTIO_BLK_T_WRITE_ZEROES 13
#define VIRTIO_BLK_T_SECURE_ERASE 14
```

The *sector* number indicates the offset (multiplied by 512) where the read or write is to occur. This field is unused and set to 0 for commands other than read or write.

VIRTIO\_BLK\_T\_IN requests populate *data* with the contents of sectors read from the block device (in multiples of 512 bytes). VIRTIO\_BLK\_T\_OUT requests write the contents of *data* to the block device (in multiples of 512 bytes).

The *data* used for discard, secure erase or write zeroes commands consists of one or more segments. The maximum number of segments is *max\_discard\_seg* for discard commands, *max\_secure\_erase\_seg* for secure erase commands and *max\_write\_zeroes\_seg* for write zeroes commands. Each segment is of form:

```
struct virtio_blk_discard_write_zeroes {
    le64 sector;
    le32 num_sectors;
    struct {
        le32 unmap:1;
        le32 reserved:31;
    } flags;
};
```

sector indicates the starting offset (in 512-byte units) of the segment, while *num\_sectors* indicates the number of sectors in each discarded range. *unmap* is only used in write zeroes commands and allows the device to discard the specified range, provided that following reads return zeroes.

VIRTIO\_BLK\_T\_GET\_ID requests fetch the device ID string from the device into *data*. The device ID string is a NUL-padded ASCII string up to 20 bytes long. If the string is 20 bytes long then there is no NUL terminator.

The data used for VIRTIO\_BLK\_T\_GET\_LIFETIME requests is populated by the device, and is of the form

```
struct virtio_blk_lifetime {
  le16 pre_eol_info;
  le16 device_lifetime_est_typ_a;
  le16 device_lifetime_est_typ_b;
};
```

The *pre\_eol\_info* specifies the percentage of reserved blocks that are consumed and will have one of these values:

```
/* Value not available */
#define VIRTIO_BLK_PRE_EOL_INFO_UNDEFINED 0
/* < 80% of reserved blocks are consumed */
#define VIRTIO_BLK_PRE_EOL_INFO_NORMAL 1
/* 80% of reserved blocks are consumed */
#define VIRTIO_BLK_PRE_EOL_INFO_WARNING 2
/* 90% of reserved blocks are consumed */
#define VIRTIO_BLK_PRE_EOL_INFO_URGENT 3
/* All others values are reserved */
```

The *device\_lifetime\_est\_typ\_a* refers to wear of SLC cells and is provided in increments of 10used, and so on, thru to 11 meaning estimated lifetime exceeded. All values above 11 are reserved.

The device\_lifetime\_est\_typ\_b refers to wear of MLC cells and is provided with the same semantics as device\_lifetime\_est\_typ\_a.

The final *status* byte is written by the device: either VIRTIO\_BLK\_S\_OK for success, VIRTIO\_BLK\_S\_IOERR for device or driver error or VIRTIO\_BLK\_S\_UNSUPP for a request unsupported by device:

```
#define VIRTIO_BLK_S_OK 0
#define VIRTIO_BLK_S_IOERR 1
#define VIRTIO_BLK_S_UNSUPP 2
```

The status of individual segments is indeterminate when a discard or write zero command produces VIR-TIO\_BLK\_S\_IOERR. A segment may have completed successfully, failed, or not been processed by the device.

#### 5.2.6.1 Driver Requirements: Device Operation

A driver MUST NOT submit a request which would cause a read or write beyond capacity.

A driver SHOULD accept the VIRTIO\_BLK\_F\_RO feature if offered.

A driver MUST set *sector* to 0 for a VIRTIO\_BLK\_T\_FLUSH request. A driver SHOULD NOT include any data in a VIRTIO\_BLK\_T\_FLUSH request.

The length of *data* MUST be a multiple of 512 bytes for VIRTIO\_BLK\_T\_IN and VIRTIO\_BLK\_T\_OUT requests.

The length of *data* MUST be a multiple of the size of struct virtio\_blk\_discard\_write\_zeroes for VIRTIO\_-BLK\_T\_DISCARD, VIRTIO\_BLK\_T\_SECURE\_ERASE and VIRTIO\_BLK\_T\_WRITE\_ZEROES requests.

The length of data MUST be 20 bytes for VIRTIO\_BLK\_T\_GET\_ID requests.

VIRTIO\_BLK\_T\_DISCARD requests MUST NOT contain more than *max\_discard\_seg* struct virtio\_blk\_-discard write zeroes segments in *data*.

VIRTIO\_BLK\_T\_SECURE\_ERASE requests MUST NOT contain more than *max\_secure\_erase\_seg* struct virtio\_blk\_discard\_write\_zeroes segments in *data*.

VIRTIO\_BLK\_T\_WRITE\_ZEROES requests MUST NOT contain more than *max\_write\_zeroes\_seg* struct virtio blk discard write zeroes segments in *data*.

If the VIRTIO\_BLK\_F\_CONFIG\_WCE feature is negotiated, the driver MAY switch to writethrough or write-back mode by writing respectively 0 and 1 to the *writeback* field. After writing a 0 to *writeback*, the driver MUST NOT assume that any volatile writes have been committed to persistent device backend storage.

The *unmap* bit MUST be zero for discard commands. The driver MUST NOT assume anything about the data returned by read requests after a range of sectors has been discarded.

A driver MUST NOT assume that individual segments in a multi-segment VIRTIO\_BLK\_T\_DISCARD or VIRTIO\_BLK\_T\_WRITE\_ZEROES request completed successfully, failed, or were processed by the device at all if the request failed with VIRTIO\_BLK\_S\_IOERR.

#### 5.2.6.2 Device Requirements: Device Operation

A device MUST set the *status* byte to VIRTIO\_BLK\_S\_IOERR for a write request if the VIRTIO\_BLK\_F\_RO feature if offered, and MUST NOT write any data.

The device MUST set the *status* byte to VIRTIO\_BLK\_S\_UNSUPP for discard, secure erase and write zeroes commands if any unknown flag is set. Furthermore, the device MUST set the *status* byte to VIRTIO\_-BLK\_S\_UNSUPP for discard commands if the *unmap* flag is set.

For discard commands, the device MAY deallocate the specified range of sectors in the device backend storage.

For write zeroes commands, if the *unmap* is set, the device MAY deallocate the specified range of sectors in the device backend storage, as if the discard command had been sent. After a write zeroes command is completed, reads of the specified ranges of sectors MUST return zeroes. This is true independent of whether *unmap* was set or clear.

The device SHOULD clear the *write\_zeroes\_may\_unmap* field of the virtio configuration space if and only if a write zeroes request cannot result in deallocating one or more sectors. The device MAY change the content of the field during operation of the device; when this happens, the device SHOULD trigger a configuration change notification.

A write is considered volatile when it is submitted; the contents of sectors covered by a volatile write are undefined in persistent device backend storage until the write becomes stable. A write becomes stable once it is completed and one or more of the following conditions is true:

- 1. neither VIRTIO\_BLK\_F\_CONFIG\_WCE nor VIRTIO\_BLK\_F\_FLUSH feature were negotiated, but VIRTIO\_BLK\_F\_FLUSH was offered by the device;
- 2. the VIRTIO\_BLK\_F\_CONFIG\_WCE feature was negotiated and the *writeback* field in configuration space was 0 all the time between the submission of the write and its completion;
- 3. a VIRTIO BLK T FLUSH request is sent after the write is completed and is completed itself.

If the device is backed by persistent storage, the device MUST ensure that stable writes are committed to it, before reporting completion of the write (cases 1 and 2) or the flush (case 3). Failure to do so can cause data loss in case of a crash.

If the driver changes *writeback* between the submission of the write and its completion, the write could be either volatile or stable when its completion is reported; in other words, the exact behavior is undefined.

If VIRTIO\_BLK\_F\_FLUSH was not offered by the device<sup>5</sup>, the device MAY also commit writes to persistent device backend storage before reporting their completion. Unlike case 1, however, this is not an absolute requirement of the specification.

**Note:** An implementation that does not offer VIRTIO\_BLK\_F\_FLUSH and does not commit completed writes will not be resilient to data loss in case of crashes. Not offering VIRTIO\_BLK\_F\_FLUSH is an absolute requirement for implementations that do not wish to be safe against such data losses.

If the device is backed by storage providing lifetime metrics (such as eMMC or UFS persistent storage), the device SHOULD offer the VIRTIO\_BLK\_F\_LIFETIME flag. The flag MUST NOT be offered if the device is backed by storage for which the lifetime metrics described in this document cannot be obtained or for which such metrics have no useful meaning. If the metrics are offered, the device MUST NOT send any reserved values, as defined in this specification.

**Note:** The device lifetime metrics *pre\_eol\_info*, *device\_lifetime\_est\_a* and *device\_lifetime\_est\_b* are discussed in the JESD84-B50 specification.

The complete JESD84-B50 is available at the JEDEC website (https://www.jedec.org) pursuant to JEDEC's licensing terms and conditions. This information is provided to simplfy passthrough implementations from eMMC devices.

## **5.2.6.3** Legacy Interface: Device Operation

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_blk\_-req according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

When using the legacy interface, transitional drivers SHOULD ignore the used length values.

**Note:** Historically, some devices put the total descriptor length, or the total length of device-writable buffers there, even when only the status byte was actually written.

The *reserved* field was previously called *ioprio*. *ioprio* is a hint about the relative priorities of requests to the device: higher numbers indicate more important requests.

```
#define VIRTIO_BLK_T_FLUSH_OUT 5
```

The command VIRTIO\_BLK\_T\_FLUSH\_OUT was a synonym for VIRTIO\_BLK\_T\_FLUSH; a driver MUST treat it as a VIRTIO\_BLK\_T\_FLUSH command.

```
#define VIRTIO_BLK_T_BARRIER 0x8000000
```

If the device has VIRTIO\_BLK\_F\_BARRIER feature the high bit (VIRTIO\_BLK\_T\_BARRIER) indicates that this request acts as a barrier and that all preceding requests SHOULD be complete before this one, and all following requests SHOULD NOT be started until this is complete.

**Note:** A barrier does not flush caches in the underlying backend device in host, and thus does not serve as data consistency guarantee. Only a VIRTIO BLK T FLUSH request does that.

Some older legacy devices did not commit completed writes to persistent device backend storage when VIRTIO\_BLK\_F\_FLUSH was offered but not negotiated. In order to work around this, the driver MAY set the *writeback* to 0 (if available) or it MAY send an explicit flush request after every completed write.

If the device has VIRTIO\_BLK\_F\_SCSI feature, it can also support scsi packet command requests, each of these requests is of form:

<sup>&</sup>lt;sup>5</sup>Note that in this case, according to 5.2.5.2, the device will not have offered VIRTIO\_BLK\_F\_CONFIG\_WCE either.

```
/* All fields are in guest's native endian. */
struct virtio_scsi_pc_req {
    u32 type;
    u32 ioprio;
    u64 sector;
    u8 cmd[];
    u8 data[][512];
#define SCSI_SENSE_BUFFERSIZE 96
    u8 sense[SCSI_SENSE_BUFFERSIZE];
    u32 errors;
    u32 data_len;
    u32 sense_len;
    u32 residual;
    u8 status;
};
```

A request type can also be a scsi packet command (VIRTIO\_BLK\_T\_SCSI\_CMD or VIRTIO\_BLK\_T\_SCSI\_-CMD\_OUT). The two types are equivalent, the device does not distinguish between them:

```
#define VIRTIO_BLK_T_SCSI_CMD 2
#define VIRTIO_BLK_T_SCSI_CMD_OUT 3
```

The *cmd* field is only present for scsi packet command requests, and indicates the command to perform. This field MUST reside in a single, separate device-readable buffer; command length can be derived from the length of this buffer.

Note that these first three (four for scsi packet commands) fields are always device-readable: *data* is either device-readable or device-writable, depending on the request. The size of the read or write can be derived from the total size of the request buffers.

sense is only present for scsi packet command requests, and indicates the buffer for scsi sense data.

data\_len is only present for scsi packet command requests, this field is deprecated, and SHOULD be ignored by the driver. Historically, devices copied data length there.

sense\_len is only present for scsi packet command requests and indicates the number of bytes actually written to the sense buffer.

residual field is only present for scsi packet command requests and indicates the residual size, calculated as data length - number of bytes actually transferred.

## 5.2.6.4 Legacy Interface: Framing Requirements

When using legacy interfaces, transitional drivers which have not negotiated VIRTIO F ANY LAYOUT:

- MUST use a single 8-byte descriptor containing type, reserved and sector, followed by descriptors for data, then finally a separate 1-byte descriptor for status.
- For SCSI commands there are additional constraints. *sense* MUST reside in a single separate device-writable descriptor of size 96 bytes, and *errors*, *data\_len*, *sense\_len* and *residual* MUST reside a single separate device-writable descriptor.

See 2.7.4.

# 5.3 Console Device

The virtio console device is a simple device for data input and output. A device MAY have one or more ports. Each port has a pair of input and output virtqueues. Moreover, a device has a pair of control IO virtqueues. The control virtqueues are used to communicate information between the device and the driver about ports being opened and closed on either side of the connection, indication from the device about whether a particular port is a console port, adding new ports, port hot-plug/unplug, etc., and indication from the driver about whether a port or a device was successfully added, port open/close, etc. For data IO, one or more empty buffers are placed in the receive queue for incoming data and outgoing characters are placed in the transmit queue.

## 5.3.1 Device ID

3

## 5.3.2 Virtqueues

- 0 receiveq(port0)
- 1 transmitq(port0)
- 2 control received
- 3 control transmitq
- 4 receiveq(port1)
- 5 transmitq(port1)

. . .

The port 0 receive and transmit queues always exist: other queues only exist if VIRTIO\_CONSOLE\_F\_- MULTIPORT is set.

#### 5.3.3 Feature bits

VIRTIO\_CONSOLE\_F\_SIZE (0) Configuration cols and rows are valid.

**VIRTIO\_CONSOLE\_F\_MULTIPORT (1)** Device has support for multiple ports; *max\_nr\_ports* is valid and control virtqueues will be used.

**VIRTIO\_CONSOLE\_F\_EMERG\_WRITE (2)** Device has support for emergency write. Configuration field emerg wr is valid.

# 5.3.4 Device configuration layout

The size of the console is supplied in the configuration space if the VIRTIO\_CONSOLE\_F\_SIZE feature is set. Furthermore, if the VIRTIO\_CONSOLE\_F\_MULTIPORT feature is set, the maximum number of ports supported by the device can be fetched.

If VIRTIO\_CONSOLE\_F\_EMERG\_WRITE is set then the driver can use emergency write to output a single character without initializing virtio queues, or even acknowledging the feature.

```
struct virtio_console_config {
    le16 cols;
    le16 rows;
    le32 max_nr_ports;
    le32 emerg_wr;
};
```

## 5.3.4.1 Legacy Interface: Device configuration layout

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_console\_config according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

# 5.3.5 Device Initialization

- 1. If the VIRTIO\_CONSOLE\_F\_EMERG\_WRITE feature is offered, *emerg\_wr* field of the configuration can be written at any time. Thus it works for very early boot debugging output as well as catastophic OS failures (eg. virtio ring corruption).
- 2. If the VIRTIO\_CONSOLE\_F\_SIZE feature is negotiated, the driver can read the console dimensions from *cols* and *rows*.

- 3. If the VIRTIO\_CONSOLE\_F\_MULTIPORT feature is negotiated, the driver can spawn multiple ports, not all of which are necessarily attached to a console. Some could be generic ports. In this case, the control virtqueues are enabled and according to max\_nr\_ports, the appropriate number of virtqueues are created. A control message indicating the driver is ready is sent to the device. The device can then send control messages for adding new ports to the device. After creating and initializing each port, a VIRTIO\_CONSOLE\_PORT\_READY control message is sent to the device for that port so the device can let the driver know of any additional configuration options set for that port.
- 4. The received for each port is populated with one or more receive buffers.

## 5.3.5.1 Device Requirements: Device Initialization

The device MUST allow a write to *emerg\_wr*, even on an unconfigured device.

The device SHOULD transmit the lower byte written to emerg\_wr to an appropriate log or output method.

# **5.3.6 Device Operation**

- 1. For output, a buffer containing the characters is placed in the port's transmitq<sup>6</sup>.
- 2. When a buffer is used in the receiveq (signalled by a used buffer notification), the contents is the input to the port associated with the virtqueue for which the notification was received.
- 3. If the driver negotiated the VIRTIO\_CONSOLE\_F\_SIZE feature, a configuration change notification indicates that the updated size can be read from the configuration fields. This size applies to port 0 only.
- 4. If the driver negotiated the VIRTIO\_CONSOLE\_F\_MULTIPORT feature, active ports are announced by the device using the VIRTIO\_CONSOLE\_PORT\_ADD control message. The same message is used for port hot-plug as well.

## 5.3.6.1 Driver Requirements: Device Operation

The driver MUST NOT put a device-readable buffer in a receiveq. The driver MUST NOT put a device-writable buffer in a transmitg.

# 5.3.6.2 Multiport Device Operation

If the driver negotiated the VIRTIO\_CONSOLE\_F\_MULTIPORT, the two control queues are used to manipulate the different console ports: the control received for messages from the device to the driver, and the control sendd for driver-to-device messages. The layout of the control messages is:

```
struct virtio_console_control {
    le32 id;    /* Port number */
    le16 event; /* The kind of control event */
    le16 value; /* Extra information for the event */
};
```

The values for event are:

**VIRTIO\_CONSOLE\_DEVICE\_READY (0)** Sent by the driver at initialization to indicate that it is ready to receive control messages. A value of 1 indicates success, and 0 indicates failure. The port number *id* is unused.

VIRTIO\_CONSOLE\_DEVICE\_ADD (1) Sent by the device, to create a new port. value is unused.

VIRTIO\_CONSOLE\_DEVICE\_REMOVE (2) Sent by the device, to remove an existing port. *value* is unused.

<sup>&</sup>lt;sup>6</sup>Because this is high importance and low bandwidth, the current Linux implementation polls for the buffer to become used, rather than waiting for a used buffer notification, simplifying the implementation significantly. However, for generic serial ports with the O\_-NONBLOCK flag set, the polling limitation is relaxed and the consumed buffers are freed upon the next write or poll call or when a port is closed or hot-unplugged.

- **VIRTIO\_CONSOLE\_PORT\_READY (3)** Sent by the driver in response to the device's VIRTIO\_CONSOLE\_-PORT\_ADD message, to indicate that the port is ready to be used. A *value* of 1 indicates success, and 0 indicates failure.
- **VIRTIO\_CONSOLE\_PORT (4)** Sent by the device to nominate a port as a console port. There MAY be more than one console port.
- **VIRTIO\_CONSOLE\_RESIZE (5)** Sent by the device to indicate a console size change. *value* is unused. The buffer is followed by the number of columns and rows:

```
struct virtio_console_resize {
    le16 cols;
    le16 rows;
};
```

- **VIRTIO\_CONSOLE\_PORT\_OPEN (6)** This message is sent by both the device and the driver. *value* indicates the state: 0 (port closed) or 1 (port open). This allows for ports to be used directly by guest and host processes to communicate in an application-defined manner.
- **VIRTIO\_CONSOLE\_PORT\_NAME (7)** Sent by the device to give a tag to the port. This control command is immediately followed by the UTF-8 name of the port for identification within the guest (without a NUL terminator).

#### 5.3.6.2.1 Device Requirements: Multiport Device Operation

The device MUST NOT specify a port which exists in a VIRTIO\_CONSOLE\_DEVICE\_ADD message, nor a port which is equal or greater than *max\_nr\_ports*.

The device MUST NOT specify a port in VIRTIO\_CONSOLE\_DEVICE\_REMOVE which has not been created with a previous VIRTIO\_CONSOLE\_DEVICE\_ADD.

#### 5.3.6.2.2 Driver Requirements: Multiport Device Operation

The driver MUST send a VIRTIO\_CONSOLE\_DEVICE\_READY message if VIRTIO\_CONSOLE\_F\_MULTIPORT is negotiated.

Upon receipt of a VIRTIO\_CONSOLE\_CONSOLE\_PORT message, the driver SHOULD treat the port in a manner suitable for text console access and MUST respond with a VIRTIO\_CONSOLE\_PORT\_OPEN message, which MUST have *value* set to 1.

## 5.3.6.3 Legacy Interface: Device Operation

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_console\_control according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

When using the legacy interface, the driver SHOULD ignore the used length values for the transmit queues and the control transmitq.

**Note:** Historically, some devices put the total descriptor length there, even though no data was actually written.

## 5.3.6.4 Legacy Interface: Framing Requirements

When using legacy interfaces, transitional drivers which have not negotiated VIRTIO\_F\_ANY\_LAYOUT MUST use only a single descriptor for all buffers in the control received and control transmitd.

# 5.4 Entropy Device

The virtio entropy device supplies high-quality randomness for guest use.

### 5.4.1 Device ID

4

## 5.4.2 Virtqueues

0 requestq

## 5.4.3 Feature bits

None currently defined

## 5.4.4 Device configuration layout

None currently defined.

#### 5.4.5 Device Initialization

1. The virtqueue is initialized

## **5.4.6 Device Operation**

When the driver requires random bytes, it places the descriptor of one or more buffers in the queue. It will be completely filled by random data by the device.

### 5.4.6.1 Driver Requirements: Device Operation

The driver MUST NOT place device-readable buffers into the queue.

The driver MUST examine the length written by the device to determine how many random bytes were received.

## 5.4.6.2 Device Requirements: Device Operation

The device MUST place one or more random bytes into the buffer, but it MAY use less than the entire buffer length.

# 5.5 Traditional Memory Balloon Device

This is the traditional balloon device. The device number 13 is reserved for a new memory balloon interface, with different semantics, which is expected in a future version of the standard.

The traditional virtio memory balloon device is a primitive device for managing guest memory: the device asks for a certain amount of memory, and the driver supplies it (or withdraws it, if the device has more than it asks for). This allows the guest to adapt to changes in allowance of underlying physical memory. If the feature is negotiated, the device can also be used to communicate guest memory statistics to the host.

## 5.5.1 Device ID

5

## 5.5.2 Virtqueues

- 0 inflateq
- 1 deflateg
- 2 statsq
- 3 free page vq

## 4 reporting\_vq

statsq only exists if VIRTIO BALLOON F STATS VQ is set.

free\_page\_vq only exists if VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT is set.

reporting vg only exists if VIRTIO BALLOON F PAGE REPORTING is set.

### 5.5.3 Feature bits

VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST (0) Host has to be told before pages from the balloon are used.

VIRTIO\_BALLOON\_F\_STATS\_VQ (1) A virtqueue for reporting guest memory statistics is present.

VIRTIO\_BALLOON\_F\_DEFLATE\_ON\_OOM (2) Deflate balloon on guest out of memory condition.

**VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT(3)** The device has support for free page hinting. A virtqueue for providing hints as to what memory is currently free is present. Configuration field *free\_page\_hint\_cmd\_id* is valid.

**VIRTIO\_BALLOON\_F\_PAGE\_POISON(4)** A hint to the device, that the driver will immediately write *poison val* to pages after deflating them. Configuration field *poison val* is valid.

**VIRTIO\_BALLOON\_F\_PAGE\_REPORTING(5)** The device has support for free page reporting. A virtqueue for reporting free guest memory is present.

#### 5.5.3.1 Driver Requirements: Feature bits

The driver SHOULD accept the VIRTIO BALLOON F MUST TELL HOST feature if offered by the device.

The driver SHOULD clear the VIRTIO\_BALLOON\_F\_PAGE\_POISON flag if it will not immediately write *poison\_val* to deflated pages (e.g., to initialize them, or fill them with a poison value).

If the driver is expecting the pages to retain some initialized value, it MUST NOT accept VIRTIO\_BALLOON\_F\_PAGE\_REPORTING unless it also negotiates VIRTIO\_BALLOON\_F\_PAGE\_POISON.

#### 5.5.3.2 Device Requirements: Feature bits

If the device offers the VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST feature bit, and if the driver did not accept this feature bit, the device MAY signal failure by failing to set FEATURES\_OK *device status* bit when the driver writes it.

#### 5.5.3.2.0.1 Legacy Interface: Feature bits

As the legacy interface does not have a way to gracefully report feature negotiation failure, when using the legacy interface, transitional devices MUST support guests which do not negotiate VIRTIO\_BALLOON\_-F\_MUST\_TELL\_HOST feature, and SHOULD allow guest to use memory before notifying host if VIRTIO\_-BALLOON\_F\_MUST\_TELL\_HOST is not negotiated.

## 5.5.4 Device configuration layout

num pages and actual are always available.

free\_page\_hint\_cmd\_id is available if VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT has been negotiated. The field is read-only by the driver. poison\_val is available if VIRTIO\_BALLOON\_F\_PAGE\_POISON has been negotiated.

```
struct virtio_balloon_config {
    le32 num_pages;
    le32 actual;
    le32 free_page_hint_cmd_id;
    le32 poison_val;
};
```

## 5.5.4.0.0.1 Legacy Interface: Device configuration layout

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_-balloon config according to the little-endian format.

Note: This is unlike the usual convention that legacy device fields are guest endian.

## 5.5.5 Device Initialization

The device initialization process is outlined below:

- 1. The inflate and deflate virtqueues are identified.
- 2. If the VIRTIO\_BALLOON\_F\_STATS\_VQ feature bit is negotiated:
  - (a) Identify the stats virtqueue.
  - (b) Add one empty buffer to the stats virtqueue.
- 3. If the VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT feature bit is negotiated, identify the free\_page\_vq.
- 4. If the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature bit is negotiated, update the *poison\_val* configuration field.
- 5. If the VIRTIO\_BALLOON\_F\_PAGE\_REPORTING feature bit is negotiated, identify the reporting\_vq.
- 6. DRIVER OK is set: device operation begins.
- 7. If the VIRTIO\_BALLOON\_F\_STATS\_VQ feature bit is negotiated, then notify the device about the stats virtqueue buffer.
- 8. If the VIRTIO\_BALLOON\_F\_PAGE\_REPORTING feature bit is negotiated, then begin reporting free pages to the device.

## 5.5.6 Device Operation

The device is driven either by the receipt of a configuration change notification, or by changing guest memory needs, such as performing memory compaction or responding to out of memory conditions.

- 1. *num\_pages* configuration field is examined. If this is greater than the *actual* number of pages, the balloon wants more memory from the guest. If it is less than *actual*, the balloon doesn't need it all.
- 2. To supply memory to the balloon (aka. inflate):
  - (a) The driver constructs an array of addresses of unused memory pages. These addresses are divided by 4096<sup>7</sup> and the descriptor describing the resulting 32-bit array is added to the inflateq.
- 3. To remove memory from the balloon (aka. deflate):
  - (a) The driver constructs an array of addresses of memory pages it has previously given to the balloon, as described above. This descriptor is added to the deflateq.
  - (b) If the VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST feature is negotiated, the guest informs the device of pages before it uses them.
  - (c) Otherwise, the guest is allowed to re-use pages previously given to the balloon before the device has acknowledged their withdrawal<sup>8</sup>.
- 4. In either case, the device acknowledges inflate and deflate requests by using the descriptor.
- 5. Once the device has acknowledged the inflation or deflation, the driver updates *actual* to reflect the new number of pages in the balloon.

<sup>&</sup>lt;sup>7</sup>This is historical, and independent of the guest page size.

<sup>&</sup>lt;sup>8</sup>In this case, deflation advice is merely a courtesy.

### 5.5.6.1 Driver Requirements: Device Operation

The driver SHOULD supply pages to the balloon when *num\_pages* is greater than the actual number of pages in the balloon.

The driver MAY use pages from the balloon when *num\_pages* is less than the actual number of pages in the balloon.

The driver MAY supply pages to the balloon when *num\_pages* is greater than or equal to the actual number of pages in the balloon.

If VIRTIO\_BALLOON\_F\_DEFLATE\_ON\_OOM has not been negotiated, the driver MUST NOT use pages from the balloon when *num\_pages* is less than or equal to the actual number of pages in the balloon.

If VIRTIO\_BALLOON\_F\_DEFLATE\_ON\_OOM has been negotiated, the driver MAY use pages from the balloon when *num\_pages* is less than or equal to the actual number of pages in the balloon if this is required for system stability (e.g. if memory is required by applications running within the guest).

The driver MUST use the deflated to inform the device of pages that it wants to use from the balloon.

If the VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST feature is negotiated, the driver MUST NOT use pages from the balloon until the device has acknowledged the deflate request.

Otherwise, if the VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST feature is not negotiated, the driver MAY begin to re-use pages previously given to the balloon before the device has acknowledged the deflate request.

In any case, the driver MUST NOT use pages from the balloon after adding the pages to the balloon, but before the device has acknowledged the inflate request.

The driver MUST NOT request deflation of pages in the balloon before the device has acknowledged the inflate request.

The driver MUST update *actual* after changing the number of pages in the balloon.

The driver MAY update actual once after multiple inflate and deflate operations.

## 5.5.6.2 Device Requirements: Device Operation

The device MAY modify the contents of a page in the balloon after detecting its physical number in an inflate request and before acknowledging the inflate request by using the inflated descriptor.

If the VIRTIO\_BALLOON\_F\_MUST\_TELL\_HOST feature is negotiated, the device MAY modify the contents of a page in the balloon after detecting its physical number in an inflate request and before detecting its physical number in a deflate request and acknowledging the deflate request.

### 5.5.6.2.1 Legacy Interface: Device Operation

When using the legacy interface, the driver SHOULD ignore the used length values.

**Note:** Historically, some devices put the total descriptor length there, even though no data was actually written.

When using the legacy interface, the driver MUST write out all 4 bytes each time it updates the *actual* value in the configuration space, using a single atomic operation.

When using the legacy interface, the device SHOULD NOT use the *actual* value written by the driver in the configuration space, until the last, most-significant byte of the value has been written.

**Note:** Historically, devices used the *actual* value, even though when using Virtio Over PCI Bus the device-specific configuration space was not guaranteed to be atomic. Using intermediate values during update by driver is best avoided, except for debugging.

Historically, drivers using Virtio Over PCI Bus wrote the *actual* value by using multiple single-byte writes in order, from the least-significant to the most-significant value.

## 5.5.6.3 Memory Statistics

The stats virtqueue is atypical because communication is driven by the device (not the driver). The channel becomes active at driver initialization time when the driver adds an empty buffer and notifies the device. A request for memory statistics proceeds as follows:

- 1. The device uses the buffer and sends a used buffer notification.
- 2. The driver pops the used buffer and discards it.
- 3. The driver collects memory statistics and writes them into a new buffer.
- 4. The driver adds the buffer to the virtqueue and notifies the device.
- 5. The device pops the buffer (retaining it to initiate a subsequent request) and consumes the statistics.

Within the buffer, statistics are an array of 10-byte entries. Each statistic consists of a 16 bit tag and a 64 bit value. All statistics are optional and the driver chooses which ones to supply. To guarantee backwards compatibility, devices omit unsupported statistics.

## 5.5.6.3.1 Driver Requirements: Memory Statistics

Normative statements in this section apply if and only if the VIRTIO\_BALLOON\_F\_STATS\_VQ feature has been negotiated.

The driver MUST make at most one buffer available to the device in the statsq, at all times.

After initializing the device, the driver MUST make an output buffer available in the statsq.

Upon detecting that device has used a buffer in the statsq, the driver MUST make an output buffer available in the statsq.

Before making an output buffer available in the statsq, the driver MUST initialize it, including one struct virtio balloon stat entry for each statistic that it supports.

Driver MUST use an output buffer size which is a multiple of 6 bytes for all buffers submitted to the statsq.

Driver MAY supply struct virtio\_balloon\_stat entries in the output buffer submitted to the statsq in any order, without regard to *tag* values.

Driver MAY supply a subset of all statistics in the output buffer submitted to the statsq.

Driver MUST supply the same subset of statistics in all buffers submitted to the statsq.

## 5.5.6.3.2 Device Requirements: Memory Statistics

Normative statements in this section apply if and only if the VIRTIO\_BALLOON\_F\_STATS\_VQ feature has been negotiated.

Within an output buffer submitted to the statsq, the device MUST ignore entries with *tag* values that it does not recognize.

Within an output buffer submitted to the statsq, the device MUST accept struct virtio\_balloon\_stat entries in any order without regard to *tag* values.

### 5.5.6.3.3 Legacy Interface: Memory Statistics

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_balloon\_stat according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

When using the legacy interface, the device SHOULD ignore all values in the first buffer in the statsq supplied by the driver after device initialization.

**Note:** Historically, drivers supplied an uninitialized buffer in the first buffer.

## 5.5.6.4 Memory Statistics Tags

VIRTIO\_BALLOON\_S\_SWAP\_IN (0) The amount of memory that has been swapped in (in bytes).

VIRTIO\_BALLOON\_S\_SWAP\_OUT (1) The amount of memory that has been swapped out to disk (in bytes).

VIRTIO\_BALLOON\_S\_MAJFLT (2) The number of major page faults that have occurred.

**VIRTIO\_BALLOON\_S\_MINFLT (3)** The number of minor page faults that have occurred.

VIRTIO\_BALLOON\_S\_MEMFREE (4) The amount of memory not being used for any purpose (in bytes).

VIRTIO\_BALLOON\_S\_MEMTOT (5) The total amount of memory available (in bytes).

**VIRTIO\_BALLOON\_S\_AVAIL (6)** An estimate of how much memory is available (in bytes) for starting new applications, without pushing the system to swap.

**VIRTIO\_BALLOON\_S\_CACHES (7)** The amount of memory, in bytes, that can be quickly reclaimed without additional I/O. Typically these pages are used for caching files from disk.

VIRTIO\_BALLOON\_S\_HTLB\_PGALLOC (8) The number of successful hugetlb page allocations in the guest.

VIRTIO\_BALLOON\_S\_HTLB\_PGFAIL (9) The number of failed hugetlb page allocations in the guest.

### 5.5.6.5 Free Page Hinting

Free page hinting is designed to be used during migration to determine what pages within the guest are currently unused so that they can be skipped over while migrating the guest. The device will indicate that it is ready to start performing hinting by setting the *free\_page\_hint\_cmd\_id* to one of the non-reserved values that can be used as a command ID. The following values are reserved:

**VIRTIO\_BALLOON\_CMD\_ID\_STOP (0)** Any command ID previously supplied by the device is invalid. The driver should stop hinting free pages until a new command ID is supplied, but should not release any hinted pages for use by the guest.

**VIRTIO\_BALLOON\_CMD\_ID\_DONE (1)** Any command ID previously supplied by the device is invalid. The driver should stop hinting free pages, and should release all hinted pages for use by the guest.

When a hint is provided by the driver it indicates that the data contained in the given page is no longer needed and can be discarded. If the driver writes to the page this overrides the hint and the data will be retained. The contents of any stale pages that have not been written to since the page was hinted may be lost, and if read the contents of such pages will be uninitialized memory.

A request for free page hinting proceeds as follows:

- 1. The driver examines the *free\_page\_hint\_cmd\_id* configuration field. If it contains a non-reserved value then free page hinting will begin.
- 2. To supply free page hints:

- (a) The driver constructs an output buffer containing the new value from the *free\_page\_hint\_cmd\_id* configuration field and adds it to the free\_page\_vq.
- (b) The driver maps a series of pages and adds them to the free\_page\_vq as individual scatter-gather input buffer entries.
- (c) When the driver is no longer able to fetch additional pages to add to the free\_page\_vq, it will construct an output buffer containing the command ID VIRTIO\_BALLOON\_CMD\_ID\_STOP.
- 3. A round of hinting ends either when the driver is no longer able to supply more pages for hinting as described above, or when the device updates <a href="mailto:free\_page\_hint\_cmd\_id">free\_page\_hint\_cmd\_id</a> configuration field to contain either VIRTIO\_BALLOON\_CMD\_ID\_STOP or VIRTIO\_BALLOON\_CMD\_ID\_DONE.
- 4. The device may follow VIRTIO\_BALLOON\_CMD\_ID\_STOP with a new non-reserved value for the *free\_page\_hint\_cmd\_id* configuration field in which case it will resume supplying free page hints.
- 5. Otherwise, if the device provides VIRTIO\_BALLOON\_CMD\_ID\_DONE then hinting is complete and the driver may release all previously hinted pages for use by the guest.

## 5.5.6.5.1 Driver Requirements: Free Page Hinting

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT feature has been negotiated.

The driver MUST use an output buffer size of 4 bytes for all output buffers submitted to the free\_page\_vq.

The driver MUST start hinting by providing an output buffer containing the current command ID for the given block of pages.

The driver MUST NOT provide more than one output buffer containing the current command ID.

The driver SHOULD supply pages to the free\_page\_vq as input buffers when free\_page\_hint\_cmd\_id specifies a value of 2 or greater.

The driver SHOULD stop supplying pages for hinting when *free\_page\_hint\_cmd\_id* specifies a value of VIRTIO\_BALLOON\_CMD\_ID\_STOP or VIRTIO\_BALLOON\_CMD\_ID\_DONE.

If the driver is unable to supply pages, it MUST complete hinting by adding an output buffer containing the command ID VIRTIO BALLOON CMD ID STOP.

The driver MAY release hinted pages for use by the guest including when the device has not yet used the descriptor containing the hinting request.

The driver MUST treat the content of all hinted pages as uninitialized memory.

The driver MUST initialize the contents of any previously hinted page released before *free\_page\_hint\_-cmd id* specifies a value of VIRTIO BALLOON CMD ID DONE.

The driver SHOULD release all previously hinted pages once *free\_page\_hint\_cmd\_id* specifies a value of VIRTIO BALLOON CMD ID DONE.

#### 5.5.6.5.2 Device Requirements: Free Page Hinting

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_FREE\_PAGE\_HINT feature has been negotiated.

The device SHOULD set *free\_page\_hint\_cmd\_id* to VIRTIO\_BALLOON\_CMD\_ID\_STOP any time that it will not be able to make use of the hints provided by the driver.

The device MUST NOT reuse a command ID until it has received an output buffer containing VIRTIO\_-BALLOON\_CMD\_ID\_STOP from the driver.

The device MUST ignore pages that are provided with a command ID that does not match the current value in *free\_page\_hint\_cmd\_id*.

If the content of a previously hinted page has not been modified by the guest since the device issued the free\_page\_hint\_cmd\_id associated with the hint, the device MAY modify the contents of the page.

The device MUST NOT modify the content of a previously hinted page after *free\_page\_hint\_cmd\_id* is set to VIRTIO\_BALLOON\_CMD\_ID\_DONE.

The device MUST report a value of VIRTIO\_BALLOON\_CMD\_ID\_DONE in *free\_page\_hint\_cmd\_id* when it no longer has need for the previously hinted pages.

## 5.5.6.5.3 Legacy Interface: Free Page Hinting

When using the legacy interface, transitional devices and drivers MUST format the command ID field in output buffers according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.5.6.6 Page Poison

Page Poison provides a way to notify the host that the guest is initializing free pages with *poison\_val*. When the feature is enabled, pages will be immediately written to by the driver after deflating, and pages reported by free page reporting will retain the value indicated by *poison\_val*.

If the guest is not initializing freed pages, the driver should reject the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature.

If VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has been negotiated, the driver will place the initialization value into the *poison\_val* configuration field data.

### 5.5.6.6.1 Driver Requirements: Page Poison

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has been negotiated.

The driver MUST initialize the deflated pages with poison\_val when they are reused by the driver.

The driver MUST populate the poison\_val configuration data before setting the DRIVER\_OK bit.

The driver MUST NOT modify *poison\_val* while the DRIVER\_OK bit is set.

## 5.5.6.6.2 Device Requirements: Page Poison

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has been negotiated.

The device MAY use the content of poison\_val as a hint to guest behavior.

## 5.5.6.7 Free Page Reporting

Free Page Reporting provides a mechanism similar to balloon inflation, however it does not provide a deflation queue. Reported free pages can be reused by the driver after the reporting request has been acknowledged without notifying the device.

The driver will begin reporting free pages. When exactly and which free pages are reported is up to the driver.

- 1. The driver determines it has enough pages available to begin reporting free pages.
- 2. The driver gathers free pages into a scatter-gather list and adds them to the reporting\_vq.
- 3. The device acknowledges the reporting request by using the reporting vq descriptor.
- 4. Once the device has acknowledged the report, the driver can reuse the reported free pages when needed (e.g., by putting them back to free page lists in the guest operating system).
- 5. The driver can then continue to gather and report free pages until it has determined it has reported a sufficient quantity of pages.

#### 5.5.6.7.1 Driver Requirements: Free Page Reporting

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_PAGE\_REPORTING feature has been negotiated.

If the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has not been negotiated, then the driver MUST treat all reported pages as uninitialized memory.

If the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has been negotiated, the driver MUST initialize all free pages with *poison\_val* before reporting them.

The driver MUST NOT use the reported pages until the device has acknowledged the reporting request.

The driver MAY report free pages any time after DRIVER\_OK is set.

The driver SHOULD attempt to report large pages rather than smaller ones.

The driver SHOULD avoid reading/writing reported pages if not strictly necessary.

## 5.5.6.7.2 Device Requirements: Free Page Reporting

Normative statements in this section apply if the VIRTIO\_BALLOON\_F\_PAGE\_REPORTING feature has been negotiated.

If the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has not been negotiated, the device MAY modify the contents of any page supplied in a report request before acknowledging that request by using the reporting\_vq descriptor.

If the VIRTIO\_BALLOON\_F\_PAGE\_POISON feature has been negotiated, the device MUST NOT modify the the content of a reported page to a value other than *poison val*.

## 5.6 SCSI Host Device

The virtio SCSI host device groups together one or more virtual logical units (such as disks), and allows communicating to them using the SCSI protocol. An instance of the device represents a SCSI host to which many targets and LUNs are attached.

The virtio SCSI device services two kinds of requests:

- command requests for a logical unit;
- task management functions related to a logical unit, target or command.

The device is also able to send out notifications about added and removed logical units. Together, these capabilities provide a SCSI transport protocol that uses virtqueues as the transfer medium. In the transport protocol, the virtio driver acts as the initiator, while the virtio SCSI host provides one or more targets that receive and process the requests.

This section relies on definitions from SAM.

### 5.6.1 Device ID

8

### 5.6.2 Virtqueues

0 controlg

- 1 eventq
- 2...n request queues

### 5.6.3 Feature bits

- **VIRTIO\_SCSI\_F\_INOUT (0)** A single request can include both device-readable and device-writable data buffers.
- **VIRTIO\_SCSI\_F\_HOTPLUG (1)** The host SHOULD enable reporting of hot-plug and hot-unplug events for LUNs and targets on the SCSI bus. The guest SHOULD handle hot-plug and hot-unplug events.
- **VIRTIO\_SCSI\_F\_CHANGE (2)** The host will report changes to LUN parameters via a VIRTIO\_SCSI\_T\_-PARAM CHANGE event; the guest SHOULD handle them.
- VIRTIO\_SCSI\_F\_T10\_PI (3) The extended fields for T10 protection information (DIF/DIX) are included in the SCSI request header.

## 5.6.4 Device configuration layout

All fields of this configuration are always available.

```
struct virtio_scsi_config {
    le32 num_queues;
    le32 seg_max;
    le32 max_sectors;
    le32 cmd_per_lun;
    le32 event_info_size;
    le32 sense_size;
    le32 cdb_size;
    le16 max_channel;
    le16 max_target;
    le32 max_lun;
};
```

- **num\_queues** is the total number of request virtqueues exposed by the device. The driver MAY use only one request queue, or it can use more to achieve better performance.
- **seg\_max** is the maximum number of segments that can be in a command. A bidirectional command can include seg\_max input segments and seg\_max output segments.
- max\_sectors is a hint to the driver about the maximum transfer size to use.
- cmd per lun tells the driver the maximum number of linked commands it can send to one LUN.
- **event\_info\_size** is the maximum size that the device will fill for buffers that the driver places in the eventq. It is written by the device depending on the set of negotiated features.
- **sense\_size** is the maximum size of the sense data that the device will write. The default value is written by the device and MUST be 96, but the driver can modify it. It is restored to the default when the device is reset.
- cdb\_size is the maximum size of the CDB that the driver will write. The default value is written by the device and MUST be 32, but the driver can likewise modify it. It is restored to the default when the device is reset.
- max\_channel, max\_target and max\_lun can be used by the driver as hints to constrain scanning the logical units on the host to channel/target/logical unit numbers that are less than or equal to the value of the fields. max\_channel SHOULD be zero. max\_target SHOULD be less than or equal to 255. max\_lun SHOULD be less than or equal to 16383.

## 5.6.4.1 Driver Requirements: Device configuration layout

The driver MUST NOT write to device configuration fields other than sense size and cdb size.

The driver MUST NOT send more than *cmd\_per\_lun* linked commands to one LUN, and MUST NOT send more than the virtqueue size number of linked commands to one LUN.

## 5.6.4.2 Device Requirements: Device configuration layout

On reset, the device MUST set sense\_size to 96 and cdb\_size to 32.

### 5.6.4.3 Legacy Interface: Device configuration layout

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_-scsi\_config according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.6.5 Device Requirements: Device Initialization

On initialization the driver SHOULD first discover the device's virtqueues.

If the driver uses the eventq, the driver SHOULD place at least one buffer in the eventq.

The driver MAY immediately issue requests<sup>9</sup> or task management functions<sup>10</sup>.

## 5.6.6 Device Operation

Device operation consists of operating request queues, the control queue and the event queue.

## 5.6.6.0.1 Legacy Interface: Device Operation

When using the legacy interface, the driver SHOULD ignore the used length values.

**Note:** Historically, devices put the total descriptor length, or the total length of device-writable buffers there, even when only part of the buffers were actually written.

## 5.6.6.1 Device Operation: Request Queues

The driver queues requests to an arbitrary request queue, and they are used by the device on that same queue. It is the responsibility of the driver to ensure strict request ordering for commands placed on different queues, because they will be consumed with no order constraints.

Requests have the following format:

```
struct virtio scsi req cmd {
       // Device-readable part
       u8 lun[8];
       le64 id;
       u8 task_attr;
       u8 prio;
       u8 crn;
       u8 cdb[cdb size];
       // The next three fields are only present if VIRTIO SCSI F T10 PI
       // is negotiated.
       le32 pi bytesout;
       le32 pi bytesin;
       u8 pi out[pi bytesout];
       u8 dataout[];
       // Device-writable part
       le32 sense len;
       le32 residual;
       le16 status qualifier;
       u8 status;
       u8 response;
       u8 sense[sense size];
       // The next field is only present if VIRTIO SCSI F T10 PI
       // is negotiated
       u8 pi in[pi bytesin];
       u8 datain[];
};
/* command-specific response values */
#define VIRTIO SCSI S OK
                                        Ω
#define VIRTIO SCSI S OVERRUN
```

<sup>&</sup>lt;sup>9</sup>For example, INQUIRY or REPORT LUNS.

<sup>&</sup>lt;sup>10</sup>For example, I\_T RESET.

```
#define VIRTIO SCSI S ABORTED
#define VIRTIO SCSI S BAD TARGET
                                        3
#define VIRTIO SCSI S RESET
#define VIRTIO SCSI S BUSY
                                        5
#define VIRTIO_SCSI_S_TRANSPORT_FAILURE 6
#define VIRTIO SCSI S TARGET FAILURE
#define VIRTIO SCSI S NEXUS FAILURE
                                        8
#define VIRTIO SCSI S FAILURE
/* task attr */
#define VIRTIO SCSI S SIMPLE
                                        0
#define VIRTIO SCSI S ORDERED
                                        1
#define VIRTIO SCSI S HEAD
                                        2
#define VIRTIO SCSI S ACA
                                        3
```

*lun* addresses the REPORT LUNS well-known logical unit, or a target and logical unit in the virtio-scsi device's SCSI domain. When used to address the REPORT LUNS logical unit, *lun* is 0xC1, 0x01 and six zero bytes. The virtio-scsi device SHOULD implement the REPORT LUNS well-known logical unit.

When used to address a target and logical unit, the only supported format for *lun* is: first byte set to 1, second byte set to target, third and fourth byte representing a single level LUN structure, followed by four zero bytes. With this representation, a virtio-scsi device can serve up to 256 targets and 16384 LUNs per target. The device MAY also support having a well-known logical units in the third and fourth byte.

id is the command identifier ("tag").

task\_attr defines the task attribute as in the table above, but all task attributes MAY be mapped to SIMPLE by the device. Some commands are defined by SCSI standards as "implicit head of queue"; for such commands, all task attributes MAY also be mapped to HEAD OF QUEUE. Drivers and applications SHOULD NOT send a command with the ORDERED task attribute if the command has an implicit HEAD OF QUEUE attribute, because whether the ORDERED task attribute is honored is vendor-specific.

*crn* may also be provided by clients, but is generally expected to be 0. The maximum CRN value defined by the protocol is 255, since CRN is stored in an 8-bit integer.

The CDB is included in *cdb* and its size, *cdb\_size*, is taken from the configuration space.

All of these fields are defined in SAM and are always device-readable.

*pi\_bytesout* determines the size of the *pi\_out* field in bytes. If it is nonzero, the *pi\_out* field contains outgoing protection information for write operations. *pi\_bytesin* determines the size of the *pi\_in* field in the devicewritable section, in bytes. All three fields are only present if VIRTIO\_SCSI\_F\_T10\_PI has been negotiated.

The remainder of the device-readable part is the data output buffer, dataout.

sense and subsequent fields are always device-writable. sense\_len indicates the number of bytes actually written to the sense buffer.

residual indicates the residual size, calculated as "data\_length - number\_of\_transferred\_bytes", for read or write operations. For bidirectional commands, the number\_of\_transferred\_bytes includes both read and written bytes. A residual that is less than the size of datain means that dataout was processed entirely. A residual that exceeds the size of datain means that dataout was processed partially and datain was not processed at all.

If the *pi\_bytesin* is nonzero, the *pi\_in* field contains incoming protection information for read operations. *pi\_in* is only present if VIRTIO\_SCSI\_F\_T10\_PI has been negotiated<sup>11</sup>.

The remainder of the device-writable part is the data input buffer, *datain*.

## 5.6.6.1.1 Device Requirements: Device Operation: Request Queues

The device MUST write the status byte as the status code as defined in SAM.

The device MUST write the *response* byte as one of the following:

<sup>&</sup>lt;sup>11</sup>There is no separate residual size for  $pi\_bytesout$  and  $pi\_bytesin$ . It can be computed from the *residual* field, the size of the data integrity information per sector, and the sizes of  $pi\_out$ ,  $pi\_in$ , *dataout* and *datain*.

- **VIRTIO\_SCSI\_S\_OK** when the request was completed and the *status* byte is filled with a SCSI status code (not necessarily "GOOD").
- **VIRTIO\_SCSI\_S\_OVERRUN** if the content of the CDB (such as the allocation length, parameter length or transfer size) requires more data than is available in the datain and dataout buffers.
- **VIRTIO\_SCSI\_S\_ABORTED** if the request was cancelled due to an ABORT TASK or ABORT TASK SET task management function.
- VIRTIO\_SCSI\_S\_BAD\_TARGET if the request was never processed because the target indicated by *lun* does not exist.
- **VIRTIO\_SCSI\_S\_RESET** if the request was cancelled due to a bus or device reset (including a task management function).
- **VIRTIO\_SCSI\_S\_TRANSPORT\_FAILURE** if the request failed due to a problem in the connection between the host and the target (severed link).
- **VIRTIO\_SCSI\_S\_TARGET\_FAILURE** if the target is suffering a failure and to tell the driver not to retry on other paths.
- **VIRTIO\_SCSI\_S\_NEXUS\_FAILURE** if the nexus is suffering a failure but retrying on other paths might yield a different result.
- VIRTIO\_SCSI\_S\_BUSY if the request failed but retrying on the same path is likely to work.
- **VIRTIO\_SCSI\_S\_FAILURE** for other host or driver error. In particular, if neither *dataout* nor *datain* is empty, and the VIRTIO\_SCSI\_F\_INOUT feature has not been negotiated, the request will be immediately returned with a response equal to VIRTIO\_SCSI\_S\_FAILURE.

All commands must be completed before the virtio-scsi device is reset or unplugged. The device MAY choose to abort them, or if it does not do so MUST pick the VIRTIO\_SCSI\_S\_FAILURE response.

### 5.6.6.1.2 Driver Requirements: Device Operation: Request Queues

task\_attr, prio and crn SHOULD be zero.

Upon receiving a VIRTIO\_SCSI\_S\_TARGET\_FAILURE response, the driver SHOULD NOT retry the request on other paths.

## 5.6.6.1.3 Legacy Interface: Device Operation: Request Queues

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_scsi\_req\_cmd according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.6.6.2 Device Operation: controlq

The controlq is used for other SCSI transport operations. Requests have the following format:

```
struct virtio scsi ctrl {
      le32 type;
       u8 response:
/* response values valid for all commands */
#define VIRTIO SCSI S OK
                                               0
#define VIRTIO SCSI S BAD TARGET
                                               3
#define VIRTIO SCSI S BUSY
#define VIRTIO SCSI S TRANSPORT FAILURE
                                               6
#define VIRTIO SCSI S TARGET FAILURE
                                               7
                                               8
#define VIRTIO_SCSI_S_NEXUS_FAILURE
#define VIRTIO_SCSI_S_FAILURE
#define VIRTIO SCSI S INCORRECT LUN
                                               12
```

The type identifies the remaining fields.

The following commands are defined:

· Task management function.

```
#define VIRTIO SCSI T TMF
#define VIRTIO SCSI T TMF ABORT TASK
#define VIRTIO SCSI T TMF ABORT TASK SET
                                              1
#define VIRTIO_SCSI_T_TMF_CLEAR_ACA
#define VIRTIO SCSI T TMF CLEAR TASK SET
#define VIRTIO SCSI T TMF I T NEXUS RESET
#define VIRTIO SCSI T TMF LOGICAL UNIT RESET
#define VIRTIO_SCSI_T_TMF_QUERY_TASK
#define VIRTIO SCSI T TMF QUERY TASK SET
struct virtio scsi ctrl tmf {
       // Device-readable part
       le32 type;
       le32 subtype;
       u8 lun[8];
       le64 id:
       // Device-writable part
       u8 response;
};
/* command-specific response values */
#define VIRTIO SCSI S FUNCTION COMPLETE
                                              0
#define VIRTIO_SCSI_S_FUNCTION_SUCCEEDED
                                              10
#define VIRTIO SCSI S FUNCTION REJECTED
```

The *type* is VIRTIO\_SCSI\_T\_TMF; *subtype* defines which task management function. All fields except *response* are filled by the driver.

Other fields which are irrelevant for the requested TMF are ignored but they are still present. *Iun* is in the same format specified for request queues; the single level LUN is ignored when the task management function addresses a whole I\_T nexus. When relevant, the value of *id* is matched against the id values passed on the requestq.

The outcome of the task management function is written by the device in *response*. The command-specific response values map 1-to-1 with those defined in SAM.

Task management function can affect the response value for commands that are in the request queue and have not been completed yet. For example, the device MUST complete all active commands on a logical unit or target (possibly with a VIRTIO\_SCSI\_S\_RESET response code) upon receiving a "logical unit reset" or "I\_T nexus reset" TMF. Similarly, the device MUST complete the selected commands (possibly with a VIRTIO\_SCSI\_S\_ABORTED response code) upon receiving an "abort task" or "abort task set" TMF. Such effects MUST take place before the TMF itself is successfully completed, and the device MUST use memory barriers appropriately in order to ensure that the driver sees these writes in the correct order.

Asynchronous notification query.

```
#define VIRTIO_SCSI_T_AN_QUERY 1

struct virtio_scsi_ctrl_an {
    // Device-readable part
    le32 type;
    u8 lun[8];
    le32 event_requested;
    // Device-writable part
    le32 event_actual;
    u8 response;
};

#define VIRTIO_SCSI_EVT_ASYNC_OPERATIONAL_CHANGE 2
#define VIRTIO_SCSI_EVT_ASYNC_POWER_MGMT 4
#define VIRTIO_SCSI_EVT_ASYNC_EXTERNAL_REQUEST 8
```

By sending this command, the driver asks the device which events the given LUN can report, as described in paragraphs 6.6 and A.6 of SCSI MMC. The driver writes the events it is interested in into event\_requested; the device responds by writing the events that it supports into event\_actual.

The *type* is VIRTIO\_SCSI\_T\_AN\_QUERY. *lun* and *event\_requested* are written by the driver. *event\_-actual* and *response* fields are written by the device.

No command-specific values are defined for the *response* byte.

Asynchronous notification subscription.

```
#define VIRTIO_SCSI_T_AN_SUBSCRIBE 2

struct virtio_scsi_ctrl_an {
    // Device-readable part
    le32 type;
    u8 lun[8];
    le32 event_requested;
    // Device-writable part
    le32 event_actual;
    u8 response;
};
```

By sending this command, the driver asks the specified LUN to report events for its physical interface, again as described in SCSI MMC. The driver writes the events it is interested in into event\_requested; the device responds by writing the events that it supports into event\_actual.

Event types are the same as for the asynchronous notification query message.

The *type* is VIRTIO\_SCSI\_T\_AN\_SUBSCRIBE. *lun* and *event\_requested* are written by the driver. *event\_actual* and *response* are written by the device.

No command-specific values are defined for the response byte.

## 5.6.6.2.1 Legacy Interface: Device Operation: controlq

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_scsi\_ctrl, struct virtio\_scsi\_ctrl\_an and struct virtio\_scsi\_ctrl\_an according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

## 5.6.6.3 Device Operation: eventq

The eventq is populated by the driver for the device to report information on logical units that are attached to it. In general, the device will not queue events to cope with an empty eventq, and will end up dropping events if it finds no buffer ready. However, when reporting events for many LUNs (e.g. when a whole target disappears), the device can throttle events to avoid dropping them. For this reason, placing 10-15 buffers on the event queue is sufficient.

Buffers returned by the device on the eventq will be referred to as "events" in the rest of this section. Events have the following format:

```
#define VIRTIO_SCSI_T_EVENTS_MISSED 0x80000000

struct virtio_scsi_event {
    // Device-writable part
    le32 event;
    u8 lun[8];
    le32 reason;
};
```

The devices sets bit 31 in event to report lost events due to missing buffers.

The meaning of *reason* depends on the contents of *event*. The following events are defined:

· No event.

```
#define VIRTIO_SCSI_T_NO_EVENT 0
```

This event is fired in the following cases:

- When the device detects in the eventq a buffer that is shorter than what is indicated in the configuration field, it MAY use it immediately and put this dummy value in event. A well-written driver will never observe this situation.
- When events are dropped, the device MAY signal this event as soon as the drivers makes a buffer available, in order to request action from the driver. In this case, of course, this event will be reported with the VIRTIO\_SCSI\_T\_EVENTS\_MISSED flag.
- Transport reset

```
#define VIRTIO_SCSI_T_TRANSPORT_RESET 1

#define VIRTIO_SCSI_EVT_RESET_HARD 0

#define VIRTIO_SCSI_EVT_RESET_RESCAN 1

#define VIRTIO_SCSI_EVT_RESET_REMOVED 2
```

By sending this event, the device signals that a logical unit on a target has been reset, including the case of a new device appearing or disappearing on the bus. The device fills in all fields. *event* is set to VIRTIO\_SCSI\_T\_TRANSPORT\_RESET. *Iun* addresses a logical unit in the SCSI host.

The *reason* value is one of the three #define values appearing above:

**VIRTIO\_SCSI\_EVT\_RESET\_REMOVED** ("LUN/target removed") is used if the target or logical unit is no longer able to receive commands.

**VIRTIO\_SCSI\_EVT\_RESET\_HARD** ("LUN hard reset") is used if the logical unit has been reset, but is still present.

**VIRTIO\_SCSI\_EVT\_RESET\_RESCAN** ("rescan LUN/target") is used if a target or logical unit has just appeared on the device.

The "removed" and "rescan" events can happen when VIRTIO\_SCSI\_F\_HOTPLUG feature was negotiated; when sent for LUN 0, they MAY apply to the entire target so the driver can ask the initiator to rescan the target to detect this.

Events will also be reported via sense codes (this obviously does not apply to newly appeared buses or targets, since the application has never discovered them):

- "LUN/target removed" maps to sense key ILLEGAL REQUEST, asc 0x25, ascq 0x00 (LOGICAL UNIT NOT SUPPORTED)
- "LUN hard reset" maps to sense key UNIT ATTENTION, asc 0x29 (POWER ON, RESET OR BUS DEVICE RESET OCCURRED)
- "rescan LUN/target" maps to sense key UNIT ATTENTION, asc 0x3f, ascq 0x0e (REPORTED LUNS DATA HAS CHANGED)

The preferred way to detect transport reset is always to use events, because sense codes are only seen by the driver when it sends a SCSI command to the logical unit or target. However, in case events are dropped, the initiator will still be able to synchronize with the actual state of the controller if the driver asks the initiator to rescan of the SCSI bus. During the rescan, the initiator will be able to observe the above sense codes, and it will process them as if it the driver had received the equivalent event.

· Asynchronous notification

```
#define VIRTIO_SCSI_T_ASYNC_NOTIFY 2
```

By sending this event, the device signals that an asynchronous event was fired from a physical interface.

All fields are written by the device. *event* is set to VIRTIO\_SCSI\_T\_ASYNC\_NOTIFY. *lun* addresses a logical unit in the SCSI host. *reason* is a subset of the events that the driver has subscribed to via the "Asynchronous notification subscription" command.

### LUN parameter change

```
#define VIRTIO SCSI T PARAM CHANGE 3
```

By sending this event, the device signals a change in the configuration parameters of a logical unit, for example the capacity or cache mode. *event* is set to VIRTIO\_SCSI\_T\_PARAM\_CHANGE. *lun* addresses a logical unit in the SCSI host.

The same event SHOULD also be reported as a unit attention condition. *reason* contains the additional sense code and additional sense code qualifier, respectively in bits 0...7 and 8...15.

**Note:** For example, a change in capacity will be reported as asc 0x2a, ascq 0x09 (CAPACITY DATA HAS CHANGED).

For MMC devices (inquiry type 5) there would be some overlap between this event and the asynchronous notification event, so for simplicity the host never reports this event for MMC devices.

### 5.6.6.3.1 Driver Requirements: Device Operation: eventq

The driver SHOULD keep the eventq populated with buffers. These buffers MUST be device-writable, and SHOULD be at least event\_info\_size bytes long, and MUST be at least the size of struct virtio\_scsi\_event.

If event has bit 31 set, the driver SHOULD poll the logical units for unit attention conditions, and/or do whatever form of bus scan is appropriate for the guest operating system and SHOULD poll for asynchronous events manually using SCSI commands.

When receiving a VIRTIO\_SCSI\_T\_TRANSPORT\_RESET message with *reason* set to VIRTIO\_SCSI\_-EVT\_RESET\_REMOVED or VIRTIO\_SCSI\_EVT\_RESET\_RESCAN for LUN 0, the driver SHOULD ask the initiator to rescan the target, in order to detect the case when an entire target has appeared or disappeared.

## 5.6.6.3.2 Device Requirements: Device Operation: eventq

The device MUST set bit 31 in *event* if events were lost due to missing buffers, and it MAY use a VIRTIO\_- SCSI\_T\_NO\_EVENT event to report this.

The device MUST NOT send VIRTIO\_SCSI\_T\_TRANSPORT\_RESET messages with *reason* set to VIRTIO\_SCSI\_EVT\_RESET\_REMOVED or VIRTIO\_SCSI\_EVT\_RESET\_RESCAN unless VIRTIO\_SCSI\_F\_-HOTPLUG was negotiated.

The device MUST NOT report VIRTIO\_SCSI\_T\_PARAM\_CHANGE for MMC devices.

#### 5.6.6.3.3 Legacy Interface: Device Operation: eventq

When using the legacy interface, transitional devices and drivers MUST format the fields in struct virtio\_-scsi\_event according to the native endian of the guest rather than (necessarily when not using the legacy interface) little-endian.

#### 5.6.6.4 Legacy Interface: Framing Requirements

When using legacy interfaces, transitional drivers which have not negotiated VIRTIO\_F\_ANY\_LAYOUT MUST use a single descriptor for the *lun*, *id*, *task\_attr*, *prio*, *crn* and *cdb* fields, and MUST only use a single descriptor for the *sense len*, *residual*, *status\_qualifier*, *status*, *response* and *sense* fields.

## 5.7 GPU Device

virtio-gpu is a virtio based graphics adapter. It can operate in 2D mode and in 3D mode. 3D mode will offload rendering ops to the host gpu and therefore requires a gpu with 3D support on the host machine.

In 2D mode the virtio-gpu device provides support for ARGB Hardware cursors and multiple scanouts (aka heads).

### 5.7.1 Device ID

16

## 5.7.2 Virtqueues

0 controlq - queue for sending control commands

1 cursorq - queue for sending cursor updates

Both queues have the same format. Each request and each response have a fixed header, followed by command specific data fields. The separate cursor queue is the "fast track" for cursor commands (VIRTIO\_-GPU\_CMD\_UPDATE\_CURSOR and VIRTIO\_GPU\_CMD\_MOVE\_CURSOR), so they go through without being delayed by time-consuming commands in the control queue.

## 5.7.3 Feature bits

VIRTIO\_GPU\_F\_VIRGL (0) virgl 3D mode is supported.

VIRTIO\_GPU\_F\_EDID (1) EDID is supported.

VIRTIO\_GPU\_F\_RESOURCE\_UUID (2) assigning resources UUIDs for export to other virtio devices is supported.

VIRTIO\_GPU\_F\_RESOURCE\_BLOB (3) creating and using size-based blob resources is supported.

**VIRTIO\_GPU\_F\_CONTEXT\_INIT (4)** multiple context types and synchronization timelines supported. Requires VIRTIO\_GPU\_F\_VIRGL.

## 5.7.4 Device configuration layout

GPU device configuration uses the following layout structure and definitions:

```
#define VIRTIO_GPU_EVENT_DISPLAY (1 << 0)
struct virtio_gpu_config {
    le32 events_read;
    le32 events_clear;
    le32 num_scanouts;
    le32 num_capsets;
};</pre>
```

## 5.7.4.1 Device configuration fields

events\_read signals pending events to the driver. The driver MUST NOT write to this field.

**events\_clear** clears pending events in the device. Writing a '1' into a bit will clear the corresponding bit in **events\_read**, mimicking write-to-clear behavior.

num\_scanouts specifies the maximum number of scanouts supported by the device. Minimum value is 1, maximum value is 16.

num\_capsets specifies the maximum number of capability sets supported by the device. The minimum value is zero.

#### 5.7.4.2 Events

VIRTIO\_GPU\_EVENT\_DISPLAY Display configuration has changed. The driver SHOULD use the VIRTIO\_GPU\_CMD\_GET\_DISPLAY\_INFO command to fetch the information from the device. In case EDID support is negotiated (VIRTIO\_GPU\_F\_EDID feature flag) the device SHOULD also fetch the updated EDID blobs using the VIRTIO\_GPU\_CMD\_GET\_EDID command.

## 5.7.5 Device Requirements: Device Initialization

The driver SHOULD query the display information from the device using the VIRTIO\_GPU\_CMD\_GET\_-DISPLAY\_INFO command and use that information for the initial scanout setup. In case EDID support is negotiated (VIRTIO\_GPU\_F\_EDID feature flag) the device SHOULD also fetch the EDID information using the VIRTIO\_GPU\_CMD\_GET\_EDID command. If no information is available or all displays are disabled the driver MAY choose to use a fallback, such as 1024x768 at display 0.

The driver SHOULD query all shared memory regions supported by the device. If the device supports shared memory, the *shmid* of a region MUST (see 2.10 Shared Memory Regions) be one of the following:

```
enum virtio_gpu_shm_id {
     VIRTIO_GPU_SHM_ID_UNDEFINED = 0,
     VIRTIO_GPU_SHM_ID_HOST_VISIBLE = 1,
};
```

The shared memory region with VIRTIO\_GPU\_SHM\_ID\_HOST\_VISIBLE is referred as the "host visible memory region". The device MUST support the VIRTIO\_GPU\_CMD\_RESOURCE\_MAP\_BLOB and VIRTIO\_GPU\_CMD\_RESOURCE\_UNMAP\_BLOB if the host visible memory region is available.

## 5.7.6 Device Operation

The virtio-gpu is based around the concept of resources private to the host. The guest must DMA transfer into these resources, unless shared memory regions are supported. This is a design requirement in order to interface with future 3D rendering. In the unaccelerated 2D mode there is no support for DMA transfers from resources, just to them.

Resources are initially simple 2D resources, consisting of a width, height and format along with an identifier. The guest must then attach backing store to the resources in order for DMA transfers to work. This is like a GART in a real GPU.

## 5.7.6.1 Device Operation: Create a framebuffer and configure scanout

- Create a host resource using VIRTIO GPU CMD RESOURCE CREATE 2D.
- Allocate a framebuffer from guest ram, and attach it as backing storage to the resource just created, using VIRTIO\_GPU\_CMD\_RESOURCE\_ATTACH\_BACKING. Scatter lists are supported, so the framebuffer doesn't need to be contignous in guest physical memory.
- Use VIRTIO GPU CMD SET SCANOUT to link the framebuffer to a display scanout.

#### 5.7.6.2 Device Operation: Update a framebuffer and scanout

- · Render to your framebuffer memory.
- Use VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_2D to update the host resource from guest memory.
- Use VIRTIO GPU CMD RESOURCE FLUSH to flush the updated resource to the display.

## 5.7.6.3 Device Operation: Using pageflip

It is possible to create multiple framebuffers, flip between them using VIRTIO\_GPU\_CMD\_SET\_SCANOUT and VIRTIO\_GPU\_CMD\_RESOURCE\_FLUSH, and update the invisible framebuffer using VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_2D.

#### 5.7.6.4 Device Operation: Multihead setup

In case two or more displays are present there are different ways to configure things:

- · Create a single framebuffer, link it to all displays (mirroring).
- Create an framebuffer for each display.
- · Create one big framebuffer, configure scanouts to display a different rectangle of that framebuffer each.

## 5.7.6.5 Device Requirements: Device Operation: Command lifecycle and fencing

The device MAY process controlq commands asyncronously and return them to the driver before the processing is complete. If the driver needs to know when the processing is finished it can set the VIRTIO\_GPU\_-FLAG\_FENCE flag in the request. The device MUST finish the processing before returning the command then.

Note: current qemu implementation does asyncrounous processing only in 3d mode, when offloading the processing to the host gpu.

### 5.7.6.6 Device Operation: Configure mouse cursor

The mouse cursor image is a normal resource, except that it must be 64x64 in size. The driver MUST create and populate the resource (using the usual VIRTIO\_GPU\_CMD\_RESOURCE\_CREATE\_2D, VIRTIO\_GPU\_CMD\_RESOURCE\_ATTACH\_BACKING and VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_2D controlq commands) and make sure they are completed (using VIRTIO\_GPU\_FLAG\_FENCE).

Then VIRTIO\_GPU\_CMD\_UPDATE\_CURSOR can be sent to the cursorq to set the pointer shape and position. To move the pointer without updating the shape use VIRTIO GPU CMD MOVE CURSOR instead.

## 5.7.6.7 Device Operation: Request header

All requests and responses on the virt queues have a fixed header using the following layout structure and definitions:

```
enum virtio_gpu_ctrl_type {
        /* 2d commands */
       VIRTIO GPU CMD GET DISPLAY INFO = 0 \times 0100,
       VIRTIO GPU CMD RESOURCE CREATE 2D,
       VIRTIO GPU CMD RESOURCE UNREF,
       VIRTIO GPU CMD SET SCANOUT,
       VIRTIO GPU CMD RESOURCE FLUSH,
       VIRTIO GPU CMD TRANSFER TO HOST 2D,
       VIRTIO GPU CMD RESOURCE ATTACH BACKING,
       VIRTIO GPU CMD RESOURCE DETACH BACKING,
       VIRTIO GPU CMD GET CAPSET INFO,
       VIRTIO GPU CMD GET CAPSET,
       VIRTIO GPU CMD GET EDID,
       VIRTIO GPU CMD RESOURCE ASSIGN UUID,
       VIRTIO GPU CMD RESOURCE CREATE BLOB,
       VIRTIO GPU CMD SET SCANOUT BLOB,
        /* 3d commands */
       VIRTIO GPU CMD CTX CREATE = 0 \times 0200,
       VIRTIO GPU CMD CTX DESTROY,
       VIRTIO_GPU_CMD_CTX_ATTACH_RESOURCE,
       VIRTIO GPU CMD CTX DETACH RESOURCE,
       VIRTIO GPU CMD RESOURCE CREATE 3D,
       VIRTIO GPU CMD TRANSFER TO HOST 3D,
       VIRTIO GPU CMD TRANSFER FROM HOST 3D,
       VIRTIO GPU CMD SUBMIT 3D,
       VIRTIO GPU CMD RESOURCE MAP BLOB,
       VIRTIO GPU CMD RESOURCE UNMAP BLOB,
        /* cursor commands */
       VIRTIO GPU CMD UPDATE CURSOR = 0x0300,
        VIRTIO GPU CMD MOVE CURSOR,
        /* success responses */
```

```
VIRTIO GPU RESP OK NODATA = 0x1100,
        VIRTIO GPU RESP OK DISPLAY INFO,
        VIRTIO GPU RESP OK CAPSET INFO,
       VIRTIO GPU RESP OK CAPSET,
        VIRTIO_GPU_RESP_OK_EDID,
        VIRTIO GPU RESP OK RESOURCE UUID,
        VIRTIO GPU RESP OK MAP INFO,
        /* error responses */
        VIRTIO GPU RESP ERR UNSPEC = 0x1200,
        VIRTIO GPU RESP ERR OUT OF MEMORY,
       VIRTIO GPU RESP ERR INVALID SCANOUT ID,
        VIRTIO GPU RESP ERR INVALID RESOURCE ID,
        VIRTIO_GPU_RESP_ERR_INVALID_CONTEXT_ID,
        VIRTIO GPU RESP ERR INVALID PARAMETER,
};
#define VIRTIO GPU FLAG FENCE (1 << 0)
\#define VIRTIO GPU FLAG INFO RING IDX (1 << 1)
struct virtio_gpu_ctrl_hdr {
       le32 type;
       le32 flags;
       le64 fence id;
        le32 ctx id;
       u8 ring idx;
       u8 padding[3];
};
```

The fixed header struct virtio\_gpu\_ctrl\_hdr in each request includes the following fields:

**type** specifies the type of the driver request (VIRTIO\_GPU\_CMD\_\*) or device response (VIRTIO\_GPU\_-RESP\_\*).

flags request / response flags.

fence id If the driver sets the VIRTIO GPU FLAG FENCE bit in the request flags field the device MUST:

- set VIRTIO GPU FLAG FENCE bit in the response,
- copy the content of the *fence\_id* field from the request to the response, and
- · send the response only after command processing is complete.

ctx id Rendering context (used in 3D mode only).

**ring\_idx** If VIRTIO\_GPU\_F\_CONTEXT\_INIT is supported, then the driver MAY set VIRTIO\_GPU\_FLAG\_-INFO\_RING\_IDX bit in the request *flags*. In that case:

- ring\_idx indicates the value of a context-specific ring index. The minimum value is 0 and maximum value is 63 (inclusive).
- If VIRTIO\_GPU\_FLAG\_FENCE is set, *fence\_id* acts as a sequence number on the synchronization timeline defined by *ctx\_idx* and the ring index.
- If VIRTIO\_GPU\_FLAG\_FENCE is set and when the command associated with fence\_id is complete, the device MUST send a response for all outstanding commands with a sequence number less than or equal to fence\_id on the same synchronization timeline.

On success the device will return VIRTIO\_GPU\_RESP\_OK\_NODATA in case there is no payload. Otherwise the *type* field will indicate the kind of payload.

On error the device will return one of the VIRTIO\_GPU\_RESP\_ERR\_\* error codes.

#### 5.7.6.8 Device Operation: controlq

For any coordinates given 0,0 is top left, larger x moves right, larger y moves down.

**VIRTIO\_GPU\_CMD\_GET\_DISPLAY\_INFO** Retrieve the current output configuration. No request data (just bare *struct virtio\_gpu\_ctrl\_hdr*). Response type is VIRTIO\_GPU\_RESP\_OK\_DISPLAY\_INFO, response data is *struct virtio\_gpu\_resp\_display\_info*.

```
#define VIRTIO_GPU_MAX_SCANOUTS 16

struct virtio_gpu_rect {
    le32 x;
    le32 y;
    le32 width;
    le32 height;
};

struct virtio_gpu_resp_display_info {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_display_one {
        struct virtio_gpu_rect r;
        le32 enabled;
        le32 flags;
    } pmodes[VIRTIO_GPU_MAX_SCANOUTS];
};
```

The response contains a list of per-scanout information. The info contains whether the scanout is enabled and what its preferred position and size is.

The size (fields *width* and *height*) is similar to the native panel resolution in EDID display information, except that in the virtual machine case the size can change when the host window representing the guest display is gets resized.

The position (fields x and y) describe how the displays are arranged (i.e. which is – for example – the left display).

The *enabled* field is set when the user enabled the display. It is roughly the same as the connected state of a physical display connector.

**VIRTIO\_GPU\_CMD\_GET\_EDID** Retrieve the EDID data for a given scanout. Request data is *struct virtio\_gpu\_get\_edid*). Response type is VIRTIO\_GPU\_RESP\_OK\_EDID, response data is *struct virtio\_gpu\_resp\_edid*. Support is optional and negotiated using the VIRTIO\_GPU\_F\_EDID feature flag.

```
struct virtio_gpu_get_edid {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 scanout;
    le32 padding;
};
struct virtio_gpu_resp_edid {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 size;
    le32 padding;
    u8 edid[1024];
};
```

The response contains the EDID display data blob (as specified by VESA) for the scanout.

**VIRTIO\_GPU\_CMD\_RESOURCE\_CREATE\_2D** Create a 2D resource on the host. Request data is *struct virtio\_gpu\_resource\_create\_2d*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
enum virtio_gpu_formats {
    VIRTIO_GPU_FORMAT_B8G8R8A8_UNORM = 1,
    VIRTIO_GPU_FORMAT_B8G8R8X8_UNORM = 2,
    VIRTIO_GPU_FORMAT_A8R8G8B8_UNORM = 3,
    VIRTIO_GPU_FORMAT_X8R8G8B8_UNORM = 4,

    VIRTIO_GPU_FORMAT_R8G8B8A8_UNORM = 67,
    VIRTIO_GPU_FORMAT_X8B8G8R8_UNORM = 68,

    VIRTIO_GPU_FORMAT_A8B8G8R8_UNORM = 121,
    VIRTIO_GPU_FORMAT_R8G8B8X8_UNORM = 134,
};

struct virtio_gpu_resource_create_2d {
    struct virtio_gpu_resource_create_2d {
        struct virtio_gpu_ctrl_hdr hdr;
}
```

```
le32 resource_id;
le32 format;
le32 width;
le32 height;
};
```

This creates a 2D resource on the host with the specified width, height and format. The resource ids are generated by the guest.

**VIRTIO\_GPU\_CMD\_RESOURCE\_UNREF** Destroy a resource. Request data is *struct virtio\_gpu\_resource\_unref*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
struct virtio_gpu_resource_unref {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 resource_id;
    le32 padding;
};
```

This informs the host that a resource is no longer required by the guest.

**VIRTIO\_GPU\_CMD\_SET\_SCANOUT** Set the scanout parameters for a single output. Request data is struct virtio\_gpu\_set\_scanout. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
struct virtio_gpu_set_scanout {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_rect r;
    le32 scanout_id;
    le32 resource_id;
};
```

This sets the scanout parameters for a single scanout. The resource\_id is the resource to be scanned out from, along with a rectangle.

Scanout rectangles must be completely covered by the underlying resource. Overlapping (or identical) scanouts are allowed, typical use case is screen mirroring.

The driver can use resource id = 0 to disable a scanout.

**VIRTIO\_GPU\_CMD\_RESOURCE\_FLUSH** Flush a scanout resource Request data is *struct virtio\_gpu\_-resource\_flush*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
struct virtio_gpu_resource_flush {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_rect r;
    le32 resource_id;
    le32 padding;
};
```

This flushes a resource to screen. It takes a rectangle and a resource id, and flushes any scanouts the resource is being used on.

VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_2D Transfer from guest memory to host resource. Request data is struct virtio\_gpu\_transfer\_to\_host\_2d. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
struct virtio_gpu_transfer_to_host_2d {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_rect r;
    le64 offset;
    le32 resource_id;
    le32 padding;
};
```

This takes a resource id along with an destination offset into the resource, and a box to transfer to the host backing for the resource.

**VIRTIO\_GPU\_CMD\_RESOURCE\_ATTACH\_BACKING** Assign backing pages to a resource. Request data is *struct virtio\_gpu\_resource\_attach\_backing*, followed by *struct virtio\_gpu\_mem\_entry* entries. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
struct virtio_gpu_resource_attach_backing {
         struct virtio_gpu_ctrl_hdr hdr;
         le32 resource_id;
         le32 nr_entries;
};

struct virtio_gpu_mem_entry {
        le64 addr;
        le32 length;
        le32 padding;
};
```

This assign an array of guest pages as the backing store for a resource. These pages are then used for the transfer operations for that resource from that point on.

**VIRTIO\_GPU\_CMD\_RESOURCE\_DETACH\_BACKING** Detach backing pages from a resource. Request data is *struct virtio\_gpu\_resource\_detach\_backing*. Response type is VIRTIO\_GPU\_RESP\_OK\_NO-DATA.

```
struct virtio_gpu_resource_detach_backing {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 resource_id;
    le32 padding;
};
```

This detaches any backing pages from a resource, to be used in case of guest swapping or object destruction.

VIRTIO\_GPU\_CMD\_GET\_CAPSET\_INFO Gets the information associated with a particular capset\_index, which MUST less than num\_capsets defined in the device configuration. Request data is struct virtio\_gpu\_get\_capset\_info. Response type is VIRTIO\_GPU\_RESP\_OK\_CAPSET\_INFO.

On success, struct virtio\_gpu\_resp\_capset\_info contains the capset\_id, capset\_max\_version, capset\_max\_size associated with capset at the specified capset\_idex. fieldcapset\_id MUST be one of the following (see listing for values):

- VIRTIO\_GPU\_CAPSET\_VIRGL the first edition of Virgl (Gallium OpenGL) protocol.
- VIRTIO\_GPU\_CAPSET\_VIRGL2 the second edition of Virgl (Gallium OpenGL) protocol after the capset fix.
- VIRTIO\_GPU\_CAPSET\_GFXSTREAM gfxtream's (mostly) autogenerated GLES and Vulkan streaming protocols.
- VIRTIO\_GPU\_CAPSET\_VENUS Mesa's (mostly) autogenerated Vulkan protocol.
- VIRTIO\_GPU\_CAPSET\_CROSS\_DOMAIN protocol for display virtualization via Wayland proxying.

```
struct virtio gpu get capset info {
       struct virtio_gpu_ctrl_hdr hdr;
       le32 capset index;
       le32 padding;
};
#define VIRTIO GPU CAPSET VIRGL 1
#define VIRTIO GPU CAPSET VIRGL2 2
#define VIRTIO GPU CAPSET GFXSTREAM 3
#define VIRTIO GPU CAPSET VENUS 4
#define VIRTIO GPU CAPSET CROSS DOMAIN 5
struct virtio_gpu_resp_capset_info {
       struct virtio gpu ctrl hdr hdr;
       le32 capset id;
       le32 capset max version;
       le32 capset max size;
       le32 padding;
};
```

VIRTIO\_GPU\_CMD\_GET\_CAPSET Gets the capset associated with a particular capset\_id and capset\_version. Request data is struct virtio\_gpu\_get\_capset. Response type is VIRTIO\_GPU\_RESP\_OK\_CAPSET.

```
struct virtio_gpu_get_capset {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 capset_id;
    le32 capset_version;
};
struct virtio_gpu_resp_capset {
    struct virtio_gpu_ctrl_hdr hdr;
    u8 capset_data[];
};
```

VIRTIO\_GPU\_CMD\_RESOURCE\_ASSIGN\_UUID Creates an exported object from a resource. Request data is struct virtio\_gpu\_resource\_assign\_uuid. Response type is VIRTIO\_GPU\_RESP\_OK\_RESOURCE\_-UUID, response data is struct virtio\_gpu\_resp\_resource\_uuid. Support is optional and negotiated using the VIRTIO\_GPU\_F\_RESOURCE\_UUID feature flag.

```
struct virtio_gpu_resource_assign_uuid {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 resource_id;
    le32 padding;
};
struct virtio_gpu_resp_resource_uuid {
    struct virtio_gpu_ctrl_hdr hdr;
    u8 uuid[16];
};
```

The response contains a UUID which identifies the exported object created from the host private resource. Note that if the resource has an attached backing, modifications made to the host private resource through the exported object by other devices are not visible in the attached backing until they are transferred into the backing.

**VIRTIO\_GPU\_CMD\_RESOURCE\_CREATE\_BLOB** Creates a virtio-gpu blob resource. Request data is *struct virtio\_gpu\_resource\_create\_blob*, followed by *struct virtio\_gpu\_mem\_entry* entries. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA. Support is optional and negotiated using the VIRTIO\_GPU\_F RESOURCE\_BLOB feature flag.

```
0x0001
#define VIRTIO GPU BLOB MEM GUEST
#define VIRTIO GPU BLOB MEM HOST3D
                                                  0x0002
#define VIRTIO_GPU BLOB MEM HOST3D GUEST
                                                 0x0003
#define VIRTIO_GPU_BLOB_FLAG_USE_MAPPABLE 0x0001
#define VIRTIO_GPU_BLOB_FLAG_USE_SHAREABLE 0x0002
#define VIRTIO GPU BLOB FLAG USE CROSS DEVICE 0x0004
struct virtio gpu resource create blob {
       struct virtio gpu ctrl hdr hdr;
       le32 resource id;
       le32 blob mem;
       le32 blob flags;
       le32 nr entries;
       le64 blob id;
       le64 size;
};
```

A blob resource is a container for:

- a guest memory allocation (referred to as a "guest-only blob resource").
- a host memory allocation (referred to as a "host-only blob resource").
- a guest memory and host memory allocation (referred to as a "default blob resource").

The memory properties of the blob resource MUST be described by *blob\_mem*, which MUST be non-zero.

For default and guest-only blob resources, *nr\_entries* guest memory entries may be assigned to the resource. For default blob resources (i.e, when *blob\_mem* is VIRTIO\_GPU\_BLOB\_MEM\_HOST3D\_GUEST), these memory entries are used as a shadow buffer for the host memory. To facilitate drivers that support swap-in and swap-out, *nr\_entries* may be zero and VIRTIO\_GPU\_CMD\_RESOURCE\_-ATTACH\_BACKING may be subsequently used. VIRTIO\_GPU\_CMD\_RESOURCE\_DETACH\_BACKING may be used to unassign memory entries.

blob\_mem can only be VIRTIO\_GPU\_BLOB\_MEM\_HOST3D and VIRTIO\_GPU\_BLOB\_MEM\_HOST3D\_-GUEST if VIRTIO\_GPU\_F\_VIRGL is supported. VIRTIO\_GPU\_BLOB\_MEM\_GUEST is valid regardless whether VIRTIO\_GPU\_F\_VIRGL is supported or not.

For VIRTIO\_GPU\_BLOB\_MEM\_HOST3D and VIRTIO\_GPU\_BLOB\_MEM\_HOST3D\_GUEST, the virtio-gpu resource MUST be created from the rendering context local object identified by the *blob\_id*. The actual allocation is done via VIRTIO\_GPU\_CMD\_SUBMIT\_3D.

The driver MUST inform the device if the blob resource is used for memory access, sharing between driver instances and/or sharing with other devices. This is done via the *blob\_flags* field.

If VIRTIO\_GPU\_F\_VIRGL is set, both VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_3D and VIRTIO\_-GPU\_CMD\_TRANSFER\_FROM\_HOST\_3D may be used to update the resource. There is no restriction on the image/buffer view the driver has on the blob resource.

**VIRTIO\_GPU\_CMD\_SET\_SCANOUT\_BLOB** sets scanout parameters for a blob resource. Request data is *struct virtio\_gpu\_set\_scanout\_blob*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA. Support is optional and negotiated using the VIRTIO\_GPU\_F\_RESOURCE\_BLOB feature flag.

```
struct virtio_gpu_set_scanout_blob {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_rect r;
    le32 scanout_id;
    le32 resource_id;
    le32 width;
    le32 height;
    le32 format;
    le32 padding;
    le32 strides[4];
};
```

The rectangle *r* represents the portion of the blob resource being displayed. The rest is the metadata associated with the blob resource. The format MUST be one of *enum virtio\_gpu\_formats*. The format MAY be compressed with header and data planes.

## 5.7.6.9 Device Operation: controlq (3d)

These commands are supported by the device if the VIRTIO\_GPU\_F\_VIRGL feature flag is set.

**VIRTIO\_GPU\_CMD\_CTX\_CREATE** creates a context for submitting an opaque command stream. Request data is *struct virtio\_gpu\_ctx\_create*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

```
#define VIRTIO_GPU_CONTEXT_INIT_CAPSET_ID_MASK 0x000000ff;
struct virtio_gpu_ctx_create {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 nlen;
    le32 context_init;
    char debug_name[64];
};
```

The implementation MUST create a context for the given <code>ctx\_id</code> in the <code>hdr</code>. For debugging purposes, a <code>debug\_name</code> and it's length <code>nlen</code> is provided by the driver. If VIRTIO\_GPU\_F\_CONTEXT\_INIT is supported, then lower 8 bits of <code>context\_init</code> MAY contain the <code>capset\_id</code> associated with context. In that case, then the device MUST create a context that can handle the specified command stream.

If the lower 8-bits of the *context\_init* are zero, then the type of the context is determined by the device.

## VIRTIO\_GPU\_CMD\_CTX\_DESTROY

VIRTIO\_GPU\_CMD\_CTX\_ATTACH\_RESOURCE

VIRTIO\_GPU\_CMD\_CTX\_DETACH\_RESOURCE Manage virtio-gpu 3d contexts.

VIRTIO\_GPU\_CMD\_RESOURCE\_CREATE\_3D Create virtio-gpu 3d resources.

VIRTIO\_GPU\_CMD\_TRANSFER\_TO\_HOST\_3D

VIRTIO\_GPU\_CMD\_TRANSFER\_FROM\_HOST\_3D Transfer data from and to virtio-gpu 3d resources.

**VIRTIO\_GPU\_CMD\_SUBMIT\_3D** Submit an opaque command stream. The type of the command stream is determined when creating a context.

VIRTIO\_GPU\_CMD\_RESOURCE\_MAP\_BLOB maps a host-only blob resource into an offset in the host visible memory region. Request data is *struct virtio\_gpu\_resource\_map\_blob*. The driver MUST not map a blob resource that is already mapped. Response type is VIRTIO\_GPU\_RESP\_OK\_MAP\_INFO. Support is optional and negotiated using the VIRTIO\_GPU\_F\_RESOURCE\_BLOB feature flag and checking for the presence of the host visible memory region.

```
struct virtio_gpu_resource_map_blob
        struct virtio_gpu_ctrl_hdr hdr;
        le32 resource id;
        le32 padding;
        le64 offset;
};
#define VIRTIO GPU MAP CACHE MASK
                                       0x0f
#define VIRTIO_GPU_MAP_CACHE_NONE 0x00 #define VIRTIO_GPU_MAP_CACHE_CACHED 0x01
#define VIRTIO GPU MAP CACHE UNCACHED 0x02
#define VIRTIO GPU MAP CACHE WC 0x03
struct virtio gpu resp map info {
       struct virtio_gpu_ctrl_hdr hdr;
        u32 map info;
        u32 padding;
};
```

VIRTIO\_GPU\_CMD\_RESOURCE\_UNMAP\_BLOB unmaps a host-only blob resource from the host visible memory region. Request data is struct virtio\_gpu\_resource\_unmap\_blob. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA. Support is optional and negotiated using the VIRTIO\_GPU\_F\_RESOURCE\_BLOB feature flag and checking for the presence of the host visible memory region.

```
struct virtio_gpu_resource_unmap_blob {
    struct virtio_gpu_ctrl_hdr hdr;
    le32 resource_id;
    le32 padding;
};
```

## 5.7.6.10 Device Operation: cursorq

Both cursorg commands use the same command struct.

```
struct virtio_gpu_cursor_pos {
    le32 scanout_id;
    le32 x;
    le32 y;
    le32 padding;
};

struct virtio_gpu_update_cursor {
    struct virtio_gpu_ctrl_hdr hdr;
    struct virtio_gpu_cursor_pos pos;
    le32 resource_id;
    le32 hot_x;
    le32 hot_y;
    le32 padding;
};
```

**VIRTIO\_GPU\_CMD\_UPDATE\_CURSOR** Update cursor. Request data is *struct virtio\_gpu\_update\_cursor*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

Full cursor update. Cursor will be loaded from the specified *resource\_id* and will be moved to *pos*. The driver must transfer the cursor into the resource beforehand (using control queue commands) and make sure the commands to fill the resource are actually processed (using fencing).

**VIRTIO\_GPU\_CMD\_MOVE\_CURSOR** Move cursor. Request data is *struct virtio\_gpu\_update\_cursor*. Response type is VIRTIO\_GPU\_RESP\_OK\_NODATA.

Move cursor to the place specified in *pos*. The other fields are not used and will be ignored by the device.

## 5.7.7 VGA Compatibility

Applies to Virtio Over PCI only. The GPU device can come with and without VGA compatibility. The PCI class should be DISPLAY VGA if VGA compatibility is present and DISPLAY OTHER otherwise.

VGA compatibility: PCI region 0 has the linear framebuffer, standard vga registers are present. Configuring a scanout (VIRTIO\_GPU\_CMD\_SET\_SCANOUT) switches the device from vga compatibility mode into native virtio mode. A reset switches it back into vga compatibility mode.

Note: qemu implementation also provides bochs dispi interface io ports and mmio bar at pci region 1 and is therefore fully compatible with the qemu stdvga (see <a href="docs/specs/standard-vga.txt">docs/specs/standard-vga.txt</a> in the qemu source tree).

# 5.8 Input Device

The virtio input device can be used to create virtual human interface devices such as keyboards, mice and tablets. An instance of the virtio device represents one such input device. Device behavior mirrors that of the evdev layer in Linux, making pass-through implementations on top of evdev easy.

This specification defines how evdev events are transported over virtio and how the set of supported events is discovered by a driver. It does not, however, define the semantics of input events as this is dependent on the particular evdev implementation. For the list of events used by Linux input devices, see include/uapi/linux/input-event-codes.h in the Linux source tree.

## 5.8.1 Device ID

18

## 5.8.2 Virtqueues

0 eventq

1 statusq

## 5.8.3 Feature bits

None.

## 5.8.4 Device configuration layout

Device configuration holds all information the guest needs to handle the device, most importantly the events which are supported.

```
enum virtio_input_config_select {
   VIRTIO_INPUT_CFG_UNSET = 0x00,
   VIRTIO_INPUT_CFG_ID_NAME = 0x01,
   VIRTIO_INPUT_CFG_ID_SERIAL = 0x02,
   VIRTIO_INPUT_CFG_ID_DEVIDS = 0x03,
   VIRTIO_INPUT_CFG_PROP_BITS = 0x10,
   VIRTIO_INPUT_CFG_EV_BITS = 0x11,
```

```
VIRTIO INPUT CFG ABS INFO = 0x12,
};
struct virtio input absinfo {
 le32 min;
 le32 max;
 le32 fuzz;
le32 flat;
 le32 res;
} ;
struct virtio input devids {
 le16 bustype;
 le16 vendor;
 le16 product;
 le16 version;
struct virtio input config {
 u8 select;
 u8
      subsel:
 u8 size;
 u8 reserved[5];
 union {
   char string[128];
   u8 bitmap[128];
   struct virtio input absinfo abs;
   struct virtio input devids ids;
 } u;
};
```

To query a specific piece of information the driver sets *select* and *subsel* accordingly, then checks *size* to see how much information is available. *size* can be zero if no information is available. Strings do not include a NUL terminator. Related evdev ioctl names are provided for reference.

**VIRTIO\_INPUT\_CFG\_ID\_NAME** subsel is zero. Returns the name of the device, in *u.string*.

Similar to EVIOCGNAME ioctl for Linux evdev devices.

**VIRTIO\_INPUT\_CFG\_ID\_SERIAL** subsel is zero. Returns the serial number of the device, in u.string.

**VIRTIO\_INPUT\_CFG\_ID\_DEVIDS** subsel is zero. Returns ID information of the device, in *u.ids*.

Similar to EVIOCGID ioctl for Linux evdev devices.

**VIRTIO\_INPUT\_CFG\_PROP\_BITS** *subsel* is zero. Returns input properties of the device, in *u.bitmap*. Individual bits in the bitmap correspond to INPUT\_PROP\_\* constants used by the underlying evdev implementation.

Similar to EVIOCGPROP ioctl for Linux evdev devices.

**VIRTIO\_INPUT\_CFG\_EV\_BITS** *subsel* specifies the event type using EV\_\* constants in the underlying evdev implementation. If *size* is non-zero the event type is supported and a bitmap of supported event codes is returned in *u.bitmap*. Individual bits in the bitmap correspond to implementation-defined input event codes, for example keys or pointing device axes.

Similar to EVIOCGBIT ioctl for Linux evdev devices.

**VIRTIO\_INPUT\_CFG\_ABS\_INFO** *subsel* specifies the absolute axis using ABS\_\* constants in the underlying evdev implementation. Information about the axis will be returned in *u.abs*.

Similar to EVIOCGABS joctl for Linux evdev devices.

#### 5.8.5 Device Initialization

- 1. The device is queried for supported event types and codes.
- 2. The eventq is populated with receive buffers.

#### 5.8.5.1 Driver Requirements: Device Initialization

A driver MUST set both select and subsel when querying device configuration, in any order.

A driver MUST NOT write to configuration fields other than select and subsel.

A driver SHOULD check the *size* field before accessing the configuration information.

## 5.8.5.2 Device Requirements: Device Initialization

A device MUST set the size field to zero if it doesn't support a given select and subsel combination.

## **5.8.6 Device Operation**

- 1. Input events such as press and release events for keys and buttons, and motion events for pointing devices are sent from the device to the driver using the eventq.
- 2. Status feedback such as keyboard LED updates are sent from the driver to the device using the statusq.
- 3. Both queues use the same virtio\_input\_event struct. *type*, *code* and *value* are filled according to the Linux input layer (evdev) interface, except that the fields are in little endian byte order whereas the evdev ioctl interface uses native endian-ness.

```
struct virtio_input_event {
  le16 type;
  le16 code;
  le32 value;
};
```

## 5.8.6.1 Driver Requirements: Device Operation

A driver SHOULD keep the eventq populated with buffers. These buffers MUST be device-writable and MUST be at least the size of struct virtio\_input\_event.

Buffers placed into the statusg by a driver MUST be at least the size of struct virtio input event.

A driver SHOULD ignore eventq input events it does not recognize. Note that evdev devices generally maintain backward compatibility by sending redundant events and relying on the consuming side using only the events it understands and ignoring the rest.

## 5.8.6.2 Device Requirements: Device Operation

A device MAY drop input events if the eventq does not have enough available buffers. It SHOULD NOT drop individual input events if they are part of a sequence forming one input device update. For example, a pointing device update typically consists of several input events, one for each axis, and a terminating EV\_SYN event. A device SHOULD either buffer or drop the entire sequence.

# 5.9 Crypto Device

The virtio crypto device is a virtual cryptography device as well as a virtual cryptographic accelerator. The virtio crypto device provides the following crypto services: CIPHER, MAC, HASH, and AEAD. Virtio crypto devices have a single control queue and at least one data queue. Crypto operation requests are placed into a data queue, and serviced by the device. Some crypto operation requests are only valid in the context of a session. The role of the control queue is facilitating control operation requests. Sessions management is realized with control operation requests.

## 5.9.1 Device ID

20

## 5.9.2 Virtqueues

0 dataq1

. . .

N-1 dataqN

N controlq

N is set by max\_dataqueues.

#### 5.9.3 Feature bits

VIRTIO\_CRYPTO\_F\_REVISION\_1 (0) revision 1. Revision 1 has a specific request format and other enhancements (which result in some additional requirements).

VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE (1) stateless mode requests are supported by the CIPHER service.

VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE (2) stateless mode requests are supported by the HASH service.

VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE (3) stateless mode requests are supported by the MAC service.

VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE (4) stateless mode requests are supported by the AEAD service.

#### 5.9.3.1 Feature bit requirements

Some crypto feature bits require other crypto feature bits (see 2.2.1):

VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE Requires VIRTIO CRYPTO F REVISION 1.

VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE Requires VIRTIO CRYPTO F REVISION 1.

VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE Requires VIRTIO\_CRYPTO\_F\_REVISION\_1.

VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE Requires VIRTIO\_CRYPTO\_F\_REVISION\_1.

## 5.9.4 Supported crypto services

The following crypto services are defined:

```
/* CIPHER service */
#define VIRTIO_CRYPTO_SERVICE_CIPHER 0
/* HASH service */
#define VIRTIO_CRYPTO_SERVICE_HASH 1
/* MAC (Message Authentication Codes) service */
#define VIRTIO_CRYPTO_SERVICE_MAC 2
/* AEAD (Authenticated Encryption with Associated Data) service */
#define VIRTIO_CRYPTO_SERVICE_AEAD 3
```

The above constants designate bits used to indicate the which of crypto services are offered by the device as described in, see 5.9.5.

#### 5.9.4.1 CIPHER services

The following CIPHER algorithms are defined:

```
#define VIRTIO_CRYPTO_NO_CIPHER 0
#define VIRTIO_CRYPTO_CIPHER_ARC4 1
#define VIRTIO_CRYPTO_CIPHER_AES_ECB 2
#define VIRTIO_CRYPTO_CIPHER_AES_CBC 3
#define VIRTIO_CRYPTO_CIPHER_AES_CTR 4
#define VIRTIO_CRYPTO_CIPHER_DES_ECB 5
#define VIRTIO_CRYPTO_CIPHER_DES_ECB 5
#define VIRTIO_CRYPTO_CIPHER_DES_CBC 6
```

```
#define VIRTIO_CRYPTO_CIPHER_3DES_ECB 7
#define VIRTIO_CRYPTO_CIPHER_3DES_CBC 8
#define VIRTIO_CRYPTO_CIPHER_3DES_CTR 9
#define VIRTIO_CRYPTO_CIPHER_KASUMI_F8 10
#define VIRTIO_CRYPTO_CIPHER_SNOW3G_UEA2 11
#define VIRTIO_CRYPTO_CIPHER_AES_F8 12
#define VIRTIO_CRYPTO_CIPHER_AES_XTS 13
#define VIRTIO_CRYPTO_CIPHER_ZUC_EEA3 14
```

## The above constants have two usages:

- 1. As bit numbers, used to tell the driver which CIPHER algorithms are supported by the device, see 5.9.5.
- 2. As values, used to designate the algorithm in (CIPHER type) crypto operation requests, see 5.9.7.2.1.

#### 5.9.4.2 HASH services

The following HASH algorithms are defined:

```
#define VIRTIO CRYPTO NO HASH
#define VIRTIO CRYPTO HASH MD5
                                         1
#define VIRTIO CRYPTO HASH SHA1
#define VIRTIO CRYPTO HASH SHA 224
                                        3
#define VIRTIO_CRYPTO_HASH_SHA_256
                                        4
#define VIRTIO CRYPTO HASH SHA 384
#define VIRTIO CRYPTO HASH SHA 512
#define VIRTIO CRYPTO HASH SHA3 224
#define VIRTIO_CRYPTO_HASH_SHA3_256
                                        8
#define VIRTIO_CRYPTO_HASH_SHA3_384
#define VIRTIO CRYPTO HASH SHA3 512
                                         10
#define VIRTIO_CRYPTO_HASH_SHA3_SHAKE128
                                              11
#define VIRTIO CRYPTO HASH SHA3 SHAKE256
```

## The above constants have two usages:

- 1. As bit numbers, used to tell the driver which HASH algorithms are supported by the device, see 5.9.5.
- 2. As values, used to designate the algorithm in (HASH type) crypto operation requires, see 5.9.7.2.1.

#### 5.9.4.3 MAC services

The following MAC algorithms are defined:

```
#define VIRTIO CRYPTO NO MAC
#define VIRTIO CRYPTO MAC HMAC MD5
                                                  1
#define VIRTIO CRYPTO MAC HMAC SHA1
#define VIRTIO CRYPTO MAC HMAC SHA 224
                                                  3
#define VIRTIO_CRYPTO_MAC_HMAC_SHA_256
                                                  4
#define VIRTIO CRYPTO MAC HMAC SHA 384
                                                  5
#define VIRTIO CRYPTO MAC HMAC SHA 512
                                                  6
#define VIRTIO CRYPTO MAC CMAC 3DES
#define VIRTIO CRYPTO MAC CMAC AES
#define VIRTIO CRYPTO MAC KASUMI F9
#define VIRTIO CRYPTO MAC SNOW3G UIA2
                                                  28
#define VIRTIO CRYPTO MAC GMAC AES
                                                  41
#define VIRTIO CRYPTO MAC GMAC TWOFISH
                                                  42
#define VIRTIO CRYPTO MAC CBCMAC AES
                                                  49
#define VIRTIO CRYPTO MAC CBCMAC KASUMI F9
                                                   50
#define VIRTIO CRYPTO MAC XCBC AES
                                                   53
#define VIRTIO CRYPTO MAC ZUC EIA3
```

### The above constants have two usages:

- 1. As bit numbers, used to tell the driver which MAC algorithms are supported by the device, see 5.9.5.
- 2. As values, used to designate the algorithm in (MAC type) crypto operation requests, see 5.9.7.2.1.

#### 5.9.4.4 AEAD services

The following AEAD algorithms are defined:

```
#define VIRTIO_CRYPTO_NO_AEAD 0
#define VIRTIO_CRYPTO_AEAD_GCM 1
#define VIRTIO_CRYPTO_AEAD_CCM 2
#define VIRTIO_CRYPTO_AEAD_CHACHA20_POLY1305 3
```

The above constants have two usages:

- 1. As bit numbers, used to tell the driver which AEAD algorithms are supported by the device, see 5.9.5.
- 2. As values, used to designate the algorithm in (DEAD type) crypto operation requests, see 5.9.7.2.1.

## 5.9.5 Device configuration layout

Crypto device configuration uses the following layout structure:

```
struct virtio crypto config {
   le32 status;
   le32 max dataqueues;
   le32 crypto services;
   /* Detailed algorithms mask */
   le32 cipher algo 1;
   le32 cipher algo h;
   le32 hash algo;
   le32 mac algo 1;
   le32 mac algo h;
   le32 aead algo;
   /* Maximum length of cipher key in bytes */
   le32 max cipher key len;
   /* Maximum length of authenticated key in bytes */
   le32 max auth key len;
   le32 reserved;
    /* Maximum size of each crypto request's content in bytes */
   le64 max size;
};
```

Currently, only one *status* bit is defined: VIRTIO\_CRYPTO\_S\_HW\_READY set indicates that the device is ready to process requests, this bit is read-only for the driver

```
#define VIRTIO_CRYPTO_S_HW_READY (1 << 0)
```

max\_dataqueues is the maximum number of data virtqueues that can be configured by the device. The driver MAY use only one data queue, or it can use more to achieve better performance.

```
crypto services crypto service offered, see 5.9.4.
```

```
cipher_algo_I CIPHER algorithms bits 0-31, see 5.9.4.1.
```

cipher\_algo\_h CIPHER algorithms bits 32-63, see 5.9.4.1.

hash\_algo HASH algorithms bits, see 5.9.4.2.

mac\_algo\_I MAC algorithms bits 0-31, see 5.9.4.3.

mac\_algo\_h MAC algorithms bits 32-63, see 5.9.4.3.

aead\_algo AEAD algorithms bits, see 5.9.4.4.

max\_cipher\_key\_len is the maximum length of cipher key supported by the device.

max\_auth\_key\_len is the maximum length of authenticated key supported by the device.

reserved is reserved for future use.

max\_size is the maximum size of the variable-length parameters of data operation of each crypto request's content supported by the device.

**Note:** Unless explicitly stated otherwise all lengths and sizes are in bytes.

### 5.9.5.1 Device Requirements: Device configuration layout

- The device MUST set max dataqueues to between 1 and 65535 inclusive.
- The device MUST set the status with valid flags, undefined flags MUST NOT be set.
- The device MUST accept and handle requests after status is set to VIRTIO CRYPTO S HW READY.
- The device MUST set crypto\_services based on the crypto services the device offers.
- The device MUST set detailed algorithms masks for each service advertised by crypto\_services. The
  device MUST NOT set the not defined algorithms bits.
- The device MUST set max size to show the maximum size of crypto request the device supports.
- The device MUST set *max\_cipher\_key\_len* to show the maximum length of cipher key if the device supports CIPHER service.
- The device MUST set *max\_auth\_key\_len* to show the maximum length of authenticated key if the device supports MAC service.

## 5.9.5.2 Driver Requirements: Device configuration layout

- The driver MUST read the status from the bottom bit of status to check whether the VIRTIO\_CRYPTO\_-S\_HW\_READY is set, and the driver MUST reread it after device reset.
- The driver MUST NOT transmit any requests to the device if the VIRTIO\_CRYPTO\_S\_HW\_READY is not set.
- The driver MUST read max\_dataqueues field to discover the number of data queues the device supports.
- The driver MUST read crypto services field to discover which services the device is able to offer.
- The driver SHOULD ignore the not defined algorithms bits.
- The driver MUST read the detailed algorithms fields based on crypto\_services field.
- The driver SHOULD read max\_size to discover the maximum size of the variable-length parameters of
  data operation of the crypto request's content the device supports and MUST guarantee that the size
  of each crypto request's content is within the max\_size, otherwise the request will fail and the driver
  MUST reset the device.
- The driver SHOULD read max\_cipher\_key\_len to discover the maximum length of cipher key the device supports and MUST guarantee that the key\_len (CIPHER service or AEAD service) is within the max\_cipher\_key\_len of the device configuration, otherwise the request will fail.
- The driver SHOULD read max\_auth\_key\_len to discover the maximum length of authenticated key the
  device supports and MUST guarantee that the auth\_key\_len (MAC service) is within the max\_auth\_key\_len of the device configuration, otherwise the request will fail.

### 5.9.6 Device Initialization

## 5.9.6.1 Driver Requirements: Device Initialization

- The driver MUST configure and initialize all virtqueues.
- The driver MUST read the supported crypto services from bits of crypto\_services.
- The driver MUST read the supported algorithms based on *crypto\_services* field.

## **5.9.7 Device Operation**

The operation of a virtio crypto device is driven by requests placed on the virtqueues. Requests consist of a queue-type specific header (specifying among others the operation) and an operation specific payload.

If VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated the device may support both session mode (See 5.9.7.2.1) and stateless mode operation requests. In stateless mode all operation parameters are supplied as a part of each request, while in session mode, some or all operation parameters are managed within the session. Stateless mode is guarded by feature bits 0-4 on a service level. If stateless mode is negotiated for a service, the service accepts both session mode and stateless requests; otherwise stateless mode requests are rejected (via operation status).

#### 5.9.7.1 Operation Status

The device MUST return a status code as part of the operation (both session operation and service operation) result. The valid operation status as follows:

```
enum VIRTIO_CRYPTO_STATUS {
    VIRTIO_CRYPTO_OK = 0,
    VIRTIO_CRYPTO_ERR = 1,
    VIRTIO_CRYPTO_BADMSG = 2,
    VIRTIO_CRYPTO_NOTSUPP = 3,
    VIRTIO_CRYPTO_INVSESS = 4,
    VIRTIO_CRYPTO_NOSPC = 5,
    VIRTIO_CRYPTO_MAX
};
```

- VIRTIO\_CRYPTO\_OK: success.
- VIRTIO\_CRYPTO\_BADMSG: authentication failed (only when AEAD decryption).
- VIRTIO\_CRYPTO\_NOTSUPP: operation or algorithm is unsupported.
- VIRTIO\_CRYPTO\_INVSESS: invalid session ID when executing crypto operations.
- VIRTIO\_CRYPTO\_NOSPC: no free session ID (only when the VIRTIO\_CRYPTO\_F\_REVISION\_1 feature bit is negotiated).
- VIRTIO\_CRYPTO\_ERR: any failure not mentioned above occurs.

### 5.9.7.2 Control Virtqueue

The driver uses the control virtqueue to send control commands to the device, such as session operations (See 5.9.7.2.1).

The header for controlq is of the following form:

```
#define VIRTIO CRYPTO OPCODE(service, op) (((service) << 8) | (op))</pre>
struct virtio crypto ctrl header {
#define VIRTIO CRYPTO CIPHER CREATE SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE CIPHER, 0x02)
#define VIRTIO CRYPTO CIPHER DESTROY SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE CIPHER, 0x03)
#define VIRTIO CRYPTO HASH CREATE SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE HASH, 0x02)
#define VIRTIO_CRYPTO_HASH_DESTROY_SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE HASH, 0x03)
#define VIRTIO CRYPTO MAC CREATE SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE MAC, 0x02)
#define VIRTIO CRYPTO MAC DESTROY SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE MAC, 0x03)
#define VIRTIO CRYPTO AEAD CREATE SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE AEAD, 0x02)
#define VIRTIO CRYPTO AEAD DESTROY SESSION \
      VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE AEAD, 0x03)
   le32 opcode;
   /* algo should be service-specific algorithms */
   le32 algo;
   le32 flag;
   le32 reserved;
};
```

The control request is composed of four parts:

```
struct virtio_crypto_op_ctrl_req {
    /* Device read only portion */

    struct virtio_crypto_ctrl_header header;

#define VIRTIO_CRYPTO_CTRLQ_OP_SPEC_HDR_LEGACY 56
    /* fixed length fields, opcode specific */
    u8 op_flf[flf_len];

    /* variable length fields, opcode specific */
```

```
u8 op_vlf[vlf_len];

/* Device write only portion */

/* op result or completion status */
u8 op_outcome[outcome_len];
};
```

header is a general header (see above).

op\_flf is the opcode (in header) specific fixed-length paramenters.

flf\_len depends on the VIRTIO\_CRYPTO\_F\_REVISION\_1 feature bit (see below).

*op\_vlf* is the opcode (in *header*) specific variable-length paramenters.

*vlf\_len* is the size of the specific structure used.

**Note:** The *vlf\_len* of session-destroy operation and the hash-session-create operation is ZERO.

- If the opcode (in header) is VIRTIO\_CRYPTO\_CIPHER\_CREATE\_SESSION then op\_flf is struct virtio\_crypto\_sym\_create\_session\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_sym\_create\_session\_flf is padded to 56 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_sym\_create\_session\_vlf.
- If the opcode (in *header*) is VIRTIO\_CRYPTO\_HASH\_CREATE\_SESSION then *op\_fif* is struct virtio\_crypto\_hash\_create\_session\_fif if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto hash create session fif is padded to 56 bytes if NOT negotiated.
- If the opcode (in header) is VIRTIO\_CRYPTO\_MAC\_CREATE\_SESSION then op\_flf is struct virtio\_crypto\_mac\_create\_session\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_mac\_create\_session\_flf is padded to 56 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_mac\_create\_session\_vlf.
- If the opcode (in header) is VIRTIO\_CRYPTO\_AEAD\_CREATE\_SESSION then op\_flf is struct virtio\_-crypto\_aead\_create\_session\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_-crypto\_aead\_create\_session\_flf is padded to 56 bytes if NOT negotiated, and op\_vlf is struct virtio\_-crypto\_aead\_create\_session\_vlf.
- If the opcode (in header) is VIRTIO\_CRYPTO\_CIPHER\_DESTROY\_SESSION or VIRTIO\_CRYPTO\_-HASH\_DESTROY\_SESSION or VIRTIO\_CRYPTO\_MAC\_DESTROY\_SESSION or VIRTIO\_CRYPTO\_-AEAD\_DESTROY\_SESSION then op\_flf is struct virtio\_crypto\_destroy\_session\_flf if VIRTIO\_CRYPTO\_-F\_REVISION\_1 is negotiated and struct virtio\_crypto\_destroy\_session\_flf is padded to 56 bytes if NOT negotiated.

*op\_outcome* stores the result of operation and must be struct virtio\_crypto\_destroy\_session\_input for destroy session or struct virtio\_crypto\_create\_session\_input for create session.

outcome len is the size of the structure used.

## 5.9.7.2.1 Session operation

The session is a handle which describes the cryptographic parameters to be applied to a number of buffers.

The following structure stores the result of session creation set by the device:

```
struct virtio_crypto_create_session_input {
   le64 session_id;
   le32 status;
   le32 padding;
};
```

A request to destroy a session includes the following information:

```
struct virtio_crypto_destroy_session_flf {
    /* Device read only portion */
    le64 session_id;
};
```

```
struct virtio_crypto_destroy_session_input {
    /* Device write only portion */
    u8 status;
};
```

# 5.9.7.2.1.1 Session operation: HASH session

The fixed-length parameters of HASH session requests is as follows:

```
struct virtio_crypto_hash_create_session_flf {
    /* Device read only portion */

    /* See VIRTIO_CRYPTO_HASH_* above */
    le32 algo;
    /* hash result length */
    le32 hash_result_len;
};
```

### 5.9.7.2.1.2 Session operation: MAC session

The fixed-length and the variable-length parameters of MAC session requests are as follows:

```
struct virtio_crypto_mac_create_session_flf {
    /* Device read only portion */

    /* See VIRTIO_CRYPTO_MAC_* above */
    le32 algo;
    /* hash result length */
    le32 hash_result_len;
    /* length of authenticated key */
    le32 auth_key_len;
    le32 padding;
};

struct virtio_crypto_mac_create_session_vlf {
    /* Device read only portion */

    /* The authenticated key */
    u8 auth_key[auth_key_len];
};
```

The length of auth key is specified in auth key len in the struct virtio crypto mac create session flf.

# 5.9.7.2.1.3 Session operation: Symmetric algorithms session

The request of symmetric session could be the CIPHER algorithms request or the chain algorithms (chaining CIPHER and HASH/MAC) request.

The fixed-length and the variable-length parameters of CIPHER session requests are as follows:

```
struct virtio_crypto_cipher_session_flf {
    /* Device read only portion */

    /* See VIRTIO_CRYPTO_CIPHER* above */
    le32 algo;
    /* length of key */
    le32 key_len;
#define VIRTIO_CRYPTO_OP_ENCRYPT 1
#define VIRTIO_CRYPTO_OP_DECRYPT 2
    /* encryption or decryption */
    le32 op;
    le32 padding;
};

struct virtio_crypto_cipher_session_vlf {
    /* Device read only portion */
```

```
/* The cipher key */
u8 cipher_key[key_len];
};
```

The length of cipher\_key is specified in key\_len in the struct virtio\_crypto\_cipher\_session\_flf.

The fixed-length and the variable-length parameters of Chain session requests are as follows:

```
struct virtio crypto alg chain session flf {
   /* Device read only portion */
#define VIRTIO CRYPTO SYM ALG CHAIN ORDER HASH THEN CIPHER 1
#define VIRTIO CRYPTO SYM ALG CHAIN ORDER CIPHER THEN HASH 2
   le32 alg_chain_order;
/* Plain hash */
#define VIRTIO CRYPTO SYM HASH MODE PLAIN
/* Authenticated hash (mac) */
#define VIRTIO CRYPTO SYM HASH MODE AUTH
/* Nested hash */
#define VIRTIO CRYPTO SYM HASH MODE NESTED
   le32 hash mode;
   struct virtio crypto cipher session flf cipher hdr;
#define VIRTIO CRYPTO ALG CHAIN SESS OP SPEC HDR SIZE 16
    /* fixed length fields, algo specific */
   u8 algo flf[VIRTIO CRYPTO ALG CHAIN SESS OP SPEC HDR SIZE];
   /* length of the additional authenticated data (AAD) in bytes */
   le32 aad len;
   le32 padding;
};
struct virtio crypto alg chain session vlf {
   /* Device read only portion */
   /* The cipher key */
   u8 cipher key[key len];
   /* The authenticated key */
   u8 auth key[auth_key_len];
};
```

hash mode decides the type used by algo flf.

algo flf is fixed to 16 bytes and MUST contains or be one of the following types:

- · struct virtio crypto hash create session flf
- struct virtio\_crypto\_mac\_create\_session\_flf

The data of unused part (if has) in algo\_flf will be ignored.

The length of cipher\_key is specified in key\_len in cipher\_hdr.

The length of auth\_key is specified in auth\_key\_len in struct virtio\_crypto\_mac\_create\_session\_flf.

The fixed-length parameters of Symmetric session requests are as follows:

```
le32 padding;
};
```

op\_flf is fixed to 48 bytes, MUST contains or be one of the following types:

- · struct virtio\_crypto\_cipher\_session\_flf
- struct virtio\_crypto\_alg\_chain\_session\_flf

The data of unused part (if has) in op\_flf will be ignored.

op\_type decides the type used by op\_flf.

The variable-length parameters of Symmetric session requests are as follows:

```
struct virtio_crypto_sym_create_session_vlf {
    /* Device read only portion */
    /* variable length fields, opcode specific */
    u8 op_vlf[vlf_len];
};
```

op\_vlf MUST contains or be one of the following types:

- · struct virtio crypto cipher session vlf
- struct virtio\_crypto\_alg\_chain\_session\_vlf

op\_type in struct virtio\_crypto\_sym\_create\_session\_flf decides the type used by op\_vlf.

vlf\_len is the size of the specific structure used.

#### 5.9.7.2.1.4 Session operation: AEAD session

The fixed-length and the variable-length parameters of AEAD session requests are as follows:

```
struct virtio_crypto_aead_create_session_flf {
    /* Device read only portion */
    /* See VIRTIO_CRYPTO_AEAD_* above */
   le32 algo;
    /* length of key */
   le32 key len;
   /* Authentication tag length */
   le32 tag_len;
    ^{\prime *} The length of the additional authenticated data (AAD) in bytes ^{*}/
   le32 aad len;
    /* encryption or decryption, See above VIRTIO CRYPTO OP * */
   le32 op;
    le32 padding;
};
struct virtio crypto aead create session vlf {
   /* Device read only portion */
   u8 key[key_len];
};
```

The length of key is specified in key\_len in struct virtio\_crypto\_aead\_create\_session\_flf.

# 5.9.7.2.1.5 Driver Requirements: Session operation: create session

- The driver MUST set the opcode field based on service type: CIPHER, HASH, MAC, or AEAD.
- The driver MUST set the control general header, the opcode specific header, the opcode specific extra parameters and the opcode specific outcome buffer in turn. See 5.9.7.2.
- The driver MUST set the reversed field to zero.

#### 5.9.7.2.1.6 Device Requirements: Session operation: create session

- The device MUST use the corresponding opcode specific structure according to the opcode in the control general header.
- The device MUST extract extra parameters according to the structures used.
- The device MUST set the status field to one of the following values of enum VIRTIO\_CRYPTO\_STATUS
  after finish a session creation:
  - VIRTIO\_CRYPTO\_OK if a session is created successfully.
  - VIRTIO CRYPTO NOTSUPP if the requested algorithm or operation is unsupported.
  - VIRTIO\_CRYPTO\_NOSPC if no free session ID (only when the VIRTIO\_CRYPTO\_F\_REVISION\_1 feature bit is negotiated).
  - VIRTIO\_CRYPTO\_ERR if failure not mentioned above occurs.
- The device MUST set the session\_id field to a unique session identifier only if the status is set to VIRTIO CRYPTO OK.

#### 5.9.7.2.1.7 Driver Requirements: Session operation: destroy session

- The driver MUST set the opcode field based on service type: CIPHER, HASH, MAC, or AEAD.
- The driver MUST set the session\_id to a valid value assigned by the device when the session was created.

### 5.9.7.2.1.8 Device Requirements: Session operation: destroy session

- The device MUST set the status field to one of the following values of enum VIRTIO\_CRYPTO\_STA-TUS.
  - VIRTIO CRYPTO OK if a session is created successfully.
  - VIRTIO\_CRYPTO\_ERR if any failure occurs.

#### 5.9.7.3 Data Virtqueue

The driver uses the data virtqueues to transmit crypto operation requests to the device, and completes the crypto operations.

The header for dataq is as follows:

```
struct virtio crypto op header {
#define VIRTIO CRYPTO CIPHER ENCRYPT \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE CIPHER, 0x00)
#define VIRTIO CRYPTO CIPHER DECRYPT \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE CIPHER, 0x01)
#define VIRTIO CRYPTO HASH \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE HASH, 0x00)
#define VIRTIO CRYPTO MAC \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE MAC, 0x00)
#define VIRTIO CRYPTO AEAD ENCRYPT \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE AEAD, 0x00)
#define VIRTIO CRYPTO AEAD DECRYPT \
   VIRTIO CRYPTO OPCODE (VIRTIO CRYPTO SERVICE AEAD, 0x01)
   le32 opcode;
    /* algo should be service-specific algorithms */
   le32 algo;
   le64 session id;
#define VIRTIO_CRYPTO FLAG SESSION MODE 1
   /* control flag to control the request */
   le32 flag;
   le32 padding;
};
```

Note: If VIRTIO CRYPTO F REVISION 1 is not negotiated the flag is ignored.

If VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated but VIRTIO\_CRYPTO\_F\_<SERVICE>\_STATE-LESS\_MODE is not negotiated, then the device SHOULD reject <SERVICE> requests if VIRTIO\_-CRYPTO\_FLAG\_SESSION\_MODE is not set (in *flag*).

#### The dataq request is composed of four parts:

```
struct virtio_crypto_op_data_req {
    /* Device read only portion */
    struct virtio_crypto_op_header header;

#define VIRTIO_CRYPTO_DATAQ_OP_SPEC_HDR_LEGACY 48
    /* fixed length fields, opcode specific */
    u8 op_flf[flf_len];

    /* Device read && write portion */
    /* variable length fields, opcode specific */
    u8 op_vlf[vlf_len];

    /* Device write only portion */
    struct virtio_crypto_inhdr inhdr;
};
```

header is a general header (see above).

op\_flf is the opcode (in header) specific header.

flf\_len depends on the VIRTIO\_CRYPTO\_F\_REVISION\_1 feature bit (see below).

op\_vlf is the opcode (in header) specific parameters.

*vlf\_len* is the size of the specific structure used.

- If the the opcode (in header) is VIRTIO\_CRYPTO\_CIPHER\_ENCRYPT or VIRTIO\_CRYPTO\_CIPHER\_-DECRYPT then:
  - If VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE is negotiated, op\_flf is struct virtio\_crypto\_sym\_data\_flf\_stateless, and op\_vlf is struct virtio\_crypto\_sym\_data\_vlf\_stateless.
  - If VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE is NOT negotiated, op\_flf is struct virtio\_crypto\_sym\_data\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_sym\_data\_flf is padded to 48 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_sym\_data\_vlf.
- If the the opcode (in *header*) is VIRTIO CRYPTO HASH:
  - If VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE is negotiated, op\_flf is struct virtio\_crypto\_hash\_data\_flf\_stateless, and op\_vlf is struct virtio\_crypto\_hash\_data\_vlf\_stateless.
  - If VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE is NOT negotiated, op\_flf is struct virtio\_crypto\_hash\_data\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_hash\_data\_flf is padded to 48 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_hash\_data\_vlf.
- If the the opcode (in header) is VIRTIO CRYPTO MAC:
  - If VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE is negotiated, op\_flf is struct virtio\_crypto\_mac data flf stateless, and op\_vlf is struct virtio crypto mac data vlf stateless.
  - If VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE is NOT negotiated, op\_flf is struct virtio\_crypto\_mac\_data\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_mac\_data\_flf is padded to 48 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_mac\_data\_vlf.
- If the the opcode (in *header*) is VIRTIO\_CRYPTO\_AEAD\_ENCRYPT or VIRTIO\_CRYPTO\_AEAD\_-DECRYPT then:
  - If VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE is negotiated, op\_flf is struct virtio\_crypto\_aead\_data\_flf\_stateless, and op\_vlf is struct virtio\_crypto\_aead\_data\_vlf\_stateless.
  - If VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE is NOT negotiated, op\_flf is struct virtio\_crypto\_aead\_data\_flf if VIRTIO\_CRYPTO\_F\_REVISION\_1 is negotiated and struct virtio\_crypto\_aead\_data\_flf is padded to 48 bytes if NOT negotiated, and op\_vlf is struct virtio\_crypto\_aead\_data\_vlf.

inhdr is a unified input header that used to return the status of the operations, is defined as follows:

```
struct virtio_crypto_inhdr {
   u8 status;
};
```

#### 5.9.7.4 HASH Service Operation

Session mode HASH service requests are as follows:

```
struct virtio_crypto_hash_data_flf {
    /* length of source data */
    le32 src_data_len;
    /* hash result length */
    le32 hash_result_len;
};

struct virtio_crypto_hash_data_vlf {
    /* Device read only portion */
    /* Source data */
    u8 src_data[src_data_len];

    /* Device write only portion */
    /* Hash result data */
    u8 hash_result[hash_result_len];
};
```

Each data request uses the virtio\_crypto\_hash\_data\_flf structure and the virtio\_crypto\_hash\_data\_vlf structure to store information used to run the HASH operations.

src\_data is the source data that will be processed. src\_data\_len is the length of source data. hash\_result
is the result data and hash\_result\_len is the length of it.

Stateless mode HASH service requests are as follows:

```
struct virtio_crypto_hash_data_flf_stateless {
   struct {
       /* See VIRTIO CRYPTO_HASH_* above */
       le32 algo;
   } sess_para;
   /* length of source data */
   le32 src data len;
   /* hash result length */
   le32 hash result len;
   le32 reserved;
struct virtio crypto hash data vlf stateless {
   /* Device read only portion */
   /* Source data */
   u8 src data[src data len];
   /* Device write only portion */
   /* Hash result data */
   u8 hash result[hash result len];
};
```

#### 5.9.7.4.1 Driver Requirements: HASH Service Operation

- If the driver uses the session mode, then the driver MUST set session\_id in struct virtio\_crypto\_op\_header to a valid value assigned by the device when the session was created.
- If the VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE feature bit is negotiated, 1) if the driver uses the stateless mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to ZERO and MUST set the fields in struct virtio\_crypto\_hash\_data\_flf\_stateless.sess\_para, 2) if the driver uses the session mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to VIRTIO\_-CRYPTO\_FLAG\_SESSION\_MODE.
- The driver MUST set opcode in struct virtio crypto op header to VIRTIO CRYPTO HASH.

# 5.9.7.4.2 Device Requirements: HASH Service Operation

• The device MUST use the corresponding structure according to the opcode in the data general header.

- If the VIRTIO\_CRYPTO\_F\_HASH\_STATELESS\_MODE feature bit is negotiated, the device MUST parse flag field in struct virtio crypto op header in order to decide which mode the driver uses.
- The device MUST copy the results of HASH operations in the hash result[] if HASH operations success.
- The device MUST set *status* in struct virtio\_crypto\_inhdr to one of the following values of enum VIR-TIO CRYPTO STATUS:
  - VIRTIO CRYPTO OK if the operation success.
  - VIRTIO CRYPTO NOTSUPP if the requested algorithm or operation is unsupported.
  - VIRTIO\_CRYPTO\_INVSESS if the session ID invalid when in session mode.
  - VIRTIO CRYPTO ERR if any failure not mentioned above occurs.

#### 5.9.7.5 MAC Service Operation

Session mode MAC service requests are as follows:

```
struct virtio_crypto_mac_data_flf {
    struct virtio_crypto_hash_data_flf hdr;
};

struct virtio_crypto_mac_data_vlf {
    /* Device read only portion */
    /* Source data */
    u8 src_data[src_data_len];

    /* Device write only portion */
    /* Hash result data */
    u8 hash_result[hash_result_len];
};
```

Each request uses the virtio\_crypto\_mac\_data\_flf structure and the virtio\_crypto\_mac\_data\_vlf structure to store information used to run the MAC operations.

src\_data is the source data that will be processed. src\_data\_len is the length of source data. hash\_result
is the result data and hash\_result\_len is the length of it.

Stateless mode MAC service requests are as follows:

```
struct virtio crypto mac data flf stateless {
   struct {
       /* See VIRTIO CRYPTO MAC * above */
       le32 algo;
        /* length of authenticated key */
       le32 auth key len;
   } sess_para;
   /* length of source data */
   le32 src data len;
   /* hash result length */
   le32 hash result len;
};
struct virtio crypto mac data vlf stateless {
   /* Device read only portion */
   /* The authenticated key */
   u8 auth key[auth key len];
   /* Source data */
   u8 src data[src data len];
   /* Device write only portion */
   /* Hash result data */
   u8 hash result[hash result len];
};
```

auth\_key is the authenticated key that will be used during the process. auth\_key\_len is the length of the key.

# 5.9.7.5.1 Driver Requirements: MAC Service Operation

- If the driver uses the session mode, then the driver MUST set session\_id in struct virtio\_crypto\_op\_header to a valid value assigned by the device when the session was created.
- If the VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE feature bit is negotiated, 1) if the driver uses
  the stateless mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to ZERO
  and MUST set the fields in struct virtio\_crypto\_mac\_data\_flf\_stateless.sess\_para, 2) if the driver uses
  the session mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to VIRTIO\_CRYPTO FLAG SESSION MODE.
- The driver MUST set opcode in struct virtio\_crypto\_op\_header to VIRTIO\_CRYPTO\_MAC.

#### 5.9.7.5.2 Device Requirements: MAC Service Operation

- If the VIRTIO\_CRYPTO\_F\_MAC\_STATELESS\_MODE feature bit is negotiated, the device MUST parse flag field in struct virtio crypto op header in order to decide which mode the driver uses.
- The device MUST copy the results of MAC operations in the hash\_result[] if HASH operations success.
- The device MUST set status in struct virtio\_crypto\_inhdr to one of the following values of enum VIR-TIO\_CRYPTO\_STATUS:
  - VIRTIO CRYPTO OK if the operation success.
  - VIRTIO\_CRYPTO\_NOTSUPP if the requested algorithm or operation is unsupported.
  - VIRTIO CRYPTO INVSESS if the session ID invalid when in session mode.
  - VIRTIO CRYPTO ERR if any failure not mentioned above occurs.

# 5.9.7.6 Symmetric algorithms Operation

Session mode CIPHER service requests are as follows:

```
struct virtio_crypto_cipher_data_flf {
    ^{\star} Byte Length of valid IV/Counter data pointed to by the below iv data.
    * For block ciphers in CBC or F8 mode, or for Kasumi in F8 mode, or for
       SNOW3G in UEA2 mode, this is the length of the IV (which
    * must be the same as the block length of the cipher).
    \mbox{\scriptsize \star} For block ciphers in CTR mode, this is the length of the counter
        (which must be the same as the block length of the cipher).
   le32 iv len;
   /* length of source data */
   le32 src data len;
    /* length of destination data */
   le32 dst data len;
   le32 padding;
};
struct virtio crypto cipher data vlf {
   /* Device read only portion */
    * Initialization Vector or Counter data.
     ^{\star} For block ciphers in CBC or F8 mode, or for Kasumi in F8 mode, or for
    * SNOW3G in UEA2 mode, this is the Initialization Vector (IV)
       value.
    * For block ciphers in CTR mode, this is the counter.
    * For AES-XTS, this is the 128bit tweak, i, from IEEE Std 1619-2007.
    * The IV/Counter will be updated after every partial cryptographic
    * operation.
   u8 iv[iv len];
   /* Source data */
   u8 src data[src data len];
    /* Device write only portion */
   /* Destination data */
```

```
u8 dst_data[dst_data_len];
};
```

# Session mode requests of algorithm chaining are as follows:

```
struct virtio crypto alg chain data flf {
   le32 iv len;
   /* Length of source data */
   le32 src data len;
   /* Length of destination data */
   le32 dst data len;
   /* Starting point for cipher processing in source data */
   le32 cipher start src offset;
   ^{\prime \star} Length of the source data that the cipher will be computed on ^{\star \prime}
   le32 len_to_cipher;
    /* Starting point for hash processing in source data */
   le32 hash start src offset;
   /* Length of the source data that the hash will be computed on */
   le32 len to hash;
   /* Length of the additional auth data */
   le32 aad len;
   /* Length of the hash result */
   le32 hash result len;
   le32 reserved;
};
struct virtio crypto alg chain data vlf {
   /* Device read only portion */
    /* Initialization Vector or Counter data */
   u8 iv[iv len];
   /* Source data */
   u8 src data[src data len];
   /\star Additional authenticated data if exists \star/
   u8 aad[aad len];
   /* Device write only portion */
    /* Destination data */
   u8 dst data[dst data len];
   /* Hash result data */
   u8 hash result[hash result len];
```

### Session mode requests of symmetric algorithm are as follows:

Each request uses the virtio\_crypto\_sym\_data\_flf structure and the virtio\_crypto\_sym\_data\_flf structure to store information used to run the CIPHER operations.

op type flf is the op type specific header, it MUST starts with or be one of the following structures:

- struct virtio crypto cipher data flf
- struct virtio\_crypto\_alg\_chain\_data\_flf

The length of op\_type\_fif is fixed to 40 bytes, the data of unused part (if has) will be ingored.

op type vlf is the op type specific parameters, it MUST starts with or be one of the following structures:

- struct virtio\_crypto\_cipher\_data\_vlf
- · struct virtio\_crypto\_alg\_chain\_data\_vlf

sym\_para\_len is the size of the specific structure used.

Stateless mode CIPHER service requests are as follows:

```
struct virtio crypto cipher data flf stateless {
       /* See VIRTIO_CRYPTO_CIPHER* above */
       le32 algo;
       /* length of key */
       le32 key_len;
       /* See VIRTIO CRYPTO OP * above */
       le32 op;
   } sess_para;
    * Byte Length of valid IV/Counter data pointed to by the below iv data.
   le32 iv_len;
    /* length of source data */
   le32 src_data_len;
   /* length of destination data */
   le32 dst data len;
};
struct virtio_crypto_cipher_data_vlf_stateless {
   /* Device read only portion */
   /* The cipher key */
   u8 cipher key[key len];
   /* Initialization Vector or Counter data. */
   u8 iv[iv len];
   /* Source data */
   u8 src data[src data len];
   /* Device write only portion */
   /* Destination data */
   u8 dst data[dst data len];
};
```

#### Stateless mode requests of algorithm chaining are as follows:

```
struct virtio crypto alg chain data flf stateless {
   struct {
       /\star See VIRTIO CRYPTO SYM ALG CHAIN ORDER \star above \star/
       le32 alg chain order;
       /* length of the additional authenticated data in bytes */
       le32 aad len;
        struct {
           /* See VIRTIO_CRYPTO_CIPHER* above */
           le32 algo;
            /* length of key */
           le32 key len;
            /* See VIRTIO CRYPTO OP * above */
           le32 op;
       } cipher;
        struct {
            /* See VIRTIO CRYPTO HASH * or VIRTIO CRYPTO MAC * above */
           le32 algo;
            /* length of authenticated key */
           le32 auth_key_len;
            /* See VIRTIO CRYPTO SYM HASH MODE * above */
            le32 hash mode;
        } hash;
```

```
} sess para;
   le32 iv len;
   /* Length of source data */
   le32 src data_len;
    /* Length of destination data */
   le32 dst data_len;
   /* Starting point for cipher processing in source data */
   le32 cipher start src offset;
   /* Length of the source data that the cipher will be computed on */
   le32 len to cipher;
   /* Starting point for hash processing in source data */
   le32 hash start src offset;
   /st Length of the source data that the hash will be computed on st/
   le32 len to hash;
    /* Length of the additional auth data */
   le32 aad len;
    /* Length of the hash result */
   le32 hash result len;
   le32 reserved;
};
struct virtio crypto alg chain data vlf stateless {
   /* Device read only portion */
   /* The cipher key */
   u8 cipher key[key len];
   /* The auth key */
   u8 auth_key[auth_key_len];
   /* Initialization Vector or Counter data */
   u8 iv[iv_len];
   /* Additional authenticated data if exists */
   u8 aad[aad len];
   /* Source data */
   u8 src data[src data len];
   /* Device write only portion */
    /* Destination data */
   u8 dst data[dst data len];
   /* Hash result data */
   u8 hash result[hash result len];
};
```

#### Stateless mode requests of symmetric algorithm are as follows:

op\_type\_flf is the op\_type specific header, it MUST starts with or be one of the following structures:

- · struct virtio crypto cipher data flf stateless
- struct virtio\_crypto\_alg\_chain\_data\_flf\_stateless

The length of op\_type\_flf is fixed to 72 bytes, the data of unused part (if has) will be ingored.

op type vlf is the op type specific parameters, it MUST starts with or be one of the following structures:

struct virtio\_crypto\_cipher\_data\_vlf\_stateless

struct virtio\_crypto\_alg\_chain\_data\_vlf\_stateless

sym\_para\_len is the size of the specific structure used.

### 5.9.7.6.1 Driver Requirements: Symmetric algorithms Operation

- If the driver uses the session mode, then the driver MUST set session\_id in struct virtio\_crypto\_op\_header to a valid value assigned by the device when the session was created.
- If the VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE feature bit is negotiated, 1) if the driver uses
  the stateless mode, then the driver MUST set the flag field in struct virtio\_crypto\_op\_header to ZERO
  and MUST set the fields in struct virtio\_crypto\_cipher\_data\_flf\_stateless.sess\_para or struct virtio\_crypto\_alg\_chain\_data\_flf\_stateless.sess\_para, 2) if the driver uses the session mode, then the driver
  MUST set the flag field in struct virtio\_crypto\_op\_header to VIRTIO\_CRYPTO\_FLAG\_SESSION\_MODE.
- The driver MUST set the opcode field in struct virtio\_crypto\_op\_header to VIRTIO\_CRYPTO\_CIPHER\_-ENCRYPT or VIRTIO\_CRYPTO\_CIPHER\_DECRYPT.
- The driver MUST specify the fields of struct virtio\_crypto\_cipher\_data\_flf in struct virtio\_crypto\_sym\_-data\_flf and struct virtio\_crypto\_cipher\_data\_vlf in struct virtio\_crypto\_sym\_data\_vlf if the request is based on VIRTIO CRYPTO SYM OP CIPHER.
- The driver MUST specify the fields of struct virtio\_crypto\_alg\_chain\_data\_flf in struct virtio\_crypto\_sym\_data\_flf and struct virtio\_crypto\_alg\_chain\_data\_vlf in struct virtio\_crypto\_sym\_data\_vlf if the request is of the VIRTIO\_CRYPTO\_SYM\_OP\_ALGORITHM\_CHAINING type.

# 5.9.7.6.2 Device Requirements: Symmetric algorithms Operation

- If the VIRTIO\_CRYPTO\_F\_CIPHER\_STATELESS\_MODE feature bit is negotiated, the device MUST parse *flag* field in struct virtio crypto op header in order to decide which mode the driver uses.
- The device MUST parse the virtio\_crypto\_sym\_data\_req based on the opcode field in general header.
- The device MUST parse the fields of struct virtio\_crypto\_cipher\_data\_flf in struct virtio\_crypto\_sym\_-data\_flf and struct virtio\_crypto\_cipher\_data\_vlf in struct virtio\_crypto\_sym\_data\_vlf if the request is based on VIRTIO CRYPTO SYM OP CIPHER.
- The device MUST parse the fields of struct virtio\_crypto\_alg\_chain\_data\_flf in struct virtio\_crypto\_sym\_data\_flf and struct virtio\_crypto\_alg\_chain\_data\_vlf in struct virtio\_crypto\_sym\_data\_vlf if the request is of the VIRTIO CRYPTO SYM OP ALGORITHM CHAINING type.
- The device MUST copy the result of cryptographic operation in the dst\_data[] in both plain CIPHER mode and algorithms chain mode.
- The device MUST check the *para.add\_len* is bigger than 0 before parse the additional authenticated data in plain algorithms chain mode.
- The device MUST copy the result of HASH/MAC operation in the hash\_result[] is of the VIRTIO\_-CRYPTO\_SYM\_OP\_ALGORITHM\_CHAINING type.
- The device MUST set the *status* field in struct virtio\_crypto\_inhdr to one of the following values of enum VIRTIO CRYPTO STATUS:
  - VIRTIO\_CRYPTO\_OK if the operation success.
  - VIRTIO\_CRYPTO\_NOTSUPP if the requested algorithm or operation is unsupported.
  - VIRTIO CRYPTO INVSESS if the session ID is invalid in session mode.
  - VIRTIO CRYPTO ERR if failure not mentioned above occurs.

### 5.9.7.7 AEAD Service Operation

Session mode requests of symmetric algorithm are as follows:

```
struct virtio_crypto_aead_data_flf {
    /*
    * Byte Length of valid IV data.
    *
    * For GCM mode, this is either 12 (for 96-bit IVs) or 16, in which
    * case iv points to J0.
    * For CCM mode, this is the length of the nonce, which can be in the
    * range 7 to 13 inclusive.
    */
```

```
le32 iv len;
    /* length of additional auth data */
   le32 aad len;
   /* length of source data */
   le32 src data_len;
    /st length of dst data, this should be at least src data len + tag len st/
   le32 dst data len;
    /* Authentication tag length */
   le32 tag len;
   le32 reserved;
};
struct virtio crypto aead data vlf {
   /* Device read only portion */
     * Initialization Vector data.
     ^{\star} For GCM mode, this is either the IV (if the length is 96 bits) or J0 \,
        (for other sizes), where JO is as defined by NIST SP800-38D.
        Regardless of the IV length, a full 16 bytes needs to be allocated.
     ^{\star} For CCM mode, the first byte is reserved, and the nonce should be
        written starting at &iv[1] (to allow space for the implementation
        to write in the flags in the first byte). Note that a full 16 bytes
        should be allocated, even though the iv len field will have
        a value less than this.
     ^{\star} The IV will be updated after every partial cryptographic operation.
    * /
   u8 iv[iv len];
    /* Source data */
   u8 src data[src data len];
   /* Additional authenticated data if exists */
   u8 aad[aad len];
    /* Device write only portion */
   /* Pointer to output data */
   u8 dst data[dst data len];
};
```

Each request uses the virtio\_crypto\_aead\_data\_flf structure and the virtio\_crypto\_aead\_data\_flf structure to store information used to run the AEAD operations.

Stateless mode AEAD service requests are as follows:

```
struct virtio crypto aead data flf stateless {
   struct {
       /* See VIRTIO_CRYPTO_AEAD_* above */
       le32 algo;
       /* length of key */
       le32 key len;
       /* encrypt or decrypt, See above VIRTIO CRYPTO OP * */
       le32 op;
   } sess_para;
    /* Byte Length of valid IV data. */
   le32 iv len;
   /* Authentication tag length */
   le32 tag_len;
   /* length of additional auth data */
   le32 aad len;
   /* length of source data */
   le32 src data len;
    /st length of dst data, this should be at least src data len + tag len st/
   le32 dst_data_len;
};
struct virtio crypto aead data vlf stateless {
   /* Device read only portion */
/* The cipher key */
```

```
u8 key[key_len];
/* Initialization Vector data. */
u8 iv[iv_len];
/* Source data */
u8 src_data[src_data_len];
/* Additional authenticated data if exists */
u8 aad[aad_len];

/* Device write only portion */
/* Pointer to output data */
u8 dst_data[dst_data_len];
};
```

# 5.9.7.7.1 Driver Requirements: AEAD Service Operation

- If the driver uses the session mode, then the driver MUST set session\_id in struct virtio\_crypto\_op\_header to a valid value assigned by the device when the session was created.
- If the VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE feature bit is negotiated, 1) if the driver uses the stateless mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to ZERO and MUST set the fields in struct virtio\_crypto\_aead\_data\_flf\_stateless.sess\_para, 2) if the driver uses the session mode, then the driver MUST set the *flag* field in struct virtio\_crypto\_op\_header to VIRTIO\_-CRYPTO\_FLAG\_SESSION\_MODE.
- The driver MUST set the opcode field in struct virtio\_crypto\_op\_header to VIRTIO\_CRYPTO\_AEAD\_-ENCRYPT or VIRTIO\_CRYPTO\_AEAD\_DECRYPT.

# 5.9.7.7.2 Device Requirements: AEAD Service Operation

- If the VIRTIO\_CRYPTO\_F\_AEAD\_STATELESS\_MODE feature bit is negotiated, the device MUST parse the virtio\_crypto\_aead\_data\_vlf\_stateless based on the opcode field in general header.
- The device MUST copy the result of cryptographic operation in the dst\_data[].
- The device MUST copy the authentication tag in the dst\_data[] offset the cipher result.
- The device MUST set the status field in struct virtio\_crypto\_inhdr to one of the following values of enum VIRTIO CRYPTO STATUS:
- When the opcode field is VIRTIO\_CRYPTO\_AEAD\_DECRYPT, the device MUST verify and return the verification result to the driver.
  - VIRTIO CRYPTO OK if the operation success.
  - VIRTIO\_CRYPTO\_NOTSUPP if the requested algorithm or operation is unsupported.
  - VIRTIO CRYPTO BADMSG if the verification result is incorrect.
  - VIRTIO CRYPTO INVSESS if the session ID invalid when in session mode.
  - VIRTIO CRYPTO ERR if any failure not mentioned above occurs.

# 5.10 Socket Device

The virtio socket device is a zero-configuration socket communications device. It facilitates data transfer between the guest and device without using the Ethernet or IP protocols.

#### 5.10.1 Device ID

19

#### 5.10.2 Virtqueues

**0** rx

1 tx

2 event

### 5.10.3 Feature bits

If no feature bit is set, only stream socket type is supported. If VIRTIO\_VSOCK\_F\_SEQPACKET has been negotiated, the device MAY act as if VIRTIO\_VSOCK\_F\_STREAM has also been negotiated.

VIRTIO\_VSOCK\_F\_STREAM (0) stream socket type is supported.

**VIRTIO\_VSOCK\_F\_SEQPACKET (1)** seqpacket socket type is supported.

# 5.10.4 Device configuration layout

Socket device configuration uses the following layout structure:

```
struct virtio_vsock_config {
  le64 guest_cid;
};
```

The *guest\_cid* field contains the guest's context ID, which uniquely identifies the device for its lifetime. The upper 32 bits of the CID are reserved and zeroed.

The following CIDs are reserved and cannot be used as the guest's context ID:

CID	Notes
0	Reserved
1	Reserved
2	Well-known CID for the host
0xfffffff	Reserved
0xfffffffffffx0	Reserved

#### 5.10.5 Device Initialization

- 1. The guest's cid is read from guest\_cid.
- 2. Buffers are added to the event virtqueue to receive events from the device.
- 3. Buffers are added to the rx virtqueue to start receiving packets.

# 5.10.6 Device Operation

Packets transmitted or received contain a header before the payload:

```
struct virtio_vsock_hdr {
  le64 src_cid;
  le64 dst_cid;
  le32 src_port;
  le32 dst_port;
  le32 len;
  le16 type;
  le16 op;
  le32 flags;
  le32 buf_alloc;
  le32 fwd_cnt;
};
```

The upper 32 bits of src\_cid and dst\_cid are reserved and zeroed.

Most packets simply transfer data but control packets are also used for connection and buffer space management. *op* is one of the following operation constants:

```
#define VIRTIO_VSOCK_OP_INVALID 0
/* Connect operations */
#define VIRTIO_VSOCK_OP_REQUEST 1
#define VIRTIO_VSOCK_OP_RESPONSE 2
#define VIRTIO_VSOCK_OP_RST 3
```

```
#define VIRTIO_VSOCK_OP_SHUTDOWN 4

/* To send payload */

#define VIRTIO_VSOCK_OP_RW 5

/* Tell the peer our credit info */

#define VIRTIO_VSOCK_OP_CREDIT_UPDATE 6

/* Request the peer to send the credit info to us */

#define VIRTIO_VSOCK_OP_CREDIT_REQUEST 7
```

### 5.10.6.1 Virtqueue Flow Control

The tx virtqueue carries packets initiated by applications and replies to received packets. The rx virtqueue carries packets initiated by the device and replies to previously transmitted packets.

If both rx and tx virtqueues are filled by the driver and device at the same time then it appears that a deadlock is reached. The driver has no free tx descriptors to send replies. The device has no free rx descriptors to send replies either. Therefore neither device nor driver can process virtqueues since that may involve sending new replies.

This is solved using additional resources outside the virtqueue to hold packets. With additional resources, it becomes possible to process incoming packets even when outgoing packets cannot be sent.

Eventually even the additional resources will be exhausted and further processing is not possible until the other side processes the virtqueue that it has neglected. This stop to processing prevents one side from causing unbounded resource consumption in the other side.

### 5.10.6.1.1 Driver Requirements: Device Operation: Virtqueue Flow Control

The rx virtqueue MUST be processed even when the tx virtqueue is full so long as there are additional resources available to hold packets outside the tx virtqueue.

## 5.10.6.1.2 Device Requirements: Device Operation: Virtqueue Flow Control

The tx virtqueue MUST be processed even when the rx virtqueue is full so long as there are additional resources available to hold packets outside the rx virtqueue.

# 5.10.6.2 Addressing

Flows are identified by a (source, destination) address tuple. An address consists of a (cid, port number) tuple. The header fields used for this are *src\_cid*, *src\_port*, *dst\_cid*, and *dst\_port*.

Currently stream and seqpacket sockets are supported. *type* is 1 (VIRTIO\_VSOCK\_TYPE\_STREAM) for stream socket types, and 2 (VIRTIO\_VSOCK\_TYPE\_SEQPACKET) for seqpacket socket types.

```
#define VIRTIO_VSOCK_TYPE_STREAM 1
#define VIRTIO_VSOCK_TYPE_SEQPACKET 2
```

Stream sockets provide in-order, guaranteed, connection-oriented delivery without message boundaries. Seqpacket sockets provide in-order, guaranteed, connection-oriented delivery with message and record boundaries.

### 5.10.6.3 Buffer Space Management

buf\_alloc and fwd\_cnt are used for buffer space management of stream sockets. The guest and the device publish how much buffer space is available per socket. Only payload bytes are counted and header bytes are not included. This facilitates flow control so data is never dropped.

buf\_alloc is the total receive buffer space, in bytes, for this socket. This includes both free and in-use buffers. fwd\_cnt is the free-running bytes received counter. The sender calculates the amount of free receive buffer space as follows:

```
/* tx_cnt is the sender's free-running bytes transmitted counter */
u32 peer_free = peer_buf_alloc - (tx_cnt - peer_fwd_cnt);
```

If there is insufficient buffer space, the sender waits until virtqueue buffers are returned and checks <code>buf\_-alloc</code> and <code>fwd\_cnt</code> again. Sending the VIRTIO\_VSOCK\_OP\_CREDIT\_REQUEST packet queries how much buffer space is available. The reply to this query is a VIRTIO\_VSOCK\_OP\_CREDIT\_UPDATE packet. It is also valid to send a VIRTIO\_VSOCK\_OP\_CREDIT\_UPDATE packet without previously receiving a VIRTIO\_VSOCK\_OP\_CREDIT\_REQUEST packet. This allows communicating updates any time a change in buffer space occurs.

#### 5.10.6.3.1 Driver Requirements: Device Operation: Buffer Space Management

VIRTIO\_VSOCK\_OP\_RW data packets MUST only be transmitted when the peer has sufficient free buffer space for the payload.

All packets associated with a stream flow MUST contain valid information in buf alloc and fwd cnt fields.

# 5.10.6.3.2 Device Requirements: Device Operation: Buffer Space Management

VIRTIO\_VSOCK\_OP\_RW data packets MUST only be transmitted when the peer has sufficient free buffer space for the payload.

All packets associated with a stream flow MUST contain valid information in buf\_alloc and fwd\_cnt fields.

#### 5.10.6.4 Receive and Transmit

The driver queues outgoing packets on the tx virtqueue and incoming packet receive buffers on the rx virtqueue. Packets are of the following form:

```
struct virtio_vsock_packet {
   struct virtio_vsock_hdr hdr;
   u8 data[];
};
```

Virtqueue buffers for outgoing packets are read-only. Virtqueue buffers for incoming packets are write-only.

#### 5.10.6.4.1 Driver Requirements: Device Operation: Receive and Transmit

The *guest cid* configuration field MUST be used as the source CID when sending outgoing packets.

A VIRTIO\_VSOCK\_OP\_RST reply MUST be sent if a packet is received with an unknown type value.

#### 5.10.6.4.2 Device Requirements: Device Operation: Receive and Transmit

The guest cid configuration field MUST NOT contain a reserved CID as listed in 5.10.4.

A VIRTIO VSOCK OP RST reply MUST be sent if a packet is received with an unknown type value.

#### 5.10.6.5 Stream Sockets

Connections are established by sending a VIRTIO\_VSOCK\_OP\_REQUEST packet. If a listening socket exists on the destination a VIRTIO\_VSOCK\_OP\_RESPONSE reply is sent and the connection is established. A VIRTIO\_VSOCK\_OP\_RST reply is sent if a listening socket does not exist on the destination or the destination has insufficient resources to establish the connection.

When a connected socket receives VIRTIO\_VSOCK\_OP\_SHUTDOWN the header *flags* field bit VIRTIO\_-VSOCK\_SHUTDOWN\_F\_RECEIVE (bit 0) set indicates that the peer will not receive any more data and bit VIRTIO\_VSOCK\_SHUTDOWN\_F\_SEND (bit 1) set indicates that the peer will not send any more data. These hints are permanent once sent and successive packets with bits clear do not reset them.

```
#define VIRTIO_VSOCK_SHUTDOWN_F_RECEIVE 0
#define VIRTIO_VSOCK_SHUTDOWN_F_SEND 1
```

The VIRTIO\_VSOCK\_OP\_RST packet aborts the connection process or forcibly disconnects a connected socket.

Clean disconnect is achieved by one or more VIRTIO\_VSOCK\_OP\_SHUTDOWN packets that indicate no more data will be sent and received, followed by a VIRTIO\_VSOCK\_OP\_RST response from the peer. If no VIRTIO\_VSOCK\_OP\_RST response is received within an implementation-specific amount of time, a VIRTIO\_VSOCK\_OP\_RST packet is sent to forcibly disconnect the socket.

The clean disconnect process ensures that neither peer reuses the (source, destination) address tuple for a new connection while the other peer is still processing the old connection.

#### 5.10.6.6 Segpacket Sockets

# 5.10.6.6.1 Message and record boundaries

Two types of boundaries are supported: message and record boundaries.

A message contains data sent in a single operation. A single message can be split into multiple RW packets. To provide message boundaries, last RW packet of each message has VIRTIO\_VSOCK\_SEQ\_EOM bit (bit 0) set in the *flags* of packet's header.

Record is any number of subsequent messages, where last message is sent with POSIX MSG\_EOR flag set. Record boundary means that receiver gets MSG\_EOR flag set in the corresponding message where sender set it. To provide record boundaries, last RW packet of each record has VIRTIO\_VSOCK\_SEQ\_EOR bit (bit 1) set in the *flags* of packet's header.

```
#define VIRTIO_VSOCK_SEQ_EOM (1 << 0)
#define VIRTIO_VSOCK_SEQ_EOR (1 << 1)</pre>
```

#### 5.10.6.7 Device Events

Certain events are communicated by the device to the driver using the event virtgueue.

The event buffer is as follows:

```
#define VIRTIO_VSOCK_EVENT_TRANSPORT_RESET 0
struct virtio_vsock_event {
    le32 id;
};
```

The VIRTIO\_VSOCK\_EVENT\_TRANSPORT\_RESET event indicates that communication has been interrupted. This usually occurs if the guest has been physically migrated. The driver shuts down established connections and the *guest\_cid* configuration field is fetched again. Existing listen sockets remain but their CID is updated to reflect the current *guest\_cid*.

# 5.10.6.7.1 Driver Requirements: Device Operation: Device Events

Event virtqueue buffers SHOULD be replenished quickly so that no events are missed.

The *guest\_cid* configuration field MUST be fetched to determine the current CID when a VIRTIO\_VSOCK\_-EVENT\_TRANSPORT\_RESET event is received.

Existing connections MUST be shut down when a VIRTIO\_VSOCK\_EVENT\_TRANSPORT\_RESET event is received.

Listen connections MUST remain operational with the current CID when a VIRTIO\_VSOCK\_EVENT\_TRANS-PORT\_RESET event is received.

# 5.11 File System Device

The virtio file system device provides file system access. The device either directly manages a file system or it acts as a gateway to a remote file system. The details of how the device implementation accesses files are hidden by the device interface, allowing for a range of use cases.

Unlike block-level storage devices such as virtio block and SCSI, the virtio file system device provides file-level access to data. The device interface is based on the Linux Filesystem in Userspace (FUSE) protocol. This consists of requests for file system traversal and access the files and directories within it. The protocol details are defined by FUSE.

The device acts as the FUSE file system daemon and the driver acts as the FUSE client mounting the file system. The virtio file system device provides the mechanism for transporting FUSE requests, much like /dev/fuse in a traditional FUSE application.

This section relies on definitions from FUSE.

#### 5.11.1 Device ID

26

# 5.11.2 Virtqueues

0 hiprio

1 notification queue

2...n request queues

The notification queue only exists if VIRTIO FS F NOTIFICATION is set.

#### 5.11.3 Feature bits

**VIRTIO\_FS\_F\_NOTIFICATION (0)** Device has support for FUSE notify messages. The notification queue is virtqueue 1.

# 5.11.4 Device configuration layout

```
struct virtio_fs_config {
    char tag[36];
    le32 num_request_queues;
    le32 notify_buf_size;
};
```

The *tag* and *num\_request\_queues* fields are always available. The *notify\_buf\_size* field is only available when VIRTIO FS F NOTIFICATION is set.

tag is the name associated with this file system. The tag is encoded in UTF-8 and padded with NUL bytes if shorter than the available space. This field is not NUL-terminated if the encoded bytes take up the entire field.

num\_request\_queues is the total number of request virtqueues exposed by the device. Each virtqueue offers identical functionality and there are no ordering guarantees between requests made available on different queues. Use of multiple queues is intended to increase performance.

notify\_buf\_size is the minimum number of bytes required for each buffer in the notification queue.

#### 5.11.4.1 Driver Requirements: Device configuration layout

The driver MUST NOT write to device configuration fields.

The driver MAY use from one up to *num\_request\_queues* request virtqueues.

# 5.11.4.2 Device Requirements: Device configuration layout

The device MUST set *num\_request\_queues* to 1 or greater.

The device MUST set *notify\_buf\_size* to be large enough to hold any of the FUSE notify messages that this device emits.

#### 5.11.5 Device Initialization

On initialization the driver first discovers the device's virtqueues.

The driver populates the notification queue with buffers for receiving FUSE notify messages if VIRTIO\_FS\_-F NOTIFICATION is set.

The FUSE session is started by sending a FUSE\_INIT request as defined by the FUSE protocol on one request virtqueue. All virtqueues provide access to the same FUSE session and therefore only one FUSE\_-INIT request is required regardless of the number of available virtqueues.

# 5.11.6 Device Operation

Device operation consists of operating the virtqueues to facilitate file system access.

The FUSE request types are as follows:

- Normal requests are made available by the driver on request queues and are used by the device.
- High priority requests (FUSE\_INTERRUPT, FUSE\_FORGET, and FUSE\_BATCH\_FORGET) are made
  available by the driver on the hiprio queue so the device is able to process them even if the request
  queues are full.

FUSE notify messages are received on the notification queue if VIRTIO FS F NOTIFICATION is set.

### 5.11.6.1 Device Operation: Request Queues

The driver enqueues normal requests on an arbitrary request queue. High priority requests are not placed on request queues. The device processes requests in any order. The driver is responsible for ensuring that ordering constraints are met by making available a dependent request only after its prerequisite request has been used.

Requests have the following format with endianness chosen by the driver in the FUSE\_INIT request used to initiate the session as detailed below:

```
struct virtio_fs_req {
    // Device-readable part
    struct fuse_in_header in;
    u8 datain[];

    // Device-writable part
    struct fuse_out_header out;
    u8 dataout[];
};
```

Note that the words "in" and "out" follow the FUSE meaning and do not indicate the direction of data transfer under VIRTIO. "In" means input to a request and "out" means output from processing a request.

in is the common header for all types of FUSE requests.

datain consists of request-specific data, if any. This is identical to the data read from the /dev/fuse device by a FUSE daemon.

*out* is the completion header common to all types of FUSE requests.

dataout consists of request-specific data, if any. This is identical to the data written to the /dev/fuse device by a FUSE daemon.

For example, the full layout of a FUSE READ request is as follows:

```
struct virtio_fs_read_req {
    // Device-readable part
    struct fuse_in_header in;
    union {
        struct fuse_read_in readin;
        u8 datain[sizeof(struct fuse_read_in)];
    };

    // Device-writable part
    struct fuse_out_header out;
    u8 dataout[out.len - sizeof(struct fuse_out_header)];
};
```

The FUSE protocol documented in FUSE specifies the set of request types and their contents.

The endianness of the FUSE protocol session is detectable by inspecting the uint32\_t *in.opcode* field of the FUSE\_INIT request sent by the driver to the device. This allows the device to determine whether the session is little-endian or big-endian. The next FUSE\_INIT message terminates the current session and starts a new session with the possibility of changing endianness.

# 5.11.6.2 Device Operation: High Priority Queue

The hiprio queue follows the same request format as the request queues. This queue only contains FUSE\_-INTERRUPT, FUSE\_FORGET, and FUSE\_BATCH\_FORGET requests.

Interrupt and forget requests have a higher priority than normal requests. The separate hiprio queue is used for these requests to ensure they can be delivered even when all request queues are full.

# 5.11.6.2.1 Device Requirements: Device Operation: High Priority Queue

The device MUST NOT pause processing of the hiprio queue due to activity on a normal request queue.

The device MAY process request queues concurrently with the hiprio queue.

#### 5.11.6.2.2 Driver Requirements: Device Operation: High Priority Queue

The driver MUST submit FUSE\_INTERRUPT, FUSE\_FORGET, and FUSE\_BATCH\_FORGET requests solely on the hiprio queue.

The driver MUST not submit normal requests on the hiprio queue.

The driver MUST anticipate that request queues are processed concurrently with the hiprio queue.

# 5.11.6.3 Device Operation: Notification Queue

The notification queue is populated with buffers by the driver and these buffers are used by the device to emit FUSE notify messages. Notification queue buffer layout is as follows:

```
struct virtio_fs_notify {
    // Device-writable part
    struct fuse_out_header out_hdr;
    char outarg[notify_buf_size - sizeof(struct fuse_out_header)];
};
```

outarg contains the FUSE notify message payload that depends on the type of notification being emitted.

If the driver provides notification queue buffers at a slower rate than the device emits FUSE notify messages then the virtqueue will eventually become empty. The behavior in response to an empty virtqueue depends on the FUSE notify message type. The following FUSE notify message types are supported:

• FUSE\_NOTIFY\_LOCK messages are delivered when buffers become available again. The device has resources for a certain number of lock requests. If the device runs out of resources new lock requests fail with ENOLCK.

#### 5.11.6.3.1 Driver Requirements: Device Operation: Notification Queue

The driver MUST provide buffers of at least *notify\_buf\_size* bytes.

The driver SHOULD replenish notification queue buffers sufficiently quickly so that there is always at least one available buffer.

#### 5.11.6.4 Device Operation: DAX Window

FUSE\_READ and FUSE\_WRITE requests transfer file contents between the driver-provided buffer and the device. In cases where data transfer is undesirable, the device can map file contents into the DAX window shared memory region. The driver then accesses file contents directly in device-owned memory without a data transfer.

The DAX Window is an alternative mechanism for accessing file contents. FUSE\_READ/FUSE\_WRITE requests and DAX Window accesses are possible at the same time. Providing the DAX Window is optional for devices. Using the DAX Window is optional for drivers.

Shared memory region ID 0 is called the DAX window. Drivers map this shared memory region with writeback caching as if it were regular RAM. The contents of the DAX window are undefined unless a mapping exists for that range.

The driver maps a file range into the DAX window using the FUSE\_SETUPMAPPING request. Alignment constraints for FUSE\_SETUPMAPPING and FUSE\_REMOVEMAPPING requests are communicated during FUSE\_INIT negotiation.

When a FUSE\_SETUPMAPPING request perfectly overlaps a previous mapping, the previous mapping is replaced. When a mapping partially overlaps a previous mapping, the previous mapping is split into one or two smaller mappings. When a mapping is partially unmapped it is also split into one or two smaller mappings.

Establishing new mappings or splitting existing mappings consumes resources. If the device runs out of resources the FUSE\_SETUPMAPPING request fails until resources are available again following FUSE\_-REMOVEMAPPING.

After FUSE\_SETUPMAPPING has completed successfully the file range is accessible from the DAX window at the offset provided by the driver in the request. A mapping is removed using the FUSE\_REMOVEMAP-PING request.

Data is only guaranteed to be persistent when a FUSE\_FSYNC request is used by the device after having been made available by the driver following the write.

#### 5.11.6.4.1 Device Requirements: Device Operation: DAX Window

The device MAY provide the DAX Window to memory-mapped access to file contents. If present, the DAX Window MUST be shared memory region ID 0.

The device MUST support FUSE\_READ and FUSE\_WRITE requests regardless of whether the DAX Window is being used or not.

The device MUST allow mappings that completely or partially overlap existing mappings within the DAX window.

The device MUST reject mappings that would go beyond the end of the DAX window.

### 5.11.6.4.2 Driver Requirements: Device Operation: DAX Window

The driver SHOULD be prepared to find shared memory region ID 0 absent and fall back to FUSE\_READ and FUSE\_WRITE requests.

The driver MAY use both FUSE\_READ/FUSE\_WRITE requests and the DAX Window to access file contents.

The driver MUST NOT access DAX window areas that have not been mapped.

#### 5.11.6.5 Security Considerations

The device provides access to a file system containing files owned by one or more POSIX user ids and group ids. The device has no secure way of differentiating between users originating requests via the driver. Therefore the device accepts the POSIX user ids and group ids provided by the driver and security is enforced by the driver rather than the device. It is nevertheless possible for devices to implement POSIX user id and group id mapping or whitelisting to control the ownership and access available to the driver.

File systems containing special files including device nodes and setuid executable files pose a security concern. These properties are defined by the file type and mode, which are set by the driver when creating new files or by changes at a later time. These special files present a security risk when the file system is shared with another machine. A setuid executable or a device node placed by a malicious machine make it possible for unprivileged users on other machines to elevate their privileges through the shared file system. This issue can be solved on some operating systems using mount options that ignore special files. It is also possible for devices to implement restrictions on special files by refusing their creation.

When the device provides shared access to a file system between multiple machines, symlink race conditions, exhausting file system capacity, and overwriting or deleting files used by others are factors to consider. These issues have a long history in multi-user operating systems and also apply to virtio-fs. They are typically managed at the file system administration level by providing shared access only to mutually trusted users.

Multiple machines sharing access to a file system are susceptible to timing side-channel attacks. By measuring the latency of accesses to file contents or file system metadata it is possible to infer whether other machines also accessed the same information. Short latencies indicate that the information was cached due to a previous access. This can reveal sensitive information, such as whether certain code paths were taken. The DAX Window provides direct access to file contents and is therefore a likely target of such attacks. These attacks are also possible with traditional FUSE requests. The safest approach is to avoid sharing file systems between untrusted machines.

#### 5.11.6.6 Live migration considerations

When a driver is migrated to a new device it is necessary to consider the FUSE session and its state. The continuity of FUSE inode numbers (also known as nodeids) and fh values is necessary so the driver can continue operation without disruption.

It is possible to maintain the FUSE session across live migration either by transferring the state or by redirecting requests from the new device to the old device where the state resides. The details of how to achieve this are implementation-dependent and are not visible at the device interface level.

Maintaining version and feature information negotiated by FUSE\_INIT is necessary so that no FUSE protocol feature changes are visible to the driver across live migration. The FUSE\_INIT information forms part of the FUSE session state that needs to be transferred during live migration.

# 5.12 RPMB Device

virtio-rpmb is a virtio based RPMB (Replay Protected Memory Block) device. It is used as a tamper-resistant and anti-replay storage. The device is driven via requests including read, write, get write counter and program key, which are submitted via a request queue. This section relies on definitions from paragraph 6.6.22 of eMMC.

### **5.12.1** Device ID

28

#### 5.12.2 Virtqueues

0 requesta

### 5.12.3 Feature bits

None.

# 5.12.4 Device configuration layout

All fields of this configuration are always available and read-only for the driver.

```
struct virtio_rpmb_config {
    u8 capacity;
    u8 max_wr_cnt;
    u8 max_rd_cnt;
}
```

**capacity** is the capacity of the device (expressed in 128KB units). The values MUST range between 0x00 and 0x80 inclusive.

max\_wr\_cnt and max\_rd\_cnt are the maximum numbers of RPMB block count (256B) that can be performed to device in one request. 0 implies no limitation.

# 5.12.5 Device Requirements: Device Initialization

- 1. The virtqueue is initialized.
- 2. The device capacity MUST be initialized to a multiple of 128Kbytes and up to 16Mbytes.

# 5.12.6 Device Operation

The operation of a virtio RPMB device is driven by the requests placed on the virtqueue. The type of request can be program key (VIRTIO\_RPMB\_REQ\_PROGRAM\_KEY), get write counter (VIRTIO\_RPMB\_REQ\_GET\_WRITE\_COUNTER), write (VIRTIO\_RPMB\_REQ\_DATA\_WRITE), and read (VIRTIO\_RPMB\_REQ\_DATA\_READ). A program key or write request can also combine with a result read (VIRTIO\_RPMB\_REQ\_RESULT\_READ) for a returned result.

```
/* RPMB Request Types */
#define VIRTIO RPMB REQ PROGRAM KEY 0x0001
#define VIRTIO_RPMB_REQ_GET_WRITE_COUNTER 0x0002
#define VIRTIO_RPMB_REQ_DATA_WRITE 0x0003
#define VIRTIO RPMB REQ DATA READ
                                         0 \times 0004
#define VIRTIO RPMB REQ RESULT READ
                                         0x0005
/* RPMB Response Types */
#define VIRTIO RPMB RESP PROGRAM KEY
                                         0x0100
#define VIRTIO RPMB RESP GET COUNTER
                                         0x0200
#define VIRTIO RPMB RESP DATA WRITE
                                         0×0300
#define VIRTIO RPMB RESP DATA READ
```

- VIRTIO\_RPMB\_REQ\_PROGRAM\_KEY requests for authentication key programming. If VIRTIO\_RPMB\_-REQ\_RESULT\_READ is requested, the device returns the RPMB frame with the response (VIRTIO\_-RPMB\_RESP\_PROGRAM\_KEY), the calculated MAC and the result.
- VIRTIO\_RPMB\_REQ\_GET\_WRITE\_COUNTER requests for reading the write counter. The device returns the RPMB frame with the response (VIRTIO\_RPMB\_RESP\_GET\_COUNTER), the writer counter, a copy of the nonce received in the request, the calculated MAC and the result.
- VIRTIO\_RPMB\_REQ\_DATA\_WRITE requests for authenticated data write. If VIRTIO\_RPMB\_REQ\_RE-SULT\_READ is requested, the device returns the RPMB data frame with the response (VIRTIO\_-RPMB\_RESP\_DATA\_WRITE), the incremented counter value, the data address, the calculated MAC and the result.
- **VIRTIO\_RPMB\_REQ\_DATA\_READ** requests for authenticated data read. The device returns the RPMB frame with the response (VIRTIO\_RPMB\_RESP\_DATA\_READ), the block count, a copy of the nonce received in the request, the address, the data, the calculated MAC and the result.

VIRTIO\_RPMB\_REQ\_RESULT\_READ requests for a returned result. It is used following with VIRTIO\_-RPMB\_REQ\_PROGRAM\_KEY or VIRTIO\_RPMB\_REQ\_DATA\_WRITE request types for a returned result in one or multiple RPMB frames. If it's not requested, the device will not return result frame to the driver.

### 5.12.6.1 Device Operation: Request Queue

The request information is delivered in RPMB frame. The frame is in size of 512B.

```
struct virtio rpmb frame {
       u8 stuff[196];
       u8 key mac[32];
       u8 data[256];
       u8 nonce[16];
       be32 write counter;
       be16 address;
       be16 block count;
       be16 result;
       bel6 req resp;
};
/* RPMB Operation Results */
#define VIRTIO RPMB RES OK
                                               0x0000
#define VIRTIO_RPMB_RES_GENERAL_FAILURE
                                             0x0001
#define VIRTIO_RPMB_RES_AUTH_FAILURE
                                              0x0002
0x0003
#define VIRTIO RPMB RES COUNT FAILURE
#define VIRTIO RPMB RES ADDR FAILURE
                                              0x0004
#define VIRTIO RPMB RES WRITE FAILURE
#define VIRTIO_RPMB_RES_READ_FAILURE 0x0006
#define VIRTIO_RPMB_RES_NO_AUTH_KEY
#define VIRTIO RPMB RES NO AUTH KEY
#define VIRTIO RPMB RES WRITE COUNTER EXPIRED 0x0080
```

stuff Padding for the frame.

key\_mac is the authentication key or the message authentication code (MAC) depending on the request/response type. If the request is VIRTIO\_RPMB\_REQ\_PROGRAM\_KEY, it's used as an authentication key. Otherwise, it's used as MAC. The MAC is calculated using HMAC SHA-256. It takes as input a key and a message. The key used for the MAC calculation is always the 256-bit RPMB authentication key. The message used as input to the MAC calculation is the concatenation of the fields in the RPMB frames excluding stuff bytes and the MAC itself.

data is used to be written or read via authenticated read/write access. It's fixed 256B.

**nonce** is a random number generated by the user for the read or get write counter requests and copied to the response by the device. It's used for anti-replay protection.

writer counter is the counter value for the total amount of the successful authenticated data write requests.

**address** is the address of the data to be written to or read from the RPMB virtio device. It is the number of the accessed half sector (256B).

block\_count is the number of blocks (256B) requested to be read/written. It's limited by max\_wr\_cnt or max\_rd\_cnt. For RPMB read request, one virtio buffer including request command and the subsequent [block\_count] virtio buffers for response data are placed in the queue. For RPMB write request, [block\_count] virtio buffers including request command and data are placed in the queue.

result includes information about the status of access made to the device. It is written by the device.

**req\_resp** is the type of request or response, to/from the device.

#### 5.12.6.1.1 Device Requirements: Device Operation: Program Key

If VIRTIO\_RPMB\_REQ\_RESULT\_READ is requested, the device SHOULD return the RPMB frame with the response, the calculated MAC and the result:

1. If the *block\_count* is not set to 1 then VIRTIO\_RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded as *result*.

- 2. If the programming of authentication key fails, then VIRTIO\_RPMB\_RES\_WRITE\_FAILURE SHOULD be responded as *result*.
- 3. If some other error occurs then returned result VIRTIO\_RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded as *result*.
- 4. The *req\_resp* value VIRTIO\_RPMB\_RESP\_PROGRAM\_KEY SHOULD be responded.

# 5.12.6.1.2 Device Requirements: Device Operation: Get Write Counter

If the authentication key is not yet programmed then VIRTIO\_RPMB\_RES\_NO\_AUTH\_KEY SHOULD be returned in *result*.

If block count has not been set to 1 then VIRTIO\_RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded as *result*.

The req\_resp value VIRTIO\_RPMB\_RESP\_GET\_COUNTER SHOULD be responded.

# 5.12.6.1.3 Device Requirements: Device Operation: Data Write

If VIRTIO\_RPMB\_REQ\_RESULT\_READ is requested, the device SHOULD return the RPMB data frame with the response VIRTIO\_RPMB\_RESP\_DATA\_WRITE, the incremented counter value, the data address, the calculated MAC and the result:

- 1. If the authentication key is not yet programmed, then VIRTIO\_RPMB\_RES\_NO\_AUTH\_KEY SHOULD be returned in *result*.
- 2. If block count is zero or greater than *max\_wr\_cnt* then VIRTIO\_RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded.
- 3. The device MUST check whether the write counter has expired. If the write counter is expired then the *result* SHOULD be set to VIRTIO\_RPMB\_RES\_WRITE\_COUNTER\_EXPIRED.
- 4. If there is an error in the address (out of range) then the *result* SHOULD be set to VIRTIO\_RPMB\_- RES\_ADDR\_FAILURE.
- 5. The device MUST calculate the MAC taking authentication key and frame as input, and compare this with the MAC in the request. If the two MAC's are different then VIRTIO\_RPMB\_RES\_AUTH\_FAILURE SHOULD be returned in *result*.
- 6. If the writer counter in the request is different from the one maintained by the device then VIRTIO\_- RPMB\_RES\_COUNT\_FAILURE SHOULD be returned in *result*.
- 7. If the MAC and write counter comparisons are matched then the write request is considered to be authenticated. The data from the request SHOULD be written to the address indicated in the request and the write counter SHOULD be incremented by 1.
- 8. If the write fails then the result SHOULD be VIRTIO RPMB RES WRITE FAILURE.
- 9. If some other error occurs during the writing procedure then the *result* SHOULD be VIRTIO\_RPMB\_- RES\_GENERAL\_FAILURE.
- 10. The *req\_resp* value VIRTIO\_RPMB\_RESP\_DATA\_WRITE SHOULD be responded.

### 5.12.6.1.4 Device Requirements: Device Operation: Data Read

- 1. If the authentication key is not yet programmed then VIRTIO\_RPMB\_RES\_NO\_AUTH\_KEY SHOULD be returned in *result*.
- 2. If block count is zero or greater than *max\_rd\_cnt* then VIRTIO\_RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded as *result*.
- 3. If there is an error in the address (out of range) then the *result* SHOULD be set to VIRTIO\_RPMB\_- RES\_ADDR\_FAILURE.

- 4. If data fetch from addressed location inside the device fails then the *result* SHOULD be VIRTIO\_- RPMB RES READ FAILURE.
- If some other error occurs during the read procedure then the result SHOULD be VIRTIO\_RPMB\_-RES\_GENERAL\_FAILURE.
- 6. The device SHOULD respond with *block\_count* frames containing the data and *req\_resp* value set to VIRTIO\_RPMB\_RESP\_DATA\_READ.

### 5.12.6.1.5 Device Requirements: Device Operation: Result Read

If the *block\_count* has not been set to 1 of VIRTIO\_RPMB\_REQ\_RESULT\_READ request then VIRTIO\_-RPMB\_RES\_GENERAL\_FAILURE SHOULD be responded as *result*.

### 5.12.6.2 Driver Requirements: Device Operation

The RPMB frames MUST not be packed by the driver. The driver MUST configure, initialize and format virtqueue for the RPMB requests received from its caller then send it to the device.

#### 5.12.6.3 Device Requirements: Device Operation

The virtio-rpmb device could be backed in a number of ways. It SHOULD keep consistent behaviors with hardware as described in paragraph 6.6.22 of eMMC. Some elements are maintained by the device:

- The device MUST maintain a one-time programmable authentication key. It cannot be overwritten, erased or read. The key is used to authenticate the accesses when MAC is calculated. This key MUST be kept regardless of device reset or reboot.
- 2. The device MUST maintain a read-only monotonic write counter. It MUST be initialized to zero and added by one automatically along with successful write operation. The value cannot be reset. After the counter has reached its maximum value 0xFFFF FFFF, it will not be incremented anymore. This counter MUST be kept regardless of device reset or reboot.
- 3. The device MUST maintain the data for read/write via authenticated access.

# 5.13 IOMMU device

The virtio-iommu device manages Direct Memory Access (DMA) from one or more endpoints. It may act both as a proxy for physical IOMMUs managing devices assigned to the guest, and as virtual IOMMU managing emulated and paravirtualized devices.

The driver first discovers endpoints managed by the virtio-iommu device using platform specific mechanisms. It then sends requests to create virtual address spaces and virtual-to-physical mappings for these endpoints. In its simplest form, the virtio-iommu supports four request types:

```
1. Create a domain and attach an endpoint to it. attach (endpoint = 0x8, domain = 1)
```

2. Create a mapping between a range of guest-virtual and guest-physical address.

```
map(domain = 1, virt_start = 0x1000, virt_end = 0x1fff, phys = 0xa000, flags
= READ)
```

Endpoint 0x8, for example a hardware PCI endpoint with BDF 00:01.0, can now read at addresses 0x1000-0x1fff. These accesses are translated into system-physical addresses by the IOMMU.

3. Remove the mapping.

```
unmap(domain = 1, virt start = 0x1000, virt end = 0x1fff)
```

Any access to addresses 0x1000-0x1fff by endpoint 0x8 would now be rejected.

4. Detach the device and remove the domain.

```
detach(endpoint = 0x8, domain = 1)
```

#### 5.13.1 Device ID

23

## 5.13.2 Virtqueues

0 requestq

1 eventq

#### 5.13.3 Feature bits

VIRTIO IOMMU F INPUT RANGE (0) Available range of virtual addresses is described in input range.

**VIRTIO\_IOMMU\_F\_DOMAIN\_RANGE (1)** The number of domains supported is described in *domain\_-range*.

VIRTIO IOMMU F MAP UNMAP (2) Map and unmap requests are available. 12

VIRTIO\_IOMMU\_F\_BYPASS (3) Endpoints that are not attached to a domain are in bypass mode.

VIRTIO\_IOMMU\_F\_PROBE (4) The PROBE request is available.

VIRTIO\_IOMMU\_F\_MMIO (5) The VIRTIO IOMMU MAP F MMIO flag is available.

**VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG (6)** Field *bypass* of struct virtio\_iommu\_config determines whether endpoints that are not attached to a domain are in bypass mode. Flag VIRTIO\_IOMMU\_ATTACH\_F\_-BYPASS determines whether endpoints that are attached to a domain are in bypass mode.

### 5.13.3.1 Driver Requirements: Feature bits

The driver SHOULD accept any of the VIRTIO\_IOMMU\_F\_INPUT\_RANGE, VIRTIO\_IOMMU\_F\_DOMAIN\_-RANGE and VIRTIO\_IOMMU\_F\_PROBE feature bits if offered by the device.

#### 5.13.3.2 Device Requirements: Feature bits

The device SHOULD offer feature bit VIRTIO IOMMU F MAP UNMAP.

The VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG feature supersedes VIRTIO\_IOMMU\_F\_BYPASS. New devices SHOULD NOT offer VIRTIO\_IOMMU\_F\_BYPASS. Devices SHOULD NOT offer both VIRTIO\_IOMMU\_F\_BYPASS and VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG.

# 5.13.4 Device configuration layout

The *page\_size\_mask* field is always present. Availability of the others all depend on feature bits described in 5.13.3.

```
struct virtio_iommu_config {
  le64 page_size_mask;
  struct virtio_iommu_range_64 {
   le64 start;
  le64 end;
  } input_range;
  struct virtio_iommu_range_32 {
   le32 start;
  le32 end;
  } domain_range;
  le32 probe_size;
  u8 bypass;
  u8 reserved[3];
};
```

<sup>&</sup>lt;sup>12</sup>Future extensions may add different modes of operations. At the moment, only VIRTIO\_IOMMU\_F\_MAP\_UNMAP is supported.

#### 5.13.4.1 Driver Requirements: Device configuration layout

When the VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG feature is negotiated, the driver MAY write to *bypass*. The driver MUST NOT write to any other device configuration field.

The driver MUST NOT write a value different than 0 or 1 to *bypass*. The driver SHOULD ignore bits 1-7 of *bypass*.

#### 5.13.4.2 Device Requirements: Device configuration layout

The device MUST set at least one bit in *page\_size\_mask*, describing the page granularity. The device MAY set more than one bit in *page\_size\_mask*.

If the device offers the VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG feature, it MAY initialize the *bypass* field to 1. Field *bypass* SHOULD NOT change on device reset, but SHOULD be restored to its initial value on system reset.

The device MUST NOT present a value different than 0 or 1 in bypass.

#### 5.13.5 Device initialization

When the device is reset, endpoints are not attached to any domain.

Future devices might support more modes of operation besides MAP/UNMAP. Drivers verify that devices set VIRTIO\_IOMMU\_F\_MAP\_UNMAP and fail gracefully if they don't.

#### 5.13.5.1 Driver Requirements: Device Initialization

The driver MUST NOT negotiate VIRTIO\_IOMMU\_F\_MAP\_UNMAP if it is incapable of sending VIRTIO\_IOMMU\_T\_MAP and VIRTIO\_IOMMU\_T\_UNMAP requests.

If the VIRTIO\_IOMMU\_F\_PROBE feature is negotiated, the driver SHOULD send a VIRTIO\_IOMMU\_T\_-PROBE request for each endpoint before attaching the endpoint to a domain.

# 5.13.6 Device operations

Driver send requests on the request virtqueue, notifies the device and waits for the device to return the request with a status in the used ring. All requests are split in two parts: one device-readable, one device-writable.

```
struct virtio_iommu_req_head {
   u8   type;
   u8   reserved[3];
};

struct virtio_iommu_req_tail {
   u8   status;
   u8   reserved[3];
};
```

### Type may be one of:

```
#define VIRTIO_IOMMU_T_ATTACH 1
#define VIRTIO_IOMMU_T_DETACH 2
#define VIRTIO_IOMMU_T_MAP 3
#define VIRTIO_IOMMU_T_UNMAP 4
#define VIRTIO_IOMMU_T_PROBE 5
```

A few general-purpose status codes are defined here.

When the device fails to parse a request, for instance if a request is too small for its type and the device cannot find the tail, then it is unable to set *status*. In that case, it returns the buffers without writing to them.

Range limits of some request fields are described in the device configuration:

• page\_size\_mask contains the bitmask of all page sizes that can be mapped. The least significant bit set defines the page granularity of IOMMU mappings.

The smallest page granularity supported by the IOMMU is one byte. It is legal for the driver to map one byte at a time if bit 0 of *page size mask* is set.

Other bits in page\_size\_mask are hints and describe larger page sizes that the IOMMU device handles efficiently. For example, when the device stores mappings using a page table tree, it may be able to describe large mappings using a few leaf entries in intermediate tables, rather than using lots of entries in the last level of the tree. Creating mappings aligned on large page sizes can improve performance since they require fewer page table and TLB entries.

- If the VIRTIO\_IOMMU\_F\_DOMAIN\_RANGE feature is offered, domain\_range describes the values supported in a domain field. If the feature is not offered, any domain value is valid.
- If the VIRTIO\_IOMMU\_F\_INPUT\_RANGE feature is offered, <code>input\_range</code> contains the virtual address range that the IOMMU is able to translate. Any mapping request to virtual addresses outside of this range fails.

If the feature is not offered, virtual mappings span over the whole 64-bit address space (start = 0, end = 0xfffffffff ffffffff)

An endpoint is in bypass mode if:

- the VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG feature is offered and:
  - config field bypass is 1 and the endpoint is not attached to a domain. This applies even if the driver does not accept the VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG feature and the device initializes field bypass to 1.

or

the endpoint is attached to a domain with VIRTIO\_IOMMU\_ATTACH\_F\_BYPASS.

or

• the VIRTIO\_IOMMU\_F\_BYPASS feature is negotiated and the endpoint is not attached to a domain.

All accesses from an endpoint in bypass mode are allowed and translated by the IOMMU using the identity function.

### 5.13.6.1 Driver Requirements: Device operations

The driver SHOULD set field *reserved* of struct virtio\_iommu\_req\_head to zero and MUST ignore field *reserved* of struct virtio iommu\_req\_tail.

When a device uses a buffer without having written to it (i.e. used length is zero), the driver SHOULD interpret it as a request failure.

If the VIRTIO\_IOMMU\_F\_INPUT\_RANGE feature is negotiated, the driver MUST NOT send requests with virt\_start less than input\_range.start or virt\_end greater than input\_range.end.

If the VIRTIO\_IOMMU\_F\_DOMAIN\_RANGE feature is negotiated, the driver MUST NOT send requests with *domain* less than *domain\_range.start* or greater than *domain\_range.end*.

# 5.13.6.2 Device Requirements: Device operations

The device SHOULD set status to VIRTIO\_IOMMU\_S\_OK if a request succeeds.

If a request *type* is not recognized, the device SHOULD NOT write the buffer and SHOULD set the used length to zero.

The device MUST ignore field *reserved* of struct virtio\_iommu\_req\_head and SHOULD set field *reserved* of struct virtio\_iommu\_req\_tail to zero.

The device SHOULD NOT let unattached endpoints that are not in bypass mode access the guest-physical address space.

### 5.13.6.3 ATTACH request

```
struct virtio_iommu_req_attach {
   struct virtio_iommu_req_head head;
   le32 domain;
   le32 endpoint;
   le32 flags;
   u8   reserved[4];
   struct virtio_iommu_req_tail tail;
};

#define VIRTIO_IOMMU_ATTACH_F_BYPASS (1 << 0)</pre>
```

Attach an endpoint to a domain. *domain* uniquely identifies a domain within the virtio-iommu device. If the domain doesn't exist in the device, it is created. Semantics of the *endpoint* identifier are platform specific, but the following rules apply:

- The endpoint ID uniquely identifies an endpoint from the virtio-iommu point of view. Multiple endpoints
  whose DMA transactions are not translated by the same virtio-iommu device can have the same endpoint ID. Endpoints whose DMA transactions may be translated by the same virtio-iommu device have
  different endpoint IDs.
- On some platforms, it might not be possible to completely isolate two endpoints from each other. For example on a conventional PCI bus, endpoints can snoop DMA transactions from other endpoints on the same bus. Such limitations need to be communicated in a platform specific way.

Multiple endpoints can be attached to the same domain. An endpoint can be attached to a single domain at a time. Endpoints attached to different domains are isolated from each other.

When the VIRTIO\_IOMMU\_F\_BYPASS\_CONFIG is negotiated, the driver can set the VIRTIO\_IOMMU\_-ATTACH\_F\_BYPASS flag to create a bypass domain. Endpoints attached to this domain are in bypass mode.

#### 5.13.6.3.1 Driver Requirements: ATTACH request

The driver SHOULD set reserved to zero.

The driver SHOULD ensure that endpoints that cannot be isolated from each other are attached to the same domain.

If the domain already exists and is a bypass domain, the driver SHOULD set the VIRTIO\_IOMMU\_ATTACH\_-F\_BYPASS flag. If the domain exists and is not a bypass domain, the driver SHOULD NOT set the VIRTIO\_-IOMMU\_ATTACH\_F\_BYPASS flag.

#### 5.13.6.3.2 Device Requirements: ATTACH request

If the *reserved* field of an ATTACH request is not zero, the device MUST reject the request and set *status* to VIRTIO\_IOMMU\_S\_INVAL.

If the device does not recognize a *flags* bit, it MUST reject the request and set *status* to VIRTIO\_IOMMU\_-S INVAL.

If the endpoint identified by *endpoint* doesn't exist, the device MUST reject the request and set *status* to VIRTIO\_IOMMU\_S\_NOENT.

If another endpoint is already attached to the domain identified by *domain*, then the device MAY attach the endpoint identified by *endpoint* to the domain. If it cannot do so, the device MUST reject the request and set *status* to VIRTIO\_IOMMU\_S\_UNSUPP.

If the domain already exists and the VIRTIO\_IOMMU\_ATTACH\_F\_BYPASS flag is not consistent with that domain, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_INVAL.

If the endpoint identified by *endpoint* is already attached to another domain, then the device SHOULD first detach it from that domain and attach it to the one identified by *domain*. In that case the device SHOULD behave as if the driver issued a DETACH request with this *endpoint*, followed by the ATTACH request. If the device cannot do so, it MUST reject the request and set *status* to VIRTIO IOMMU S UNSUPP.

If properties of the endpoint (obtained with a PROBE request) are compatible with properties of other endpoints already attached to the requested domain, then the device SHOULD attach the endpoint. Otherwise the device SHOULD reject the request and set *status* to VIRTIO IOMMU S UNSUPP.

A device that does not reject the request MUST attach the endpoint.

#### 5.13.6.4 DETACH request

```
struct virtio_iommu_req_detach {
  struct virtio_iommu_req_head head;
  le32 domain;
  le32 endpoint;
  u8   reserved[8];
  struct virtio_iommu_req_tail tail;
};
```

Detach an endpoint from a domain. When this request completes, the endpoint cannot access any mapping from that domain anymore. However the endpoint may then be in bypass mode and access the guest-physical address space.

After all endpoints have been successfully detached from a domain, it ceases to exist and its ID can be reused by the driver for another domain.

# 5.13.6.4.1 Driver Requirements: DETACH request

The driver SHOULD set reserved to zero.

#### 5.13.6.4.2 Device Requirements: DETACH request

The device MUST ignore reserved.

If the endpoint identified by *endpoint* doesn't exist, then the device MUST reject the request and set *status* to VIRTIO\_IOMMU\_S\_NOENT.

If the domain identified by *domain* doesn't exist, or if the endpoint identified by *endpoint* isn't attached to this domain, then the device MAY set the request *status* to VIRTIO IOMMU S INVAL.

The device MUST ensure that after being detached from a domain, the endpoint cannot access any mapping from that domain.

#### **5.13.6.5** MAP request

Map a range of virtually-contiguous addresses to a range of physically-contiguous addresses of the same size. After the request succeeds, all endpoints attached to this domain can access memory in the range  $[virt\_start; virt\_end]$  (inclusive). For example, if an endpoint accesses address  $VA \in [virt\_start; virt\_end]$ , the device (or the physical IOMMU) translates the address:  $PA = VA - virt\_start + phys\_start$ . If the access parameters are compatible with flags (for instance, the access is write and flags are VIRTIO\_IOMMU\_MAP\_F\_WRITE) then the IOMMU allows the access to reach PA.

The range defined by  $virt\_start$  and  $virt\_end$  should be within the limits specified by  $input\_range$ . Given  $phys\_end = phys\_start + virt\_end - virt\_start$ , the range defined by  $phys\_start$  and phys\\_end should be within the guest-physical address space. This includes upper and lower limits, as well as any carving of guest-physical addresses for use by the host. Guest physical boundaries are set by the host in a platform specific way.

Availability and allowed combinations of *flags* depend on the underlying IOMMU architectures. VIRTIO\_-IOMMU\_MAP\_F\_READ and VIRTIO\_IOMMU\_MAP\_F\_WRITE are usually implemented, although READ is sometimes implied by WRITE. In addition combinations such as "WRITE and not READ" might not be supported.

The VIRTIO\_IOMMU\_MAP\_F\_MMIO flag is a memory type rather than a protection flag. It is only available when the VIRTIO\_IOMMU\_F\_MMIO feature has been negotiated. Accesses to the mapping are not speculated, buffered, cached, split into multiple accesses or combined with other accesses. It may be used, for example, to map Message Signaled Interrupt doorbells when a VIRTIO\_IOMMU\_RESV\_MEM\_T\_MSI region isn't available. To trigger interrupts the endpoint performs a direct memory write to another peripheral, the IRQ chip.

This request is only available when VIRTIO\_IOMMU\_F\_MAP\_UNMAP has been negotiated.

#### 5.13.6.5.1 Driver Requirements: MAP request

The driver SHOULD set undefined flags bits to zero.

The driver SHOULD NOT send MAP requests on a bypass domain.

virt\_end MUST be strictly greater than virt\_start.

The driver SHOULD set the VIRTIO\_IOMMU\_MAP\_F\_MMIO flag when the physical range corresponds to memory-mapped device registers. The physical range SHOULD have a single memory type: either normal memory or memory-mapped I/O.

If it intends to allow read accesses from endpoints attached to the domain, the driver MUST set the VIRTIO\_-IOMMU\_MAP\_F\_READ flag.

If the VIRTIO\_IOMMU\_F\_MMIO feature isn't negotiated, the driver MUST NOT use the VIRTIO\_IOMMU\_-MAP\_F\_MMIO flag.

#### 5.13.6.5.2 Device Requirements: MAP request

If *virt\_start*, *phys\_start* or (*virt\_end* + 1) is not aligned on the page granularity, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_RANGE.

If a mapping already exists in the requested range, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_INVAL.

If the device doesn't recognize a *flags* bit, it MUST reject the request and set *status* to VIRTIO\_IOMMU\_- S INVAL.

If domain does not exist, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_-NOENT.

If the domain is a bypass domain, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_-S\_INVAL.

The device MUST NOT allow writes to a range mapped without the VIRTIO\_IOMMU\_MAP\_F\_WRITE flag. However, if the underlying architecture does not support write-only mappings, the device MAY allow reads to a range mapped with VIRTIO\_IOMMU\_MAP\_F\_WRITE but not VIRTIO\_IOMMU\_MAP\_F\_READ.

#### 5.13.6.6 UNMAP request

```
struct virtio_iommu_req_unmap {
   struct virtio_iommu_req_head head;
   le32 domain;
   le64 virt_start;
   le64 virt_end;
   u8 reserved[4];
   struct virtio_iommu_req_tail tail;
};
```

Unmap a range of addresses mapped with VIRTIO\_IOMMU\_T\_MAP. We define here a mapping as a virtual region created with a single MAP request. All mappings covered by the range [virt\_start; virt\_end] (inclusive) are removed.

The semantics of unmapping are specified in 5.13.6.6.1 and 5.13.6.6.2, and illustrated with the following requests, assuming each example sequence starts with a blank address space. We define two pseudocode functions map(virt start, virt end) -> mapping and unmap(virt start, virt end).

```
(1) unmap(virt start=0,
        virt end=4)
                                -> succeeds, doesn't unmap anything
(2) a = map(virt start=0,
          virt end=9);
   unmap(0, 9)
                                -> succeeds, unmaps a
(3) a = map(0, 4);
  b = map(5, 9);
  unmap(0, 9)
                                -> succeeds, unmaps a and b
(4) a = map(0, 9);
                                -> fails, doesn't unmap anything
  unmap(0, 4)
(5) a = map(0, 4);
   b = map(5, 9);
  unmap(0, 4)
                                -> succeeds, unmaps a
(6) a = map(0, 4);
  unmap(0, 9)
                                -> succeeds, unmaps a
(7) a = map(0, 4);
  b = map(10, 14);
   unmap(0, 14)
                                -> succeeds, unmaps a and b
```

As illustrated by example (4), partially removing a mapping isn't supported.

This request is only available when VIRTIO\_IOMMU\_F\_MAP\_UNMAP has been negotiated.

# 5.13.6.6.1 Driver Requirements: UNMAP request

The driver SHOULD set the reserved field to zero.

The range, defined by *virt\_start* and *virt\_end*, SHOULD cover one or more contiguous mappings created with MAP requests. The range MAY spill over unmapped virtual addresses.

The first address of a range MUST either be the first address of a mapping or be outside any mapping. The last address of a range MUST either be the last address of a mapping or be outside any mapping.

The driver SHOULD NOT send UNMAP requests on a bypass domain.

### 5.13.6.6.2 Device Requirements: UNMAP request

If the *reserved* field of an UNMAP request is not zero, the device MAY set the request *status* to VIRTIO\_-IOMMU S INVAL, in which case the device MAY perform the UNMAP operation.

If domain does not exist, the device SHOULD set the request status to VIRTIO IOMMU S NOENT.

If the domain is a bypass domain, the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_- S INVAL.

If a mapping affected by the range is not covered in its entirety by the range (the UNMAP request would split the mapping), then the device SHOULD set the request *status* to VIRTIO\_IOMMU\_S\_RANGE, and SHOULD NOT remove any mapping.

If part of the range or the full range is not covered by an existing mapping, then the device SHOULD remove all mappings affected by the range and set the request *status* to VIRTIO\_IOMMU\_S\_OK.

# 5.13.6.7 PROBE request

If the VIRTIO\_IOMMU\_F\_PROBE feature bit is present, the driver sends a VIRTIO\_IOMMU\_T\_PROBE request for each endpoint that the virtio-iommu device manages. This probe is performed before attaching the endpoint to a domain.

```
struct virtio_iommu_req_probe {
   struct virtio_iommu_req_head head;
   /* Device-readable */
   le32 endpoint;
   u8   reserved[64];

   /* Device-writable */
   u8   properties[probe_size];
   struct virtio_iommu_req_tail tail;
};
```

endpoint has the same meaning as in ATTACH and DETACH requests.

reserved is used as padding, so that future extensions can add fields to the device-readable part.

**properties** contains a list of properties of the *endpoint*, filled by the device. The length of the *properties* field is *probe\_size* bytes. Each property is described with a struct virtio\_iommu\_probe\_property header, which may be followed by a value of size *length*.

```
struct virtio_iommu_probe_property {
  le16 {
    type : 12;
    reserved : 4;
  };
  le16 length;
};
```

The driver allocates a buffer for the PROBE request, large enough to accommodate *probe\_size* bytes of *properties*. It writes *endpoint* and adds the buffer to the request queue. The device fills the *properties* field with a list of properties for this endpoint.

The driver parses the first property by reading type, then length. If the driver recognizes type, it reads and handles the rest of the property. The driver then reads the next property, that is located (length + 4) bytes after the beginning of the first one, and so on. The driver parses all properties until it reaches an empty property (type) is 0) or the end of properties.

Available property types are described in section 5.13.6.8.

#### 5.13.6.7.1 Driver Requirements: PROBE request

The size of properties MUST be probe\_size bytes.

The driver SHOULD set field reserved of the PROBE request to zero.

If the driver doesn't recognize the type of a property, it SHOULD ignore the property.

The driver SHOULD NOT deduce the property length from type.

The driver MUST ignore a property whose *reserved* field is not zero.

If the driver ignores a property, it SHOULD continue parsing the list.

### 5.13.6.7.2 Device Requirements: PROBE request

The device MUST ignore field reserved of a PROBE request.

If the endpoint identified by *endpoint* doesn't exist, then the device SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_NOENT.

If the device does not offer the VIRTIO\_IOMMU\_F\_PROBE feature, and if the driver sends a VIRTIO\_-IOMMU\_T\_PROBE request, then the device SHOULD NOT write the buffer and SHOULD set the used length to zero.

The device SHOULD set field reserved of a property to zero.

The device MUST write the size of a property without the struct virtio\_iommu\_probe\_property header, in bytes, into *length*.

When two properties follow each other, the device MUST put the second property exactly (length + 4) bytes after the beginning of the first one.

If the *properties* list is smaller than *probe\_size*, the device SHOULD NOT write any property. It SHOULD reject the request and set *status* to VIRTIO\_IOMMU\_S\_INVAL.

If the device doesn't fill all *probe\_size* bytes with properties, it SHOULD fill the remaining bytes of *properties* with zeroes.

#### 5.13.6.8 PROBE properties

```
#define VIRTIO_IOMMU_PROBE_T_RESV_MEM 1
```

#### 5.13.6.8.1 Property RESV\_MEM

The RESV\_MEM property describes a chunk of reserved virtual memory. It may be used by the device to describe virtual address ranges that cannot be used by the driver, or that are special.

```
struct virtio_iommu_probe_resv_mem {
  struct virtio_iommu_probe_property head;
  u8   subtype;
  u8   reserved[3];
  le64   start;
  le64   end;
};
```

Fields start and end describe the range of reserved virtual addresses. subtype may be one of:

- VIRTIO\_IOMMU\_RESV\_MEM\_T\_RESERVED (0) These virtual addresses cannot be used in a MAP requests. The region is be reserved by the device, for example, if the platform needs to setup DMA mappings of its own.
- VIRTIO\_IOMMU\_RESV\_MEM\_T\_MSI (1) This region is a doorbell for Message Signaled Interrupts (MSIs). It is similar to VIRTIO\_IOMMU\_RESV\_MEM\_T\_RESERVED, in that the driver cannot map virtual addresses described by the property.

In addition it provides information about MSI doorbells. If the endpoint doesn't have a VIRTIO\_-IOMMU\_RESV\_MEM\_T\_MSI property, then the driver creates an MMIO mapping to the doorbell of the MSI controller.

## 5.13.6.8.1.1 Driver Requirements: Property RESV\_MEM

The driver SHOULD NOT map any virtual address described by a VIRTIO\_IOMMU\_RESV\_MEM\_T\_RE-SERVED or VIRTIO\_IOMMU\_RESV\_MEM\_T\_MSI property.

The driver MUST ignore reserved.

The driver SHOULD treat any *subtype* it doesn't recognize as if it was VIRTIO\_IOMMU\_RESV\_MEM\_T\_-RESERVED.

# 5.13.6.8.1.2 Device Requirements: Property RESV\_MEM

The device SHOULD set reserved to zero.

The device SHOULD NOT present more than one VIRTIO\_IOMMU\_RESV\_MEM\_T\_MSI property per endpoint.

The device SHOULD NOT present multiple RESV\_MEM properties that overlap each other for the same endpoint.

The device SHOULD reject a MAP request that overlaps a RESV MEM region.

The device SHOULD NOT allow accesses from the endpoint to RESV\_MEM regions to affect any other component than the endpoint and the driver.

## 5.13.6.9 Fault reporting

The device can report translation faults and other significant asynchronous events on the event virtqueue. The driver initially populates the queue with device-writeable buffers. When the device needs to report an event, it fills a buffer and notifies the driver. The driver consumes the report and adds a new buffer to the virtqueue.

If no buffer is available, the device can either wait for one to be consumed, or drop the event.

**reason** The reason for this report. It may have the following values:

**VIRTIO\_IOMMU\_FAULT\_R\_UNKNOWN (0)** An internal error happened, or an error that cannot be described with the following reasons.

VIRTIO\_IOMMU\_FAULT\_R\_DOMAIN (1) The endpoint attempted to access address without being attached to a domain.

**VIRTIO\_IOMMU\_FAULT\_R\_MAPPING (2)** The endpoint attempted to access *address*, which wasn't mapped in the domain or didn't have the correct protection flags.

flags Information about the fault context.

endpoint The endpoint causing the fault.

reserved and reserved1 Should be zero.

address If VIRTIO\_IOMMU\_FAULT\_F\_ADDRESS is set, the address causing the fault.

When the fault is reported by a physical IOMMU, the fault reasons may not match exactly the reason of the original fault report. The device does its best to find the closest match.

If the device encounters an internal error that wasn't caused by a specific endpoint, it is unlikely that the driver would be able to do anything else than print the fault and stop using the device, so reporting the fault on the event queue isn't useful. In that case, we recommend using the DEVICE NEEDS RESET status bit.

### 5.13.6.9.1 Driver Requirements: Fault reporting

If the reserved field is not zero, the driver MUST ignore the fault report.

The driver MUST ignore reserved1.

The driver MUST ignore undefined flags.

If the driver doesn't recognize *reason*, it SHOULD treat the fault as if it was VIRTIO\_IOMMU\_FAULT\_R\_-UNKNOWN.

## 5.13.6.9.2 Device Requirements: Fault reporting

The device SHOULD set reserved and reserved1 to zero.

The device SHOULD set undefined flags to zero.

The device SHOULD write a valid endpoint ID in endpoint.

The device MAY omit setting VIRTIO\_IOMMU\_FAULT\_F\_ADDRESS and writing *address* in any fault report, regardless of the *reason*.

If a buffer is too small to contain the fault report<sup>13</sup>, the device SHOULD NOT use multiple buffers to describe it. The device MAY fall back to using an older fault report format that fits in the buffer.

# 5.14 Sound Device

The virtio sound card is a virtual audio device supporting input and output PCM streams.

A device is managed by control requests and can send various notifications through dedicated queues. A driver can transmit PCM frames using message-based transport or shared memory.

A small part of the specification reuses existing layouts and values from the High Definition Audio specification (HDA). It allows to provide the same functionality and assist in two possible cases:

- 1. implementation of a universal sound driver,
- 2. implementation of a sound driver as part of the High Definition Audio subsystem.

## **5.14.1 Device ID**

25

<sup>&</sup>lt;sup>13</sup>This would happen for example if the device implements a more recent version of this specification, whose fault report contains additional fields.

# 5.14.2 Virtqueues

- 0 controlq
- 1 eventq
- 2 txq
- 3 rxq

The control queue is used for sending control messages from the driver to the device.

The event queue is used for sending notifications from the device to the driver.

The tx queue is used to send PCM frames for output streams.

The rx queue is used to receive PCM frames from input streams.

## 5.14.3 Feature Bits

None currently defined.

# 5.14.4 Device Configuration Layout

```
struct virtio_snd_config {
  le32 jacks;
  le32 streams;
  le32 chmaps;
};
```

A configuration space contains the following fields:

jacks (driver-read-only) indicates a total number of all available jacks.

streams (driver-read-only) indicates a total number of all available PCM streams.

chmaps (driver-read-only) indicates a total number of all available channel maps.

## 5.14.5 Device Initialization

- 1. Configure the control, event, tx and rx queues.
- 2. Read the jacks field and send a control request to query information about the available jacks.
- 3. Read the *streams* field and send a control request to query information about the available PCM streams.
- 4. Read the *chmaps* field and send a control request to query information about the available channel maps.
- 5. Populate the event queue with empty buffers.

### 5.14.5.1 Driver Requirements: Device Initialization

- The driver MUST populate the event queue with empty buffers of at least the struct virtio\_snd\_event size.
- The driver MUST NOT put a device-readable buffers in the event queue.

## 5.14.6 Device Operation

All control messages are placed into the control queue and all notifications are placed into the event queue. They use the following layout structure and definitions:

```
enum {
   /* jack control request types */
   VIRTIO SND R JACK INFO = 1,
   VIRTIO SND R JACK REMAP,
   /* PCM control request types */
   VIRTIO SND R PCM INFO = 0 \times 0100,
   VIRTIO SND R PCM SET PARAMS,
   VIRTIO SND R PCM PREPARE,
   VIRTIO SND R PCM RELEASE,
   VIRTIO SND R PCM START,
   VIRTIO SND R PCM STOP,
   /* channel map control request types */
   VIRTIO SND R CHMAP INFO = 0x0200,
   /* jack event types */
   VIRTIO SND EVT JACK CONNECTED = 0x1000,
   VIRTIO SND EVT JACK DISCONNECTED,
   /* PCM event types */
   VIRTIO SND EVT PCM PERIOD ELAPSED = 0x1100,
   VIRTIO SND EVT PCM XRUN,
   /* common status codes */
   VIRTIO SND S OK = 0 \times 8000,
   VIRTIO SND S BAD MSG,
   VIRTIO SND S NOT SUPP,
   VIRTIO SND S IO ERR
};
/* a common header */
struct virtio snd hdr {
   le32 code;
};
/* an event notification */
struct virtio snd event {
   struct virtio snd hdr hdr;
   le32 data;
};
```

A generic control message consists of a request part and a response part.

A request part has, or consists of, a common header containing the following device-readable field: **code** specifies a device request type (VIRTIO\_SND\_R\_\*).

A response part has, or consists of, a common header containing the following device-writable field: **code** indicates a device request status (VIRTIO\_SND\_S\_\*).

The status field can take one of the following values:

- VIRTIO\_SND\_S\_OK success.
- VIRTIO\_SND\_S\_BAD\_MSG a control message is malformed or contains invalid parameters.
- VIRTIO\_SND\_S\_NOT\_SUPP requested operation or parameters are not supported.
- VIRTIO SND\_S\_IO\_ERR an I/O error occurred.

The request part may be followed by an additional device-readable payload, and the response part may be followed by an additional device-writable payload.

An event notification contains the following device-writable fields:

hdr indicates an event type (VIRTIO\_SND\_EVT\_\*).

data indicates an optional event data.

For all entities involved in the exchange of audio data, the device uses one of the following data flow directions:

```
enum {
    VIRTIO_SND_D_OUTPUT = 0,
    VIRTIO_SND_D_INPUT
};
```

### 5.14.6.1 Item Information Request

A special control message is used to request information about any kind of configuration item. The request part uses the following structure definition:

```
struct virtio_snd_query_info {
   struct virtio_snd_hdr hdr;
   le32 start_id;
   le32 count;
   le32 size;
};
```

The request contains the following device-readable fields:

hdr specifies a particular item request type (VIRTIO\_SND\_R\_\*\_INFO).

**start\_id** specifies the starting identifier for the item (the range of available identifiers is limited by the total number of particular items that is indicated in the device configuration space).

**count** specifies the number of items for which information is requested (the total number of particular items is indicated in the device configuration space).

size specifies the size of the structure containing information for one item (used for backward compatibility).

The response consists of the virtio\_snd\_hdr structure (contains the request status code), followed by the device-writable information structures of the item. Each information structure begins with the following common header:

```
struct virtio_snd_info {
  le32 hda_fn_nid;
};
```

The header contains the following field:

**hda\_fn\_nid** indicates a function group node identifier (see HDA, section 7.1.2). This field can be used to link together different types of resources (e.g. jacks with streams and channel maps with streams).

#### 5.14.6.2 Driver Requirements: Item Information Request

- The driver MUST NOT set start\_id and count such that start\_id + count is greater than the total number
  of particular items that is indicated in the device configuration space.
- The driver MUST provide a buffer of sizeof(struct virtio snd hdr) + count \* size bytes for the response.

# 5.14.6.3 Relationships with the High Definition Audio Specification

The High Definition Audio specification introduces the codec as part of the hardware that implements some of the functionality. The codec architecture and capabilities are described by tree structure of special nodes each of which is either a function module or a function group (see HDA for details).

The virtio sound specification assumes that a single codec is implemented in the device. Function module nodes are simulated by item information structures, and function group nodes are simulated by the *hda\_-fn\_nid* field in each such structure.

#### 5.14.6.4 Jack Control Messages

A jack control request has, or consists of, a common header with the following layout structure:

```
struct virtio_snd_jack_hdr {
    struct virtio_snd_hdr hdr;
    le32 jack_id;
};
```

The header consists of the following device-readable fields:

hdr specifies a request type (VIRTIO\_SND\_R\_JACK\_\*).

jack\_id specifies a jack identifier from 0 to jacks - 1.

## 5.14.6.4.1 VIRTIO\_SND\_R\_JACK\_INFO

Query information about the available jacks.

The request consists of the virtio\_snd\_query\_info structure (see <u>Item Information Request</u>). The response consists of the virtio snd hdr structure, followed by the following jack information structures:

```
/* supported jack features */
enum {
    VIRTIO_SND_JACK_F_REMAP = 0
};

struct virtio_snd_jack_info {
    struct virtio_snd_info hdr;
    le32 features; /* 1 << VIRTIO_SND_JACK_F_XXX */
    le32 hda_reg_defconf;
    le32 hda_reg_caps;
    u8 connected;

u8 padding[7];
};</pre>
```

The structure contains the following device-writable fields:

features indicates a supported feature bit map:

VIRTIO SND JACK F REMAP - jack remapping support.

hda\_reg\_defconf indicates a pin default configuration value (see HDA, section 7.3.3.31).

hda\_reg\_caps indicates a pin capabilities value (see HDA, section 7.3.4.9).

connected indicates the current jack connection status (1 - connected, 0 - disconnected).

#### 5.14.6.4.1.1 Device Requirements: Jack Information

- · The device MUST NOT set undefined feature values.
- The device MUST initialize the padding bytes to 0.

### 5.14.6.4.2 VIRTIO\_SND\_R\_JACK\_REMAP

If the VIRTIO\_SND\_JACK\_F\_REMAP feature bit is set in the jack information, then the driver can send a control request to change the association and/or sequence number for the specified jack ID.

The request uses the following structure and layout definitions:

```
struct virtio_snd_jack_remap {
   struct virtio_snd_jack_hdr hdr; /* .code = VIRTIO_SND_R_JACK_REMAP */
   le32 association;
   le32 sequence;
};
```

The request contains the following device-readable fields:

association specifies the selected association number.

sequence specifies the selected sequence number.

#### 5.14.6.5 Jack Notifications

Jack notifications consist of a virtio\_snd\_event structure, which has the following device-writable fields:

hdr indicates a jack event type:

- VIRTIO\_SND\_EVT\_JACK\_CONNECTED an external device has been connected to the jack.
- VIRTIO\_SND\_EVT\_JACK\_DISCONNECTED an external device has been disconnected from the jack.

data indicates a jack identifier from 0 to jacks - 1.

## 5.14.6.6 PCM Control Messages

A PCM control request has, or consists of, a common header with the following layout structure:

```
struct virtio_snd_pcm_hdr {
   struct virtio_snd_hdr hdr;
   le32 stream_id;
};
```

The header consists of the following device-readable fields:

hdr specifies request type (VIRTIO\_SND\_R\_PCM\_\*).

**stream\_id** specifies a PCM stream identifier from 0 to *streams* - 1.

### 5.14.6.6.1 PCM Command Lifecycle

A PCM stream has the following command lifecycle:

1. SET PARAMETERS

The driver negotiates the stream parameters (format, transport, etc) with the device.

Possible valid transitions: set parameters, prepare.

2. PREPARE

The device prepares the stream (allocates resources, etc).

Possible valid transitions: set parameters, prepare, start, release.

- 3. Output only: the driver transfers data for pre-buffing.
- 4. START

The device starts the stream (unmute, putting into running state, etc).

Possible valid transitions: stop.

- 5. The driver transfers data to/from the stream.
- 6. STOP

The device stops the stream (mute, putting into non-running state, etc).

Possible valid transitions: start, release.

7. RELEASE

The device releases the stream (frees resources, etc).

Possible valid transitions: set parameters, prepare.

## 5.14.6.6.2 VIRTIO\_SND\_R\_PCM\_INFO

Query information about the available streams.

The request consists of the virtio\_snd\_query\_info structure (see <a href="Item">Item</a> Information Request). The response consists of the virtio\_snd\_hdr structure, followed by the following stream information structures:

```
/* supported PCM stream features */
enum {
   VIRTIO SND PCM F SHMEM HOST = 0,
   VIRTIO SND PCM F SHMEM GUEST,
   VIRTIO_SND_PCM_F_MSG_POLLING,
   VIRTIO SND PCM F EVT SHMEM PERIODS,
   VIRTIO SND PCM F EVT XRUNS
};
/* supported PCM sample formats */
   /* analog formats (width / physical width) */
  ^{\prime \star} digital formats (width ^{\prime} physical width) ^{\star \prime}
   VIRTIO SND PCM FMT IEC958 SUBFRAME /* 32 / 32 bits */
};
/* supported PCM frame rates */
   VIRTIO SND PCM RATE 5512 = 0,
   VIRTIO SND PCM RATE 8000,
   VIRTIO SND PCM RATE 11025,
   VIRTIO SND PCM RATE 16000,
   VIRTIO SND PCM RATE 22050,
   VIRTIO_SND_PCM_RATE_32000,
   VIRTIO SND PCM RATE 44100,
   VIRTIO SND PCM RATE 48000,
   VIRTIO SND PCM RATE 64000,
   VIRTIO SND PCM RATE 88200,
   VIRTIO_SND_PCM_RATE_96000,
   VIRTIO SND PCM RATE 176400,
   VIRTIO SND PCM RATE 192000,
   VIRTIO_SND_PCM_RATE 384000
};
struct virtio snd pcm info {
  struct virtio snd info hdr;
   le32 features; /* 1 << VIRTIO SND PCM F XXX */
   le64 formats; /* 1 << VIRTIO SND PCM FMT XXX */
   le64 rates; /* 1 << VIRTIO SND PCM RATE XXX */
   u8 direction;
   u8 channels min;
```

```
u8 channels_max;
u8 padding[5];
};
```

The structure contains the following device-writable fields:

**features** indicates a bit map of the supported features, which can be negotiated by setting the stream parameters:

- VIRTIO\_SND\_PCM\_F\_SHMEM\_HOST supports sharing a host memory with a guest,
- · VIRTIO SND PCM F SHMEM GUEST supports sharing a guest memory with a host,
- · VIRTIO SND PCM F MSG POLLING supports polling mode for message-based transport,
- VIRTIO\_SND\_PCM\_F\_EVT\_SHMEM\_PERIODS supports elapsed period notifications for shared memory transport,
- VIRTIO\_SND\_PCM\_F\_EVT\_XRUNS supports underrun/overrun notifications.

formats indicates a supported sample format bit map.

rates indicates a supported frame rate bit map.

direction indicates the direction of data flow (VIRTIO\_SND\_D\_\*).

**channels\_min** indicates a minimum number of supported channels.

channels max indicates a maximum number of supported channels.

Only interleaved samples are supported.

## 5.14.6.6.2.1 Device Requirements: Stream Information

- The device MUST NOT set undefined feature, format, rate and direction values.
- The device MUST initialize the padding bytes to 0.

## 5.14.6.6.3 VIRTIO\_SND\_R\_PCM\_SET\_PARAMS

Set selected stream parameters for the specified stream ID.

The request uses the following structure and layout definitions:

```
struct virtio_snd_pcm_set_params {
    struct virtio_snd_pcm_hdr hdr; /* .code = VIRTIO_SND_R_PCM_SET_PARAMS */
    le32 buffer_bytes;
    le32 period_bytes;
    le32 features; /* 1 << VIRTIO_SND_PCM_F_XXX */
    u8 channels;
    u8 format;
    u8 rate;

u8 padding;
};</pre>
```

The request contains the following device-readable fields:

**buffer\_bytes** specifies the size of the hardware buffer used by the driver.

period\_bytes specifies the size of the hardware period used by the driver.

features specifies a selected feature bit map:

- VIRTIO\_SND\_PCM\_F\_SHMEM\_HOST use shared memory allocated by the host (is a place-holder and MUST NOT be selected at the moment),
- VIRTIO\_SND\_PCM\_F\_SHMEM\_GUEST use shared memory allocated by the guest (is a place-holder and MUST NOT be selected at the moment),

- VIRTIO\_SND\_PCM\_F\_MSG\_POLLING suppress available buffer notifications for tx and rx queues (device should poll virtqueue),
- VIRTIO\_SND\_PCM\_F\_EVT\_SHMEM\_PERIODS enable elapsed period notifications for shared memory transport,
- VIRTIO\_SND\_PCM\_F\_EVT\_XRUNS enable underrun/overrun notifications.

**channels** specifies a selected number of channels.

format specifies a selected sample format (VIRTIO SND PCM FMT \*).

rate specifies a selected frame rate (VIRTIO\_SND\_PCM\_RATE\_\*).

### 5.14.6.6.3.1 Device Requirements: Stream Parameters

• If the device has an intermediate buffer, its size MUST be no less than the specified buffer\_bytes value.

### 5.14.6.6.3.2 Driver Requirements: Stream Parameters

- period bytes MUST be a divider buffer bytes, i.e. buffer bytes % period bytes == 0.
- The driver MUST NOT set undefined feature, format and rate values.
- The driver MUST NOT set the feature, format, and rate that are not specified in the stream configuration.
- The driver MUST NOT set the *channels* value as less than the *channels\_min* or greater than the *channels\_max* values specified in the stream configuration.
- The driver MUST NOT set the VIRTIO\_SND\_PCM\_F\_SHMEM\_HOST and VIRTIO\_SND\_PCM\_F\_-SHMEM GUEST bits at the same time.
- The driver MUST initialize the padding byte to 0.
- If the bits associated with the shared memory are not selected, the driver MUST use the tx and rx queues for data transfer (see PCM I/O Messages).

#### 5.14.6.6.4 VIRTIO SND R PCM PREPARE

Prepare a stream with specified stream ID.

# 5.14.6.6.5 VIRTIO\_SND\_R\_PCM\_RELEASE

Release a stream with specified stream ID.

### 5.14.6.6.5.1 Device Requirements: Stream Release

- The device MUST complete all pending I/O messages for the specified stream ID.
- The device MUST NOT complete the control request while there are pending I/O messages for the specified stream ID.

### 5.14.6.6.6 VIRTIO\_SND\_R\_PCM\_START

Start a stream with specified stream ID.

## 5.14.6.6.7 VIRTIO\_SND\_R\_PCM\_STOP

Stop a stream with specified stream ID.

#### 5.14.6.7 PCM Notifications

The device can announce support for different PCM events using feature bits in the stream information structure. To enable notifications, the driver must negotiate these features using the set stream parameters request (see 5.14.6.6.3).

PCM stream notifications consist of a virtio\_snd\_event structure, which has the following device-writable fields:

hdr indicates a PCM stream event type:

- VIRTIO\_SND\_EVT\_PCM\_PERIOD\_ELAPSED a hardware buffer period has elapsed, the period size is controlled using the *period bytes* field.
- VIRTIO\_SND\_EVT\_PCM\_XRUN an underflow for the output stream or an overflow for the input stream has occurred.

data indicates a PCM stream identifier from 0 to streams - 1.

## 5.14.6.8 PCM I/O Messages

An I/O message consists of the header part, followed by the buffer, and then the status part.

```
/* an I/O header */
struct virtio_snd_pcm_xfer {
    le32 stream_id;
};

/* an I/O status */
struct virtio_snd_pcm_status {
    le32 status;
    le32 latency_bytes;
};
```

The header part consists of the following device-readable field:

**stream\_id** specifies a PCM stream identifier from 0 to *streams* - 1.

The status part consists of the following device-writable fields:

**status** contains VIRTIO\_SND\_S\_OK if an operation is successful, and VIRTIO\_SND\_S\_IO\_ERR otherwise.

latency bytes indicates the current device latency.

Since all buffers in the queue (with one exception) should be of the size *period\_bytes*, the completion of such an I/O request can be considered an elapsed period notification.

#### 5.14.6.8.1 Output Stream

In case of an output stream, the header is followed by a device-readable buffer containing PCM frames for writing to the device. All messages are placed into the tx queue.

### 5.14.6.8.1.1 Device Requirements: Output Stream

The device MUST NOT complete the I/O request until the buffer is totally consumed.

## 5.14.6.8.1.2 Driver Requirements: Output Stream

- The driver SHOULD populate the tx queue with *period\_bytes* sized buffers. The only exception is the end of the stream.
- The driver MUST NOT place device-writable buffers into the tx queue.

#### 5.14.6.8.2 Input Stream

In case of an input stream, the header is followed by a device-writable buffer being populated with PCM frames from the device. All messages are placed into the rx queue.

A used descriptor specifies the length of the buffer that was written by the device. It should be noted that the length value contains the size of the virtio\_snd\_pcm\_status structure plus the size of the recorded frames.

#### 5.14.6.8.2.1 Device Requirements: Input Stream

The device MUST NOT complete the I/O request until the buffer is full. The only exception is the end
of the stream.

## 5.14.6.8.2.2 Driver Requirements: Input Stream

- The driver SHOULD populate the rx queue with period\_bytes sized empty buffers before starting the stream.
- The driver MUST NOT place device-readable buffers into the rx queue.

## 5.14.6.9 Channel Map Control Messages

A device can provide one or more channel maps assigned to all streams with the same data flow direction in the same function group.

# 5.14.6.9.1 VIRTIO\_SND\_R\_CHMAP\_INFO

Query information about the available channel maps.

The request consists of the virtio\_snd\_query\_info structure (see Item Information Request). The response consists of the virtio snd hdr structure, followed by the following channel map information structures:

```
/* standard channel position definition */
enum {

VIRTIO_SND_CHMAP_NONE = 0, /* undefined */
VIRTIO_SND_CHMAP_MA, /* silent */
VIRTIO_SND_CHMAP_MONO, /* mono stream */
VIRTIO_SND_CHMAP_FL, /* front left */
VIRTIO_SND_CHMAP_FR, /* front left */
VIRTIO_SND_CHMAP_FR, /* front right */
VIRTIO_SND_CHMAP_RL, /* rear left */
VIRTIO_SND_CHMAP_RL, /* rear right */
VIRTIO_SND_CHMAP_LEF, /* front center */
VIRTIO_SND_CHMAP_LEF, /* side left */
VIRTIO_SND_CHMAP_SL, /* side left */
VIRTIO_SND_CHMAP_RC, /* rear center */
VIRTIO_SND_CHMAP_FRC, /* front left center */
VIRTIO_SND_CHMAP_FRC, /* rear left center */
VIRTIO_SND_CHMAP_FRC, /* front left wide */
VIRTIO_SND_CHMAP_FRC, /* front left wide */
VIRTIO_SND_CHMAP_FRC, /* front left wide */
VIRTIO_SND_CHMAP_FRC, /* front left high */
VIRTIO_SND_CHMAP_FRC, /* front left high */
VIRTIO_SND_CHMAP_FRC, /* front left high */
VIRTIO_SND_CHMAP_FRC, /* top front right high */
VIRTIO_SND_CHMAP_FRC, /* top front left */
VIRTIO_SND_CHMAP_TRC, /* top front left */
VIRTIO_SND_CHMAP_TRC, /* top front left */
VIRTIO_SND_CHMAP_TRC, /* top front center */
VIRTIO_SND_CHMAP_TRC, /* top front left center */
VIRTIO_SND_CHMAP_TRC, /* top side left */
VIRTIO_SND_CHMAP_TRC, /* top side left */
VIRTIO_SND
```

The structure contains the following device-writable fields:

**direction** indicates the direction of data flow (VIRTIO\_SND\_D\_\*).

**channels** indicates the number of valid channel position values.

positions indicates channel position values (VIRTIO SND CHMAP \*).

## 5.14.6.9.1.1 Device Requirements: Channel Map Information

- The device MUST NOT set undefined direction values.
- The device MUST NOT set the channels value to more than VIRTIO\_SND\_CHMAP\_MAX\_SIZE.

# **5.15 Memory Device**

The virtio memory device provides and manages a memory region in guest physical address space. This memory region is partitioned into memory blocks of fixed size that can either be in the state plugged or unplugged. Once plugged, a memory block can be used like ordinary RAM. The driver selects memory blocks to (un)plug and requests the device to perform the (un)plug.

The device requests the driver to plug a certain amount of memory, by setting the *requested\_size* in the device configuration, which can change at runtime. It is up to the device driver to fulfill this request by (un)plugging memory blocks. Once the *plugged\_size* is greater or equal to the *requested\_size*, requests to plug memory blocks will be rejected by the device.

The device-managed memory region is split into two parts, the usable region and the unusable region. All memory blocks in the unusable region are unplugged and requests to plug them will be rejected. The device will grow the usable region to fit the *requested\_size*. Usually, the usable region is bigger than the *requested\_size* of the device, to give the driver some flexibility when selecting memory blocks to plug.

On initial start, and after a system reset, all memory blocks are unplugged. In corner cases, memory blocks might still be plugged after a system reset, and the driver usually requests to unplug all memory while initializing, before starting to select memory blocks to plug.

The device-managed memory region is not exposed as RAM via other firmware / hw interfaces (e.g., e820 on x86). The driver is responsible for deciding how plugged memory blocks will be used. A common use case is to expose plugged memory blocks to the operating system as system RAM, available for the page allocator.

Some platforms provide memory properties for system RAM that are usually queried and modified using special CPU instructions. Memory properties might be implicitly queried or modified on memory access. Memory properties can include advanced memory protection, access and change indication, or memory usage indication relevant in virtualized environments. <sup>14</sup> The device provides the exact same properties

<sup>&</sup>lt;sup>14</sup>For example, s390x provides storage keys for each 4 KiB page and may, depending on the configuration, provide storage attributes for each 4 KiB page.

with the exact same semantics for plugged device memory as available for comparable RAM in the same configuration.

## 5.15.1 Device ID

24

# 5.15.2 Virtqueues

0 guest-request

## 5.15.3 Feature bits

**VIRTIO\_MEM\_F\_ACPI\_PXM (0)** The field *node\_id* in the device configuration is valid and corresponds to an ACPI PXM.

VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE (1) The driver is not allowed to access unplugged memory. <sup>15</sup>

# 5.15.4 Device configuration layout

All fields of this configuration are always available and read-only for the driver.

```
struct virtio_mem_config {
  le64 block_size;
  le16 node_id;
  le8 padding[6];
  le64 addr;
  le64 region_size;
  le64 usable_region_size;
  le64 plugged_size;
  le64 requested_size;
};
```

block size is the size and the alignment in bytes of a memory block. Cannot change.

**node\_id** has no meaning without VIRTIO\_MEM\_F\_ACPI\_PXM. With VIRTIO\_MEM\_F\_ACPI\_PXM, this field is valid and corresponds to an ACPI PXM. Cannot change.

padding has no meaning and is reserved for future use.

addr is the guest physical address of the start of the device-managed memory region in bytes. Cannot change.

**region\_size** is the size of device-managed memory region in bytes. Cannot change.

**usable\_region\_size** is the size of the usable device-managed memory region. Can grow up to **region\_size**. Can only shrink due to VIRTIO\_MEM\_REQ\_UNPLUG\_ALL requests.

plugged\_size is the amount of plugged memory in bytes within the usable device-managed memory region.

requested\_size is the requested amount of plugged memory within the usable device-managed memory region.

### 5.15.4.1 Driver Requirements: Device configuration layout

The driver MUST NOT write to device configuration fields.

The driver MUST ignore the value of padding.

The driver MUST ignore the value of node id without VIRTIO MEM F ACPI PXM.

<sup>&</sup>lt;sup>15</sup>On platforms with memory properties that might get modified implicitly on memory access, this feature is expected to be offered by the device.

## 5.15.4.2 Device Requirements: Device configuration layout

The device MAY change usable\_region\_size and requested\_size.

The device MUST NOT change block\_size, node\_id, addr, and region\_size, except during a system reset.

The device MUST change *plugged size* to reflect the size of plugged memory blocks.

The device MUST set usable\_region\_size to requested\_size or greater.

The device MUST set block\_size to a power of two.

The device MUST set addr, region\_size, usable\_region\_size, plugged\_size, requested\_size to multiples of block\_size.

The device MUST set region\_size to 0 or greater.

The device MUST NOT shrink *usable\_region\_size*, except when processing an UNPLUG ALL request, or during a system reset.

The device MUST send a configuration update notification when changing *usable\_region\_size* or *requested\_size*, except when processing an UNPLUG ALL request.

The device SHOULD NOT send a configuration update notification when changing plugged\_size.

The device MAY send a configuration update notification even if nothing changed.

## 5.15.5 Device Initialization

On initialization, the driver first discovers the device's virtqueues. It then reads the device configuration.

In case the driver detects that the device still has memory plugged (*plugged\_size* in the device configuration is greater than 0), the driver will either try to re-initialize by issuing STATE requests, or try to unplug all memory before continuing. Special handling might be necessary in case some plugged memory might still be relevant (e.g., system dump, memory still in use after unloading the driver).

## 5.15.5.1 Driver Requirements: Device Initialization

The driver SHOULD accept VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE if it is offered and the driver supports it.

The driver SHOULD issue UNPLUG ALL requests until successful if the device still has memory plugged and the plugged memory is not in use.

## 5.15.5.2 Device Requirements: Device Initialization

A device MAY fail to operate further if VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE is not accepted.

The device MUST NOT change the state of memory blocks during device reset.

The device MUST NOT modify memory or memory properties of plugged memory blocks during device reset.

### 5.15.6 Device Operation

The device notifies the driver about the amount of memory the device wants the driver to consume via the device. These resize requests from the device are communciated via the *requested\_size* in the device configuration. The driver will react by requesting to (un)plug specific memory blocks, to make the *plugged\_size* match the *requested\_size* as close as possible.

The driver sends requests to the device on the guest-request virtqueue, notifies the device, and waits for the device to respond. Requests have a common header, defining the request type, followed by request-specific data. All requests are 24 bytes long and have the layout:

```
struct virtio_mem_req {
  le16 type;
  le16 padding[3];

union {
    struct virtio_mem_req_plug plug;
    struct virtio_mem_req_unplug unplug;
    struct virtio_mem_req_state state;
  } u;
}
```

## Possible request types are:

```
#define VIRTIO_MEM_REQ_PLUG 0
#define VIRTIO_MEM_REQ_UNPLUG 1
#define VIRTIO_MEM_REQ_UNPLUG_ALL 2
#define VIRTIO_MEM_REQ_STATE 3
```

Responses have a common header, defining the response type, followed by request-specific data. All responses are 10 bytes long and have the layout:

```
struct virtio_mem_resp {
  le16 type;
  le16 padding[3];

union {
    struct virtio_mem_resp_state state;
  } u;
}
```

## Possible response types, in general, are:

```
#define VIRTIO_MEM_RESP_ACK 0
#define VIRTIO_MEM_RESP_NACK 1
#define VIRTIO_MEM_RESP_BUSY 2
#define VIRTIO_MEM_RESP_ERROR 3
```

## 5.15.6.1 Driver Requirements: Device Operation

The driver MUST NOT write memory or modify memory properties of unplugged memory blocks.

The driver MUST NOT read memory or query memory properties of unplugged memory blocks outside usable\_region\_size.

The driver MUST NOT read memory or query memory properties of unplugged memory blocks inside *us-able\_region\_size* via DMA.

If VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE has not been negotiated, the driver SHOULD NOT read memory or query memory properties of unplugged memory blocks inside *usable\_region\_size* via the CPU.

If VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE has been negotiated, the driver MUST NOT read memory or query memory properties of unplugged memory blocks.

The driver MUST NOT request unplug of memory blocks while corresponding memory or memory properties are still in use.

The driver SHOULD initialize memory blocks after plugging them, the content is undefined.

The driver SHOULD react to resize requests from the device (*requested\_size* in the device configuration changed) by (un)plugging memory blocks.

The driver SHOULD only plug memory blocks it can actually use.

The driver MAY not reach the requested size (*requested\_size* in the device configuration), for example, because it cannot free up any plugged memory blocks to unplug them, or it would not be able to make use of unplugged memory blocks after plugging them (e.g., alignment).

## 5.15.6.2 Device Requirements: Device Operation

The device MUST provide the exact same memory properties with the exact same semantics for device memory the platform provides in the same configuration for comparable RAM.

The device MAY modify memory of unplugged memory blocks or reset memory properties of such memory blocks to platform defaults at any time.

The device MUST NOT modify memory or memory properties of plugged memory blocks.

The device MUST allow the driver to read and write memory and to query and modify memory attributes of plugged memory blocks.

If VIRTIO\_MEM\_F\_UNPLUGGED\_INACCESSIBLE has not been negotiated, the device MUST allow the driver to read memory and to query memory properties of unplugged memory blocks inside *usable\_region\_-* size via the CPU. <sup>16</sup>

The device MAY change the state of memory blocks during system resets.

The device SHOULD unplug all memory blocks during system resets.

## **5.15.6.3 PLUG request**

Request to plug consecutive memory blocks that are currently unplugged.

The request-specific data in a PLUG request has the format:

```
struct virtio_mem_req_plug {
  le64 addr;
  le16 nb_blocks;
  le16 padding[3];
}
```

addr is the guest physical address of the first memory block. nb\_blocks is the number of consecutive memory blocks

Responses don't have request-specific data defined.

### 5.15.6.3.1 Driver Requirements: PLUG request

The driver MUST ignore anything except the response type in a response.

## 5.15.6.3.2 Device Requirements: PLUG request

The device MUST ignore anything except the request type and the request-specific data in a request.

The device MUST ignore the padding in the request-specific data in a request.

The device MUST reject requests with VIRTIO\_MEM\_RESP\_ERROR if addr is not aligned to the block\_size in the device configuration, if nb\_blocks is not greater than 0, or if any memory block outside of the usable device-managed memory region is covered by the request.

The device MUST reject requests with VIRTIO\_MEM\_RESP\_ERROR if any memory block covered by the request is already plugged.

The device MAY reject requests with VIRTIO\_MEM\_RESP\_BUSY if the request can currently not be processed.

The device MUST acknowledge requests with VIRTIO\_MEM\_RESP\_ACK in case all memory blocks were successfully plugged. The device MUST reflect the change in the device configuration *plugged\_size*.

<sup>&</sup>lt;sup>16</sup>To allow for simplified dumping of memory. The CPU is expected to copy such memory to another location before starting DMA.

## 5.15.6.4 UNPLUG request

Request to unplug consecutive memory blocks that are currently plugged.

The request-specific data in an UNPLUG request has the format:

```
struct virtio_mem_req_unplug {
  le64 addr;
  le16 nb_blocks;
  le16 padding[3];
}
```

addr is the guest physical address of the first memory block. nb\_blocks is the number of consecutive memory blocks

Responses don't have request-specific data defined.

## 5.15.6.4.1 Driver Requirements: UNPLUG request

The driver MUST ignore anything except the response type in a response.

## 5.15.6.4.2 Device Requirements: UNPLUG request

The device MUST ignore anything except the request type and the request-specific data in a request.

The device MUST ignore the padding in the request-specific data in a request.

The device MUST reject requests with VIRTIO\_MEM\_RESP\_ERROR if addr is not aligned to the block\_size in the device configuration, if nb\_blocks is not greater than 0, or if any memory block outside of the usable device-managed memory region is covered by the request.

The device MUST reject requests with VIRTIO\_MEM\_RESP\_ERROR if any memory block covered by the request is already unplugged.

The device MAY reject requests with VIRTIO\_MEM\_RESP\_BUSY if the request can currently not be processed.

The device MUST acknowledge requests with VIRTIO\_MEM\_RESP\_ACK in case all memory blocks were successfully unplugged. The device MUST reflect the change in the device configuration <code>plugged\_size</code>.

#### 5.15.6.5 UNPLUG ALL request

Request to unplug all memory blocks the device has currently plugged. If successful, the *plugged\_size* in the device configuration will be 0 and *usable\_region\_size* might have changed.

Requests don't have request-specific data defined, only the request type is relevant. Responses don't have request-specific data defined, only the response type is relevant.

## 5.15.6.5.1 Driver Requirements: UNPLUG request

The driver MUST ignore any data in a response except the response type.

### 5.15.6.5.2 Device Requirements: UNPLUG request

The device MUST ignore any data in a request except the request type.

The device MUST ignore the *padding* in the request-specific data in a request.

The device MAY reject requests with VIRTIO\_MEM\_RESP\_BUSY if the request can currently not be processed.

The device MUST acknowledge requests with VIRTIO\_MEM\_RESP\_ACK in case all memory blocks were successfully unplugged.

The device MUST set *plugged\_size* to 0 in case the request is acknowledged with VIRTIO\_MEM\_RESP\_-ACK.

The device MAY modify usable\_region\_size before responding with VIRTIO\_MEM\_RESP\_ACK.

#### 5.15.6.6 STATE request

Request the state (plugged, unplugged, mixed) of consecutive memory blocks.

The request-specific data in a STATE request has the format:

```
struct virtio_mem_req_state {
  le64 addr;
  le16 nb_blocks;
  le16 padding[3];
};
```

addr is the guest physical address of the first memory block. nb\_blocks is the number of consecutive memory blocks.

The request-specific data in a STATE response has the format:

```
struct virtio_mem_resp_state {
  le16 type;
};
```

Whereby type defines one of three different state types:

```
#define VIRTIO_MEM_STATE_PLUGGED 0
#define VIRTIO_MEM_STATE_UNPLUGGED 1
#define VIRTIO_MEM_STATE_MIXED 2
```

### 5.15.6.6.1 Driver Requirements: STATE request

The driver MUST ignore anything except the response type and the request-specific data in a response.

The driver MUST ignore the request-specific data in a response in case the response type is not VIRTIO\_- MEM\_RESP\_ACK.

## 5.15.6.6.2 Device Requirements: STATE request

The device MUST ignore anything except the request type and the request-specific data in a request.

The device MUST ignore the padding in the request-specific data in a request.

The device MUST reject requests with VIRTIO\_MEM\_RESP\_ERROR if addr is not aligned to the block\_size in the device configuration, if nb\_blocks is not greater than 0, or if any memory block outside of the usable device-managed memory region is covered by the request.

The device MUST acknowledge requests with VIRTIO\_MEM\_RESP\_ACK, supplying the state of the memory blocks.

The device MUST set the state type in the response to VIRTIO\_MEM\_STATE\_PLUGGED if all requested memory blocks are plugged. The device MUST set the state type in the response to VIRTIO\_MEM\_STATE\_-UNPLUGGED if all requested memory blocks are unplugged. Otherwise, the device MUST set state type in the response to VIRTIO MEM\_STATE\_MIXED.

# 5.16 I2C Adapter Device

virtio-i2c is a virtual I2C adapter device. It provides a way to flexibly organize and use the host I2C controlled devices from the guest. By attaching the host ACPI I2C controlled nodes to the virtual I2C adapter device, the guest can communicate with them without changing or adding extra drivers for these controlled I2C devices.

34

# 5.16.2 Virtqueues

0 requestq

## 5.16.3 Feature bits

**VIRTIO\_I2C\_F\_ZERO\_LENGTH\_REQUEST (0)** The device supports zero-length I2C request and *VIR-TIO\_I2C\_FLAGS\_M\_RD* flag. It is mandatory to implement this feature.

**Note:** The *VIRTIO\_I2C\_FLAGS\_M\_RD* flag was not present in the initial implementation of the specification and the direction of the transfer (read or write) was inferred from the permissions (read-only or write-only) of the buffer itself. There is no need of having backwards compatibility for the older specification and so the *VIRTIO\_I2C\_FLAGS\_FAIL\_NEXT* feature is made mandatory. The driver should abort negotiation with the device, if the device doesn't offer this feature.

# 5.16.4 Device configuration layout

None currently defined.

## 5.16.5 Device Initialization

1. The virtqueue is initialized.

## 5.16.6 Device Operation

## 5.16.6.1 Device Operation: Request Queue

The driver queues requests to the virtqueue, and they are used by the device. The request is the representation of segments of an I2C transaction. Each request is of the form:

```
struct virtio_i2c_out_hdr {
    le16 addr;
    le16 padding;
    le32 flags;
};
```

```
struct virtio_i2c_in_hdr {
     u8 status;
};
```

```
struct virtio_i2c_req {
    struct virtio_i2c_out_hdr out_hdr;
    u8 buf[];
    struct virtio_i2c_in_hdr in_hdr;
};
```

The *addr* of the request is the address of the I2C controlled device. For 7-bit address mode (A0 ... A6) and 10-bit address mode (A0 ... A9), the format of *addr* is defined as follows:

Bits	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
7-bit address	0	0	0	0	0	0	0	0	A6	A5	A4	A3	A2	A1	A0	0
10-bit address	A7	A6	A5	A4	А3	A2	A1	A0	1	1	1	1	0	A9	A8	0

The padding is used to pad to full dword.

The *flags* of the request is defined as follows:

- VIRTIO\_I2C\_FLAGS\_FAIL\_NEXT(0) is used to group the requests. For a group requests, a driver clears this bit on the final request and sets it on the other requests. If this bit is set and a device fails to process the current request, it needs to fail the next request instead of attempting to execute it.
- VIRTIO\_I2C\_FLAGS\_M\_RD(1) is used to mark the request as READ or WRITE. If VIRTIO\_I2C\_FLAGS\_-M\_RD bit is set in the flags, then the request is called a read request. If VIRTIO\_I2C\_FLAGS\_M\_RD bit is unset in the flags, then the request is called a write request.

Other bits of *flags* are currently reserved as zero for future feature extensibility.

The *buf* is optional and will not be present for a zero-length request, like the SMBus "Quick" command. The *buf* contains one segment of an I2C transaction being read from or written to the device, based on the value of the *VIRTIO I2C FLAGS M RD* bit in the *flags* field.

The final *status* byte of the request is written by the device: either VIRTIO\_I2C\_MSG\_OK for success or VIRTIO\_I2C\_MSG\_ERR for error.

The virtio I2C protocol supports write-read requests, i.e. an I2C write segment followed by a read segment (usually, the write segment provides the number of an I2C controlled device register to be read), by grouping a list of requests together using the *VIRTIO\_I2C\_FLAGS\_FAIL\_NEXT* flag.

### 5.16.6.2 Device Operation: Operation Status

addr, flags, and "length of buf" are determined by the driver, while status is determined by the processing of the device. A driver, for a write request, puts the data to be written to the device into the buf, while a device, for a read request, puts the data read from device into the buf according to the request from the driver.

A driver may send one request or multiple requests to the device at a time. The requests in the virtqueue are both queued and processed in order.

If a driver sends multiple requests at a time and a device fails to process some of them, then a device needs to set the *status* of the first failed request to be VIRTIO\_I2C\_MSG\_ERR. For the remaining requests in the same group with the first failed one, a driver needs to treat them as VIRTIO\_I2C\_MSG\_ERR, no matter what *status* of them, a device needs to fail them instead of attempting to execute them according to the VIRTIO\_I2C\_FLAGS\_FAIL\_NEXT\_bit.

### 5.16.6.3 Driver Requirements: Device Operation

A driver MUST accept the *VIRTIO\_I2C\_F\_ZERO\_LENGTH\_REQUEST* feature and MUST abort negotiation with the device, if the device doesn't offer this feature.

A driver MUST set addr and flags before sending the request.

A driver MUST set the reserved bits of *flags* to be zero.

A driver MUST NOT send the buf, for a zero-length request.

A driver MUST NOT use *buf*, for a read request, if the final *status* returned from the device is VIRTIO\_I2C\_- MSG\_ERR.

A driver MUST set the *VIRTIO\_I2C\_FLAGS\_M\_RD* flag for a read operation, where the buffer is write-only for the device.

A driver MUST NOT set the VIRTIO\_I2C\_FLAGS\_M\_RD flag for a write operation, where the buffer is readonly for the device.

A driver MUST queue the requests in order if multiple requests are going to be sent at a time.

If multiple requests are sent at a time and some of them returned from the device have the *status* being VIRTIO\_I2C\_MSG\_ERR, a driver MUST treat the first failed request and the remaining requests in the same group with the first failed one as VIRTIO\_I2C\_MSG\_ERR.

#### 5.16.6.4 Device Requirements: Device Operation

A device MUST offer the *VIRTIO\_I2C\_F\_ZERO\_LENGTH\_REQUEST* feature and MUST reject any driver that doesn't negotiate this feature.

A device SHOULD keep consistent behaviors with the hardware as described in I2C.

A device MUST NOT change the value of addr, and reserved bits of flags.

A device MUST not change the value of the buf for a write request.

A device MUST place one I2C segment of the "length of *buf*", for the read request, into the *buf* according the driver's request.

A device MUST guarantee the requests in the virtqueue being processed in order if multiple requests are received at a time.

If multiple requests are received at a time and processing of some of the requests fails, a device MUST set the *status* of the first failed request to be VIRTIO\_I2C\_MSG\_ERR and MAY set the *status* of the remaining requests in the same group with the first failed one to be VIRTIO\_I2C\_MSG\_ERR.

## 5.17 SCMI Device

An SCMI device implements the Arm System Control and Management Interface (SCMI). SCMI can be used for sensors, power state management, clock management and performance management among other things.

This section relies on definitions from the SCMI specification.

Virtio SCMI device and driver are mapped to SCMI platform and agent respectively. The device is visible to a particular SCMI agent. The device allows a guest to communicate as an SCMI agent using one or more SCMI protocols. The default SCMI protocols are defined in the SCMI specification. Virtio provides a transport medium for exchanging SCMI messages between the SCMI agent and platform. The virtio SCMI transport allows the queueing of multiple messages and responses.

SCMI FastChannels are not supported.

#### 5.17.1 Device ID

32

# 5.17.2 Virtqueues

0 cmdq

1 eventa

The cmdq is used by the driver to send commands to the device. The device replies with responses (not delayed responses) over the cmdq.

The eventq is used by the device to send notifications and delayed responses. The eventq only exists if VIRTIO SCMI F P2A CHANNELS was negotiated.

### 5.17.3 Feature bits

VIRTIO\_SCMI\_F\_P2A\_CHANNELS (0) Device implements some SCMI notifications, or delayed responses.

VIRTIO\_SCMI\_F\_SHARED\_MEMORY (1) Device implements any SCMI statistics shared memory region.

VIRTIO\_SCMI\_F\_P2A\_CHANNELS is used to determine the existence of the eventq. The eventq is required for SCMI notifications and delayed responses.

VIRTIO\_SCMI\_F\_SHARED\_MEMORY is used to determine whether the device provides any SCMI statistics shared memory region. SCMI statistics shared memory regions are defined by some SCMI protocols.

The SCMI protocols provide the PROTOCOL\_MESSAGE\_ATTRIBUTES commands to inquire about the particular SCMI notifications and delayed responses implemented by the device. The SCMI protocols provide additional commands to detect other features implemented by the device.

#### 5.17.3.1 Device Requirements: Feature bits

The device MUST offer VIRTIO\_SCMI\_F\_P2A\_CHANNELS if the device can implement at least one SCMI notification, or delayed response.

The device MUST offer VIRTIO\_SCMI\_F\_SHARED\_MEMORY if the device can implement at least one SCMI statistics shared memory region.

## 5.17.4 Device configuration layout

There is no configuration data for the device.

#### 5.17.5 Device Initialization

The general requirements on device initialization apply.

# 5.17.6 Device Operation

The SCMI transport used for the device puts each SCMI message into a dedicated virtio buffer. The driver uses the cmdq for transmitting SCMI commands and receiving the corresponding SCMI responses. The device uses the eventq for transmitting SCMI notifications and delayed responses. Each message includes an SCMI protocol header and payload, as defined by the SCMI specification.

## 5.17.6.1 cmdq Operation

Each buffer in the cmdq holds a single SCMI command once the buffer has been made available. When the buffer has been marked as used, it contains the SCMI response. An arbitrary number of such SCMI messages can be in transit at the same time. Conceptually, each SCMI message in the cmdq uses its own SCMI A2P (agent to platform) channel.

The SCMI response is in the same virtio buffer as the corresponding SCMI command. The response contains the return values which SCMI specifies for each command, whether synchronous or asynchronous. Delayed responses are distinct SCMI messages transmitted over the eventq.

Buffers in the cmdq contain both the request and the response. A request has the following layout:

```
struct virtio_scmi_request {
    le32 hdr;
    u8 params[<actual parameters size>];
};
```

The virtio scmi request fields are interpreted as follows:

hdr (device-readable) contains the SCMI message header

params (device-readable) comprises the SCMI message parameters

A cmdq response has the following layout:

```
struct virtio_scmi_response {
    le32 hdr;
    u8 ret_values[<actual return values size>];
};
```

The virtio scmi response fields are interpreted as follows:

hdr (device-writable) contains the SCMI message header

ret values (device-writable) comprises the SCMI message return values

If VIRTIO\_SCMI\_F\_P2A\_CHANNELS was not negotiated, the device responds to SCMI commands as if no SCMI notifications or delayed responses were implemented.

#### 5.17.6.1.1 Device Requirements: cmdg Operation

The device MAY process available commands out of order and in parallel.

The device MUST process all available commands eventually, even in the case of bursts of multiple command messages.

If the *status* field in the *virtio\_scmi\_response ret\_values* has a value other than SUCCESS, the device MUST set the size of *ret\_values* to the size of the *status* field.

If the driver requests an SCMI notification or a delayed response and there are currently NOT enough available buffers in the eventq, the device SHOULD still return SCMI status code SUCCESS.

If VIRTIO\_SCMI\_F\_P2A\_CHANNELS was not negotiated, the device MUST deny any request for an SCMI notification or a delayed response by returning SCMI status code NOT SUPPORTED.

If VIRTIO\_SCMI\_F\_P2A\_CHANNELS was not negotiated, the device MUST NOT indicate in the PROTO-COL\_MESSAGE\_ATTRIBUTES return values that any SCMI notification, or delayed response, is implemented.

## 5.17.6.1.2 Driver Requirements: cmdg Operation

Before sending a command, the driver MUST wait for responses to all commands whose completion the driver considers prerequisites to executing the command.

With every command message, the driver MUST provide enough device-writable memory to enable the device to return corresponding return values.

If VIRTIO\_SCMI\_F\_P2A\_CHANNELS was not negotiated, the driver MUST NOT request any SCMI notification, nor any delayed response.

## 5.17.6.2 Setting Up eventq Buffers

The driver has to populate the eventq before the device can use it.

## 5.17.6.2.1 Driver Requirements: Setting Up eventq Buffers

If VIRTIO\_SCMI\_F\_P2A\_CHANNELS was negotiated, the driver SHOULD populate the eventq with buffers.

The driver MUST NOT put device-readable descriptors into the eventq.

The driver MUST NOT put into the eventq any buffer which is smaller than the largest SCMI P2A (platform to agent) message which the driver will request.

#### 5.17.6.3 eventg Operation

Each buffer in the eventq holds (once the buffer is marked as used) either a single SCMI notification, or a single SCMI delayed response. An arbitrary number of such SCMI messages can be in transit at the same time. Conceptually, each SCMI message transmitted over the eventq uses its own SCMI P2A (platform to agent) channel. Buffers in the eventq have the following layout:

```
struct virtio_scmi_event_msg {
    /* start of device-writable data */
    le32 hdr;
    u8 payload[<actual payload size>];
};
```

hdr (device-writable) contains the SCMI message header

payload (device-writable) comprises the SCMI message payload

## 5.17.6.3.1 Device Requirements: eventg Operation

If the device intends to send a notification and there are no available buffers in the eventq, the device MAY drop the notification, or send a corresponding notification later, once enough buffers become available.

The device MAY send the notification later if the events which cause the notification take place in quick succession.

If the device sends the notification later, the device MAY send the notification with updated data, unless the specific SCMI protocol disallows this.

If the device intends to send a notification and there are available buffers, but one of the buffers is too small to fit the notification, the device MAY omit the notification.

If the device intends to send a delayed response and there are no available buffers in the eventq, the device MUST send the corresponding delayed response once enough buffers become available.

If the *status* field in a delayed response *payload* has a value other than SUCCESS, the device MUST set the size of *payload* to the size of the *status* field.

## 5.17.6.4 Shared Memory Operation

Various SCMI protocols define statistics shared memory regions (for statistics and sensor values).

## 5.17.6.4.1 Device Requirements: Shared Memory Operation

If VIRTIO\_SCMI\_F\_SHARED\_MEMORY was negotiated, the device MAY implement an SCMI statistics shared memory region using a virtio shared memory region.

If the device implements a shared memory region, the device MUST assign the corresponding shmid as per the following table:

SCMI statistics shared memory region	Virtio shmid
Reserved (invalid)	0
Power state statistics shared memory region	1
Performance domain statistics shared memory region	2
Sensor Values Shared Memory	3
Reserved for future use	4 to 0x7F
Vendor-specific statistics shared memory regions	0x80 to 0xFF
Reserved for future use	0x100 and greater

# 5.18 GPIO Device

The Virtio GPIO device is a virtual General Purpose Input/Output device that supports a variable number of named I/O lines, which can be configured in input mode or in output mode with logical level low (0) or high (1).

# **5.18.1 Device ID**

41

## 5.18.2 Virtqueues

0 requestq

1 eventa

The eventq virtqueue is available only if the VIRTIO\_GPIO\_F\_IRQ feature has been negotiated.

## 5.18.3 Feature bits

VIRTIO\_GPIO\_F\_IRQ (0) The device supports interrupts on GPIO lines.

# 5.18.4 Device configuration layout

GPIO device uses the following configuration structure layout:

```
struct virtio_gpio_config {
   le16 ngpio;
   u8 padding[2];
   le32 gpio_names_size;
};
```

ngpio is the total number of GPIO lines supported by the device.

padding has no meaning and is reserved for future use. This is set to zero by the device.

gpio\_names\_size is the size of the gpio-names memory block in bytes, which can be fetched by the driver using the VIRTIO\_GPIO\_MSG\_GET\_LINE\_NAMES message. The device sets this to 0 if it doesn't support names for the GPIO lines.

#### 5.18.5 Device Initialization

- The driver configures and initializes the requestq virtqueue.
- The driver configures and initializes the *eventq* virtqueue, if the *VIRTIO\_GPIO\_F\_IRQ* feature has been negotiated.

# 5.18.6 Device Operation: requestq

The driver uses the *requestq* virtqueue to send messages to the device. The driver sends a pair of buffers, request (filled by driver) and response (to be filled by device later), to the device. The device in turn fills the response buffer and sends it back to the driver.

```
struct virtio_gpio_request {
   le16 type;
   le16 gpio;
   le32 value;
};
```

All the fields of this structure are set by the driver and read by the device.

*type* is the GPIO message type, i.e. one of *VIRTIO\_GPIO\_MSG\_\** values.

**gpio** is the GPIO line number, i.e.  $0 \le gpio < ngpio$ .

value is a message specific value.

All the fields of this structure are set by the device and read by the driver.

**status** of the GPIO message, VIRTIO\_GPIO\_STATUS\_OK on success and VIRTIO\_GPIO\_STATUS\_ERR on failure.

value is a message specific value.

Following is the list of messages supported by the virtio gpio specification.

```
/* GPIO message types */
#define VIRTIO GPIO MSG GET LINE NAMES
                                                0x0001
#define VIRTIO GPIO MSG GET DIRECTION
                                                0 \times 0002
#define VIRTIO GPIO MSG SET DIRECTION
                                               0×0003
#define VIRTIO GPIO MSG GET VALUE
                                               0x0004
#define VIRTIO GPIO MSG SET VALUE
                                                0x0005
#define VIRTIO GPIO MSG SET IRQ TYPE
                                                0x0006
/* GPIO Direction types */
#define VIRTIO GPIO DIRECTION NONE
                                                0x00
#define VIRTIO_GPIO_DIRECTION_OUT
                                                0x01
#define VIRTIO GPIO DIRECTION IN
                                                0x02
/* GPIO interrupt types */
#define VIRTIO_GPIO_IRQ_TYPE_NONE
                                                0×00
#define VIRTIO_GPIO_IRQ_TYPE_EDGE_RISING
                                                0 \times 01
#define VIRTIO GPIO IRQ TYPE EDGE FALLING
                                                0x02
#define VIRTIO_GPIO_IRQ_TYPE_EDGE_BOTH
                                                0×03
#define VIRTIO GPIO IRQ TYPE LEVEL HIGH
                                               0 \times 0.4
#define VIRTIO GPIO IRQ TYPE LEVEL LOW
                                              0x08
```

## **5.18.6.1** request Operation: Get Line Names

The driver sends this message to receive a stream of zero-terminated strings, where each string represents the name of a GPIO line, present in increasing order of the GPIO line numbers. The names of the GPIO lines are optional and may be present only for a subset of GPIO lines. If missing, then a zero-byte must be present for the GPIO line. If present, the name string must be zero-terminated and the name must be unique within a GPIO Device. The names of the GPIO lines are encoded in 7-bit ASCII.

These names of the GPIO lines should be most meaningful producer names for the system, such as name indicating the usage. For example "MMC-CD", "Red LED Vdd" and "ethernet reset" are reasonable line names as they describe what the line is used for, while "GPIO0" is not a good name to give to a GPIO line.

Here is an example of how the gpio names memory block may look like for a GPIO device with 10 GPIO lines, where line names are provided only for lines 0 ("MMC-CD"), 5 ("Red LED Vdd") and 7 ("ethernet reset").

```
u8 gpio_names[] = {
    'M', 'M', 'C', '-', 'C', 'D', 0,
    0,
    0,
    0,
    0,
    0,
    'R', 'e', 'd', ' ', 'L', 'E', 'D', ' ', 'V', 'd', 'd', 0,
    0,
    'E', 't', 'h', 'e', 'r', 'n', 'e', 't', ' ', 'r', 'e', 's', 'e', 't', 0,
    0,
    0
};
```

The device sets the *gpio\_names\_size* to a non-zero value if this message is supported by the device, else it must be set to zero.

This message type uses different layout for the response structure, as the device needs to return the *gpio\_-names* array.

```
struct virtio_gpio_response_N {
   u8 status;
   u8 value[N];
};
```

The driver must allocate the *value[N]* buffer in the *struct virtio\_gpio\_response\_N* for N bytes, where N = *gpio\_names\_size*.

Request	type	gpio	value
	VIRTIO_GPIO_MSG GET_LINE_NAMES	0	0

Response	status	value[N]	Where N is
	VIRTIO_GPIO_STATUS_*	gpio-names	gpio_names_size

## 5.18.6.2 requestq Operation: Get Direction

The driver sends this message to request the device to return a line's configured direction.

Request	type	gpio	value
	VIRTIO_GPIO_MSG GET_DIRECTION	line number	0

Response	status	value	
	VIRTIO_GPIO_STATUS_*	0 = none, 1 = output, 2 = input	

## 5.18.6.3 requestq Operation: Set Direction

The driver sends this message to request the device to configure a line's direction. The driver can either set the direction to *VIRTIO\_GPIO\_DIRECTION\_IN* or *VIRTIO\_GPIO\_DIRECTION\_OUT*, which also activates the line, or to *VIRTIO\_GPIO\_DIRECTION\_NONE*, which deactivates the line.

The driver should set the value of the GPIO line, using the *VIRTIO\_GPIO\_MSG\_SET\_VALUE* message, before setting the direction of the line to output to avoid any undesired behavior.

Request	type	gpio	value
	VIRTIO_GPIO_MSG_SET DIRECTION	line number	0 = none, 1 = output, 2 = in- put

Response	status	value
	VIRTIO_GPIO_STATUS_*	0

## 5.18.6.4 requestq Operation: Get Value

The driver sends this message to request the device to return current value sensed on a line.

Request	type	gpio	value
	VIRTIO_GPIO_MSG GET_VALUE	line number	0

Response	status	value		
	VIRTIO_GPIO_STATUS_*	0 = low, 1 = high		

# 5.18.6.5 requestq Operation: Set Value

The driver sends this message to request the device to set the value of a line. The line may already be configured for output or may get configured to output later, at which point this output value must be used by the device for the line.

Request	type	gpio	value
	VIRTIO_GPIO_MSG_SET VALUE	line number	0 = low, 1 = high

Response	status	value
	VIRTIO_GPIO_STATUS_*	0

## 5.18.6.6 requestq Operation: Set IRQ Type

This request is allowed only if the *VIRTIO\_GPIO\_F\_IRQ* feature has been negotiated.

The interrupt configuration is divided into two steps, enabling or disabling of the interrupt at the device and masking or unmasking of the interrupt for delivery at the driver. This request only pertains to enabling or disabling of the interrupt at the device, the masking and unmasking of the interrupt is handled by a separate request that takes place over the *eventg* virtqueue.

The driver sends the *VIRTIO\_GPIO\_MSG\_SET\_IRQ\_TYPE* message over the *requestq* virtqueue to enable or disable interrupt for a GPIO line at the device.

The driver sends this message with trigger type set to any valid value other than VIRTIO\_GPIO\_IRQ\_-TYPE\_NONE, to enable the interrupt for a GPIO line, this doesn't unmask the interrupt for delivery at the driver though. For edge trigger type, the device should latch the interrupt events from this point onward and notify it to the driver once the interrupt is unmasked. For level trigger type, the device should notify the driver once the interrupt signal on a line is sensed and the interrupt is unmasked for the line.

The driver sends this message with trigger type set to VIRTIO\_GPIO\_IRQ\_TYPE\_NONE, to disable the interrupt for a GPIO line. The device should discard any latched interrupt event associated with it. In order to change the trigger type of an already enabled interrupt, the driver should first disable the interrupt and then re-enable it with appropriate trigger type.

The interrupts are masked at initialization and the driver unmasks them by queuing a pair of buffers, of type *virtio\_gpio\_irq\_request* and *virtio\_gpio\_irq\_response*, over the *eventq* virtqueue for a GPIO line. A separate pair of buffers must be queued for each GPIO line, the driver wants to configure for interrupts. Once an already enabled interrupt is unmasked by the driver, the device can notify the driver of an active interrupt signal on the GPIO line. This is done by updating the *struct virtio\_gpio\_irq\_response* buffer's *status* with *VIRTIO\_GPIO\_IRQ\_STATUS\_VALID* and returning the updated buffers to the driver. The interrupt is masked automatically at this point until the buffers are available again at the device.

The interrupt for a GPIO line should not be unmasked before being enabled by the driver.

If the interrupt is disabled by the driver, by setting the trigger type to VIRTIO\_GPIO\_IRQ\_TYPE\_NONE, or the interrupt is unmasked without being enabled first, the device should return any unused pair of buffers for the GPIO line, over the eventq virtqueue, after setting the status field to VIRTIO\_GPIO\_IRQ\_STATUS\_-INVALID. This also masks the interrupt.

Request	type	gpio	value
	VIRTIO_GPIO_MSG_SET IRQ_TYPE	line number	one of VIRTIO_GPIO_IRQ TYPE_*

Respons	e status	value
	VIRTIO_GPIO_STATUS_*	0

#### 5.18.6.7 requestq Operation: Message Flow

- The driver queues struct virtio\_gpio\_request and virtio\_gpio\_response buffers to the requestq virtqueue, after filling all fields of the struct virtio\_gpio\_request buffer as defined by the specific message type.
- The driver notifies the device of the presence of buffers on the requestq virtqueue.
- The device, after receiving the message from the driver, processes it and fills all the fields of the struct virtio\_gpio\_response buffer (received from the driver). The status must be set to VIRTIO\_GPIO\_-STATUS OK on success and VIRTIO\_GPIO\_STATUS\_ERR on failure.
- The device puts the buffers back on the requestq virtqueue and notifies the driver of the same.
- The driver fetches the buffers and processes the response received in the virtio gpio response buffer.

• The driver can send multiple messages in parallel for same or different GPIO line.

## 5.18.6.8 Driver Requirements: requestq Operation

- The driver MUST send messages on the *requestq* virtqueue.
- The driver MUST queue both struct virtio\_gpio\_request and virtio\_gpio\_response for every message sent to the device.
- The struct virtio\_gpio\_request buffer MUST be filled by the driver and MUST be read-only for the device.
- The struct virtio\_gpio\_response buffer MUST be filled by the device and MUST be writable by the device.
- The driver MAY send multiple messages for same or different GPIO lines in parallel.
- The driver MUST NOT send IRQ messages if the VIRTIO\_GPIO\_F\_IRQ feature has not been negotiated.
- The driver MUST NOT send IRQ messages for a GPIO line configured for output.
- The driver MUST set the IRQ trigger type to VIRTIO\_GPIO\_IRQ\_TYPE\_NONE once it is done using the GPIO line configured for interrupts.
- In order to change the trigger type of an already enabled interrupt, the driver MUST first disable the interrupt and then re-enable it with appropriate trigger type.

## 5.18.6.9 Device Requirements: requestq Operation

- The device MUST set all the fields of the *struct virtio\_gpio\_response* before sending it back to the driver.
- The device MUST set all the fields of the *struct virtio\_gpio\_config* on receiving a configuration request from the driver.
- The device MUST set the *gpio\_names\_size* field as zero in the *struct virtio\_gpio\_config*, if it doesn't implement names for individual GPIO lines.
- The device MUST set the gpio\_names\_size field, in the struct virtio\_gpio\_config, with the size of gpio-names memory block in bytes, if the device implements names for individual GPIO lines. The strings MUST be zero-terminated and an unique (if available) within the GPIO device.
- The device MUST process multiple messages, for the same GPIO line, sequentially and respond to them in the order they were received on the virtqueue.
- The device MAY process messages, for different GPIO lines, out of order and in parallel, and MAY send message's response to the driver out of order.
- The device MUST discard all state information corresponding to a GPIO line, once the driver has requested to set its direction to VIRTIO\_GPIO\_DIRECTION\_NONE.
- The device MUST latch an edge interrupt if the interrupt is enabled but still masked.
- The device MUST NOT latch an level interrupt if the interrupt is enabled but still masked.
- The device MUST discard any latched interrupt for a GPIO line, once interrupt is disabled for the same.

### 5.18.7 Device Operation: eventg

The *eventq* virtqueue is used by the driver to unmask the interrupts and used by the device to notify the driver of newly sensed interrupts. In order to unmask interrupt on a GPIO line, the driver queues a pair of buffers, *struct virtio\_gpio\_irq\_request* (filled by driver) and *struct virtio\_gpio\_irq\_response* (to be filled by device later), to the *eventq* virtqueue. A separate pair of buffers must be queued for each GPIO line, the driver wants to configure for interrupts. The device, on sensing an interrupt, returns the pair of buffers for the respective GPIO line, which also masks the interrupts. The driver can queue the buffers again to unmask the interrupt.

```
struct virtio_gpio_irq_request {
   le16 gpio;
};
```

This structure is filled by the driver and read by the device.

gpio is the GPIO line number, i.e. 0 <= gpio < ngpio.

This structure is filled by the device and read by the driver.

**status** of the interrupt event, *VIRTIO\_GPIO\_IRQ\_STATUS\_VALID* on interrupt and *VIRTIO\_GPIO\_IRQ\_-STATUS\_INVALID* to return the buffers back to the driver after interrupt is disabled.

## 5.18.7.1 eventq Operation: Message Flow

- The virtio-gpio driver is requested by a client driver to enable interrupt for a GPIO line and configure it to a particular trigger type.
- The driver sends the VIRTIO\_GPIO\_MSG\_SET\_IRQ\_TYPE message, over the requestq virtqueue, and the device configures the GPIO line for the requested trigger type and enables the interrupt. The interrupt is still masked for delivery though. The device shall latch the interrupt from now onward for edge trigger type.
- The driver unmasks the interrupt by queuing a pair of buffers to the eventq virtqueue for the GPIO line.
   The driver can do this before enabling the interrupt as well, though the interrupt must be both unmasked and enabled to get delivered at the driver.
- The driver notifies the device of the presence of new buffers on the *eventq* virtqueue. The interrupt is fully configured at this point.
- The device, on sensing an active interrupt on the GPIO line, finds the matching buffers (based on GPIO line number) from the *eventq* virtqueue and update its *struct virtio\_gpio\_irq\_response* buffer's *status* with *VIRTIO\_GPIO\_IRQ\_STATUS\_VALID* and returns the pair of buffers to the device. This results in masking the interrupt as well.
- The device notifies the driver of the presence of returned buffers on the eventq virtqueue.
- If the GPIO line is configured for level interrupts, the device ignores any further interrupt signals on this GPIO line, until the interrupt is unmasked again by the driver by making the buffers available to the device. Once the interrupt is unmasked again and the interrupt on the line is still active, the device shall notify the driver again.
- If the GPIO line is configured for edge interrupts, the device latches the interrupt received for this GPIO line, until the interrupt is unmasked again by the driver by making the buffers available to the device. Once the interrupt is unmasked again and an interrupt was latched earlier, the device shall notify the driver again.
- The driver on receiving the notification from the device, processes the interrupt. The interrupt is masked at the device until the buffers are queued again by the driver.
- In a typical guest operating system kernel, the virtio-gpio driver notifies the client driver, that is associated with this GPIO line, to process the event. In the case of a level triggered interrupt, the client driver shall fully process and acknowledge the event at its source to return the line to its inactive state before the interrupt is unmasked again to avoid a spurious interrupt.
- Once the interrupt is handled, the driver may queue a pair of buffers for the GPIO line to unmask the interrupt again.

• The driver can also disable the interrupt by sending the VIRTIO\_GPIO\_MSG\_SET\_IRQ\_TYPE message, with VIRTIO\_GPIO\_IRQ\_TYPE\_NONE trigger type. In that case, the device shall return the unused pair of buffers for the GPIO line after setting the status field with VIRTIO\_GPIO\_IRQ\_STATUS\_INVALID.

#### 5.18.7.2 Driver Requirements: eventq Operation

- The driver MUST both enable and unmask the interrupt in order to get notified for the same.
- The driver MUST enable the interrupt before unmasking it.
- To unmask the interrupt, the driver MUST queue a separate pair of buffers to the eventq virtqueue for each GPIO line.
- The driver MUST NOT add multiple pairs of buffers for the same GPIO line on the eventq virtqueue.

## 5.18.7.3 Device Requirements: eventq Operation

- The device MUST NOT send an interrupt event to the driver for a GPIO line unless the interrupt has been both unmasked and enabled by the driver.
- On receiving VIRTIO\_GPIO\_MSG\_SET\_IRQ\_TYPE message, with VIRTIO\_GPIO\_IRQ\_TYPE\_NONE
  trigger type, the device MUST return the buffers, if they were received earlier, after setting the status
  field to VIRTIO\_GPIO\_IRQ\_STATUS\_INVALID.

## 5.19 PMEM Device

The virtio pmem device is a persistent memory (NVDIMM) device that provides a virtio based asynchronous flush mechanism. This avoids the need for a separate page cache in the guest and keeps the page cache only in the host. Under memory pressure, the host makes use of efficient memory reclaim decisions for page cache pages of all the guests. This helps to reduce the memory footprint and fits more guests in the host system.

The virtio pmem device provides access to byte-addressable persistent memory. The persistent memory is a directly accessible range of system memory. Data written to this memory is made persistent by separately sending a flush command. Writes that have been flushed are preserved across device reset and power failure.

#### 5.19.1 Device ID

27

## 5.19.2 Virtqueues

0 req vq

### 5.19.3 Feature bits

**VIRTIO\_PMEM\_F\_SHMEM\_REGION (0)** The guest physical address range will be indicated as a shared memory region.

## 5.19.4 Device configuration layout

```
struct virtio_pmem_config {
  le64 start;
  le64 size;
};
```

**start** contains the physical address of the first byte of the persistent memory region, if VIRTIO\_PMEM\_F\_- SHMEM\_REGION has not been negotiated.

**size** contains the length of this address range, if VIRTIO\_PMEM\_F\_SHMEM\_REGION has not been negotiated.

## 5.19.5 Device Initialization

The device indicates the guest physical address to the driver in one of two ways:

- 1. As a physical address, using virtio pmem config.
- 2. As a shared memory region.

The driver determines the start address and size of the persistent memory region in preparation for reading or writing data.

The driver initializes req vq in preparation for making flush requests.

## 5.19.5.1 Device Requirements: Device Initialization

If VIRTIO\_PMEM\_F\_SHMEM\_REGION has been negotiated, the device MUST indicate the guest physical address as a shared memory region. The device MUST use shared memory region ID 0. The device SHOULD set *start* and *size* to zero.

If VIRTIO\_PMEM\_F\_SHMEM\_REGION has not been negotiated, the device MUST indicate the guest physical address as a physical address. The device MUST set *start* to the absolute address and *size* to the size of the address range, in bytes.

## 5.19.5.2 Driver Requirements: Device Initialization

If VIRTIO\_PMEM\_F\_SHMEM\_REGION has been negotiated, the driver MUST query shared memory ID 0 for the physical address ranges, and MUST NOT use *start* or *stop*.

If VIRTIO\_PMEM\_F\_SHMEM\_REGION has not been negotiated, the driver MUST read the physical address ranges from *start* and *stop*.

## 5.19.6 Driver Operations

Requests have the following format:

```
struct virtio_pmem_req {
    le32 type;
};
```

type is the request command type.

Possible request types are:

```
#define VIRTIO_PMEM_REQ_TYPE_FLUSH 0
```

## 5.19.7 Device Operations

## 5.19.7.1 Device Requirements: Device Operation: Virtqueue flush

The device MUST ensure that all writes completed before a flush request persist across device reset and power failure before completing the flush request.

#### 5.19.7.2 Device Operations

```
struct virtio_pmem_resp {
    le32 ret;
};
```

ret is the value which the device returns after command completion.

#### 5.19.7.3 Device Requirements: Device Operation: Virtgueue return

The device MUST return "0" for success and "-1" for failure.

## 5.19.8 Possible security implications

There could be potential security implications depending on how memory mapped backing device is used. By default device emulation is done with SHARED memory mapping. There is a contract between driver and device to access shared memory region for read or write operations.

If a malicious driver or device maps the same memory region, the attacker can make use of known side channel attacks to predict the current state of data. If both attacker and victim somehow execute same shared code after a flush or evict operation, with difference in execution timing attacker could infer another device's data.

## 5.19.9 Countermeasures

## 5.19.9.1 With SHARED mapping

If a device's backing region is shared between multiple devices, this may act as a metric for side channel attacks. As a counter measure every device should have its own (not shared with another driver) SHARED backing memory.

### 5.19.9.2 With PRIVATE mapping

There maybe be chances of side channels attack with PRIVATE memory mapping similar to SHARED with read-only shared mappings. PRIVATE is not used for virtio pmem making this usecase irrelevant.

### 5.19.9.3 Workload specific mapping

When using SHARED mappings with a workload that is a single application inside the driver where the risk in sharing data is very low or nonexisting, the device sharing the same backing region with a SHARED mapping can be used as a valid configuration.

### 5.19.9.4 Prevent cache eviction

Don't allow device shared region eviction from driver filesystem trim or discard like commands with virtio pmem. This rules out any possibility of evict-reload cache side channel attacks if backing region is shared (SHARED) between multiple devices. Though if we use per device backing file with shared mapping this countermeasure is not required.

# 6 Reserved Feature Bits

Currently these device-independent feature bits are defined:

- VIRTIO\_F\_INDIRECT\_DESC (28) Negotiating this feature indicates that the driver can use descriptors with the VIRTQ\_DESC\_F\_INDIRECT flag set, as described in 2.7.5.3 Indirect Descriptors and 2.8.7 Indirect Flag: Scatter-Gather Support.
- **VIRTIO\_F\_EVENT\_IDX(29)** This feature enables the *used\_event* and the *avail\_event* fields as described in 2.7.7, 2.7.8 and 2.8.10.
- **VIRTIO\_F\_VERSION\_1(32)** This indicates compliance with this specification, giving a simple way to detect legacy devices or drivers.
- VIRTIO\_F\_ACCESS\_PLATFORM(33) This feature indicates that the device can be used on a platform where device access to data in memory is limited and/or translated. E.g. this is the case if the device can be located behind an IOMMU that translates bus addresses from the device into physical addresses in memory, if the device can be limited to only access certain memory addresses or if special commands such as a cache flush can be needed to synchronise data in memory with the device. Whether accesses are actually limited or translated is described by platform-specific means. If this feature bit is set to 0, then the device has same access to memory addresses supplied to it as the driver has. In particular, the device will always use physical addresses matching addresses used by the driver (typically meaning physical addresses used by the CPU) and not translated further, and can access any address supplied to it by the driver. When clear, this overrides any platform-specific description of whether device access is limited or translated in any way, e.g. whether an IOMMU may be present.
- **VIRTIO\_F\_RING\_PACKED(34)** This feature indicates support for the packed virtqueue layout as described in 2.8 Packed Virtqueues.
- **VIRTIO\_F\_IN\_ORDER(35)** This feature indicates that all buffers are used by the device in the same order in which they have been made available.
- **VIRTIO\_F\_ORDER\_PLATFORM(36)** This feature indicates that memory accesses by the driver and the device are ordered in a way described by the platform.

If this feature bit is negotiated, the ordering in effect for any memory accesses by the driver that need to be ordered in a specific way with respect to accesses by the device is the one suitable for devices described by the platform. This implies that the driver needs to use memory barriers suitable for devices described by the platform; e.g. for the PCI transport in the case of hardware PCI devices.

- If this feature bit is not negotiated, then the device and driver are assumed to be implemented in software, that is they can be assumed to run on identical CPUs in an SMP configuration. Thus a weaker form of memory barriers is sufficient to yield better performance.
- **VIRTIO\_F\_SR\_IOV(37)** This feature indicates that the device supports Single Root I/O Virtualization. Currently only PCI devices support this feature.
- **VIRTIO\_F\_NOTIFICATION\_DATA(38)** This feature indicates that the driver passes extra data (besides identifying the virtqueue) in its device notifications. See 2.9 Driver Notifications.
- VIRTIO\_F\_NOTIF\_CONFIG\_DATA(39) This feature indicates that the driver uses the data provided by the device as a virtqueue identifier in available buffer notifications. As mentioned in section 2.9, when the driver is required to send an available buffer notification to the device, it sends the virtqueue number to be notified. The method of delivering notifications is transport specific. With the PCI transport, the device can optionally provide a per-virtqueue value for the driver to use in driver notifications, instead

of the virtqueue number. Some devices may benefit from this flexibility by providing, for example, an internal virtqueue identifier, or an internal offset related to the virtqueue number.

This feature indicates the availability of such value. The definition of the data to be provided in driver notification and the delivery method is transport specific. For more details about driver notifications over PCI see 4.1.5.2.

**VIRTIO\_F\_RING\_RESET(40)** This feature indicates that the driver can reset a queue individually. See 2.6.1.

# 6.1 Driver Requirements: Reserved Feature Bits

A driver MUST accept VIRTIO\_F\_VERSION\_1 if it is offered. A driver MAY fail to operate further if VIRTIO\_-F VERSION 1 is not offered.

A driver SHOULD accept VIRTIO\_F\_ACCESS\_PLATFORM if it is offered, and it MUST then either disable the IOMMU or configure the IOMMU to translate bus addresses passed to the device into physical addresses in memory. If VIRTIO\_F\_ACCESS\_PLATFORM is not offered, then a driver MUST pass only physical addresses to the device.

A driver SHOULD accept VIRTIO\_F\_RING\_PACKED if it is offered.

A driver SHOULD accept VIRTIO\_F\_ORDER\_PLATFORM if it is offered. If VIRTIO\_F\_ORDER\_PLATFORM has been negotiated, a driver MUST use the barriers suitable for hardware devices.

If VIRTIO\_F\_SR\_IOV has been negotiated, a driver MAY enable virtual functions through the device's PCI SR-IOV capability structure. A driver MUST NOT negotiate VIRTIO\_F\_SR\_IOV if the device does not have a PCI SR-IOV capability structure or is not a PCI device. A driver MUST negotiate VIRTIO\_F\_SR\_IOV and complete the feature negotiation (including checking the FEATURES\_OK *device status* bit) before enabling virtual functions through the device's PCI SR-IOV capability structure. After once successfully negotiating VIRTIO\_F\_SR\_IOV, the driver MAY enable virtual functions through the device's PCI SR-IOV capability structure even if the device or the system has been fully or partially reset, and even without re-negotiating VIRTIO\_F\_SR\_IOV after the reset.

A driver SHOULD accept VIRTIO F NOTIF CONFIG DATA if it is offered.

# 6.2 Device Requirements: Reserved Feature Bits

A device MUST offer VIRTIO\_F\_VERSION\_1. A device MAY fail to operate further if VIRTIO\_F\_VERSION\_1 is not accepted.

A device SHOULD offer VIRTIO\_F\_ACCESS\_PLATFORM if its access to memory is through bus addresses distinct from and translated by the platform to physical addresses used by the driver, and/or if it can only access certain memory addresses with said access specified and/or granted by the platform. A device MAY fail to operate further if VIRTIO\_F\_ACCESS\_PLATFORM is not accepted.

If VIRTIO\_F\_IN\_ORDER has been negotiated, a device MUST use buffers in the same order in which they have been available.

A device MAY fail to operate further if VIRTIO\_F\_ORDER\_PLATFORM is offered but not accepted. A device MAY operate in a slower emulation mode if VIRTIO F ORDER PLATFORM is offered but not accepted.

It is RECOMMENDED that an add-in card based PCI device offers both VIRTIO\_F\_ACCESS\_PLATFORM and VIRTIO\_F\_ORDER\_PLATFORM for maximum portability.

A device SHOULD offer VIRTIO\_F\_SR\_IOV if it is a PCI device and presents a PCI SR-IOV capability structure, otherwise it MUST NOT offer VIRTIO\_F\_SR\_IOV.

# 6.3 Legacy Interface: Reserved Feature Bits

Transitional devices MAY offer the following:

- **VIRTIO\_F\_NOTIFY\_ON\_EMPTY (24)** If this feature has been negotiated by driver, the device MUST issue a used buffer notification if the device runs out of available descriptors on a virtqueue, even though notifications are suppressed using the VIRTQ\_AVAIL\_F\_NO\_INTERRUPT flag or the *used\_event* field.
  - **Note:** An example of a driver using this feature is the legacy networking driver: it doesn't need to know every time a packet is transmitted, but it does need to free the transmitted packets a finite time after they are transmitted. It can avoid using a timer if the device notifies it when all the packets are transmitted.
- Transitional devices MUST offer, and if offered by the device transitional drivers MUST accept the following:
- **VIRTIO\_F\_ANY\_LAYOUT (27)** This feature indicates that the device accepts arbitrary descriptor layouts, as described in Section 2.7.4.3 Legacy Interface: Message Framing.
- **UNUSED (30)** Bit 30 is used by qemu's implementation to check for experimental early versions of virtio which did not perform correct feature negotiation, and SHOULD NOT be negotiated.

### 7 Conformance

This chapter lists the conformance targets and clauses for each; this also forms a useful checklist which authors are asked to consult for their implementations!

### 7.1 Conformance Targets

Conformance targets:

**Driver** A driver MUST conform to four conformance clauses:

- Clause 7.2.
- One of clauses 7.2.1, 7.2.2 or 7.2.3.
- One of clauses 7.2.4, 7.2.5, 7.2.6, 7.2.7, 7.2.8, 7.2.9, 7.2.10, 7.2.11, 7.2.12, 7.2.13, 7.2.14, 7.2.15, 7.2.16, 7.2.17, 7.2.18, 7.2.19, 7.2.20 or 7.2.21.
- Clause 7.4.

**Device** A device MUST conform to four conformance clauses:

- Clause 7.3.
- One of clauses 7.3.1, 7.3.2 or 7.3.3.
- One of clauses 7.3.4, 7.3.5, 7.3.6, 7.3.7, 7.3.8, 7.3.9, 7.3.10, 7.3.11, 7.3.12, 7.3.13, 7.3.14, 7.3.15, 7.3.16, 7.3.17, 7.3.18, 7.3.19, 7.3.20, 7.3.21 or 7.3.22.
- Clause 7.4.

#### 7.2 Clause 1: Driver Conformance

A driver MUST conform to the following normative statements:

- 2.1.1
- 2.2.1
- 2.4.2
- 2.5.1
- 2.7.1
- 2.7.4.2
- 2.7.5.2
- 2.7.5.3.1
- 2.7.7.1
- 2.7.6.1
- 2.7.8.3
- 2.7.10.1
- 2.7.13.3.1

- 2.7.13.4.1
- 2.8.11
- 2.8.16
- 2.8.17
- 2.8.19
- 2.8.21.1.1
- 2.8.21.3.1
- 3.1.1
- 3.3.1
- 6.1

#### 7.2.1 Clause 2: PCI Driver Conformance

A PCI driver MUST conform to the following normative statements:

- 4.1.2.2
- 4.1.3.1
- 4.1.4.1
- 4.1.4.3.2
- 4.1.4.5.2
- 4.1.4.9.2
- 4.1.5.1.2.2
- 4.1.5.4.2

#### 7.2.2 Clause 3: MMIO Driver Conformance

An MMIO driver MUST conform to the following normative statements:

- 4.2.2.2
- 4.2.3.1.1
- 4.2.3.4.1

#### 7.2.3 Clause 4: Channel I/O Driver Conformance

A Channel I/O driver MUST conform to the following normative statements:

- 4.3.1.4
- 4.3.2.1.2
- 4.3.2.3.1
- 4.3.3.1.2.2
- 4.3.3.2.2
- 4.3.3.3.2

#### 7.2.4 Clause 5: Network Driver Conformance

A network driver MUST conform to the following normative statements:

- 5.1.4.2
- 5.1.6.2.1
- 5.1.6.3.1
- 5.1.6.4.2
- 5.1.6.5.1.2
- 5.1.6.5.2.2
- 5.1.6.5.4.1
- 5.1.6.5.6.1
- 5.1.6.5.8.2
- 5.1.6.5.7.2

#### 7.2.5 Clause 6: Block Driver Conformance

A block driver MUST conform to the following normative statements:

- 5.2.5.1
- 5.2.6.1

#### 7.2.6 Clause 7: Console Driver Conformance

A console driver MUST conform to the following normative statements:

- 5.3.6.1
- 5.3.6.2.2

#### 7.2.7 Clause 8: Entropy Driver Conformance

An entropy driver MUST conform to the following normative statements:

• 5.4.6.1

#### 7.2.8 Clause 9: Traditional Memory Balloon Driver Conformance

A traditional memory balloon driver MUST conform to the following normative statements:

- 5.5.3.1
- 5.5.6.1
- 5.5.6.3.1
- 5.5.6.5.1
- 5.5.6.6.1
- 5.5.6.7.1

#### 7.2.9 Clause 10: SCSI Host Driver Conformance

An SCSI host driver MUST conform to the following normative statements:

- 5.6.4.1
- 5.6.6.1.2

#### 7.2.10 Clause 11: Input Driver Conformance

An input driver MUST conform to the following normative statements:

- 5.8.5.1
- 5.8.6.1

#### 7.2.11 Clause 12: Crypto Driver Conformance

A Crypto driver MUST conform to the following normative statements:

- 5.9.5.2
- 5.9.6.1
- 5.9.7.2.1.5
- 5.9.7.2.1.7
- 5.9.7.4.1
- 5.9.7.5.1
- 5.9.7.6.1
- 5.9.7.7.1

#### 7.2.12 Clause 13: Socket Driver Conformance

A socket driver MUST conform to the following normative statements:

- 5.10.6.3.1
- 5.10.6.4.1
- 5.10.6.7.1

#### 7.2.13 Clause 14: File System Driver Conformance

A file system driver MUST conform to the following normative statements:

- 5.11.4.1
- 5.11.6.2.2
- 5.11.6.3.1
- 5.11.6.4.2

#### 7.2.14 Clause 15: RPMB Driver Conformance

A RPMB driver MUST conform to the following normative statements:

• 5.12.6.2

#### 7.2.15 Clause 16: IOMMU Driver Conformance

An IOMMU driver MUST conform to the following normative statements:

- 5.13.3.1
- 5.13.4.1
- 5.13.5.1
- 5.13.6.1

- 5.13.6.3.1
- 5.13.6.4.1
- 5.13.6.5.1
- 5.13.6.6.1
- 5.13.6.7.1
- 5.13.6.8.1.1
- 5.13.6.9.1

#### 7.2.16 Clause 17: Sound Driver Conformance

A sound driver MUST conform to the following normative statements:

- 5.14.5.1
- 5.14.6.2
- 5.14.6.6.3.2
- 5.14.6.8.1.2
- 5.14.6.8.2.2

#### 7.2.17 Clause 18: Memory Driver Conformance

A memory driver MUST conform to the following normative statements:

- 5.15.4.1
- 5.15.5.1
- 5.15.6.1
- 5.15.6.3.1
- 5.15.6.4.1
- 5.15.6.5.1
- 5.15.6.6.1

#### 7.2.18 Clause 19: I2C Adapter Driver Conformance

An I2C Adapter driver MUST conform to the following normative statements:

• 5.16.6.3

#### 7.2.19 Clause 20: SCMI Driver Conformance

An SCMI driver MUST conform to the following normative statements:

- 5.17.6.1.2
- 5.17.6.2.1

#### 7.2.20 Clause 21: GPIO Driver Conformance

A General Purpose Input/Output (GPIO) driver MUST conform to the following normative statements:

- 5.18.6.8
- 5.18.7.2

#### 7.2.21 Clause 22: PMEM Driver Conformance

A PMEM driver MUST conform to the following normative statements:

• 5.19.5.2

#### 7.3 Clause 23: Device Conformance

A device MUST conform to the following normative statements:

- 2.1.2
- 2.2.2
- 2.4.1
- 2.5.2
- 2.7.4.1
- 2.7.5.1
- 2.7.5.3.2
- 2.7.7.2
- 2.7.8.2
- 2.7.10.2
- 2.8.12
- 2.8.15
- 2.8.18
- 2.10.2
- 6.2

#### 7.3.1 Clause 24: PCI Device Conformance

A PCI device MUST conform to the following normative statements:

- 4.1.1
- 4.1.2.1
- 4.1.3.2
- 4.1.4.2
- 4.1.4.3.1
- 4.1.4.4.1
- 4.1.4.5.1
- 4.1.4.6.1
- 4.1.4.7.1
- 4.1.4.9.1
- 4.1.4.11.0.1
- 4.1.5.1.2.1
- 4.1.5.3.1
- 4.1.5.4.1

#### 7.3.2 Clause 25: MMIO Device Conformance

An MMIO device MUST conform to the following normative statements:

• 4.2.2.1

#### 7.3.3 Clause 26: Channel I/O Device Conformance

A Channel I/O device MUST conform to the following normative statements:

- 4.3.1.3
- 4.3.2.1.1
- 4.3.2.2.1
- 4.3.2.3.2
- 4.3.2.6.3.1
- 4.3.3.1.2.1
- 4.3.3.2.1
- 4.3.3.3.1

#### 7.3.4 Clause 27: Network Device Conformance

A network device MUST conform to the following normative statements:

- 5.1.4.1
- 5.1.6.2.2
- 5.1.6.3.2
- 5.1.6.4.1
- 5.1.6.5.1.1
- 5.1.6.5.2.1
- 5.1.6.5.4.2
- 5.1.6.5.6.2
- 5.1.6.5.7.3

#### 7.3.5 Clause 28: Block Device Conformance

A block device MUST conform to the following normative statements:

- 5.2.5.2
- 5.2.6.2

#### 7.3.6 Clause 29: Console Device Conformance

A console device MUST conform to the following normative statements:

- 5.3.5.1
- 5.3.6.2.1

#### 7.3.7 Clause 30: Entropy Device Conformance

An entropy device MUST conform to the following normative statements:

• 5.4.6.2

#### 7.3.8 Clause 31: Traditional Memory Balloon Device Conformance

A traditional memory balloon device MUST conform to the following normative statements:

- 5.5.3.2
- 5.5.6.2
- 5.5.6.3.2
- 5.5.6.5.2
- 5.5.6.6.2
- 5.5.6.7.2

#### 7.3.9 Clause 32: SCSI Host Device Conformance

An SCSI host device MUST conform to the following normative statements:

- 5.6.4.2
- 5.6.5
- 5.6.6.1.1
- 5.6.6.3.2

#### 7.3.10 Clause 33: GPU Device Conformance

A GPU device MUST conform to the following normative statements:

- 5.7.5
- 5.7.6.5

#### 7.3.11 Clause 34: Input Device Conformance

An input device MUST conform to the following normative statements:

- 5.8.5.2
- 5.8.6.2

#### 7.3.12 Clause 35: Crypto Device Conformance

A Crypto device MUST conform to the following normative statements:

- 5.9.5.1
- 5.9.7.2.1.6
- 5.9.7.2.1.8
- 5.9.7.4.2
- 5.9.7.5.2
- 5.9.7.6.2
- 5.9.7.7.2

#### 7.3.13 Clause 36: Socket Device Conformance

A socket device MUST conform to the following normative statements:

- 5.10.6.3.2
- 5.10.6.4.2

#### 7.3.14 Clause 37: File System Device Conformance

A file system device MUST conform to the following normative statements:

- 5.11.4.2
- 5.11.6.2.1
- 5.11.6.4.1

#### 7.3.15 Clause 38: RPMB Device Conformance

An RPMB device MUST conform to the following normative statements:

- 5.12.5
- 5.12.6.1.1
- 5.12.6.1.2
- 5.12.6.1.3
- 5.12.6.1.4
- 5.12.6.1.5
- 5.12.6.3

#### 7.3.16 Clause 39: IOMMU Device Conformance

An IOMMU device MUST conform to the following normative statements:

- 5.13.3.2
- 5.13.4.2
- 5.13.6.2
- 5.13.6.3.2
- 5.13.6.4.2
- 5.13.6.5.2
- 5.13.6.6.2
- 5.13.6.7.2
- 5.13.6.8.1.2
- 5.13.6.9.2

#### 7.3.17 Clause 40: Sound Device Conformance

A sound device MUST conform to the following normative statements:

- 5.14.6.4.1.1
- 5.14.6.6.2.1
- 5.14.6.6.3.1
- 5.14.6.6.5.1
- 5.14.6.8.1.1
- 5.14.6.8.2.1
- 5.14.6.9.1.1

#### 7.3.18 Clause 41: Memory Device Conformance

A memory device MUST conform to the following normative statements:

- 5.15.4.2
- 5.15.5.2
- 5.15.6.2
- 5.15.6.3.2
- 5.15.6.4.2
- 5.15.6.5.2
- 5.15.6.6.2

#### 7.3.19 Clause 42: I2C Adapter Device Conformance

An I2C Adapter device MUST conform to the following normative statements:

• 5.16.6.4

#### 7.3.20 Clause 43: SCMI Device Conformance

An SCMI device MUST conform to the following normative statements:

- 5.17.3.1
- 5.17.6.1.1
- 5.17.6.3.1
- 5.17.6.4.1

#### 7.3.21 Clause 44: GPIO Device Conformance

A General Purpose Input/Output (GPIO) device MUST conform to the following normative statements:

- 5.18.6.9
- 5.18.7.3

#### 7.3.22 Clause 45: PMEM Device Conformance

A PMEM device MUST conform to the following normative statements:

- 5.19.5.1
- 5.19.7.1
- 5.19.7.3

# 7.4 Clause 46: Legacy Interface: Transitional Device and Transitional Driver Conformance

A conformant implementation MUST be either transitional or non-transitional, see 1.3.1.

An implementation MAY choose to implement OPTIONAL support for the legacy interface, including support for legacy drivers or devices, by conforming to all of the MUST or REQUIRED level requirements for the legacy interface for the transitional devices and drivers.

The requirements for the legacy interface for transitional implementations are located in sections named "Legacy Interface" listed below:

Section 2.2.3

- Section 2.5.3
- Section 2.5.4
- Section 2.7.2
- Section 2.7.3
- Section 2.7.4.3
- Section 3.1.2
- Section 4.1.2.3
- Section 4.1.4.10
- Section 4.1.5.1.1.1
- Section 4.1.5.1.3.1
- Section 4.2.4
- Section 4.3.2.1.3
- Section 4.3.2.2.2
- Section 4.3.3.1.3
- Section 4.3.2.6.4
- Section 5.1.3.2
- Section 5.1.4.3
- Section 5.1.6.1
- Section 5.1.6.5.2.3
- Section 5.1.6.5.3.1
- Section 5.1.6.5.6.3
- Section 5.1.6.5.8.3
- Section 5.2.3.1
- Section 5.2.4.1
- Section 5.2.5.3
- Section 5.2.6.3
- Section 5.3.4.1
- Section 5.3.6.3
- Section 5.5.3.2.0.1
- Section 5.5.6.2.1
- Section 5.5.6.3.3
- Section 5.6.4.3
- Section 5.6.6.0.1
- Section 5.6.6.1.3
- Section 5.6.6.2.1
- Section 5.6.6.3.3
- Section 6.3

### Appendix A. virtio\_queue.h

This file is also available at the link https://docs.oasis-open.org/virtio/virtio/v1.2/csd01/listings/virtio\_queue. h. All definitions in this section are for non-normative reference only.

```
#ifndef VIRTQUEUE H
#define VIRTQUEUE H
/* An interface for efficient virtio implementation.
* This header is BSD licensed so anyone can use the definitions
* to implement compatible drivers/servers.
* Copyright 2007, 2009, IBM Corporation
 * Copyright 2011, Red Hat, Inc
* All rights reserved.
* Redistribution and use in source and binary forms, with or without
 * modification, are permitted provided that the following conditions
* 1. Redistributions of source code must retain the above copyright
     notice, this list of conditions and the following disclaimer.
 * 2. Redistributions in binary form must reproduce the above copyright
     notice, this list of conditions and the following disclaimer in the
     documentation and/or other materials provided with the distribution.
 * 3. Neither the name of IBM nor the names of its contributors
     may be used to endorse or promote products derived from this software
     without specific prior written permission.
 * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS ``AS IS'' AND
 * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
* ARE DISCLAIMED. IN NO EVENT SHALL IBM OR CONTRIBUTORS BE LIABLE
  FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
* OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
* LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
* OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
* SUCH DAMAGE.
* /
#include <stdint.h>
/* This marks a buffer as continuing via the next field. */
#define VIRTQ DESC F NEXT
/* This marks a buffer as write-only (otherwise read-only). */
#define VIRTQ DESC F WRITE
                               2.
/* This means the buffer contains a list of buffer descriptors. */
#define VIRTQ DESC F INDIRECT
/* The device uses this in used->flags to advise the driver: don't kick me
* when you add a buffer. It's unreliable, so it's simply an
* optimization. */
#define VIRTQ USED F NO NOTIFY 1
/* The driver uses this in avail->flags to advise the device: don't
* interrupt me when you consume a buffer. It's unreliable, so it's
* simply an optimization. */
#define VIRTQ AVAIL F NO INTERRUPT
/* Support for indirect descriptors */
#define VIRTIO_F_INDIRECT_DESC
/* Support for avail event and used event fields */
#define VIRTIO F EVENT IDX
```

```
/* Arbitrary descriptor layouts. */
#define VIRTIO F ANY LAYOUT
/* Virtqueue descriptors: 16 bytes.
* These can chain together via "next". */
struct virtq desc {
       /* Address (guest-physical). */
       le64 addr;
        /* Length. */
       le32 len;
        /* The flags as indicated above. */
       le16 flags;
        /* We chain unused descriptors via this, too */
       le16 next;
};
struct virtq avail {
       le16 flags;
       le16 idx;
        le16 ring[];
        /* Only if VIRTIO_F_EVENT_IDX: le16 used_event; */
};
/* le32 is used here for ids for padding reasons. */
struct virtq used elem {
        /* Index of start of used descriptor chain. */
        /* Total length of the descriptor chain which was written to. */
       le32 len;
};
struct virtq used {
       le16 flags;
        le16 idx;
        struct virtq used elem ring[];
        /* Only if VIRTIO F EVENT IDX: le16 avail event; */
};
struct virtq {
       unsigned int num;
       struct virtq desc *desc;
       struct virtq_avail *avail;
        struct virtq used *used;
};
static inline int virtq need event(uint16 t event idx, uint16 t new idx, uint16 t old idx)
        return (uint16_t) (new_idx - event_idx - 1) < (uint16_t) (new_idx - old_idx);</pre>
/* Get location of event indices (only with VIRTIO F EVENT IDX) */
static inline le16 *virtq_used_event(struct virtq *vq)
        /* For backwards compat, used event index is at *end* of avail ring. */
        return &vq->avail->ring[vq->num];
static inline le16 *virtq avail event(struct virtq *vq)
        /* For backwards compat, avail event index is at *end* of used ring. */
        return (le16 *)&vq->used->ring[vq->num];
#endif /* VIRTQUEUE H */
```

### **Appendix B. Creating New Device Types**

Various considerations are necessary when creating a new device type.

#### **B.1 How Many Virtqueues?**

It is possible that a very simple device will operate entirely through its device configuration space, but most will need at least one virtqueue in which it will place requests. A device with both input and output (eg. console and network devices described here) need two queues: one which the driver fills with buffers to receive input, and one which the driver places buffers to transmit output.

#### **B.2 What Device Configuration Space Layout?**

Device configuration space should only be used for initialization-time parameters. It is a limited resource with no synchronization between field written by the driver, so for most uses it is better to use a virtqueue to update configuration information (the network device does this for filtering, otherwise the table in the config space could potentially be very large).

Remember that configuration fields over 32 bits wide might not be atomically writable by the driver. Therefore, no writeable field which triggers an action ought to be wider than 32 bits.

#### **B.3 What Device Number?**

Device numbers can be reserved by the OASIS committee: email virtio-dev@lists.oasis-open.org to secure a unique one.

Meanwhile for experimental drivers, use 65535 and work backwards.

### **B.4** How many MSI-X vectors? (for PCI)

Using the optional MSI-X capability devices can speed up interrupt processing by removing the need to read ISR Status register by guest driver (which might be an expensive operation), reducing interrupt sharing between devices and queues within the device, and handling interrupts from multiple CPUs. However, some systems impose a limit (which might be as low as 256) on the total number of MSI-X vectors that can be allocated to all devices. Devices and/or drivers should take this into account, limiting the number of vectors used unless the device is expected to cause a high volume of interrupts. Devices can control the number of vectors used by limiting the MSI-X Table Size or not presenting MSI-X capability in PCI configuration space. Drivers can control this by mapping events to as small number of vectors as possible, or disabling MSI-X capability altogether.

### **B.5** Device Improvements

Any change to device configuration space, or new virtqueues, or behavioural changes, should be indicated by negotiation of a new feature bit. This establishes clarity<sup>1</sup> and avoids future expansion problems.

Clusters of functionality which are always implemented together can use a single bit, but if one feature makes sense without the others they should not be gratuitously grouped together to conserve feature bits.

<sup>&</sup>lt;sup>1</sup>Even if it does mean documenting design or implementation mistakes!

### **Appendix C. Acknowledgements**

The following individuals have participated in the creation of this specification and are gratefully acknowledged:

**Participants** Alexander Duyck, Intel Alex Bennée, Linaro Anton Yakovlev, OpenSynergy Arseny Krasnov, Kaspersky Lab Cornelia Huck, Red Hat David Hildenbrand, Red Hat David Stevens, Chromium Dr. David Alan Gilbert, Red Hat Enrico Granata, Google Eugenio Pérez, Red Hat Felipe Franciosi, Nutanix Gaetan Harter, OpenSynergy Gerd Hoffmann, Red Hat Gurchetan Singh, Chromium Halil Pasic, IBM Hao Chen, Google Huang Yang, Intel Jan Kiszka, Siemens Jean-Philippe Brucker, Linaro

Jie Deng, Intel Joel Nider, Individual

Jiang Wang, Bytedance

Johannes Berg, Intel

Junji Wei, Bytedance

Keiichi Watanabe. Chromium Marcel Holtmann, Individual

Max Gurtovoy, Nvidia

Michael S. Tsirkin, Red Hat

Nikos Dragazis, Arrikto

Pankaj Gupta, Red Hat

Paolo Bonzini, Red Hat

Parav Pandit, Nvidia

Peter Hilber, OpenSynergy

Petre Eftime, Amazon

Philipp Hahn, Univention

Rob Bradford, Intel

Stefan Fritsch, Individual

Stefan Hajnoczi, Red Hat

Stefano Garzarella, Red Hat

Taylor Stark, Microsoft

Tiwei Bie, Intel

Viresh Kumar, Linaro

Vitaly Mireyno, Marvell

Xuan Zhuo, Alibaba Yadong Qi, Intel Yoni Bettan, Red Hat Yuri Benditovich, Red Hat / Daynix

The following non-members have provided valuable feedback on this specification and are gratefully acknowledged:

#### Reviewers

Christophe de Dinechin, Red Hat Gil Savir, Intel Ruchika Gupta, Linaro Arnd Bergmann, Individual Bing Zhu, Intel Eduardo Habkost, Red Hat Eric Auger, Red Hat Jason Wang, Red Hat Jens Freimann, Red Hat Kevin Tian, Intel Linus Walleij, Linaro Matti Möll, OpenSynergy Tomas Winkler, Intel Yang Huang, Intel

The following individuals have participated in the creation of previous versions of this specification and are gratefully acknowledged:

#### **Participants**

Allen Chia, Oracle

Amit Shah, Red Hat

Amos Kong, Red Hat

Anthony Liguori, IBM

Bruce Rogers, SUSE

Bryan Venteicher, NetApp

Chandra Thyamagondlu, Xilinx

Chet Ensign, OASIS

Cornelia Huck, Red Hat

Cunming, Liang, Intel

Damjan, Marion, Cisco

Daniel Kiper, Oracle

Fang Chen, Huawei

Fang You, Huawei

Geoff Brown, M2Mi

Gerd Hoffmann, Red Hat

Gershon Janssen, Individual Member

Grant Likely, ARM

Haggai Eran, Mellanox

Halil Pasic, IBM

James Bottomley, Parallels IP Holdings GmbH

Jani Kokkonen, Huawei

Jan Kiszka, Siemens AG

Jens Freimann, Red Hat

Jian Zhou, Huawei

Karen Xie, Xilinx

Kumar Sanghvi, Xilinx Lei Gong, Huawei Lior Narkis, Mellanox Luiz Capitulino, Red Hat Marc-André Lureau, Red Hat Mark Gray, Intel Michael S. Tsirkin, Red Hat Mihai Carabas. Oracle Nishank Trivedi, NetApp Paolo Bonzini, Red Hat Paul Mundt, Huawei Pawel Moll. ARM Peng Long, Huawei Piotr Uminski, Intel Qian Xum, Intel Richard Sohn, Alcatel-Lucent Rusty Russell, IBM Sasha Levin, Oracle Sergey Tverdyshev, Thales e-Security Stefan Hajnoczi, Red Hat Sundar Mohan, Xilinx Tom Lyon, Samya Systems, Inc. Victor Kaplansky, Red Hat Vijay Balakrishna, Oracle

The following non-members have provided valuable feedback on previous versions of this specification and are gratefully acknowledged:

#### Reviewers

Wei Wang, Intel Xin Zeng, Intel

Aaron Conole, Red Hat Adam Tao, Huawei Alexander Duyck, Intel Andreas Pape, ADITG/ESB Andrew Thornton, Google Arun Subbarao, LynuxWorks Baptiste Reynal, Virtual Open Systems Bharat Bhushan, NXP Semiconductors Brian Foley, ARM Chandra Thyamagondlu, Xilinx Changpeng Liu, Intel Christian Pinto, Virtual Open Systems Christoffer Dall, ARM Christoph Hellwig, Individual Christian Borntraeger, IBM Daniel Marcovitch, Mellanox David Alan Gilbert, Red Hat David Hildenbrand, Red Hat David Riddoch, Solarflare Denis V. Lunev, OpenVZ Dmitry Fleytman, Red Hat Don Wallwork. Broadcom Emily Drea, ARM

Eric Auger, Red Hat Fam Zheng, Red Hat

Francesco Fusco, Red Hat

Frank Yang, Google

Gil Savir, Intel

Gonglei (Arei), Huawei

Greg Kurz, IBM

Hannes Reiencke, SUSE

Ian Campbell, Docker

Ilya Lesokhin, Mellanox

Jacques Durand, Fujutsu

Jakub Jermar, Kernkonzept

Jan Scheurich, Ericsson

Jason Baron, Akamai

Jason Wang, Red Hat

Jean-Philippe Brucker, ARM

Jianfeng Tan, intel

Jonathan Helman, Oracle

Karandeep Chahal, DDN

Kevin Lo, MSI

Kevin Tian, Intel

Kully Dhanoa, Intel

Laura Novich, Red Hat

Ladi Prosek, Red Hat

Lars Ganrot, Napatech

Longpeng (Mike), Huawei

Mario Torrecillas Rodriguez, ARM

Mark Rustad, Intel

Maxime Coquelin, Red Hat

Namhyung Kim, LG

Ola Liljedahl, ARM

Pankaj Gupta, Red Hat

Patrick Durusau, OASIS

Pierre Pfister, Cisco

Pranavkumar Sawargaonkar, Linaro

Rauchfuss Holm, Huawei

Rob Miller, Broadcom

Roman Kiryanov, Google

Robin Cover, OASIS

Roger S Chien, Intel

Sameeh Jubran, Red Hat / Daynix

Si-Wei Liu, Oracle

Sridhar Samudrala, Intel

Stefan Fritsch, Individual

Stefano Garzarella, Red Hat

Steven Luong, Cisco

Thomas Huth, Red Hat

Tiwei Bie, Intel

Tomáš Golembiovský, Red Hat

Venu Busireddy, Oracle

Victor Kaplansky, Red Hat

Vijayabhaskar Balakrishna, Oracle

Vlad Yasevich, Red Hat

Yan Vugenfirer, Red Hat / Daynix

Wei Xu, Red Hat

Will Deacon, ARM

Willem de Bruijn, Google

Yuanhan Liu, Intel

Yuri Benditovich, Red Hat / Daynix

Zhi Yong Wu, IBM Zhoujian, Huawei

## **Appendix D. Revision History**

The following changes have been made since the previous version of this specification:

Revision	Date	Editor	Changes Made
d519c224ba69	20 Jun 2019	Stefan Hajnoczi	content: reserve virtio device ID for file system devices Reserve device ID 26 for virtio-fs devices. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/31 Signed-off-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.</mst@redhat.com></stefanha@redhat.com>
9454b568c29b	20 Jun 2019	Pankaj Gupta	content: reserve device ID for virtio-pmem devices  We need a device ID for virtio-pmem devices. As 25 is requested by audio device and 26 is requested by virtio-fs, so requesting next available(27). Also, updated the previously requested github issue[1] for voting.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/38  Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Pankaj Gupta <pagupta@redhat.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.</mst@redhat.com></mst@redhat.com></stefanha@redhat.com></pagupta@redhat.com></co-huck@redhat.com>
efd4028b7aec	25 Jul 2019	Dr. David Alan Gilbert	shared memory: Define shared memory regions Define the requirements and idea behind shared memory regions. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/40 Signed-off-by: Dr. David Alan Gilbert <dg-ilbert@redhat.com> Reviewed-by: Stefan Hajnoczi <ste-fanha@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 2.10.</mst@redhat.com></co-huck@redhat.com></ste-fanha@redhat.com></dg-ilbert@redhat.com>

Revision	Date	Editor	Changes Made
39dfc8afc0b9	25 Jul 2019	Dr. David Alan Gilbert	pci: Define id field For the virtio-fs device we require multiple large shared memory regions. Differentiate these by an 'id' field in the base capability. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/40 Signed-off-by: Dr. David Alan Gilbert <dg- ilbert@redhat.com=""> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 4.1.4.</mst@redhat.com></co-></dg->
8100dcfcd622	25 Jul 2019	Dr. David Alan Gilbert	pci: Define virtio_pci_cap64 Define 'virtio_pci_cap64' to allow capabilities to describe memory regions larger than, or with an offset larger than 4GiB. This will be used by the shared memory region capability. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/40 Signed-off-by: Dr. David Alan Gilbert <dg-ilbert@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 4.1.4.</mst@redhat.com></co-huck@redhat.com></dg-ilbert@redhat.com>
855ad7af2bd6	25 Jul 2019	Dr. David Alan Gilbert	shared memory: Define PCI capability Define the PCI capability used for enumerating shared memory regions. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/40 Signed-off-by: Dr. David Alan Gilbert <dgilbert@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> See 4.1.4.7.</co-huck@redhat.com></mst@redhat.com></dgilbert@redhat.com>

Revision	Date	Editor	Changes Made
2dd2d468f69b	25 Jul 2019	Dr. David Alan Gilbert	shared memory: Define mmio registers Define an MMIO interface to discover and map shared memory regions. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/40 Signed-off-by: Dr. David Alan Gilbert <dg- ilbert@redhat.com=""> Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 4.2.2.</mst@redhat.com></co-></ste-></dg->
4237d22cd5b1	08 Sep 2019	Nikos Dragazis	content: fix typo Signed-off-by: Nikos Dragazis <ndragazis@arrikto.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> See 4.1.4.</co-></mst@redhat.com></ndragazis@arrikto.com>
1571d741f300	08 Sep 2019	Dr. David Alan Gilbert	shared memory: Typo fix Fix double hex in SHM*High defs. Signed-off-by: Dr. David Alan Gilbert <dg- ilbert@redhat.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> See 4.2.2.</ste-></co-></mst@redhat.com></dg->
7a25d74962d3	08 Sep 2019	Tiwei Bie	content: fix typo in feature bit name Signed-off-by: Tiwei Bie <ti- wei.bie@intel.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/46 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> See 5.1.6.5.3.</ste-></mst@redhat.com></ti->

Revision	Date	Editor	Changes Made
6aecd69eb90b	08 Sep 2019	Tiwei Bie	content: explicitly document the VLAN filtering as best-effort Similar to the MAC address based filtering, the VLAN filtering is also best-effort in implementations, but it's not quite clear in the spec. So document this behaviour explicitly to reflect the way implementations behave.  Signed-off-by: Tiwei Bie <tiwei.bie@intel.com> Acked-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/virtio-spec/issues/47 See 5.1.6.5.3.</mst@redhat.com></co-huck@redhat.com></mst@redhat.com></tiwei.bie@intel.com>
29540779e4fd	25 Sep 2019	Stefan Hajnoczi	content: add virtio file system device The virtio file system device transports Linux FUSE requests between a FUSE daemon running on the host and the FUSE driver inside the guest. The actual FUSE request definitions are not duplicated in the virtio specification, similar to how virtio-scsi does not doc- ument SCSI command details. FUSE request definitions are available here: https://git.kernel.org/pub/scm/linux/kernel/ git/torvalds/linux.git/tree/include/uapi/linux/ fuse.h This patch documents the core virtio file system device, which is functional but lacks the DAX feature introduced in the next patch. Signed-off-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/49 See 5.11.</mst@redhat.com></co-></ste->

Revision	Date	Editor	Changes Made
ef5a7f405b95	25 Sep 2019	Stefan Hajnoczi	virtio-fs: add DAX window Describe how shared memory region ID 0 is the DAX window and how FUSE_SE- TUPMAPPING maps file ranges into the window. Signed-off-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/49 See 5.11.6.4, and 5.11.6.5.</co-></mst@redhat.com></ste->
1e30753d53d2	12 Oct 2019	Jan Kiszka	Fix ^= in example code Trying to escaping ^ here only leaves the backslash in the output. Signed-off-by: Jan Kiszka <jan.kiszka@siemens.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 2.8.21.3, and 2.8.22.</mst@redhat.com></jan.kiszka@siemens.com>
f9bed5bcb25e	12 Oct 2019	Jan Kiszka	Lift "Driver Notifications" to section level Currently, it slips under the Packed Virtqueues section while it is not specific to this format. At this chance, capitalize "Notifications". Signed-off-by: Jan Kiszka <jan.kiszka@siemens.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 2.9.</mst@redhat.com></jan.kiszka@siemens.com>
8f2c4e03eae8	27 Oct 2019	Eugenio Pérez	block: Add multiqueue The spec miss that field. Add the field, some description around. I've followed the network device's multiqueue mentions, and copied / adapted when needed. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/50 Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Eugenio Pérez <eperezma@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.2, 5.2.2, 5.2.3, 5.2.4, 5.2.5, and 5.2.6.</mst@redhat.com></eperezma@redhat.com></stefanha@redhat.com>
f1f2f85c1482	27 Oct 2019	Jan Kiszka	Console Device: Add a missing word Signed-off-by: Jan Kiszka <jan.kiszka@siemens.com> See 5.3.6.</jan.kiszka@siemens.com>

Revision	Date	Editor	Changes Made
da17c7fc4e12	27 Oct 2019	Paolo Bonzini	virtio_pci_common_cfg: fix field name The field is named config_msix_vector in the rest of the document, use the same name in the struct. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/41 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> See 4.1.4.3.</ste-></mst@redhat.com>
f459b9e0ea60	27 Oct 2019	Eugenio Pérez	virtio-blk: typo: Capitalization in Device Initialization item Signed-off-by: Eugenio Pérez <eperezma@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/51 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> See 5.2.5.</ste-></mst@redhat.com></eperezma@redhat.com>
30d8e1ad22f7	27 Oct 2019	Philipp Hahn	Balloon: Fix Memory Statistics structure size 5.5.6.3 Memory Statistics: 6 -> 10 byte > Within the buffer, statistics are an array of 6-byte entries. ^ > Each statistic consists of a 16 bit tag and a 64 bit value > struct virtio_balloon_stat > le16 tag; > le64 val; > }attribute((packed)); If my calculation is right that is a (16 + 64) = 80 bits which is a 10-byte sized entry - not 6-byte. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/45 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.5.6.3.</mst@redhat.com>
acfe7bd5bcbe	27 Oct 2019	Michael S. Tsirkin	README.md: document the minor cleanups standing rule Signed-off-by: Michael S. Tsirkin <mst@redhat.com></mst@redhat.com>

Revision	Date	Editor	Changes Made
a610121f250b	24 Nov 2019	Jan Kiszka	virtio-mmio: Rename remaining QueueAvail/Used references These have been changed in ae98c6bc21bc. Convert the rest. Signed-off-by: Jan Kiszka <jan.kiszka@siemens.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/52 See 4.2.2.</ste-></mst@redhat.com></jan.kiszka@siemens.com>
4be5d38ad692	24 Nov 2019	Stefan Fritsch	Fix typo It's balloon, not ballon. Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Stefan Fritsch <sf@sfritsch.de> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.5.2.</mst@redhat.com></sf@sfritsch.de></stefanha@redhat.com>
3109be870170	24 Nov 2019	Paolo Bonzini	Reserve id for virtio-audio device Project ACRN has a virtio-audio device. Unfortunately, the id they are using is already reserved in the virtio specification, but it is nevertheless useful to have one. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/42 Signed-off-by: Paolo Bonzini <pborphic <pborphic="" <pre="" bonzini="" paolo="">Paolo Bonzini <pre>Paolo Bonzini <pre>Paolo</pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pborphic>
4f1981a1ff46	24 Nov 2019	Vitaly Mireyno	virtio-net: Add support for correct hdr_len field. Includes device implementation note for using hdr_len Signed-off-by: Vitaly Mireyno <vmireyno@marvell.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/57 See 5.1.3, and 5.1.6.2.</mst@redhat.com></vmireyno@marvell.com>

Revision	Date	Editor	Changes Made
2c77526beb13	24 Nov 2019	Cornelia Huck	virtio-net: add missing articles for new hdr_len feature And tweak a sentence slightly. Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> See 5.1.6.2.</stefanha@redhat.com></co-huck@redhat.com></stefanha@redhat.com>
8c6acac22a99	27 Nov 2019	Huang Yang	Add virtio rpmb device specification Add virtio RPMB (Replay Protected Memory Block) device documentation to spec. Signed-off-by: Yang Huang <yang.huang@intel.com> Reviewed-by: Bing Zhu <bing.zhu@intel.com> Reviewed-by: Tomas Winkler <tomas.winkler@intel.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/53 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.12.</mst@redhat.com></tomas.winkler@intel.com></bing.zhu@intel.com></yang.huang@intel.com>
e8ba780bd7ab	27 Nov 2019	Huang Yang	Reserve device id 28 for virtio RPMB device Signed-off-by: Huang Yang <yang.huang@intel.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/58 See 5.</stefanha@redhat.com></mst@redhat.com></yang.huang@intel.com>
356aeeb40d7a	20 Jan 2020	Michael S. Tsirkin	content: add vendor specific cfg type Vendors might want to add their own ca- pability in the PCI capability list. However, Virtio already uses the vendor specific ca- pability ID (0x09) for its own purposes. Provide a structure for vendor specific ex- tensions. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/62 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 4.1.4, and 4.1.4.8.</mst@redhat.com>

Revision	Date	Editor	Changes Made
50049af040d4	20 Jan 2020	Michael S. Tsirkin	virtio_pci_cap64: bar/BAR cleanups When we mean PCI register we should say BAR. When we mean a virtio config register we should say \field{cap.bar}. Finally, offset_hi/length_hi are not within the cap structure. Tweak wording slightly: "A,B,C" are fields, there's no need to say that. Reported-by: Christophe de Dinechin <cdupontd@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> See 4.1.4, and 4.1.4.7.</co-></mst@redhat.com></cdupontd@redhat.com>
b6e992c7af88	20 Jan 2020	Yuri Benditovich	virtio-net: define support for receive-side scaling Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/48 Added support for RSS receive steering mode. Signed-off-by: Yuri Benditovich <yuri.benditovich@daynix.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.2, 5.1.3, 5.1.3.1, 5.1.4, and 5.1.6.5.</mst@redhat.com></yuri.benditovich@daynix.com>
8361dd6eb0f4	20 Jan 2020	Michael S. Tsirkin	virtio-net: receive-side scaling Typo/grammar fixes as suggested by Cornelia (and a couple noticed by myself). Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.4, and 5.1.6.5.</mst@redhat.com>
1efcda892193	20 Jan 2020	Michael S. Tsirkin	virtio-net: missing "." for feature descriptions At end of each sentence, for consistency. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.3.</mst@redhat.com>
652237ea2839	20 Jan 2020	Jean-Philippe Brucker	Add virtio-iommu device specification The IOMMU device allows a guest to manage DMA mappings for physical, emulated and paravirtualized endpoints. Add device description for the virtio-iommu device and driver. Introduce PROBE, ATTACH, DETACH, MAP and UNMAP requests, as well as translation error reporting.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/37 Signed-off-by: Jean-Philippe Brucker <jean-philippe.brucker@arm.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.13.</mst@redhat.com></jean-philippe.brucker@arm.com>

Revision	Date	Editor	Changes Made
6914d2df75ec	28 Jan 2020	Keiichi Watanabe	content: Reserve device ID for video encoder and decoder device Reserve device ID 30 for video encoder device and 31 for video decoder device. Signed-off-by: Keiichi Watanabe <kei-ichiw@chromium.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Acked-by: Gerd Hoffmann <kraxel@redhat.com> See 5.</kraxel@redhat.com></mst@redhat.com></kei-ichiw@chromium.org>
d7e91b5469fb	28 Jan 2020	Michael S. Tsirkin	virtio-rng: fix device/driver confusion The point of rng is to give data to driver so of course all buffers are driver readable. What shouldn't be there is device readable buffers - this matches our terminology else- where too (read/write-ability is from POV of device). Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/55 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Pankaj Gupta <pagupta@redhat.com> See 5.4.6.</pagupta@redhat.com></mst@redhat.com>
da60923ce164	28 Jan 2020	Michael S. Tsirkin	content: document speed, duplex Document as used by Linux. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/59 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Cornelia Huck <co- huck@redhat.com=""> See 5.1.3, and 5.1.4.</co-></mst@redhat.com>
61124330bf1c	27 Feb 2020	Gerd Hoffmann	virtio-gpu: add 3d command overview Add 3d commands to the command enumeration. Add a section with a very short overview. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/65 Signed-off-by: Gerd Hoffmann <kraxel@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.7.6.7, and 5.7.6.8.</mst@redhat.com></kraxel@redhat.com>

Revision	Date	Editor	Changes Made
0c0dd715152c	27 Feb 2020	Gerd Hoffmann	virtio-gpu: some edid clarifications Add some notes about fetching the EDID information. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/64 Signed-off-by: Gerd Hoffmann <kraxel@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.7.4, and 5.7.5.</mst@redhat.com></kraxel@redhat.com>
f42cc75d0725	01 Mar 2020	Michael S. Tsirkin	virtio-net/rss: maximal -> maximum Maximal can mean "local as opposed to a global maximum". Rest of the spec says maximum everywhere. Let's be consistent. Cc: Yuri Benditovich <yuri.benditovich@daynix.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.4.</mst@redhat.com></yuri.benditovich@daynix.com>
089bc5911dea	04 May 2020	Jean-Philippe Brucker	virtio-iommu: Remove invalid requirement about padding This reference to 'padding' is a leftover from a previous draft of the virtio-iommu device. The field doesn't exist anymore, remove the requirement. Signed-off-by: Jean-Philippe Brucker <jean-philippe@linaro.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.13.4.</mst@redhat.com></jean-philippe@linaro.org>
e73c8cdf3e82	01 Sep 2020	Anton Yakovlev	virtio-snd: add virtio sound device specification  This patch proposes virtio specification for a new virtio sound device, that may be useful in case when having audio is required but a device passthrough or emulation is not an option.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/54 Signed-off-by: Anton Yakovlev <anton.yakovlev@opensynergy.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.4.</mst@redhat.com></anton.yakovlev@opensynergy.com>

Revision	Date	Editor	Changes Made
3f27648d9c66	01 Sep 2020	Jan Kiszka	split-ring: Demand that a device must not change descriptor entries So far the spec only indirectly says that a descriptor table entry is not modified by a device when processing it. Make this explicit by adding it as normative requirement. Existing drivers already depend on this. See also https://lists.oasis-open.org/archives/virtio-dev/201910/msg00057.html. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/56 Signed-off-by: Jan Kiszka <jan.kiszka@siemens.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 2.7.5.</mst@redhat.com></jan.kiszka@siemens.com>
3353ed1c255a	01 Sep 2020	Yuri Benditovich	virtio-net: Define per-packet hash reporting feature Define respective feature bit for virtio-net. Extend packet layout to populate hash value and type. Move the definition of IP/TCP/UDP header fields to calculate the hash out of RSS section to common network device section. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/66 Signed-off-by: Yuri Benditovich <yuri.benditovich@daynix.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.1.3, 5.1.4, 5.1.6, 5.1.6.4, and 5.1.6.5.</mst@redhat.com></yuri.benditovich@daynix.com>

Revision	Date	Editor	Changes Made
51cad55ea64d	01 Sep 2020	Johannes Berg	reserve device ID for hwsim wireless simulation The Linux mac80211-hwsim module currently allows simulation of multiple wireless radios on a shared medium, and has an existing API for this to work through a userspace implementation of the medium simulation (e.g. implemented by wmediumd).  In order to simplify working with virtual machines and to enable (time-compressed) simulation use cases, allocate a virtio device ID to allow carrying this protocol over virtio in addition to the current netlink sockets.  Since device ID 28 was previously requested, use 29.  Signed-off-by: Johannes Berg <johannes.berg@intel.com>  Signed-off-by: Michael S. Tsirkin <mst@redhat.com>  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/68  See 5.</mst@redhat.com></johannes.berg@intel.com>
832099d5df8c	01 Sep 2020	Vitaly Mireyno	virtio-net: Fix VIRTIO_NET_F_GUEST HDRLEN feature definition. Fix driver and device requirements with regards to the VIRTIO_NET_F_GUEST HDRLEN feature - 'hdr_len' must be accurate only for TSO/UFO packets. Signed-off-by: Vitaly Mireyno <vmireyno@marvell.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/virtio-spec/issues/72 See 5.1.6.2.</mst@redhat.com></vmireyno@marvell.com>
5d9444d699e5	01 Sep 2020	Peter Hilber	Reserve device ID 32 for SCMI device Signed-off-by: Peter Hilber <pe- ter.hilber@opensynergy.com=""> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/74 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> See 5.</ste-></mst@redhat.com></pe->

Revision	Date	Editor	Changes Made
68f66ff7a3d9	01 Sep 2020	David Stevens	content: define what an exported object is Define a mechanism for sharing objects be- tween different virtio devices. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/76 Signed-off-by: David Stevens <stevensd@chromium.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 2.11.</mst@redhat.com></stevensd@chromium.org>
162578b7e26c	01 Sep 2020	David Stevens	virtio-gpu: add the ability to export resources Fixes: https://github.com/oasis-tcs/virtio-spec/issues/76 Signed-off-by: David Stevens <stevensd@chromium.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.7.3, 5.7.6.7, and 5.7.6.8.</mst@redhat.com></stevensd@chromium.org>

Revision	Date	Editor	Changes Made
12d74846a6ee	01 Sep 2020	Petre Eftime	content: Reserve virtio-nsm device ID The NitroSecureModule is a device with a very stripped down Trusted Platform Module functionality, which is used in the context of a Nitro Enclave (see https://lkml.org/lkml/2020/4/21/1020) to provide boot time measurement and attestation.  Since this device provides some critical cryptographic operations, there are a series of operations which are required to have guarantees of atomicity, ordering and consistency: operations fully succeed or fully fail, including when some external events might interfere in the process: live migration, crashes, etc; any failure in the critical section requires termination of the enclave it is attached to, so the device needs to be as resilient as possible, simplicity is strongly desired.  To account for that, the device and driver are made to have very few error cases in the critical path and the operations themselves can be rolled back and retried if events happen outside the critical area, while processing a request. The driver itself can be made very simple and thus is easily portable.  Since the requests can be handled directly in the virtio queue, serving most requests requires no additional buffering or memory allocations on the host side.  Signed-off-by: Petre Eftime <epetre@amazon.com> Signed-off-by: Petre Eftime <epetre@amazon.com> Signed-off-by: Stefan Hajnoczi <stefanha@redhat.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Fixes: https://github.com/oasis-tcs/virtio-spec/issues/81 See 5.</stefanha@redhat.com></stefanha@redhat.com></epetre@amazon.com></epetre@amazon.com>
7a46ee550d70	01 Sep 2020	David Hildenbrand	conformance: make driver conformance list easier to read and maintain Let's define it just like the device conformance list. Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: David Hildenbrand <david@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 7.1.</mst@redhat.com></david@redhat.com></co-huck@redhat.com>

Revision	Date	Editor	Changes Made
9abf00ff4654	01 Sep 2020	David Hildenbrand	conformance: Reference RPMB Driver Conformance We forgot to reference the driver conformance. Reviewed-by: Cornelia Huck <cohuck@redhat.com> Cc: Yang Huang <yang.huang@intel.com> Signed-off-by: David Hildenbrand <david@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Alex Bennée <alex.bennee@linaro.org> See 7.1.</alex.bennee@linaro.org></mst@redhat.com></david@redhat.com></yang.huang@intel.com></cohuck@redhat.com>
af6b93bfd9a0	01 Sep 2020	David Hildenbrand	Add virtio-mem device specification The virtio memory device provides and manages a memory region in guest physical address space. This memory region is partitioned into memory blocks of fixed size that can either be in the state plugged or unplugged.  Specify the device configuration, initialization, and operation. Introduce PLUG, UN-PLUG, UNPLUG ALL and STATE requests. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/82 Cc: teawater <teawaterz@linux.alibaba.com> Signed-off-by: David Hildenbrand <david@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.15.</mst@redhat.com></david@redhat.com></teawaterz@linux.alibaba.com>
28ea45d8d79f	11 Nov 2020	Jie Deng	content: Reserve device ID 34 for I2C adapter Request the ID 34 for I2C adapter. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/85 Signed-off-by: Jie Deng <jie.deng@intel.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.</co-huck@redhat.com></jie.deng@intel.com>

Revision	Date	Editor	Changes Made
d44895cdadc0	11 Nov 2020	Rob Bradford	content: Reserve virtio-watchog device ID Reserve an ID for a watchdog device which may be used to ensure that the guest is re- sponsive. This is equivalent of a hardware watchdog device and will trigger the reboot of the guest if the the host does not periodic ping from the the guest. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/87 Signed-off-by: Rob Bradford <robert.bradford@intel.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></robert.bradford@intel.com>
38448268eba0	11 Nov 2020	Alexander Duyck	content: Document balloon feature free page hints Free page hints allow the balloon driver to provide information on what pages are not currently in use so that we can avoid the cost of copying them in migration scenarios. Add a feature description for free page hints describing basic functioning and requirements.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/84 Acked-by: Cornelia Huck <co-huck@redhat.com> Reviewed-by: David Hildenbrand <david@redhat.com> Signed-off-by: Alexander Duyck <alexander.h.duyck@linux.intel.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.5.2, 5.5.3, 5.5.4, 5.5.5, and 5.5.6.5.</co-huck@redhat.com></co-huck@redhat.com></alexander.h.duyck@linux.intel.com></david@redhat.com></co-huck@redhat.com>

Revision	Date	Editor	Changes Made
4749f03e72f8	11 Nov 2020	Alexander Duyck	content: Document balloon feature page poison Page poison provides a way for the guest to notify the host that it is initializing or poisoning freed pages with some specific poison value. As a result of this we can infer a couple traits about the guest:  1. Free pages will contain a specific pattern within the guest. 2. Modifying free pages from this value may cause an error in the guest. 3. Pages will be immediately written to by the driver when deflated.  There are currently no existing features that make use of this data. In the upcoming feature free page reporting we will need to make use of this to identify if we can evict pages from the guest without causing data corruption.  Add documentation for the page poison feature describing the basic functionality and requirements.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/84  Reviewed-by: Cornelia Huck <co-huck@redhat.com> Reviewed-by: David Hildenbrand <david@redhat.com> Signed-off-by: Alexander Duyck <alexander.h.duyck@linux.intel.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: So.5.5, and 5.5.6.6.</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></alexander.h.duyck@linux.intel.com></david@redhat.com></co-huck@redhat.com>
d917d4a8d552	11 Nov 2020	Alexander Duyck	content: Document balloon feature free page reporting Free page reporting is a feature that allows the guest to proactively report unused pages to the host. By making use of this feature is is possible to reduce the overall memory footprint of the guest in cases where some significant portion of the memory is idle. Add documentation for the free page reporting feature describing the functionality and requirements.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/84 Reviewed-by: Cornelia Huck <co-huck@redhat.com> Reviewed-by: David Hildenbrand <david@redhat.com> Signed-off-by: Alexander Duyck <alexander.h.duyck@linux.intel.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.5.2, 5.5.3, 5.5.5, 5.5.6.6, and 5.5.6.7.</co-huck@redhat.com></co-huck@redhat.com></alexander.h.duyck@linux.intel.com></david@redhat.com></co-huck@redhat.com>

Revision	Date	Editor	Changes Made
9164d35e4b2a	13 Nov 2020	Alexander Duyck	content: Minor change to clarify free_page_hint_cmd_id The original wording was a bit unclear and could have been misinterpreted as indicating that VIRTIO_BALLOON_FREE_PAGE_HINT was read-only instead of the field free_page_hint_cmd_id. To clarify that break it up into two sentences making it clear that the field is only available if the feature is negotiated, and that the field is read-only.  Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Alexander Duyck <alexander.h.duyck@linux.intel.com> Acked-by: Michael S. Tsirkin <mst@redhat.com> [CH: included under the minor cleanup rule] Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.5.4.</co-huck@redhat.com></mst@redhat.com></alexander.h.duyck@linux.intel.com></co-huck@redhat.com>
b342d29aaf9f	19 Nov 2020	Stefan Hajnoczi	virtio-blk: document VIRTIO_BLK_TGET_ID The VIRTIO_BLK_T_GET_ID request type was implemented in Linux and QEMU in 2010. It does not have a feature bit but devices respond with VIRTIO_BLK_S_UN-SUPP if a request type is unimplemented. This patch documents the VIRTIO_BLKT_GET_ID request type as currently implemented in Linux and QEMU.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/63 Suggested-by: Jan Kiszka <jan.kiszka@siemens.com> Signed-off-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.2.6.</co-huck@redhat.com></stefanha@redhat.com></jan.kiszka@siemens.com>

Revision	Date	Editor	Changes Made
89e7eb5b9a76	19 Nov 2020	Gurchetan Singh	virtio-gpu: add resource create blob Blob resources are size-based containers for host, guest, or host+guest allocations. These resources are designed with mulit- process 3D support in mind, but also us- able in virtio-gpu 2d with guest memory. Many hypercalls are reused, since a image view into the blob resource is possible. Blob resources are both forward and back- ward looking. v2: Add TRANSFER_BLOB, SET SCANOUT_BLOB, SCANOUT_FLUSH v3: Remove SCANOUT_FLUSH and add notes v4: Remove TRANSFER_BLOB for now. v5: clarify interactions with ATTACH_BACKING / DETACH_BACK- ING. This is to preserve the possibility of guest swap-in and guest swap-out, while acknowledging this feature may never be implemented and may not be applicable for all future planned values of 'blob_mem' or context types. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/86 Signed-off-by: Gurchetan Singh <gurchetansingh@chromium.org> Acked-by: Chia-I Wu <olvented> <li>clarify</li> <li>context</li> <li>conte</li></olvented></gurchetansingh@chromium.org>
87fa6b5d8155	19 Nov 2020	Gurchetan Singh	virtio-gpu: add support for mapping/unmapping blob resources This defines a virtgpu shared memory region, with the possibilty of more in the future. This is required to implement VK/GL coherent memory semantics, among other things.  v6: disallow mapping an already mapped blob resource as a simplification Fixes: https://github.com/oasis-tcs/virtio-spec/issues/86 Signed-off-by: Gurchetan Singh <gurchetansingh@chromium.org> Acked-by: Gerd Hoffmann <kraxel@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.7.4, and 5.7.6.</co-huck@redhat.com></kraxel@redhat.com></gurchetansingh@chromium.org>

Revision	Date	Editor	Changes Made
2ff0d5c68af2	03 Dec 2020	Vitaly Mireyno	virtio-net: Add support for the flexible driver notification structure.  When the driver is required to send an available buffer notification to the device, it sends the virtqueue number to be notified. With this new feature, the device can optionally provide a per-virtqueue value for the driver to use in driver notifications, instead of the virtqueue number.  Some devices may benefit from this flexibility by providing, for example, an internal virtqueue identifier, or an internal offset related to the virtqueue number.  Changes from v8: * Incorporated comments for v8: - moved the feature from a network device to a global section - few minor changes  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/89  Signed-off-by: Vitaly Mireyno <vmireyno@marvell.com> [CH: wrapped overlong lines in commit message]  Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 4.1.4.3, 4.1.5.2, and 6.</co-huck@redhat.com></vmireyno@marvell.com>
bccdda7fb41a	15 Dec 2020	Michael S. Tsirkin	typo: VIRTIO_NET_F_MAC_ADDR -> VIRTIO_NET_F_MAC VIRTIO_NET_F_MAC_ADDR isn't defined. It's clear from context that what is meant is VIRTIO_NET_F_MAC which controls whether mac in config space is valid.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/90 Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.1.6.5.2.</co-huck@redhat.com></co-huck@redhat.com></mst@redhat.com></co-huck@redhat.com>

Revision	Date	Editor	Changes Made
87de7136382e	15 Dec 2020	David Hildenbrand	virtio-mem: minor clarification regarding read-access to unplugged blocks Let's clarify that we don't expect all DMA to work with unplugged blocks. We really only give guarantees when reading from unplugged memory blocks via the CPU, e.g., as done by Linux when creating a system dump via kdump: the new kernel will copy the content of the old (crashed) kernel via the CPU to user space, from where it will find its final destination inside the dump file. Note that dumping via makedumpfile under Linux will avoid reading unplugged blocks completely.  This is a preparation for device passthrough to VMs, whereby such dedicated devices might not be able to read from unplugged memory blocks.  Let's document that this scenario is possible, and why this handling is in place at all. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/91  Cc: teawater <teawaterz@linux.alibaba.com> Cc: Marek Kedzierski <mkedzier@redhat.com> Cc: Michael S. Tsirkin <mst@redhat.com> Cc: Gronelia Huck <cohuck@redhat.com> Cc: Cornelia Huck <cohuck@redhat.com> Signed-off-by: David Hildenbrand <david@redhat.com> Signed-off-by: Cornelia Huck <cohuck@redhat.com> See 5.15.6.</cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></cohuck@redhat.com></david@redhat.com></cohuck@redhat.com></cohuck@redhat.com></mst@redhat.com></mkedzier@redhat.com></teawaterz@linux.alibaba.com>
f725281ebba7	25 Jan 2021	Jie Deng	virtio-i2c: add the device specification virtio-i2c is a virtual I2C adapter device. It provides a way to flexibly communicate with the host I2C slave devices from the guest. This patch adds the specification for this device. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/88 Signed-off-by: Jie Deng <jie.deng@intel.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.15.6.</co-></jie.deng@intel.com>

Revision	Date	Editor	Changes Made
6ee5e4b54c8e	26 Jan 2021	Felipe Franciosi	content: Fix driver/device wording on ISR bits Section "ISR status capability" incorrectly worded that the bits part of the register allows the device to distinguish between interrupt types. It is the driver that needs access to that distinction, not the device. Signed-off-by: Felipe Franciosi <felipe@nutanix.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 4.1.4.5.</co-huck@redhat.com></stefanha@redhat.com></felipe@nutanix.com>
a17c29e2201b	26 Jan 2021	Alex Bennée	virtio-gpu.tex: fix some UTF-8 damage While building I got a warning about: ! Package utf8x Error: MalformedUTF-8sequence. Fixes: 87fa6b5 ("virtio-gpu: add support for mapping/unmapping blob resources") Signed-off-by: Alex Bennée <alex.bennee@linaro.org> Reviewed-by: Stefan Hajnoczi <ste-fanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.7.6.9.</co-huck@redhat.com></ste-fanha@redhat.com></alex.bennee@linaro.org>
a306bf467850	09 Feb 2021	Cornelia Huck	clarify device reset Properly specify that the method for the driver to request a device reset is transport specific, and some action the device has to take. Reviewed-by: Jason Wang <ja- sowang@redhat.com=""> Reviewed-by: Halil Pasic <pa- sic@linux.ibm.com=""> Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/93 Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 2.1, and 2.4.</co-></pa-></ja->

Revision	Date	Editor	Changes Made
f5fd3fca7e40	10 Feb 2021	Peter Hilber	content: reserve device ID 36 for CAN device The CAN device sends and receives CAN (Controller Area Network) messages. CAN is a communication protocol used in embedded systems. Signed-off-by: Peter Hilber <peter.hilber@opensynergy.com> Reviewed-by: Matti Möll <matti.moell@opensynergy.com> Fixes: https://github.com/oasis-tcs/virtio-spec/issues/95 Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.</co-huck@redhat.com></matti.moell@opensynergy.com></peter.hilber@opensynergy.com>
30e6526f4d8e	25 Feb 2021	Cornelia Huck	virtio-ccw: relax device requirement for revision-specific command rejection The device is currently required to reject any command that is not contained in the negotiated revision. Some implementations did not actively check for the revision when processing a command; retroactively changing these implementations can break existing drivers.  Relaxing the rejection requirement to SHOULD makes these existing device implementations compliant, and will not have any effect on drivers that did not send any commands for wrong revisions.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/96 Reviewed-by: Halil Pasic <par> Reviewed-by: Cornelia Huck <co-huck@redhat.com> See 4.3.2.1.</co-huck@redhat.com></par>

Revision	Date	Editor	Changes Made
5e9a37b9a559	30 Mar 2021	Enrico Granata	Add lifetime metrics to virtio-blk In many embedded systems, virtio-blk implementations are backed by eMMC or UFS storage devices, which are subject to predictable and measurable wear over time due to repeated write cycles. For such systems, it can be important to be able to track accurately the amount of wear imposed on the storage over time and surface it to applications. In a native deployments this is generally handled by the physical block device driver but no such provision is made in virtio-blk to expose these metrics for devices where it makes sense to do so.  This patch adds support to virtio-blk for lifetime and wear metrics to be exposed to the guest when a deployment of virtio-blk is done over compatible eMMC or UFS storage.  Signed-off-by: Enrico Granata <egranata@google.com> Fixes: https://github.org/oasis-tcs/virtio-spec/issues/97 Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.2.3, and 5.2.6.</co-huck@redhat.com></egranata@google.com>
80b54cfd10a3	30 Mar 2021	Peter Hilber	Add virtio SCMI device specification This patch proposes a new virtio device for the Arm SCMI protocol. The device provides a simple transport for the Arm SCMI protocol[1]. The *S*ystem *C*ontrol and *M*anagement *I*nterface protocol allows speaking to system con- trollers that allow orchestrating things like power management, system state man- agement and sensor access. The SCMI protocol is used on SoCs where multiple cores and co-processors need access to these resources. The virtio transport allows making use of this protocol in virtualized systems. [1] https://developer.arm.com/docs/ den0056/c Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/100 Signed-off-by: Peter Hilber <pe- ter.hilber@opensynergy.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.2.6.</co-></pe->

Revision	Date	Editor	Changes Made
f144e1847b95	06 Apr 2021	Cornelia Huck	title: list myself as Chair Reflect my position in the document as well. Signed-off-by: Cornelia Huck <co-huck@redhat.com> See .</co-huck@redhat.com>
2d827b06874d	14 Apr 2021	Michael S. Tsirkin	introduction: document #define syntax We use the C #define syntax to refer to numeric values. Let's document that. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/101 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 1.5.</co-huck@redhat.com></mst@redhat.com>
b19f28ed5076	14 Apr 2021	Hao Chen	Reserve device id for parameter server Use device ID 38 Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/102 Signed-off-by: Hao Chen <chenhaosjtu- acm@google.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></chenhaosjtu->
22179bb0875c	14 Apr 2021	Hao Chen	Reserve device id for audio policy device Use device ID 39 Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/103 Signed-off-by: Hao Chen <chenhaosjtu- acm@google.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></chenhaosjtu->
0711d7f18fa7	14 Apr 2021	Cornelia Huck	editorial: fix missing escape of '#' Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 1.5.</co-huck@redhat.com>
3590a075a5fd	03 May 2021	Marcel Holtmann	Reserve device id for Bluetooth device Use device ID 40 Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/108 Signed-off-by: Marcel Holtmann <mar- cel@holtmann.org=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></mar->

Revision	Date	Editor	Changes Made
5749014a3d50	17 May 2021	Yuri Benditovich	virtio-net: fix mistake: segmentation -> fragmentation The VIRTIO_NET_F_HOST_UFO feature fragments the packet. Only first fragment has a UDP header. Signed-off-by: Yuri Benditovich <yuri.benditovich@daynix.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.1.6.2.</co-huck@redhat.com></yuri.benditovich@daynix.com>
d1471fdf932b	17 May 2021	Yuri Benditovich	virtio-net: define USO feature Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/104 Unlike UFO (fragmenting the packet) the USO splits large UDP packet to several segments when each of these smaller packets has UDP header. In Linux see SKB_GSO_UDP_L4. Signed-off-by: Yuri Benditovich <yuri.benditovich@daynix.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.1.3, 5.1.5, and 5.1.6.</co-></yuri.benditovich@daynix.com>
c6f7149d08a1	10 Jun 2021	Joel Nider	Make global flag names consistent The global flags VIRTIO_F_EVENT_IDX and VIRTIO_F_INDIRECT_DESC have in- consistent naming throughout the docu- ment. This change removes the _RING designation from the flag names to make the usage consistent. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/36 Signed-off-by: Joel Nider <joel@nider.org> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 6, 2.8.10, and 2.8.21.3.</co-></joel@nider.org>
a57fb86cdb03	10 Jun 2021	Jiang Wang	virtio-net: fix a display for num_buffers One of num_buffers does not display correctly in the html. The _b becomes a subscript b. This will prevent it from being searched by using keyword num_buffers. Fix it by adding a field keyword. Signed-off-by: Jiang Wang <jiang.wang@bytedance.com> Message-Id: &lt;20210601172139.3725854-1-jiang.wang@bytedance.com&gt; Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.1.6.4.</co-huck@redhat.com></jiang.wang@bytedance.com>

Revision	Date	Editor	Changes Made
eddd5558447d	17 Jun 2021	Viresh Kumar	Reserve device id for GPIO device Use device ID 41 Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/109 Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></viresh.kumar@linaro.org>
63236f177602	08 Jul 2021	Stefan Hajnoczi	virtio-fs: add file system device to Conformance chapter The file system device is not listed in the Conformance chapter. Fix this. Signed-off-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 7.1.</co-huck@redhat.com></stefanha@redhat.com>
3881c6b6fca9	08 Jul 2021	Stefan Hajnoczi	virtio-fs: add notification queue The FUSE protocol allows the file server (device) to initiate communication with the client (driver) using FUSE notify messages. Normally only the client can initiate com- munication. This feature is used to report asynchronous events that are not related to an in-flight request. This patch adds a notification queue that works like an rx queue in other VIRTIO de- vice types. The device can emit FUSE no- tify messages by using a buffer from this queue. This mechanism was designed by Vivek Goyal <vgoyal@redhat.com>. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/111 Signed-off-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.11.2, 5.11.4, 5.11.5, and 5.11.6.</co-></ste-></vgoyal@redhat.com>
eb6ef453af9b	26 Jul 2021	Cornelia Huck	Reserved feature bits: fix missing verb Reviewed-by: David Hildenbrand <david@redhat.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 6.</co-></david@redhat.com>
74822ee60ea9	27 Jul 2021	Gaetan Harter	content: fix a typo Signed-off-by: Gaetan Harter <gaetan.harter@opensynergy.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.1.6.5.</co-huck@redhat.com></stefanha@redhat.com></gaetan.harter@opensynergy.com>

Revision	Date	Editor	Changes Made
23d3f7a3a7c9	27 Jul 2021	Gaetan Harter	virtio-gpu: fix a typo Signed-off-by: Gaetan Harter <gaetan.harter@opensynergy.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.7.2.</co-huck@redhat.com></stefanha@redhat.com></gaetan.harter@opensynergy.com>
247709f69260	29 Jul 2021	Gaetan Harter	virtio-crypto: fix missing conjunction and verb The condition sentences were incomplete: "guarantee THAT the size IS within the max_len". Signed-off-by: Gaetan Harter <gaetan.harter@opensynergy.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.9.5.</co-huck@redhat.com></gaetan.harter@opensynergy.com>
1dc3ff82ab18	10 Aug 2021	Max Gurtovoy	virtio-blk: fix virtqueues accounting Virtqueue index is zero based, thus virtqueue (N-1) refers to requestqN. Signed-off-by: Max Gurtovoy <mgur- tovoy@nvidia.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.2.2.</co-></mgur->
b73b74aaca01	16 Aug 2021	Alex Bennée	virtio-rpmb: fix the description for multiblock reads Previously the text said we fail if block count is set to 1 despite language elsewhere in the text referring to: "For RPMB read request, one virtio buffer including request command and the subsequent [block_count] virtio buffers for response data are placed in the queue." and the existence of both max_wr_cnt and max_rd_cnt configuration variables certainly implying devices should be able to handle multi-block reads just like writes. Fix the description as well as format the steps as an enumerated list to match the style of the previous section describing write handling. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/113 Reported-by: Ruchika Gupta <ruchika.gupta@linaro.org> Signed-off-by: Alex Bennée <alex.bennee@linaro.org> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.12.6.1.</co-huck@redhat.com></alex.bennee@linaro.org></ruchika.gupta@linaro.org>

Revision	Date	Editor	Changes Made
9547f52400c6	18 Aug 2021	Viresh Kumar	virtio-gpio: Add the device specification virtio-gpio is a virtual GPIO controller. It provides a way to flexibly communicate with the host GPIO controllers from the guest.  Note that the current implementation doesn't provide atomic APIs for GPIO configurations. i.e. the driver (guest) would need to implement sleep-able versions of the APIs as the guest will respond asynchronously over the virtqueue.  This patch adds the specification for it.  Based on the initial work posted by: "Enrico Weigelt, metux IT consult" < kml@metux.net>.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/110  Reviewed-by: Arnd Bergmann <arnd@arndb.de> Reviewed-by: Linus Walleij &lt; iinus.walleij@linaro.org&gt; Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.18.</co-huck@redhat.com></viresh.kumar@linaro.org></arnd@arndb.de>
4b65fb2f74fa	17 Sep 2021	Viresh Kumar	virtio-gpio: Specify character encoding for gpio names Specify 7-bit ASCII character encoding for GPIO names strings. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/115 Suggested-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.18.6.1.</co-huck@redhat.com></viresh.kumar@linaro.org></stefanha@redhat.com>
c8338338edaf	17 Sep 2021	Michael S. Tsirkin	virtio-net: fix speed, duplex Speed values have an extra "f" - they are 32 bit, not 36 bit. Duplex is implemented in Linux and QEMU as 0x01 for full duplex and 0x00 for half duplex. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/75 Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.1.4.</co-></mst@redhat.com>

Revision	Date	Editor	Changes Made
a4bb00171010	24 Sep 2021	Gurchetan Singh	virtio-gpu: clarify spec regarding capability sets Capability sets will be used as a proxy for the context type, so add more detail regarding their use.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/117 Reviewed-by: Gerd Hoffmann <kraxel@redhat.com> Signed-off-by: Gurchetan Singh <gurchetansingh@chromium.org> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.7.4, and 5.7.6.8.</co-huck@redhat.com></gurchetansingh@chromium.org></kraxel@redhat.com>
aad2b6f3620e	24 Sep 2021	Gurchetan Singh	virtio-gpu: add context init support This brings explicit context initialization and different types to virtio-gpu. In the past, VIRTIO_GPU_F_VIRGL meant the virglrenderer support. With VIRTIO GPU_F_VIRGL + VIRTIO_GPU_F_CON- TEXT_INIT, this means generic 3D virtu- alization defined by the context type. It's entirely possible the virglrenderer project isn't available on the host in this scenario. The VIRTIO_GPU_F_VIRGL naming con- vention is kept since it's easier to redefine the meaning rather than changing header files. The context type is associated an particular capset id. Virgl has two capsets due a prior bug, but for other cases the 1:1 mapping between context type and capset id is valid. In addition, fencing needs to be fixed to ac- comodate multiple context types. In the past, there was one global timeline asso- ciated with the OpenGL rendering. Now, there are multiple timelines which can be associated with GL, VK or even display contexts. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/117 Reviewed-by: Gerd Hoffmann <kraxel@redhat.com> Signed-off-by: Gurchetan Singh <gurchetansingh@chromium.org> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.7, 5.7.3, 5.7.6.7, 5.7.6.8, and 5.7.6.9.</co-></gurchetansingh@chromium.org></kraxel@redhat.com>

Revision	Date	Editor	Changes Made
e0e8f9ac37c5	04 Oct 2021	Junji Wei	Reserve device id for RDMA device Use device ID 42 Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/116 Signed-off-by: Junji Wei <wei- junji@bytedance.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.</co-></wei->
f5a8d38acbd0	04 Oct 2021	Max Gurtovoy	Fix copy/paste bug in PCI transport paragraph Refer to "Shared memory capability" and not to "Device-specific configuration". Signed-off-by: Max Gurtovoy <mgurtovoy@nvidia.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 4.1.4.7.</co-huck@redhat.com></mgurtovoy@nvidia.com>
bcf4bddb256e	07 Oct 2021	Jean-Philippe Brucker	content: Remove duplicate paragraph It looks like commit 356aeeb40d7a ("content: add vendor specific cfg type") had a merge issue. It includes the device normative paragraph for Shared memory capability, which was already added right above it by commit 855ad7af2bd6 ("shared memory: Define PCI capability").  The two paragraphs differ, and the first paragraph is correct. It refers to struct virtio_pci_cap64 which embeds struct virtio_pci_cap: struct virtio_pci_cap64. struct virtio_pci_cap .  le32 offset; le32 length; } cap; u32 offset_hi; u32 length_hi; .  Merge the two paragraph while keeping the best of both. Drop the spaces after \field to stay consistent with the rest of the document.  Acked-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Jean-Philippe Brucker <jean-philippe@linaro.org> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 4.1.4.7.</co-huck@redhat.com></co-huck@redhat.com></jean-philippe@linaro.org></stefanha@redhat.com></mst@redhat.com>
591eb4c2f76e	07 Oct 2021	Cornelia Huck	PCI: fix level for vendor data capability The normative statements for the vendor data capability need to be at paragraph level insted of subsection level. Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 4.1.4.8.</co->

Revision	Date	Editor	Changes Made
2f4a36d5e36d	14 Oct 2021	Enrico Granata	Provide detailed specification of virtio-blk lifetime metrics In the course of review, some concerns were surfaced about the original virtio-blk lifetime proposal, as it depends on the eMMC spec which is not open Add a more detailed description of the meaning of the fields added by that proposal to the virtio-blk specification, as to make it feasible to understand and implement the new lifetime metrics feature without needing to refer to JEDEC's specification This patch does not change the meaning of those fields nor add any new fields, but it is intended to provide an open and more clear description of the meaning associated with those fields.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/106 Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Enrico Granata <egranata@google.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.2.6.</co-huck@redhat.com></egranata@google.com></stefanha@redhat.com>
fc387ffae917	15 Oct 2021	Pankaj Gupta	virtio-pmem: PMEM device spec Posting virtio specification for virtio pmem device. Virtio pmem is a paravirtualized de- vice which allows the guest to bypass page cache. Virtio pmem kernel driver is merged in Upstream Kernel 5.3. Also, Qemu de- vice is merged in Qemu 4.1. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/78 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Signed-off-by: Pankaj Gupta <pre></pre></ste->

Revision	Date	Editor	Changes Made
b5115a8fc8ed	15 Oct 2021	David Hildenbrand	virtio-mem: simplify statements that express unexpected behavior on memory access Some statements express that the device MAY allow access to memory inside unplugged memory blocks, although it's really just unexpected behavior and conforming drivers MUST NOT perform such access. Clarify that, and move the special CPU vs. DMA handling for some unplugged memory blocks to the driver section instead. While at it, start rephrasing our statements to clarify and prepare for further changes. Signed-off-by: David Hildenbrand <david@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.15.6.</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></david@redhat.com>
708ef827b092	15 Oct 2021	David Hildenbrand	virtio-mem: rephrase remaining memory access statements Let's rephrase the remaining statements regarding memory access to unify and prepare for further changes. Signed-off-by: David Hildenbrand <david@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.15.6.</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></david@redhat.com>
f579906e7364	15 Oct 2021	David Hildenbrand	virtio-mem: document basic memory access to plugged memory blocks Let's cleanly document that the driver just has to allow for access to plugged memory blocks. Signed-off-by: David Hildenbrand <david@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.15.6.</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></david@redhat.com>

Revision	Date	Editor	Changes Made
5b6a9d2a1d43	15 Oct 2021	David Hildenbrand	virtio-mem: introduce VIRTIO_MEM_FUNPLUGGED_INACCESSIBLE Until now, we allowed a driver to read unplugged memory within the usable device-managed region: this simplified bring-up of virtio-mem in Linux quite a bit, especially when it came to physical memory dumping. When the device is using a memory backend that supports a shared zeropage, such as virtio-mem in QEMU under Linux on anonymous memory, the old behavior could be realized easily.  However, when using other memory backends (such as hugetlbfs or shmem) or architectures, such as s390x, where a shared zeropage either does not exist or cannot be used, letting the driver read unplugged memory can result in undesired memory consumption in the hypervisor. The device wants to make sure that the guest is aware and will not read unplugged memory, not even in corner cases.  In the meantime, the Linux implementation matured such that it will no longer access unplugged memory, for example, during kdump, when reading /proc/kcore, or via (now removed) /dev/kmem.  Similar to VIRTIO_F_ACCESS_PLAT-FORM, this change will be disruptive and require driver adaptions — even if it's just accepting the new feature. Devices are expected to only set the bit when really required, to keep existing setups working.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/118  Signed-off-by: David Hildenbrand <david@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cor</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></david@redhat.com>

Revision	Date	Editor	Changes Made
26947c3e7b05	15 Oct 2021	David Hildenbrand	virtio-mem: describe interaction with memory properties Let's describe how we expect the interaction with memory properties that might be available on a specific platform for ordinary system RAM. This is primarily a preparation for s390x support, which provides storage keys and may provide storage attributes, depending on the system configuration. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/118 Signed-off-by: David Hildenbrand <david@redhat.com> Reviewed-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></david@redhat.com>
ca1463daea5d	03 Nov 2021	Viresh Kumar	virtio: i2c: No need to have separate readwrite buffers The virtio I2C protocol allows to contain multiple read-write requests in a single I2C transaction using the VIRTIO_I2CFLAGS_FAIL_NEXT flag, where each request contains a header, buffer and status. There is no need to pass both read and write buffers in a single request, as we have a better way of combining requests into a single I2C transaction. Moreover, this also limits the transactions to two buffers, one for read operation and one for write. By using VIRTIO_I2C_FLAGS_FAIL_NEXT, we don't have any such limits.  Remove support for multiple buffers within a single request.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/112  Reviewed-by: Arnd Bergmann <arnd@arndb.de> Reviewed-by: Jie Deng <jie.deng@intel.com> Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.16.6.1, and 5.16.6.2.</mst@redhat.com></viresh.kumar@linaro.org></jie.deng@intel.com></arnd@arndb.de>

Revision	Date	Editor	Changes Made
69d399bd3f19	03 Nov 2021	Viresh Kumar	virtio: i2c: Allow zero-length transactions The I2C protocol allows zero-length requests with no data, like the SMBus Quick command, where the command is inferred based on the read/write flag itself. In order to allow such a request, allocate another bit, VIRTIO_I2C_FLAGS_MRD(1), in the flags to pass the request type, as read or write. This was earlier done using the read/write permission to the buffer itself.  Add a new feature flag for zero length requests and make it mandatory for it to be implemented, so we don't need to drag the old implementation around.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/112 Reviewed-by: Arnd Bergmann <arnd@arndb.de> Reviewed-by: Jie Deng <jie.deng@intel.com> Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 5.16.3, 5.16.6.1, and 5.16.6.2.</mst@redhat.com></viresh.kumar@linaro.org></jie.deng@intel.com></arnd@arndb.de>
ca3252712d98	03 Nov 2021	Viresh Kumar	virtio-gpio: Add support for interrupts This patch adds support for interrupts to the virtio-gpio specification. This uses the feature bit 0 for the same. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/114 Cc: Marc Zyngier <maz@kernel.org> Cc: Thomas Gleixner <tglx@linutronix.de> Reviewed-by: Linus Walleij <li>nus.walleij@linaro.org&gt; Signed-off-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Reviewed-by: Arnd Bergmann <arnd@arndb.de> See 5.18.2, 5.18.3, 5.18.4, and 5.18.6.</arnd@arndb.de></mst@redhat.com></viresh.kumar@linaro.org></li></tglx@linutronix.de></maz@kernel.org>

Revision	Date	Editor	Changes Made
48340e86b087	29 Nov 2021	Halil Pasic	split-ring: clarify the field len in the used ring The current description is misleading: "the descriptor chain which was used" generally includes both the descriptors that map the device read only, and descriptors that map the device write only portions of the buffer described by the descriptor chain. The argument that "used" means "written to" does not stand because one has to "use" the descriptor chain even when the whole buffer is device read only.  One can argue, that the most straightforward way to interpret the phrase "total length of that descriptor chain" (without context) like the length of the list is usually defined: i.e. like the number of descriptors that constitute the chain. This is clearly not what we want here. Another intuitive way to interpret "total length of that descriptor chain" is size of the buffer mapped by the descriptor chain. This is not what we want either. In fact such wrongful interpretations have caused bugs in the wild.  On the other hand, the text below the listing that gets modified here clearly describes the semantics of \field{len}. So let us replace the ambiguous explanation in the listing, with a hopefully non-ambiguous one. Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Halil Pasic <par> Signed-off-by: Gornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 2.7.8.</co-huck@redhat.com></co-huck@redhat.com></par></stefanha@redhat.com>

Revision	Date	Editor	Changes Made
795391311bb1	30 Nov 2021	Taylor Stark	virtio-pmem: Support describing pmem as shared memory region Update the virtio-pmem spec to add support for describing the pmem region as a shared memory window. This is required to support virtio-pmem in Hyper-V, since Hyper-V only allows PCI devices to operate on memory ranges defined via BARs. When using the virtio PCI transport, shared memory regions are described via PCI BARs.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/121 Reviewed-by: Pankaj Gupta <pankaj.gupta.linux@gmail.com> Signed-off-by: Taylor Stark <tstark@microsoft.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.19.3, 5.19.4, and 5.19.5.</co-huck@redhat.com></tstark@microsoft.com></pankaj.gupta.linux@gmail.com>
ec3997b8a402	30 Nov 2021	Cornelia Huck	pmem: correct wording s/guest absolute/physical/ Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.19.5.</co-huck@redhat.com>
d6645979da9b	07 Dec 2021	Cornelia Huck	ccw: clarify device reset Unlike other transports, a reset triggered by the driver is actually complete once the command has been completed. Make this behaviour and the requirements more ex- plicit. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/123 Reviewed-by: Jason Wang <ja- sowang@redhat.com=""> Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 4.3.3.3.</co-></ste-></ja->

41644c17c971  Jean-Philippe Brucker  The VIRTIO_IOMMU_F_BYPASS feature The VIRTIO_IOMMU_F BYPASS feature is awkward to use and incomplete. Al- though it is implemented by QEMU, it is not supported by any driver as far as I know. Replace it with a new VIRTIO_IOMMU_F BYPASS_CONFIG feature. Two features are missing from virtio- iomius:  The ability for an hypervisor to start the device in bypass mode. The wording for VIRTIO_IOMMU_F_BYPASS is not clear enough to allow it at the moment, because it only specifies the behavior after feature negotiation.  The ability for a guest to set individual endpoints in bypass mode when bypass is globally disabled. An OS should have the ability to allow only endpoints it trusts to by- pass the IOMMU, while keeping DMA dis- abiled for endpoints it isn't even aware of. At the moment this can only be emulated by creating identify mappings. The VIRTIO_IOMMU_F_BYPASS_CON- FIG feature adds a bypass' configled that allows to enable and disable bypass globally. It also adds a new flag for the ATTACH request.  The hypervisor can start the VM with by- pass enabled or, if it knows that the soft- ware stack supports it, disabled. The 'by- pass' config fields is initialized to 0 or. It is sticky and isn't affected by device reset. Generally the firmware won't have a no IOMMU driver and will need to be started in bypass mode, so the bootloader and kernel can be loaded from storage endpoint. For more security, the firmware could implement a minimal virtic-inommu driver that reuses existing virtio support and only touches the config space. It could en- able PCI bus mastering in bridges only for the endpoints that need it, enable global IOMMU bypass by flipping a bit, then tear everything down before handing control over to the OS. This prevents vulnerability windows where a malicious endpoint repro- grams the IOMMU while the OS is config uring it [1].  The isolation provided by vIOMMUs has mainly been used for securely assigning endpoints to untrusted applications so the while kernel DMA bypas	Revision	Date	Editor	Changes Made
pass the IOMMU, while keeping DMA disabled for endpoints it isn't even aware of. At the moment this can only be emulated by creating identity mappings. The VIRTIO_IOMMU_F_BYPASS_CONFIG feature adds a 'bypass' config field that allows to enable and disable bypass globally. It also adds a new flag for the ATTACH request.  * The hypervisor can start the VM with bypass enabled or, if it knows that the software stack supports it, disabled. The 'bypass' config fields is initialized to 0 or 1. It is sticky and Isn't affected by device reset.  * Generally the firmware won't have an IOMMU driver and will need to be started in bypass mode, so the bootloader and kernel can be loaded from storage endpoint.  For more security, the firmware could implement a minimal virtio-iommu driver that reuses existing virtio support and only touches the config space. It could enable PCI bus mastering in bridges only for the endpoints that need it, enable global IOMMU bypass by flipping a bit, then tear everything down before handing control over to the OS. This prevents vulnerability windows where a malicious endpoint reprograms the IOMMU while the OS is configuring it [1].  The isolation provided by vIOMMUs has mainly been used for securely assigning endpoints to untrusted applications so far, while kernel DMA bypasses the IOMMU. But we can expect boot security to become as important in virtualization as it presently is on bare-metal systems, where some devices are untrusted and must never be able				virtio-iommu: Rework the bypass feature The VIRTIO_IOMMU_F_BYPASS feature is awkward to use and incomplete. Al- though it is implemented by QEMU, it is not supported by any driver as far as I know. Replace it with a new VIRTIO_IOMMU_F BYPASS_CONFIG feature. Two features are missing from virtio- iommu: * The ability for an hypervisor to start the device in bypass mode. The wording for VIRTIO_IOMMU_F_BYPASS is not clear enough to allow it at the moment, because it only specifies the behavior after feature negotiation. * The ability for a guest to set individual endpoints in bypass mode when bypass is globally disabled. An OS should have the
* Generally the firmware won't have an IOMMU driver and will need to be started in bypass mode, so the bootloader and kernel can be loaded from storage endpoint.  For more security, the firmware could implement a minimal virtio-iommu driver that reuses existing virtio support and only touches the config space. It could enable PCI bus mastering in bridges only for the endpoints that need it, enable global IOMMU bypass by flipping a bit, then tear everything down before handing control over to the OS. This prevents vulnerability windows where a malicious endpoint reprograms the IOMMU while the OS is configuring it [1].  The isolation provided by vIOMMUs has mainly been used for securely assigning endpoints to untrusted applications so far, while kernel DMA bypasses the IOMMU. But we can expect boot security to become as important in virtualization as it presently is on bare-metal systems, where some devices are untrusted and must never be able				ability to allow only endpoints it trusts to bypass the IOMMU, while keeping DMA disabled for endpoints it isn't even aware of. At the moment this can only be emulated by creating identity mappings.  The VIRTIO_IOMMU_F_BYPASS_CONFIG feature adds a 'bypass' config field that allows to enable and disable bypass globally. It also adds a new flag for the ATTACH request.  * The hypervisor can start the VM with bypass enabled or, if it knows that the software stack supports it, disabled. The 'bypass' config fields is initialized to 0 or 1. It
windows where a malicious endpoint reprograms the IOMMU while the OS is configuring it [1].  The isolation provided by vIOMMUs has mainly been used for securely assigning endpoints to untrusted applications so far, while kernel DMA bypasses the IOMMU. But we can expect boot security to become as important in virtualization as it presently is on bare-metal systems, where some devices are untrusted and must never be able				* Generally the firmware won't have an IOMMU driver and will need to be started in bypass mode, so the bootloader and kernel can be loaded from storage endpoint. For more security, the firmware could implement a minimal virtio-iommu driver that reuses existing virtio support and only touches the config space. It could enable PCI bus mastering in bridges only for the endpoints that need it, enable global IOMMU bypass by flipping a bit, then tear everything down before handing control
to access memory that wasn't assigned to				windows where a malicious endpoint reprograms the IOMMU while the OS is configuring it [1].  The isolation provided by vIOMMUs has mainly been used for securely assigning endpoints to untrusted applications so far, while kernel DMA bypasses the IOMMU. But we can expect boot security to become as important in virtualization as it presently is on bare-metal systems, where some de-

Copyright © OASIS Open 2022. All Tight® Reserved. Page 276 of 282

\* The OS can enable and disable bypass globally. It can then enable bypass for

Revision	Date	Editor	Changes Made
ed9152310708	21 Dec 2021	Yadong Qi	virtio-blk: add secure erase feature to specification There are user requests to use the Linux BLKSECDISCARD ioctl on virtio-blk device. A secure discard is the same as a regular discard except that all copies of the discarded blocks that were possibly created by garbage collection must also be erased. This requires support from the device. And "secure erase" is more commonly used in industry to name this feature. Hence in this proposal, extend virtio-blk protocol to support secure erase command. Introduced new feature flag and command type: VIRTIO_BLK_F_SECURE_ERASE VIRTIO_BLK_T_SECURE_ERASE This feature is a passthrough feature on backend because it is hard to emulate a secure erase. So virtio-blk will report this feature to guest OS if backend device support such kind of feature. And when guest OS issues a secure erase command, backend driver will passthrough the command to host device blocks.  Introduced new fields in virtio_blk_config for secure erase commands: struct virtio_blk_config.  max_secure_erase_sectors; max_secure_erase_seg; secure_erase_sector_alignment; };  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/125  Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Yadong Qi <yadong.qi@intel.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.2.3, 5.2.4, 5.2.5, and 5.2.6.</co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></co-huck@redhat.com></yadong.qi@intel.com></stefanha@redhat.com>

Revision	Date	Editor	Changes Made
3b5378d70a42	21 Dec 2021	Xuan Zhuo	virtio: introduce virtqueue reset as basic facility This patch allows the driver to reset a queue individually. This is very common on general network equipment. By disabling a queue, you can quickly reclaim the buffer currently on the queue. If necessary, we can reinitialize the queue separately. For example, when virtio-net implements support for AF_XDP, we need to disable a queue to release all the original buffers when AF_XDP setup. And quickly release all the AF_XDP buffers that have been placed in the queue when AF_XDP exits. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/124 Reviewed-by: Jason Wang <jasowang@redhat.com> Signed-off-by: Xuan Zhuo <xuanzhuo@linux.alibaba.com> Signed-off-by: Cornelia Huck <cohuck@redhat.com> See 2.6, and 6.</cohuck@redhat.com></xuanzhuo@linux.alibaba.com></jasowang@redhat.com>
12998e738621	21 Dec 2021	Xuan Zhuo	virtio: pci support virtqueue reset PCI support virtqueue reset. virtio_pci_common_cfg add "queue_reset" to support virtqueue reset. The driver uses this to selectively reset the queue. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/124 Reviewed-by: Jason Wang <ja- sowang@redhat.com=""> Signed-off-by: Xuan Zhuo <xu- anzhuo@linux.alibaba.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 4.1.4.3.</co-></xu-></ja->
a4ce81a83780	21 Dec 2021	Xuan Zhuo	virtio: mmio support virtqueue reset mmio support virtqueue reset.  MMIO Device Register Layout "QueueReady" to support virtqueue reset. The driver uses this to selectively reset the queue.  Fixes: https://github.com/oasis-tcs/virtio-spec/issues/124 Reviewed-by: Jason Wang <jasowang@redhat.com> Signed-off-by: Xuan Zhuo <xuanzhuo@linux.alibaba.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 4.2.2.</co-huck@redhat.com></xuanzhuo@linux.alibaba.com></jasowang@redhat.com>

Revision	Date	Editor	Changes Made
f65613a48826	11 Jan 2022	Max Gurtovoy	Fix reserved Feature bits numbering This should have been updated during VIR- TIO_F_NOTIFICATION_DATA, VIRTIO F_NOTIF_CONFIG_DATA and VIRTIO F_RING_RESET standartization. Fixes: https://github.com/oasis-tcs/ virtio-spec/issues/128 Reviewed-by: Stefan Hajnoczi <ste- fanha@redhat.com=""> Signed-off-by: Max Gurtovoy <mgur- tovoy@nvidia.com=""> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 2.2.</co-></mgur-></ste->
5e1c3fa81e29	21 Jan 2022	Arseny Krasnov	virtio-vsock: use C style defines for constants This: 1) Replaces enums with C style "defines", because use of enums is not documented, while "defines" are widely used in spec. 2) Adds defines for some constants. Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Arseny Krasnov <arseny.krasnov@kaspersky.com> Reviewed-by: Stefano Garzarella <sgarzare@redhat.com> Signed-off-by: Stefano Garzarella <sgarzare@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.10.6.</co-huck@redhat.com></sgarzare@redhat.com></sgarzare@redhat.com></arseny.krasnov@kaspersky.com></stefanha@redhat.com>
1a90fc6e4228	21 Jan 2022	Stefano Garzarella	virtio-vsock: add VIRTIO_VSOCK_F STREAM feature bit Initially vsock devices only supported stream sockets, but now we are adding support for new types (i.e. SEQPACKET, DGRAM). Since some devices may not want to support stream sockets, we add a feature bit for this type. For backward compatibility, if no feature bit is set, only stream socket type is supported. Reviewed-by: Stefan Hajnoczi <stefanha@redhat.com> Signed-off-by: Stefano Garzarella <sgarzare@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.10.3.</co-huck@redhat.com></sgarzare@redhat.com></stefanha@redhat.com>

Revision	Date	Editor	Changes Made
d6d9c734b42e	21 Jan 2022	Arseny Krasnov	virtio-vsock: SOCK_SEQPACKET description This adds description of SOCK_SEQPACKET socket type support for virtio-vsock. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/132 Signed-off-by: Arseny Krasnov <arseny.krasnov@kaspersky.com> [reworked "Message and record boundaries" paragraph] Signed-off-by: Stefano Garzarella <sgarzare@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 5.10.3, and 5.10.6.</co-huck@redhat.com></sgarzare@redhat.com></arseny.krasnov@kaspersky.com>
88895f56e642	24 Jan 2022	Cornelia Huck	Reserve more feature bits for device type usage Feature bits 41 and above are noted as being reserved for future extensions. However, the net device has been using bits in that space for some time now, as it already used up the device type specific range up to 23.  To avoid problems in the future, let's designate bits 50 to 127 to device type specific usage (which accommodates current usage by the net driver, and gives breathing room for future type specific bits), and declare bits 41 to 49 and bits 128 and above to be reserved for future extensions (which gives us some time before bit numbers move beyond 63, which would need some changes in existing device and driver implementations.) Reported-by: Max Gurtovoy <mgurtovoy@nvidia.com> Fixes: https://github.com/oasis-tcs/virtio-spec/issues/131 Reviewed-by: Max Gurtovoy <mgurtovoy@nvidia.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 2.2.</co-huck@redhat.com></mgurtovoy@nvidia.com></mgurtovoy@nvidia.com>

Revision	Date	Editor	Changes Made
6708e0fc2f7d	07 Apr 2022	Michael S. Tsirkin	virtio-gpio: offered -> negotiated virtqueues are only discovered after FEA- TURES_OK. As such it makes no sense to talk about virtqueues being affected by fea- tures which are offered but not negotiated, and doing so will confuse the reader. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Acked-by: Viresh Kumar <viresh.kumar@linaro.org> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 5.18.2.</co-></viresh.kumar@linaro.org></mst@redhat.com>
a214ffb64f45	11 Apr 2022	Cornelia Huck	introduction: add more section labels In order to be able to refer to changes in sections. Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 1.4, and 1.5.</co-huck@redhat.com>
79f705b96040	11 Apr 2022	Cornelia Huck	conformance: hook up GPU device normative statements These statements already exist, but were not linked in the conformance section. Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 7.1.</co-huck@redhat.com>
26f15550226b	19 Apr 2022	Michael S. Tsirkin	packed-ring: fix some typos The VIRTQ_DESC_F_INDIRECT flag is misnamed in a couple of places. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 2.8.19.</co-></mst@redhat.com>
b13f67fca90e	20 Apr 2022	Michael S. Tsirkin	packed-ring.tex: link conformance statements Link conformance statements into conformance chapter. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co-huck@redhat.com> See 7.1.</co-huck@redhat.com></mst@redhat.com>
3a7f07897958	20 Apr 2022	Michael S. Tsirkin	content.tex: drop space after \field Always use \field{foo} not \field {foo}, the latter confuses latexdiff. Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Cornelia Huck <co- huck@redhat.com=""> See 4.1.4.</co-></mst@redhat.com>

Revision	Date	Editor	Changes Made
c5fd7eda1203	29 Apr 2022	Parav Pandit	virtio: Improve queue_reset polarity to match to default reset state Currently when driver initiates a queue reset, device is expected to communicate reset status to the driver by changing the value of the queue_reset register twice. First to return value other than 1 when reset is ongoing, later to return 1 when queue reset is completed. However initially during the device reset time the queue reset value is zero. queue_reset changes the value of the register to a different value on reset completion. Yet another time queue_reset value is expected to change when queue_select is reprogrammed. Instead, it is better and efficient to maintain the same VQ state on the device when queue reset is completed.  new proposed flow: q_enable, q_reset A) 0, 0 -> default, device init time B) 1, 0 -> driver has enabled vq C) 1, 1 -> driver started q reset D) 1, 1 -> q_reset stays 1 until device is busy resetting vq (device communicates that its working on resetting VQ, consistent with #C) E) 0, 0 -> q_reset by device is completed, q got disabled (consistent with device init time #A) Hence, this patch proposes a simple change to have reset register polarity to be same as that of initial reset value. Fixes: https://github.com/oasis-tcs/virtio-spec/issues/139 Fixes: 12998e738621 ("virtio: pci support virtqueue reset") Fixes: a4ce81a83780 ("virtio: mmio support virtqueue reset as basic facility") Reviewed-by: Jason Wang <jarsowang@redhat.com> Reviewed-by: Jason Wang <jarsowang@redhat.com> Reviewed-by: Jason Wang <jarsowang@redhat.com> Reviewed-by: Parav Pandit <par> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> Signed-off-by: Michael S. Tsirkin <mst@redhat.com> See 4.1.4.3 and 4.2.2.</mst@redhat.com></mst@redhat.com></mst@redhat.com></par></jarsowang@redhat.com></jarsowang@redhat.com></jarsowang@redhat.com>