

# WATER TECHNOLOGY




#### **Lecture - I**

- Introduction to water technology
- Chemistry of water
- Specifications of drinking water
- •Source of impurities in water and types of impurities.



## **Chemistry of Water**

- Universal Solvent
- Polar Molecule
- High Latent Heat
- Hydrogen bonding
- High Surface Tension





## WHO Specification for Drinking Water

Parameter	Values (ppm) except pH	
рН	6.5 - 8.5	
Hardness	300	
Chloride	250	
DO	5	
Nitrate	50	
Turbidity	5	
Fluoride	1.5	
TDS	500	



## Impurities in water

- Suspended Impurities
- Dissolved Impurities
- Colloidal Impurities
- Biological Impurities



- Water analysis types and units of hardness
- •Estimation of hardness by EDTA method.
- Numericals



## **Water Analysis**

- Hardness
- Alkalinity
- Chlorides
- Dissolved oxygen



#### **Hardness of Water**

- Soap consuming capacity of water sample
- Due to dissolved salts of Calcium and Magnesium
- Expressed in terms of ppm of CaCO<sub>3</sub>



## **Temporary Hardness**

- Also known as Carbonate or alkaline hardness
- •Due to presence of Ca(HCO<sub>3</sub>)<sub>2</sub> & Mg(HCO<sub>3</sub>)<sub>2</sub>
- Temporary Hardness can be removed by boiling hard water

$$Mg (HCO_3)_2$$
  $Mg(OH)_2 \downarrow + 2CO_2 \uparrow$ 

$$Ca(HCO_3)_2$$
  $CaCO_3 \downarrow +CO_2 \uparrow +H_2O$ 



#### **Permanent Hardness**

- Also known as non carbonate or non alkaline hardness
- Due to Chlorides, Nitrates & Sulphates of Ca & Mg
- Cannot be removed by boiling

**Total hardness = Temporary Hardness + Permanent Hardness** 



## Determination of Hardness by EDTA Method: Complexometric Titration

- Complexometric titrations are particularly useful for the determination metal ions concentration in solution.
   An indicator capable of producing an unambiguous color change is usually used to detect the end-point of the titration.
- Chelating agent used is
- EDTA -Ethylene Diamine TetraAcetic Acid
- It is a hexadentate ligand
- Water is titrated against a standard solution of Na<sub>2</sub>EDTA which is preferred as it is more soluble in water



# Determination of Hardness by EDTA Method

- •Eriochrome Black T is used as the indicator
- •pH 10 is maintained by Buffer (NH<sub>4</sub>Cl + NH<sub>4</sub>OH)
- •Hardness = B.R x Molarity of EDTA  $x100 \times 1000 / V$
- •B.R=Burette reading=Volume of EDTA solution
- •V is volume of water sample used for titration

#### **Procedure**

Part-A: Standardization of Na<sub>2</sub>EDTA by std. ZnSO<sub>4</sub> solution

Part-B: Determination of total hardness of water sample using Std. Na, EDTA



### **Reactions involved in Titration**

$$M^{2+}$$
 + EBT  $\rightarrow$  M-EBT +  $2H^{+}$  Wine red



#### **Calculations**

- Metal: EDTA is 1: 1 complex
- 1 mole of EDTA complexes with 1 mole  $Ca^{2+}/Mg^{2+} = 1$  mole  $CaCO_3$
- •1 mole of EDTA =  $100 \text{ g of CaCO}_3$
- •1000 ml of 1M EDTA= 100 g of CaCO<sub>3</sub>
- •1 ml of 1M EDTA = 100 mg of  $CaCO_3$
- B.R. 'Y' (volume of EDTA)ml of 'M' M EDTA= 'Y' x 'M' x 100 mg of CaCO<sub>3</sub>
- Volume of water sample= V ml
- For 1000 ml of water,
- Hardness = Volume of EDTA x Molarity of EDTA x100 x1000
- •
- Volume of water (V ml)



#### **Numerical on Hardness**

1. <u>20 ml</u> standard hard water (containing 14 g CaCO<sub>3</sub> per lit.) required <u>22 ml</u> EDTA for the end point. <u>100 ml</u> of water sample required 15 ml EDTA solution. 100 ml of the same sample after boiling required 10 ml of EDTA solution Calculate carbonate(temporary hardness) and non-carbonate hardness(permanent hardness) of water.

Molarity of CaCO<sub>3</sub> = no. of moles of CaCO<sub>3</sub>/ volume of solution

No. of moles = given weight of CaCO<sub>3</sub>/Molecular weight of CaCO<sub>3</sub>

= 0.14

Molarity of  $CaCO_3 = 0.14$ 

M1 V1 = M2 V2

 $0.14 \times 20 = M2 \times 22$ , M2 = 0.13

• Total Hardness= 
$$15 \times 0.13 \times 100 \times 1000 = 1950 \text{ ppm}$$

• 100

• Permanent Hardness = 
$$10 \times 0.13 \times 100 \times 1000 = 1300 \text{ ppm}$$

• 100

- Temporary = Total Permanent
- = 1950 -1300 ppm
- = 650 ppm



### **Hardness of water**

2.Calculate temporary hardness, total hardness and permanent hardness in terms of CaCO<sub>3</sub> for sample with composition.

a) Ca 
$$(HCO_3)_2 = 6.4 \text{ mg/L}$$

b) Mg 
$$(HCO_3)_2 = 8.2 \text{ mg/L}$$

c) 
$$MgSO_4 = 5.6 \text{ mg/L}$$

d) 
$$MgCl_2 = 4.2 mg/L$$

e) 
$$CaSO_4 = 12.3 \text{ mg/L}$$

f) 
$$Na_2SO_4 = 6.5 \text{ mg/L}$$

 $CaCO_3$  equivalent of a substance 'X' = Amount of X (mg) x Eq. wt. of  $CaCO_3$ 

Eq wt. of X

$$Ca(HCO_3)_2 = 3.95 \text{ mg/L}$$

$$Mg (HCO_3)_2 = 5.62 mg/L$$

$$MgCl2 = 4.42 mg/L$$

$$CaSO_{4} = 9.04 \text{ mg/L} \text{ MgSO4} = 4.67 \text{ mg/L}$$

- •Temporary Hardness = 3.95 + 5.62 = 9.57 ppm
- •Permanent Hardness = 4.42+9.04+4.67=18.13 ppm
- •Total hardness = 27.7 ppm



- Sources of alkalinity and its volumetric estimation
- Sources of chlorides
- Mohr's method for determination of chlorides.
- Numericals



## **Alkalinity**

- Alkalinity is a measure of the water's ability to neutralize acidity
- •An alkalinity test measures the level of bicarbonates, carbonates, and hydroxides in water and test results are generally expressed as "ppm of calcium carbonate (CaCO<sub>3</sub>)"
- Fresh water usually has 20-200 mg/L levels of alkalinity.
- A total alkalinity level of 100-200 mg/L can stabilize the pH level in a stream.
- Determined by an acid-base titration
- Phenolphthalein And Methyl Orange are used as indicators



## **Alkalinity Types**

- •Only HO
- •Only CO<sub>3</sub><sup>2</sup>-
- •Only HCO<sub>3</sub>
- •OH<sup>-</sup> & CO<sub>3</sub><sup>2-</sup> together
- •CO<sub>3</sub><sup>2-</sup> & HCO<sub>3</sub>- together

HO

HO

HO

$$+ H_2O$$

Colourless (acid)

HO

 $+ H_3O^+$ 

Pink (base)



## **Reactions Involved**

 $O H^- + H^+ \rightarrow H_2O$  $CO_3^{2-}$  +  $H^+$   $\rightarrow$   $HCO_3^ \mathsf{HCO}_{3}^{-} + \mathsf{H}^{+} \rightarrow \mathsf{H}_{2}\mathsf{O} + \mathsf{CO}_{2}\uparrow$ 



## **Computing Alkalinity**

Phenolphthalein alkalinity (P)

 $P = (V_{1acid} \times N_{acid} \times 50 \times 1000) / V_{water}$  ppm of CaCO<sub>3</sub> equivalents.

Methyl orange alkalinity (M) OR Total alkalinity

$$\mathbf{M} = (V_{2acid} \times N_{acid} \times 50 \times 1000) / V_{water}$$
 ppm of CaCO<sub>3</sub> equivalents

- 1 g equivalent of HCl = 1 g equivalent of CaCO<sub>3</sub>
- 1000 ml of 1N HCl = 50 g of CaCO<sub>3</sub>

1000 IIII OI IN IICI – 30 g OI Caco

• 5.5

• 1 ml of 1N HCl = 50 mg of  $CaCO_3$ 

•

• V1 ml of 'Y' N HCl = 50 x V<sub>1</sub> x Y mg of CaCO<sub>3</sub>

For Volume of water analysed = V ml , Z is the quantity For 1000 ml

Phenolphthalein Alkalinity =  $V_1 \times Y \times 50 \times 1000 \text{ mg/L}$ 

Methyl Orange/Total Alkalinity = V<sub>2</sub> x Y x 50 x 1000 mg/L

0.0

8.5



## **Alkalinity Interpretation**

Relation between P & M	OH <sup>-</sup>	CO <sub>3</sub> <sup>2-</sup>	HCO <sub>3</sub>
P = 0	0	0	M
P = M	P/M	0	0
P=1/2 M	0	2P	0
P>1/2M	2P-M	2(M-P)	0
P<1/2M	0	2P	M-2P

#### **Numericals**

• 50 ml water sample requires 4.5 ml of N/50 HCl upto phenolphthalein end point and another 6 ml upto methyl orange end point, compute the individual alkalinity of water.

- P = 4.5 x 0.02 x 1000 = 90 ppm
- M= 10.5 x 20 =210 ppm

 Water sample is not alkaline to phenolphthalein. 100ml of sample on titration with N/50 HCl required 17.5 ml to get methyl orange end point.
 Compute alkalinity result.



## **Mohr's Method**

- •Chloride ions come into solution in water in underground aquifers, geological formations that contain groundwater.
- •Chloride ion concentrations of between 1 and 100 ppm (parts per million) are normal in freshwater.
- •Chloride ion concentration is determined by Mohr's Method which is a titration of water sample with AgNO<sub>3</sub> in neutral or slightly alkaline pH in presence of potassium chromate as the indicator.

#### **Mohr's Method**

- This is called Argentometric Titration.
- •Highly alkaline pH leads to formation of Silver Hydroxide (AgOH)
- •At Low pH Chromate may transformed into dichromate leading to inaccurate result ( $CrO_4^{2-} \longrightarrow Cr_2O_7^{2-}$ )



#### **Mohr's Method**

•At the start, chloride ions react with silver ions forming white ppt of Silver Chloride



#### White ppt

•After all chloride are used up Ag<sup>+</sup> reacts with chromate ion (from the indicator) forming brick red precipitate.

**Brick-red ppt** 



## Chloride ions Concentration Calculation

1 g equivalent of AgNO<sub>3</sub> = 1 g equivalent of Cl<sup>-</sup>

1000 ml 1N 
$$AgNO_3 = 35.5 g Cl^{-1}$$

amount of chloride = 
$$N_1 \times V_1 / V_2 \times 35.5 \times 1000$$
 mg/L

$$N_1 = Normality of AgNO_3$$

$$V_1 = Volume of AgNO_3$$

$$V_2$$
 = Volume of water sample

Chloride ion concentration above 250 ppm is not acceptable



#### **Lecture - IV**

- Dissolved oxygen
- •Effects of DO level on drinking water and water for industrial use
- Estimation of DO by Winkler method



## **Dissolved Oxygen**

- **Dissolved Oxygen** is the amount of gaseous **oxygen** (O<sub>2</sub>) **dissolved** in the water.
- Oxygen enters the water by direct absorption from the atmosphere, by rapid movement, or as a by product of plant photosynthesis. Water temperature, salt concentration can affect **dissolved oxygen** levels.
- Measurement gives idea about status of water system ( Aerobic /Anaerobic )
- Indicator of water pollution
- DO level can give idea about survival of aquatic life
- DO is important factor causing corrosion of boiler metal
- Possibility of aerobic biological processes for transforming biodegradable organic contaminants



### **Steps in Winkler's Method**

O<sub>2</sub> Fixation

 Conversion Mn (II) to Mn(IV) forming Brown ppt of Basic Manganic oxide

$$2Mn(OH)_2 + O_2$$
  $\longrightarrow$   $2MnO(OH)_2$  (Brown ppt)

Conversion of Mn (IV) to Mn(II) on Acidification

$$MnO(OH)_2 + H_2SO_4$$
  $MnSO_4 + 2H_2O + (O)$ 



### Winkler's Method

## Oxidation of KI into I<sub>2</sub> by Nascent oxygen

$$2KI + H_2SO_4 + O \longrightarrow K_2SO_4 + H_2O + I_2$$

Titration of liberated iodine with sodium thiosulphate using starch indicator

$$I_2 + 2Na_2S_2O_3$$
  $\longrightarrow$   $Na_2S_4O_6 \downarrow$  + 2Nal



#### **Outline Of Winkler Dissolved Oxygen Procedure**

Carefully
Collect
Sample
In 300 mL
BOD Bottle

Add
1 mL
MnSO<sub>4</sub> Soln.
and
1 mL
Alkali-iodide-azide
Reagent




Yellow To Brown Floc, D.O. Present






White Floc, No D.O. 2

Mix By Inverting and Allow To Settle



Repeat Mixing and Settling

3



Add 1 mL H<sub>2</sub>SO<sub>4</sub> and Mix


4







## **Titration of Iodine Solution**





# Winkler's Method

Nitrate ion interference may be avoided by adding sodium azide

Dissolved Oxygen =  $V_{Na2S2O3} \times N_{Na2S2O3} \times 8 \times 1000 \text{ mg/L}$ 

Volume of water

1 g eq. of  $Na_2S_2O_3.5H_2O = 1$  g eq. of oxygen 1000 ml of  $1N Na_2S_2O_3.5H_2O = 8$  g of oxygen 1 ml of  $1N Na_2S_2O_3.5H_2O = 8$  mg of oxygen Volume of water taken for titration= V ml 'X' ml of 'Y' N  $Na_2S_2O_3.5H_2O = 8 \times X \times Y$  mg of oxygen For  $1000 \text{ ml} = 8 \times X \times Y \times 1000$ 



# **Lecture - V**

- Quality requirements of boiler feed water
- External treatments
- Ill effects of hard water in boilers
- Carryover(priming and foaming)
- Caustic embrittlement
- Boiler corrosion
- Sludge and scale formation



# III Effects of boiler feed water

Water expands 1600 times as it evaporates to form steam at atmospheric pressure.

The steam is capable of carrying large quantities of heat.

These unique properties of water make it an ideal raw material for heating and power generating processes.

All natural waters contain varying amounts of dissolved and suspended matter and dissolved gases the amount of minerals dissolved in water varies from 30 g/l in sea water to anything from 0.005 to 1500 mg/l in fresh water supplies.

Since water impurities cause boiler problems, careful consideration must be given to the quality of the water used for generating steam



#### Ill Effects of Boiler Feed Water

- A) Priming & foaming (carryover)
- B) Caustic embrittlement
- **C)** Boiler Corrosion
- D) Scales & Sludges



# **Priming**

Priming is the carryover of varying amounts of droplets of water in the steam (foam and mist), which lowers the energy efficiency of the steam and leads to the deposit of salt crystals on the super heaters and in the turbines.

#### **Causes**

- Very high level of boiler feed water
- Presence of excessive foam
- High speed of steam generation
- Faulty boiler design.



# **Prevention of Priming**

- Avoiding rapid changes in steaming rate
- Maintaining optimum level of water
- Better Boiler Design
- Removing impurities from water



# **Foaming**

Formation of continuous foam or bubbles on the surface of water resulting in wet steam formation.

#### Causes:

- High conc. of dissolved salts in boiler feed water
- Presence of oil droplets and alkalies
- Presence of finely dispersed suspended material
- Violent agitation of boiler feed water



# **Prevention of Foaming**

- •Use of antifoaming agents such as certain alcohols like cetostearyl alcohol, oils like castor oil.
- •Removal of oil and greases using sodium aluminates
- •Removal of silica using ferrous sulphate
- •By using soft water



# Disadvantages of priming and foaming

- Actual height of water column cannot be judged well due to foaming
- •Because of priming, the salts present in the droplets enter in different parts of machineries.
- The dissolved salts in droplet of wet steam get deposited on evaporation of water
- Foaming causes wet steam formation



## **Caustic Embrittlement**

- Boiler material gets brittle due to exposure to caustic solution under high pressure and high temperature condition.
- Cause
- As water evaporates in the boiler, the concentration of sodium carbonate increases in the boiler. Sodium carbonate is used in softening of water by lime soda process, due to this some sodium carbonate maybe left behind in the water. As the concentration of sodium carbonate increases, it undergoes hydrolysis to form sodium hydroxide.

#### Galvanic cell or Concentration cell formation

- The presence of sodium hydroxide makes the water alkaline. This alkaline water enters minute cracks present in the inner walls of the boiler by capillary action.
- Inside the cracks, the water evaporates and the amount of hydroxide keeps increasing progressively.
- The concentrated area with high stress works as anode and diluted area works as cathode.
- At anode, sodium hydroxide attacks the surrounding material and then dissolves the iron of the boiler as sodium ferrate forming rust.
- This causes embrittlement of boiler parts like rivets, bends and joints, which are under stress.



# **Prevention**

- •Use of materials that do not crack when used in given environments.
- •Avoiding alkali where necessary or adjusting pH.
- •Replacing sodium carbonate with sodium sulphate as softening reagents.
- •Adding lignin, tannin or sodium sulphate that blocks hairline cracks as well as preventing infiltration of sodium hydroxide into those areas.



# **Boiler Corrosion**

#### 1.Dissolved oxygen

• 2Fe + 
$$2H_2O + O_2 \longrightarrow 2Fe(OH)_2\downarrow$$

# Removal of oxygen from water Chemical deaeration

• 
$$N_2H_4 + O_2$$
  $N_2\uparrow + 2H_2O$ 

#### Removal







## **Corrosion in Boiler**

## III) Hydrolysis of salts

•MgCl<sub>2</sub> +2H<sub>2</sub>O 
$$\longrightarrow$$
 2Mg(OH)<sub>2</sub> +2HCl

•FeCl<sub>2</sub> + 
$$2H_2O$$
 Fe(OH)<sub>2</sub> +  $2HCI$ 

## **Disadvantages**

- Reducing the life of boiler
- Leakage of joints and rivets
- Increased cost of repairs & maintenance



# Scales & Sludges formation

- Boiler scale is caused by impurities being precipitated out of the water directly on heat transfer surfaces or by suspended matter in water settling out on the metal and becoming hard and adherent.
- Evaporation in a boiler causes impurities to concentrate.
- This interferes with heat transfers and may cause hot spots. Leading to local overheating. Scaling mechanism is the exceeding of the solubility limits of mineral substances due to elevated temperature.
- The less heat they conduct, the more dangerous they are.

Scales are formed due to the presence of CaSO<sub>4</sub>, Mg(OH)<sub>2</sub>, MgCl<sub>2</sub>, CaCO<sub>3</sub>, silicates of Ca & Mg.







## Scale formation

#### Causes -


- i) Thermal decomposition of bicarbonates of Ca & Mg
- ii) Hydrolysis of magnesium salts
- iii) Presence of silica
- iv) Decreased solubilities of CaSO<sub>4</sub> at high temperature





# Disadvantages of Scale Formation

- Wastage of Fuel
- Over heating of boiler
- Boiler safety
- Danger of explosion





# Sludge

## **Disadvantages**

- Bad conductor of heat (Wastage of Fuel)
- Reduces boiler efficiency
- Reduces the flow rate of water in boiler.

#### **Prevention**

- Use of water containing very low quantity of total dissolved solids.
- •Frequently doing blow down operation.



# **Prevention of Scale formation**

- Use of softened water
- Phosphate conditioning
- Adding sodium aluminates
- Adding organic chemicals like tannin.



# **Lecture - VI**

- Boiler feed water treatments
- •Internal treatments- phosphate, calgon and colloidal conditioning.
- External treatment
- Ion exchange resins method
- Zeolite process
- numerical



#### Internal treatment

# **Phosphate Conditioning**

- Various phosphate are used depending on pH of boiler feed water
- Sodium phosphates converts Ca/Mg salt into corresponding phosphates
- Ca/Mg phosphates are easily removed by Blow down operation





# Selection of phosphate

Phosphate used	Nature of boiler Feed water
Na <sub>3</sub> PO <sub>4</sub>	Highly Acidic
NaH <sub>2</sub> PO <sub>4</sub>	Highly Alkaline
Na <sub>2</sub> HPO <sub>4</sub>	Weakly Alkaline

3 CaSO<sub>4</sub>+ 2 Na<sub>3</sub>PO<sub>4</sub> Ca<sub>3</sub> (PO<sub>4</sub>)<sub>2</sub>
$$\downarrow$$
 + 3 Na<sub>2</sub>SO<sub>4</sub>



# **Internal Treatments**

#### **Calgon Conditioning**

Sodium hexametaphosphate forms
 soluble complex with Ca/Mg at pH 10

#### **Colloidal conditioning**

- Addition of tannin and agar agar
- •Exceptional Ability to get coated over scale forming salts converting them into sludge




# **External treatment**

- Zeolite process
- Ion exchange method
- Synthetic ion exchange resins



# **Zeolite**

- Naturally occurring hydrated
   aluminosilicates(Na<sub>2</sub>O.Al<sub>2</sub>O<sub>3</sub>.
- •xSiO<sub>2</sub>.yH<sub>2</sub>O)
- Also known as Permutit or
   Molecular Sieves
- Porous Material
- Insoluble in water
- Works on Reversible Ion exchange Process








# **Zeolite**

- •Zeolites are crystalline microporous aluminosilicates with open **3D** framework structures built of SiO<sub>4</sub> and AlO<sub>4</sub> tetrahedra linked to each other by sharing all the oxygen form atoms to regular intra-crystalline cavities and channels of molecular dimensions.
- •Zeolite can trap Ca<sup>2+</sup>, Mg<sup>2+</sup> from hard water and release Na<sup>+</sup> ions into water





# **Zeolite process**

#### **Process**

 Zeolites capture cations and releases equivalent Na<sup>+</sup> ions into water

$$Na_2 Ze + Ca^{2+} \rightarrow CaZe + 2Na^+$$

#### Regeneration

Brine solution is used



# **Limitations of Zeolite**

- The effective concentration of sodium salt increases
- Mineral acid may disintegrate Zeolite bed
- Highly turbid water can not be treated
- Boiler feed Water with Fe<sup>+2</sup> and Mn<sup>+2</sup> can not be treated properly
- Capable of removing only Cations
- Hot water dissolves Zeolite



#### **Numericals**

- A zeolite bed was exhausted on softening of 4000 litre
  of water requires 10 litres of 15 % NaCl solution for
  regeneration. Calculate hardness of water sample.
- 2. A Zeolite softener was completely exhausted and was regenerated by passing 100 L of NaCl solution containing 120 g/L of NaCl. How many litres of water having hardness 500 ppm can be softened by this softener?

- Solution to problem 1
- Hardness of water = Amount of CaCO<sub>3</sub> (mg)
- •
- Volume of water (L)
- 15 g in 100 ml, so in 10 L NaCl is 1500 g.
- Amount of NaCl =  $1500 \times 10^3 \text{ mg}$

- No. of equivalents of CaCO<sub>3</sub> = No. of equivalents of NaCl
- Amount of  $CaCO_3 = 1.5 \times 10^6 \times 50 = 1.28 \times 10^6 \text{ mg}$
- 58.5
- •
- Hardness =  $1.28 \times 10^6$  (mg)
- 4000 L
- = 320.6 ppm

- Solution to Problem 2
- Hardness of water= 500 ppm
- No. of equivalents of CaCO<sub>3</sub> = No. of equivalents of NaCl
- Amt of CaCO<sub>3</sub> = amt of NaCl (mg) x 50 (equivalent weight of CaCO<sub>3</sub>)
- 58.5 (eq. wt. of NaCl)
- 120 g of NaCl in 1 L
- 1.2 x 10<sup>7</sup> mg of NaCl in 100 L
- Volume of water =  $1.2 \times 10^7 \times 0.855 \text{ mg}$
- 500
- = 20512.8 L



## **Lecture - VII**

- Synthetic ion exchange resins method
- Desalination techniques
- Electrodialysis and Reverse osmosis



# Ion Exchange Method

- An ion-exchange resin or ion-exchange polymer is a polymer that contains positively or negatively charged sites that can attract an ion of opposite charge from a surrounding solution.
- Resins have either Acidic or Basic Functional group with loosely bound ions.
- Resins are used for water softening.


Cation Exchange Resin (RH)

2RSO<sub>3</sub>H + CaSO<sub>4</sub> (RSO<sub>3</sub>)<sub>2</sub>Ca + H<sub>2</sub>SO<sub>4</sub>



# Ion Exchange Method


- Most commercial resins are made of polystyrene sulfonate.
- an insoluble matrix (or support structure) normally in the form of small (0.25–0.5 mm radius) microbeads, usually white yellowish, fabricated from or an organic polymer substrate. The beads typically porous, <u>providing</u> are large surface area on and inside them and the trapping of ions occurs along with the accompanying release of other ions, and thus the process is called ion exchange.





# **Key Points – Ion Exchange Method**


- Cation exchange resins exchange only cations
- Anion exchange resins exchange only anions
- Net result is demineralised water
- Cation Exchange resin are
- regenerated by dilute HCI
- Anion exchange resin
- are regenerated by dilute NaOH





# Ion Exchange Process


- Works well for variation of hardness of water
- Apparatus occupies small space
- Process is easy to operate
- Acidic or highly alkaline water
   can be treated effectively





# **Electrodialysis**


- The process of removing ionic pollutants from water using membranes under electrical potential difference is known as Electro dialysis.
- Ion selective membranes are used
- Cation selective membrane allow passage of cations only
- Anion Selective Membrane allow passage of anions only





# **Electrodialysis**

- Under the influence of electric field, ions migrate towards
   Electrode with opposite sign
- Concentrated and dilute
   solution are created in
   alternate compartments



#### Anode and cathode reactions

- Reactions take place at each electrode.
- At the cathode,
- $2e^{-} + 2 H_{2}O \rightarrow H_{2}(g) + 2 OH^{-}$
- while at the anode,
- $H_2O \rightarrow 2 H^+ + \frac{1}{2} O_2(g) + 2e^- \text{ or }$
- $2 \text{ Cl}^- \rightarrow \text{Cl}_2(g) + 2e^-$
- Small amounts of hydrogen gas are generated at the cathode and small amounts of either oxygen or chlorine gas (depending on composition of the E stream) at the anode.
- These gases are typically subsequently dissipated as the E stream effluent from each electrode compartment is combined to maintain a neutral pH and discharged or re-circulated to a separate E tank.
- Some researchers have proposed collection of hydrogen gas for use in energy production.




# **Applications of Electrodialysis**

- •In almost all practical electrodialysis processes, multiple electrodialysis cells are arranged into a configuration called an electrodialysis stack, with alternating anion and cation exchange membranes forming the multiple electrodialysis cells.
- •Removal of ionic pollutants from treated industrial waste.
- Removal of salt from water.
- Removal of limited quantity of salts from sea water.



#### **Reverse Osmosis**

- In RO process solvent molecules travel from high region of solute concentration to low solute concentration through semi-permeable membrane.
- External pressure is applied through high solute concentration compartment
- Most commonly used RO membranes are typically composed by a thin film composite membrane consisting of three layers: a polyester support web, a microporous polysulfone interlayer and an ultra thin polyamide barrier layer on the top surface.





#### **Reverse Osmosis**

- •External applied pressure is greater than osmotic pressure (Typical pressures for brackish water range from 1.6 to 2.6 MPa (225 to 376 psi). In the case of seawater, they range from 5.5 to 8 MPa (800 to 1,180 psi)).
- •Semi permeable membrane made up from polymeric materials like acrylics, polyamides, aramids.
- •Membrane allow only passage of water molecules (Selective Porosity) and other impurities are rejected.
- Water gets separated from contaminants



# **Advantages of RO Process**

- •lonic, colloidal, non-ionic impurities removed from water.
- •Pure water for high pressure boiler can be obtained.
- Used to obtain drinking mineral water.
- Simple to operate.
- Low cost process.

## **Numericals**

- •Q1. An exhausted zeolite softener was regenerated by passing 150 L of NaCl solution having strength of 150 g/L. If the hardness of water is 600 ppm, then calculate the total volume of water that can be softened by this zeolite.
- Amount of NaCl = 22500 g
- Amt of CaCO3 =  $22500 \times 0.855 g = 1.92 \times 10^7 mg$
- Volume =  $1.92 \times 10^7 \,\text{mg}/600 = 32051 \,\text{L}$

- Q2. A sample of water on analysis, gave the following data:
- $Ca(HCO_3)_2 = 10.5 \text{ ppm}, CaSO_4 = 7.5 \text{ ppm}$
- $CaCl_2 = 8.2 \text{ ppm}, \quad Mg(NO_3)_2 = 2.6 \text{ ppm}$
- Calculate the temporary and permanent hardness of the water sample.