# **Experiment No: 01 and 02**

- 1. Simple Assembly language programming.
- a. Write assembly language program for addition of two 8-bit numbers.
- b. Write assembly language program for addition of N 8-bit numbers. Take the input numbers

from memory and store result in memory.

- 2. Complex Assembly language programming.
- a. Find square of a number using DPTR.

```
// 1 - Addition of n 8-bit numbers
MOV R0,#30H; pointer to memory
MOV R1,#05H; counter
MOV 36H,#00H; initialize sum=0
MOV 35H, #00H; initialize carry=0
MOV A, #00H;
L2:ADD A,@R0; A=A+@R0
DA A
JNC L1
INC 35H; store carry
L1: INC RO; point to next loc
DJNZ R1,L2
MOV 36H,A;
L3:SJMP L3;
END
// 2 - Square of a number with DPTR
MOV R0,#30H;
MOV A,@R0;
MOV DPTR,#2000H;
MOVC A,@A+DPTR;
MOV 31H, A;
L1:SJMP L1
ORG 2000H
   DATA1: DB 0,1,4,9,16,25,36,49,64,81,100
END
  3- Addition of two 16-bit numbers
```

```
MOV A,30H; A=LB1
ADD A,31H; A=A+LB2=LBR
MOV 36H,A; LBR STR
CLR A;
MOV A,32H; A=HB1
ADDC A,33H; A=A+HB2=HBR
MOV 35H,A; HBR STR
JNC L1;
INC 34H; INCREMENT CARRY
L1:SJMP L1;
END
*****
// 4 - Finding No.of ODD and EVEN Nos. from set of 10 numbers
MOV R0,#30H
MOV R1,30AH
MOV 0BH,R1
MOV R2, OBH
MOV 3AH, #00H
MOV 3BH, #00H
L2:MOV A,@R0
RRC A
JNC L1
INC 3AH
L1:INC R0
DJNZ R1,L2
CLR C
MOV A, R2
SUBB A,3AH
MOV 3BH,A
L3:SJMP L3
END
//5 - Finding No.of Positive and Negative Integers from set of 10 numbers
MOV R0,#30H
MOV R1,#OAH
MOV OBH, R1
MOV R2, OBH
MOV 3AH,#00H
MOV 3BH,#00H
L2:MOV A,@RO
RLC A
JNC L1
INC 3AH
L1:INC R0
DJNZ R1,L2
```

CLR C
MOV A,R2
SUBB A,3AH
MOV 3BH,A
L3:SJMP L3
END

# EXP-3 Interfacing of LED, Buzzer, Relay and Switch with C8051F340

Write C program for interfacing of LED, Buzzer, Relay and Switch with C8051F340 to turn it ON when key is pressed

## **LED Interfacing**

```
#include"C8051F340.h"
#define LED P4
sbit key3=P1^2;
sbit key4=P1^3;
sbit Relay=P1^4;
sbit Buzzer=P3^3;
void main()
XBR1=0X40;
P1MDIN=0X0C;
P3MDOUT=0X80;
P1MDOUT=0X10;
P4MDOUT=0XFF;
while(1){
    if(key3==0){
        while(1){
            Relay = 0;
            Buzzer = 1;
            LED = 0x00;
            if(key4==0){
                    break;
    if(key3==0){
        while(1){
                LED = 0XFF;
                Relay = 1;
                Buzzer = 0;
                if(key4==0){
                    break;
```

# **EXP-4 Interfacing of LCD**

Write C program for interfacing of 16x2 LCD with C8051F340 in 8-bit mode

#### **Basic LCD interfacing**

```
#include"c8051f340.h"
void DelayMs(unsigned int Ms);
void Write_command_LCD(unsigned char character);
void Write_Data_LCD(unsigned char name);
sbit LCD_RS=P1^5;
sbit LCD_RW=P1^6;
sbit LCD_EN=P1^7;
void main()
    XBR1=0x40;
    P2MDOUT=0xFF;
    P1MDOUT=0xE0;
    Write_command_LCD(0x38);
    DelayMs(50);
    Write_command_LCD(0x01);
    DelayMs(50);
    Write_command_LCD(0x0C);
    DelayMs(50);
    Write_command_LCD(0x80);
    DelayMs(50);
    Write_Data_LCD('W');
    DelayMs(50);
    Write_Data_LCD('P');
    DelayMs(50);
    Write_Data_LCD('U');
    DelayMs(50);
    while(1);
void DelayMs(unsigned int Ms)
    unsigned int n;
    unsigned int i;
    for(n=0;n<Ms;n++)</pre>
        for(i=0;i<65;i++);
    }
void Write_Command_Lcd(unsigned char command)
    LCD_RS=0;
    LCD RW=0;
```

```
P2=command;
LCD_EN=1;
DelayMs(15);
LCD_EN=0;
}

void Write_Data_LCD(unsigned char character)
{
    LCD_RS=1;
    LCD_RW=0;
    P2=character;
    LCD_EN=1;
    DelayMs(15);
    LCD_EN=0;
}
```

#### LCD interfacing/displaying name Shreerang in 8-bit

```
#include"c8051f340.h"
void DelayMs(unsigned int Ms);
void Write_command_LCD(unsigned char character);
void Write_Data_LCD(unsigned char name);
sbit LCD_RS=P1^5;
sbit LCD_RW=P1^6;
sbit LCD_EN=P1^7;
void main()
    unsigned char name[]={"SHREERANG"};
    int i;
    XBR1=0x40;
    P2MDOUT=0xFF;
    P1MDOUT=0xE0;
    Write_command_LCD(0x38);
    DelayMs(50);
    Write_command_LCD(0x01);
    DelayMs(50);
    Write_command_LCD(0x0C);
    DelayMs(50);
    Write_command_LCD(0x80);
    DelayMs(50);
    for(i=0;name[i]!='\0'; i++)
```

```
Write_Data_LCD(name[i]);
        DelayMs(50);
   while(1);
void DelayMs(unsigned int Ms)
    unsigned int n;
   unsigned int i;
   for(n=0;n<Ms;n++)</pre>
        for(i=0;i<65;i++);
void Write_Command_Lcd(unsigned char command)
    LCD_RS=0;
    LCD_RW=0;
    P2=command;
    LCD_EN=1;
   DelayMs(15);
    LCD_EN=0;
void Write_Data_LCD(unsigned char character)
    LCD_RS=1;
    LCD_RW=0;
    P2=character;
    LCD_EN=1;
   DelayMs(15);
    LCD_EN=0;
```

#### LCD interfacing/displaying name Shreerang in 4-bit

```
#include"c8051f340.h"
void DelayMs(unsigned int Ms);
void Write_command_LCD(unsigned char character);
void Write_Data_LCD(unsigned char name);
sbit LCD_RS=P1^5;
sbit LCD_RW=P1^6;
sbit LCD_EN=P1^7;
void main()
    unsigned char name[]={"SHREERANG"};
    int i;
    XBR1=0x40;
    P2MDOUT=0xFF;
    P1MDOUT=0xE0;
    Write_command_LCD(0x28);
    DelayMs(50);
    Write_command_LCD(0x01);
    DelayMs(50);
    Write_command_LCD(0x0C);
    DelayMs(50);
    Write_command_LCD(0x80);
    DelayMs(50);
    for(i=0;name[i]!='\0'; i++)
        Write_Data_LCD(name[i]);
        DelayMs(50);
    while(1);
void DelayMs(unsigned int Ms)
    unsigned int n;
    unsigned int i;
    for(n=0;n<Ms;n++)</pre>
        for(i=0;i<65;i++);
void Write_Command_Lcd(unsigned char command)
    P2=(command \& 0xF0);
    LCD_RS=0;
    LCD_RW=0;
    LCD EN=1;
```

```
DelayMs(15);
    LCD_EN=0;
   P2=(command & 0x0F)<<4;
    LCD_RS=0;
    LCD_RW=0;
    LCD_EN=1;
   DelayMs(15);
    LCD_EN=0;
void Write_Data_LCD(unsigned char character)
   P2=(character & 0xF0);
    LCD_RS=1;
    LCD_RW=0;
    LCD_EN=1;
   DelayMs(15);
    LCD_EN=0;
   P2=(character & 0x0F)<<4;
    LCD_RS=1;
    LCD_RW=0;
    LCD_EN=1;
   DelayMs(15);
   LCD_EN=0;
```

# **EXP-5 Interfacing of 8-bit DAC**

Write C program for interfacing of 8 bit DAC with C8051F340 to generate

- i) Square wave
- ii) Triangular wave
- iii) Sawtooth

# **DAC Interfacing for Square Waveform**

```
#include"c8051f340.h"
void delay(unsigned int Ms);
void main(){
    P4MDOUT=0xff;
    while(1){
        P4=~P4;
            delay(50);
    }
}
void delay(unsigned int Ms){
    unsigned int n;
    unsigned int i;
    for(n=0;n<Ms;n++){
        for(i=0;i<65;i++);
    }
}</pre>
```

#### **DAC Interfacing for Triangular Waveform**

```
#include"c8051f340.h"
void main(){
    int i;
    P4MDOUT=0xff;
    while(1){
        for(i=0; i<=254;i++){
            P4=i;
        }
        for(i=255; i>=1; i--){
            P4=i;
        }
    }
}

void delay(unsigned int Ms){
    unsigned int n;
    unsigned int i;
    for(n=0;n<Ms;n++){
        for(i=0;i<65;i++);
    }
}</pre>
```

# **DAC Interfacing for Sawtooth Waveform**

```
#include"c8051f340.h"

void main(){
    int i;
    P4MDOUT=0xff;
    while(1){
        for(i=0; i<=254;i++){
            P4=i;
        }
    }
}

void delay(unsigned int Ms){
    unsigned int n;
    unsigned int i;
    for(n=0;n<Ms;n++){
        for(i=0;i<65;i++);
    }
}</pre>
```

# **EXP-6 Interfacing of 8-bit ADC**

Write C program for programming of on chip ADC of C8051F340

```
#include "C8051F340.h"
#define SYSClk 12000000
sbit Buzzer= P3^3;
void delay(unsigned int Ms);
void main()
    XBR1= 0X40;
    P4MDOUT= 0XFF;
    www.mitwpu.edu.in
    Buzzer= 0;
    P2SKIP= 0X20;
    P2MDIN= 0XD0;
    AMX0P= 0X04;
    AMX0N = 0x1F;
    ADC0CF= (((SYSClk/3000000)-1)<<3);
    REF0CN= 0x08;
    ADCOCN= 0x80;
    AD0EN= 1;
        ADC0CN =0 \times 90;
        while (AD0BUSY == 1);
        delay(50);
        P4= ~ ADC0L;
        delay(50);
        P4= \sim ADC0H;
        delay(50);
while(1);
void delay(unsigned int Ms)
    unsigned int n;
    unsigned int i;
    for (n-0; n<Ms; n++)
        for (i=0; i<65; i++);
        www.mitwpu.edu.in
```

# EXP-7 Generation of PWM using C8051F340 to control speed of DC motor

Write C program to generation PWM using C8051F340 to control speed of DC motor

```
#include "c8051f340.h"
#define SYSCLK 3000000
void main(){
    PCA0L=0 \times 10;
    OSCICN=0x83;
    CLKSEL=0x00;
    XBR1=0x41;
    P2MDOUT=0x08;
    P0SKIP=0xff;
    P1SKIP=0xff;
    P2SKIP=0x07;
    while(1){
        PCA0MD=0x02;
        PCA0CPM0=0x42;
        PCA0CPH0=(256-(256*0.75));
        CR=1;
```

# **EXP-8 Implement UART with C8051F340**

Write a C program for serial communication using C8051F340 to transfer data from C8051F340 to PC

#### Tranmission program for Uart with C8051F340

```
#include"c8051f340.h"
#define sysclk 12000000
#define BR_UART0 9600
void main()
    char ch[]=("SUGANDH");
    int i;
    OSCICN = 0X80;
    XBR0=0X01;
    XBR1=0X40;
    P0MDOUT=0X10;
    SCON0=0X00;
    CKCON=0X01;
    TH1=256-(sysclk/BR_UART0/2/4);
    TH1=TL1;
    TMOD=0 \times 20;
    TR1=1;
    while(1)
        for(i=0;ch[i]!='\0';i++)
            SBUF0=ch[i];
            while(TI0==0);
```

## **Reciving program for Uart with C8051F340**

```
#include"c8051f340.h"
#define sysclk 12000000
#define BR_UART0 9600
sbit BUZZER=P3^3;
void main()
    OSCICN = 0X83;
    XBR0=0X01;
    XBR1=0X40;
    P3MDOUT=0X08;
    BUZZER=1;
    P0MDIN=0X20;
    P4MDOUT=0xFF;
    SCON0=0X10;
    CKCON=0X01;
    TH1=256-(sysclk/BR_UART0/2/4);
    TH1=TL1;
    TMOD=0 \times 20;
    TR1=1;
    while(RI0==0)
        P4=~SBUF0;
        RI0=0;
```

# **EXP-9 Interfacing of Stepper motor with C8051F340**

## **Code for Full Stepping in Clockwise Direction**

```
#include "C8051F340.h"
void delay(unsigned int Ms);
void main()
{
    char a[4]={0x02, 0x20, 0x80, 0x08};
    int i;
    P4MDOUT=0xFF;
    while(1)
    {
        for(i=0; i<4;i++)
        {
            P4=a[i];
            delay(60);
        }
    }
}
void delay(unsigned int Ms)
{
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)
    {
        for(j=0;j<65;j++);
    }
}</pre>
```

## **Code for Full Stepping in Anti Clockwise Direction**

```
#include "C8051F340.h"
void delay(unsigned int Ms);
void main()
{
    char a[4]={0x02,0x08, 0x80, 0x20};
    int i;
    P4MDOUT=0xFF;
    while(1)
    {
        for(i=0; i<4;i++)
        {
             P4=a[i];
             delay(60);
        }
    }
}
void delay(unsigned int Ms)
{
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)
    {
        for(j=0;j<65;j++);
    }
}</pre>
```

## **Code for Half Stepping in Clockwise Direction**

```
#include "c8051F340.h"
void delay(unsigned int Ms);
void main()
{
    char a[]={0x02, 0x22, 0x20, 0xA0,0x80,0x80,0x88,0x0C};
    int i;
    P4MDOUT=0xFF;
    while(1)
    {
        for(i=0; i<8;i++)
        {
            P4=a[i];
            delay(60);
        }
    }
}
void delay(unsigned int Ms)
{
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)
    {
        for(j=0;j<65;j++);
    }
}</pre>
```

## **Code for Half Stepping in Anti Clockwise Direction**

```
#include "c8051F340.h"
void delay(unsigned int Ms);
void main()
{
    char a[]={0x02, 0x0A, 0x08, 0x88,0x80,0xA0,0x20,0x22};
    int i;
    P4MDOUT=0xFF;
    while(1)
    {
        for(i=0; i<8;i++)
        {
            P4=a[i];
            delay(60);
        }
    }
}
void delay(unsigned int Ms)
{
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)
    {
        for(j=0;j<65;j++);
    }
}</pre>
```