

Multiple Access

Data Link Layer: Two sublayers

- Dedicated point to point link may not be available in all cases
- Many users have to use same link
- Data link layer divided into two functionality-oriented sublayers:
 - LLC
 - MAC
- IEEE made this division for LANs




Medium Access Protocols




Random Access (Contention)

- Each station has the right to use the medium without being controlled by any other station
- Collision, a access conflict, if more than one station tries to send




ALOHA

- The earliest random access method developed at the University of Hawaii in the early 1970s
- Designed for a radio (wireless) LAN
- Pure ALOHA and Slotted ALOHA
- Frames in a pure ALOHA network




Pure ALOHA Protocol: Procedure

Binary Exponential Back-off Algorithm



Pure ALOHA Protocol


• Pure ALOHA vulnerable time = $2 \times T_{fr}$



- The throughput for pure ALOHA is $S = G \times e^{-2G}$ where G is average number of frames generated by the system during one transmission time.
- The maximum throughput $S_{max} = 0.184$ when G = (1/2).


Slotted ALOHA

- Pure ALOHA vulnerable time = $2 \times T_{fr}$ because there is no rule that defines when the station can send
- Slotted ALOHA was invented to improve the efficiency of pure ALOHA




Slotted ALOHA

- Throughput for slotted ALOHA is $S = G \times e^{-G}$.
- The maximum throughput $S_{max} = 0.368$ when G = 1
- Slotted ALOHA vulnerable time = T_{fr}




Carrier Sense Multiple Access (CSMA)

- CSMA
- Sense before Transmit
- Listen before Talk
- CSMA can reduce the possibility of collision, but it can not eliminate it




Collision in CSMA




CSMA: Vulnerable Time

 Vulnerable time for CSMA is the propagation time Tp needed for a signal to propagate from one end of the medium to the other




CSMA: Persistence Methods

 Behavior of 1-persistent, Nonpersistent, p-persistent method



CSMA: Persistence Methods


 Flow diagram for 1-persistent, Nonpersistent, ppersistent method




Persistence Strategy

- 1-persistent
 - Increases the chance of collision
- Non-persistent strategy
 - Reduces the chance of collision
 - Reduces the efficiency of the network
- p-persistent
 - Reduces the chance of collision and improves the efficiency by combining the other two strategies.

CSMA/CD (Collision Detection)






CSMA/CD: Min. Frame Size

• Example: A network using CSMA/CD has a bandwidth of 10 Mbps. If the maximum propagation time (including the delays in the devices and ignoring the time needed to send a jamming signal, as we see later) is $25.6 \,\mu\text{s}$, what is the minimum size of the frame?

Solution


The frame transmission time is $T_{fr} = 2 \times T_p = 51.2 \,\mu s$. This means, in the worst case, a station needs to transmit for a period of 51.2 μs to detect the collision. The minimum size of the frame is 10 Mbps \times 51.2 $\mu s = 512$ bits or 64 bytes. This is actually the minimum size of the frame for Standard Ethernet.

CSMA/CD: Flow Diagram



CSMA/CD: Energy Level & Throughput


Energy level during transmission, idleness, or collision



- Throughput of CSMA/CD is greater than that of ALOHA
- The max. throughput occurs at a different value of G and is based on the persistent method and the value of p in the p-persistent approach
- The max throughput is around 50% when G = 1 for 1-persistent, up to 90% when G is between 3 and 8 for non-persistent


CSMA/CA (Collision Avoidance)

- Invented for wireless network where we cannot detect collisions
- Collision are avoided through the use of CSMA/CA's three strategies: the interframe space, the contention window, and acknowledgement




- IFS can also be used to define the priority of a station or a frame
- During the contention window, if the station finds the channel busy, it does not restart the timer of the contention window; it stops the timer and restarts it when the channel becomes idle

CSMA/CA: Flow Diagram




Controlled Access

- The stations consult one another to find which station has the right to send
- Reservation/Polling/ Token passing
- Reservation access method




Polling: Select and Poll Functions




Token Passing


• Logical Ring and Physical Topology




a. Physical ring



c. Bus ring



b. Dual ring




d. Star ring

Channelization: FDMA

FDMA

- Available bandwidth of the common channel is divided into bands that are separated by guard bands
- FDMA is an access method in data link layer protocol. But, FDM is a physical layer technique



Channelization: TDMA

TDMA

- The bandwidth is just one channel that is timeshared between different stations

- TDMA is an access method. But, TDM is a physical layer

