Hex file creation using Keil uVision

WEL Labs, IITB

2016

Programming



Development Tools

- **Coding – Editor => Entry of code into file(s)**
- **Translation – Assembler or Compiler**
  => Generate machine code from source code
- **Program – Programmer**
  => Put machine code in the chip
- **Execution check – using Debugger to verify operation of program (on Hardware**
  or Simulator)

Single Point Solution?

Keil uVision IDE

- **µVision**

  an easy-to-use **IDE** (Integrated Development Environment)
  - Project management,
  - Source code editing,
  - Code building facilities,
  - Run-time environment,
  - Program debugging

Since 1982

Acquisition by

Around 2005

Now providing

Keil uVision IDE …

- **Project :** A **collection of files related to a particular programming task**.
- **Build :** The process in which **only the files modified since last build** are assembled/compiled for the chosen microcontroller device
- **Rebuild :** The process in which **all files** **are assembled/compiled** irrespective of their modification state.

Double click on the icon to start
“keil uVision5” or “keil uVision4”


µVision
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
New µVision Project...
New Multi-Project Workspace...
Open Project...
Close Project
Export
Manage
Select Device for Target ...
Remove Item
Options... Alt+F7
Clean Targets
Build Target F7
Rebuild all target files
Batch Build...
Translate... Ctrl+F7
Stop build
1 C:\Users\suryakant\Downloads\NrfCode\ExNewS110\ble_uarts110\ble_app_hrs\pca10028\ser_s110_uart\arm5\ble_app_hrs_s110_uart_pca10028.uvprojx
2 C:\Users\suryakant\Downloads\NrfCode\ExNewS110\ble_uarts110\ble_connectivity\pca10028\ser_s110_uart\arm5\ble_connectivity_s110_uart_pca10028.uvprojx
3 C:\Users\suryakant\Downloads\NrfCode\ExNewS110\blinky\pca10028\s110\arm5\blinky_s110_pca10028.uvprojx
4 C:\Users\suryakant\Downloads\NrfCode\ExNewS110\peripheral\blinky\pca10028\blank\arm5\blinky_blank_pca10028.uvprojx
5 C:\Users\suryakant\Downloads\NrfCode\hids_mouses110\ble_app_hids_mouse\pca10028\s110\arm5\ble_app_hids_mouse_s110_pca10028.uvprojx
6 C:\Users\suryakant\Downloads\NrfCode\ExNewS110\peripheral\blinky\pca10028\s110\arm5\blinky_s110_pca10028.uvprojx
7 C:\Keil_v5\ARM\Pack\NordicSemiconductor\nRF_Examples\8.0.0\peripheral\bl1\pca10028\blank\arm5\blinky_blank_pca10028.uvprojx
8 C:\Users\suryakant\Downloads\NrfCode\Test1\T1.uvprojx
9 C:\Users\suryakant\Downloads\NrfCode\Exagain\peripheral\blinky\pca10028\s110\arm5\blinky_s110_pca10028.uvprojx
10 C:\Users\suryakant\Downloads\NrfCode\Exagain\peripheral\blinky\pca10028\blank\arm5\blinky_blank_pca10028.uvprojx
We start by creating a new project.
Project
Build Output
Create a new µVision project
CAP NUM SCRL OVR
Start
5:18 PM
7/11/2016


C:\Keil_v5\C51\Examples\Hello\Hello.uvproj - µVision
Create New Project
« C51 › Examples › HELLO
Search HELLO
Organize
New folder
This PC
Desktop
Documents
Downloads
Music
Pictures
Videos
OS (C:)
D drive (D:)
CD Drive (E:)
Name
Date modified
Type
Hello.uvproj
14-03-2016 08:59
µVision4
File name: project1
Save as type: Project Files (*.uvproj *.uvprojx)
Hide Folders
Save
Cancel
Specify Name of your project;
One can add several files under a project
Project
Books
Functions
Templates

Creating a New Project



- Select “No” for programs in Assembly language.

- Startup.A51 is a file for programs in C. It is used to setup the proper memory areas like Code, Data and Stack for use.


C:\Keil_v5\C51\Examples\Hello\Hello.uvproj - µVision
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
New µVision Project...
New Multi-Project Workspace...
Open Project...
Close Project
Export
Manage
Select Device for Target 'Simulator'...
Remove File 'HELLO.C'
Options for File 'HELLO.C'... Alt+F7
Clean targets
Build target F7
Rebuild all target files
Batch Build...
Translate C:\Keil_v5\C51\Examples\Hello\HELLO.C Ctrl+F7
Stop build
1 C:\Keil_v5\C51\Examples\Hello\Hello.uvproj
2 C:\Keil_v5\C51\Examples\Measure\MEASURE.uvproj
3 C:\Keil_v5\C51\RtxTiny2\Examples\Traffic\TRAFFIC.uvproj
4 C:\Keil_v5\C51\Examples\Blinky\BLINKY.uvproj
5 C:\Keil_v5\C51\Examples\CSample\CSAMPLE.uvproj
6 C:\Keil_v5\C51\Examples\Infineon XC822\BOOST_LEDTS\Boost1.uvproj
7 C:\Keil_v5\C51\Examples\Infineon XC836\Alarm_Clock\Alarm_Clock.uvproj
8 C:\Keil_v5\C51\Examples\Infineon XC864\Blinky\Blinky.uvproj
9 C:\Keil_v5\C51\Examples\Infineon XC866\Blinky\Blinky.uvproj
10 C:\Keil_v5\C51\Examples\R8051XC\XBanking\R8051XC_XBanking.uvproj
One can Open existing project too…
Project
Project: Hell
Simulato
Sour
Docu
Project Books Functions Templates
#endif


C:\Keil_v5\C51\Examples\HELLO\project1.uvproj - µVision
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Target 1
Project
Select Device for Target 'Target 1'...
CPU
Vendor: Atmel
Device: AT89LV55
Toolset: C51
Search:
Use Extended Linker (LX51) instead of BL51
Use Extended Assembler (AX51) instead of A51
Description:
AnchorChips
Atmel
Cadence Design Systems Inc.
CAST, Inc.
CML Microcircuits
CORERIVER
8051-based Low-voltage 12 MHz CMOS controller with 32 I/O Lines,
3 Timers/Counters, 8 Interrupts/2 Priority Levels, UART,
Three-Level Program Memory Lock, 20K Bytes Flash Memory,
256 Bytes On-chip RAM
Help
Pt-51 uses Atmel
microcontroller.
Project Books Functions Templates
Simulation
L:1 C:1
CAP N
Search the web and Windows
ENG
15:15
09-07-2016


C:\Keil_v5\C51\Examples\HELLO\project1.uvproj - µVision
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Target 1
Project
Select Device for Target 'Target 1'...
CPU
Vendor: Atmel
Device: AT89C5131A
Toolset: C51
Search:
Use Extended Linker (LX51) instead of BL51
Description:
8051-based microcontroller with Full Speed USB Device,
Dual Data Pointers, Enhanced UART, 3 16-bit Timers,
5 Channels PCA, WDT, 34 I/O lines, SPI, USB Module,
32 kBytes ISP Flash ROM, 1280 Bytes RAM
AT89C2051
AT89C4051
AT89C51
AT89C5115
AT89C5130
AT89C5130A
AT89C5131
AT89C5131A
AT89C5132
AT89C51AC3
OK
Cancel
Help
Details of the microcontroller
We use AT89C5131A from Atmel
Project
Books
Functions
Templates
Simulation
L:1 C:1
CAP N
Search the web and Windows
ENG
15:17
09-07-2016

Configuring the Project target options



Click on this icon or press "Alt+F7"

to configure the target options

Configuring the Crystal frequency



Creating HEX file



Click this Tick box to create Hex file

Finally Click on OK to save these Options chosen for this project


E:\ACADEMIC\PG\RA\pt-51\programs\a.uvproj - µVision4
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
New... Ctrl+N
Open Ctrl+O
Close
Save Ctrl+S
Save As...
Save All
Device Database...
License Management...
Print Setup...
Print... Ctrl+P
Print Preview
1 C:\Keil\...\Hello\HELLO
2 E:\ACADEMIC\...\ES\lab\GCD
3 E:\ACADEMIC\...\ES\lab\MOVDAT
4 E:\ACADEMIC\...\ES\lab\STRCPY
5 E:\ACADEMIC\...\ES\lab\STRREV
6 E:\ACADEMIC\...\ES\lab\MATMUL
7 E:\ACADEMIC\...\ES\lab\CONV
8 E:\ACADEMIC\...\MATMUL
9 C:\Users\...\Pandey_123\MATMUL
10 C:\Users\...\Pandey_123\STRCPY
Exit
To create a new source file
Project Books Functions Templates



1. Type here the code for your program in this window.

2. Save the file as **<<file name>>.asm** for for assembly language programs) or as **<<file name>>.c** for C programs.


E:\ACADEMIC\PG\RA\pt-51\programs\a.uvproj - µVision4
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Target 1
Project
Target 1
Source Group 1
simple_move.asm
1 src equ 30h
2 dst equ 40h
3 cnt equ 5
4
5 mov r0,#src
6 mov r1,#dst
7 mov r2,#cnt
8
9 back: mov a,@r0
10 mov @r1,a
11 inc r0
12 inc r1
13
14 djnz r2,back
15
16 loop: sjmp loop
17
18 end
A saved assembly file for use with the 8051 microcontroller family
Notice the different colors used for assembler directives, opcodes, registers, data, etc by the IDE.
Project
Books
Functions
Templates


E:\ACADEMIC\PG\RA\pt-51\programs\a.uvproj - µVision4
File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
Target 1
Project
Target 1
Source Group 1
Options for Group 'Source Group 1'... Alt+F7
Open File
Open List File
Open Map File
Rebuild all target files
Build target F7
Translate File
Stop build
Add Group...
Add Files to Group 'Source Group 1'...
Remove Group 'Source Group 1' and its Files
Manage Components...
Show Include File Dependencies
simple_move.asm
src equ 30
dst equ 4
cnt equ 5
mov r0,#s
mov r1,#d
mov r2,#c
djnz r2,b
loop: s
end
Project Books Functions Templates
To compile/build the code we need to add the ".asm" file to the project.
1. Right click on Source Group 1
2. Select Add files to Group Source Group 1
3. Select the proper file in the file selection dialog box


File Edit View Project Flash Debug Peripherals Tools SVCS Window Help
New µVision Project...
New Multi-Project Workspace...
Open Project...
Close Project
Export
Manage
Select Device for Target 'Target 1'...
Remove Item
Options for Target 'Target 1'...
Clean target
Build target
Rebuild all target files
Batch Build...
Translate E:\ACADEMIC\PG\RA\pt-51\programs\simple_move.asm Ctrl+F7
Target 1
Source G
simp
Project
Books
Functions
Templates
Rebuild - two ways :
1.Click the Rebuild button
2.Use Menu
Project => Rebuild all target files
Build Program - Multiple ways :
1.Click the build button
2.Use Menu
Project => Build target
3.Press F7 function key on keyboard



At the end of the “Build” / “Rebuild” process, the compilation results are presented in the Build Output window consisting of:

1. warnings or errors if any
2. program and Data size
3. status of Hex file creation

Neglecting warnings may give wrong program results.

In case of errors we go back to program editing phase and update the program to run in error free manner.

Questions ?

Thank you

WEL Labs, IITB

2016

For doubts/errors in this PPT contact :
Suryakant Toraskar e-mail: smtoraskar.iitbombay@gmail.com location : WEL5