Name: Shreya Mamadapur Student ID:

C0774035

Instructor: Takis Zourntos

Theory: In signal processing, a finite impulse response (FIR) filter is a filter whose impulse The response is of finite length duration because it settles to zero in finite time. FIR filters have a linear phase, are stable and are typically easy to design and implement.

#### INTRODUCTION

In this report, we will learn how to implement FIR filters using window techniques like Hann, Hamming, Kaiser etc.


#### DISCUSSION

The basic idea behind the window design is to choose a proper ideal frequency-selective filter (which always has a noncausal, infinite-duration impulse response) and then to truncate (or window) its impulse response to obtain a causal linear-phase FIR filter.

Therefore the emphasis in this method is on selecting an appropriate windowing function and an appropriate ideal filter.

We will denote an ideal frequency-selective filter by  $Hd(ej\omega)$ , which has a unity magnitude gain and linear-phase characteristics over its passband, and zero response over its stopband

To obtain an FIR filter of length M from hd(n), one has to truncate hd(n). This operation is called "windowing". In general, h(n) can be thought of as being formed by the product of hd(n) and a window function w(n). Multiplication in time-domain is equivalent to periodic convolution in the frequency domain.



To limit the infinite sinc or say impulse function, we "window" it to a limited time/frequency. There are many techniques to do this. Rectangular, Hann, Hamming and Blackman methods are some popular methods. We have inbuilt functions for these in Matlab which takes an argument "M" or "L" (length of the filter). Greater the length, charger the roll-off/transition width of the filter.

Definitions of three popular windows

Hanning window:

$$w(n) = \begin{cases} 0.5 \ \left(1 - cos \frac{2\pi n}{M-1}\right), & \text{for } n=0 \text{ to } N-1 \\ 0, & \text{elsewhere} \end{cases}$$

Hamming window:

$$w(n) = \begin{cases} \left(0.54 - 0.46 cos\left(\frac{2\pi n}{N}\right)\right), & \text{for } n = 0 \text{ to } N-1 \\ 0, & \text{elsewhere} \end{cases}$$

Blackman window:

$$w(n) = \begin{cases} (0.42 - 0.5\cos(\frac{2\pi n}{N})) + 0.08\cos(\frac{4\pi n}{N}), & \text{for } n = 0 \text{ to } N - 1\\ 0, & \text{elsewhere} \end{cases}$$

These window functions are all the "fixed window functions" meaning that for a specific M, we will have a fixed transition width.

Window Name	Transition Width $\Delta \omega$		Min. Stopband
	Approximate	Exact Values	Attenuation
Rectangular	$\frac{4\pi}{M}$	$\frac{1.8\pi}{M}$	21 dB
Bartlett	$\frac{8\pi}{M}$	$\frac{6.1\pi}{M}$	$25~\mathrm{dB}$
Hann	$\frac{8\pi}{M}$	$\frac{6.2\pi}{M}$	$44 \; \mathrm{dB}$
Hamming	$\frac{8\pi}{M}$	$\frac{6.6\pi}{M}$	$53~\mathrm{dB}$
Blackman	$\frac{12\pi}{M}$	$\frac{11\pi}{M}$	$74~\mathrm{dB}$

We use these formulas in our script to get the length of the filter with the desired roll-off rate.

In the scripts in the Appendix, we are basically getting the desired h(n) by multiplying the appropriate ideal\_filter response hd(n) with the window function w(n). A function is written for an ideal Low-pass filter and response for BPF, HPF and BSF can be easily obtained from the LPF itself. And, window functions are obtained by the built-in functions in Matlab.

### **CONCLUSION**

Gained insights on the windowing techniques and successfully designed various FIR filters.


#### APPENDIX


xlabel('n'); ylabel('h(n)');


```
1. Design a bandpass filter using the Hamming window design technique. The
specifications are
Lower stopband edge: 0.3\pi
Upper stopband edge: 0.6\pi As = 50 dB
Lower passband edge: 0.4\pi
Upper passband edge: 0.5\pi Rp = 0.5 dB
Plot the impulse response and the magnitude response (in dB) of the designed
filter. Do not use the fir1 function.
ANSWER
Script:
clc; clear; close all;
%Filter specs
ws1=0.3*pi;
wp1=0.4*pi;
wp2=0.5*pi;
ws2=0.6*pi;
 Rp=0.5; Rs=50;
roll_off = min((wp1-ws1),(ws2-wp2));
wc1 = (ws1+wp1)/2; wc2 = (wp2+ws2)/2; %cut-off frequencies
M = ceil(6.6*pi/roll_off) + 1 %For hamming window mthd roll-off is 6.6*pi/M
 n=[0:M-1];
 hd = ideal_lp(wc2,M)-ideal_lp(wc1,M); %BPF is combination of LPF & HPF(reverse LPF)
w_ham = (hamming(M)');
 h = hd \cdot * w_ham;
 [db,mag,pha,w] = freqz_m(h,[1]); delta_w = pi/500;
 Rpd = -min(db((wp1/delta_w)+1:(wp2/delta_w)+1)), % Actual passband ripple
 Asd = floor(-max(db(1:(ws1/delta_w)+1))), % Actual Attn
 figure; stem(n,w_ham); title('Hamming window');
xlabel('n'); ylabel('w(n)');
figure; stem(n,hd); title('Ideal impulse response');
 xlabel('n'); ylabel('hd(n)');
figure; stem(n,h); title('Hamming filtered impulse response');
```

```
figure; plot(w/pi,db,'linewidth',1); title('Magnitude response in dB');
xlabel('Frequency (w/pi)'); ylabel('deciBels');
function hd = ideal_lp(wc,M);
% Ideal lowpass filter computation
% -----
% [hd] = ideal lp(wc,M)
% hd = ideal impulse response between 0 to M-1
% wc = cutoff frequency in radians
%M = length of the ideal filter
alpha = (M-1)/2; n = [0:1:(M-1)];
m = n - alpha; fc = wc/pi; hd = fc*sinc(fc*m);
end
function [db,mag,pha,w] = freqz_m(b,a);
% Modified version of freqz subroutine
% -----
% [db,mag,pha,w] = freqz_m(b,a);
% db = relative magnitude in dB computed over 0 to pi radians
% mag = absolute magnitude computed over 0 to pi radians
% pha = phase response in radians over 0 to pi radians
%w = 501 frequency samples between 0 to pi radians
%b = numerator polynomial of H(z) (for FIR: b=h)
%a = denominator polynomial of H(z) (for FIR: a=[1])
[H,w] = freqz(b,a,1000,'whole');
H = (H(1:1:501))'; w = (w(1:1:501))';
mag = abs(H); db = 20*log10((mag+eps)/max(mag));
pha = angle(H);
figure; plot(mag); title('Magnitude response');
xlabel('Frequency in Hz'); ylabel('Magnitude');
end
```

# Result:







2. Design a highpass filter using one of the fixed window functions. The specifications are

Stopband edge:  $0.4\pi$ , As = 50 dB Passband edge:  $0.6\pi$ , Rp = 0.004 dB

Plot the zoomed magnitude response (in dB) of the designed filter in the passband to verify the passband ripple Rp. Do not use the fir1 function. <u>ANSWER</u>

### Script:

```
clc; clear; close all;
%filter specs
ws = 0.4*pi; wp = 0.6*pi; roll_off = wp - ws;
As= 50; Rp=0.004;

M = ceil(11*pi/roll_off) + 1 %using blackman window technique
n=[0:M-1];
wc = (ws+wp)/2, % Ideal filter cutoff frequency
hd = ideal_lp(pi,M)-ideal_lp(wc,M);
```


# <u>Lab 5 – FIR Filters</u>

```
w bman = (blackman(M))';
h = hd.*w_bman;
[db,mag,pha,w] = freqz_m(h,[1]); delta_w = pi/500;
Rp = -(min(db(1:1:wp/delta_w+1))); % Actual passband ripple
As = -round(max(db(ws/delta_w+1:1:501))) % Min stopband attenuation
figure; stem(n,w_bman); title('Blackman window');
xlabel('n'); ylabel('w(n)');
figure; stem(n,hd); title('Ideal impulse response');
xlabel('n'); ylabel('hd(n)');
figure; stem(n,h); title('Blackman window filtered impulse response');
xlabel('n'); ylabel('h(n)');
figure; plot(w/pi,db,'linewidth',1); title('Magnitude response in dB');
xlabel('Frequency (w/pi)'); ylabel('deciBels');
function hd = ideal_lp(wc,M);
% Ideal lowpass filter computation
% ------
% [hd] = ideal_lp(wc,M)
% hd = ideal impulse response between 0 to M-1
% wc = cutoff frequency in radians
%M = length of the ideal filter
alpha = (M-1)/2; n = [0:1:(M-1)];
m = n - alpha; fc = wc/pi; hd = fc*sinc(fc*m);
end
function [db,mag,pha,w] = freqz_m(b,a);
% Modified version of freqz subroutine
% -----
% [db,mag,pha,w] = freqz_m(b,a);
% db = relative magnitude in dB computed over 0 to pi radians
% mag = absolute magnitude computed over 0 to pi radians
% pha = phase response in radians over 0 to pi radians
% grd = group delay over 0 to pi radians
%w = 501 frequency samples between 0 to pi radians
%b = numerator polynomial of H(z)(for FIR: b=h)
%a = denominator polynomial of H(z) (for FIR: a=[1])
```

```
[H,w] = freqz(b,a,1000,'whole');
H = (H(1:1:501))'; w = (w(1:1:501))';
mag = abs(H); db = 20*log10((mag+eps)/max(mag));
pha = angle(H);
end
```

#### Result:

Magnified image to show the pass-band ripple



3. Design a linear-phase bandpass filter using the Hann window design technique.

The specifications are

Lower stopband edge: 0.2π

Upper stopband edge:  $0.75\pi$  As = 40 dB

Lower passband edge:  $0.35\pi$ 

Upper passband edge:  $0.55\pi$  Rp = 0.25 dB

Plot the impulse response and the magnitude response (in dB) of the designed


filter. Do not use the fir1 function.


### **ANSWER**


```
Script:
clc; clear; close all;
%filter specs
ws1=0.2*pi;
wp1=0.35*pi;
wp2=0.55*pi;
ws2=0.75*pi;
Rp=0.25; Rs=40;
t_width = min((wp1-ws1),(ws2-wp2)); %smallest roll-off is considered
wc1 = (ws1+wp1)/2; wc2 = (wp2+ws2)/2;
M = ceil(6.2*pi/t_width) + 1
n=[0:M-1];
hd = ideal_lp(wc2,M)-ideal_lp(wc1,M);
w_hann = (hann(M)');
h = hd .* w_hann;
[db,mag,pha,w] = freqz_m(h,[1]); delta_w = pi/500;
Rpd = -min(db((wp1/delta_w)+1:(wp2/delta_w)+1)), % Actual passband ripple
Asd = floor(-max(db(1:(ws1/delta_w)+1))), % Actual Attn
figure; stem(n,w_hann,'filled'); title('Hann window');
xlabel('n'); ylabel('w(n)');
figure; stem(n,hd); title('Ideal impulse response');
xlabel('n'); ylabel('hd(n)');
figure; stem(n,h); title('Hann filtered impulse response');
xlabel('n'); ylabel('h(n)');
figure; plot(w/pi,db,'linewidth',1); title('Magnitude response in dB');
xlabel('Frequency (w/pi)'); ylabel('deciBels');
function hd = ideal_lp(wc,M);
% Ideal lowpass filter computation
% ------
% [hd] = ideal_lp(wc,M)
% hd = ideal impulse response between 0 to M-1
% wc = cutoff frequency in radians
%M = length of the ideal filter
%
```

```
alpha = (M-1)/2; n = [0:1:(M-1)];
m = n - alpha; fc = wc/pi; hd = fc*sinc(fc*m);
end
function [db,mag,pha,w] = freqz_m(b,a);
% Modified version of freqz subroutine
% -----
% [db,mag,pha,grd,w] = freqz_m(b,a);
% db = relative magnitude in dB computed over 0 to pi radians
% mag = absolute magnitude computed over 0 to pi radians
% pha = phase response in radians over 0 to pi radians
%w = 501 frequency samples between 0 to pi radians
%b = numerator polynomial of H(z)(for FIR: b=h)
%a = denominator polynomial of H(z) (for FIR: a=[1])
[H,w] = freqz(b,a,1000,'whole');
H = (H(1:1:501))'; w = (w(1:1:501))';
mag = abs(H); db = 20*log10((mag+eps)/max(mag));
pha = angle(H);
figure; plot(mag); title('Magnitude response');
end
```

### Result:







4. Design a bandstop filter using the Hamming window design technique. The specifications are

Lower stopband edge:  $0.4\pi$ 

Upper stopband edge:  $0.6\pi$  As = 50 dB

Lower passband edge: 0.3π

Upper passband edge:  $0.7\pi$  Rp = 0.2 dB

Plot the impulse response and the magnitude response (in dB) of the designed filter. Do not use the fir1 function.


#### **ANSWER**


Script:

```
clc; clear; close all;
ws1=0.3*pi;
wp1=0.4*pi;
wp2=0.6*pi;
ws2=0.7*pi;
Rp=0.2; Rs=50;
roll_off = min((wp1-ws1),(ws2-wp2));
wc1 = (ws1+wp1)/2; wc2 = (wp2+ws2)/2;
M = ceil(6.6*pi/roll_off) + 1
n=[0:M-1];
hd = ideal_lp(pi,M)+ideal_lp(wc1,M)-ideal_lp(wc2,M);
w_ham = (hamming(M)');
h = hd .* w_ham;
[db,mag,pha,grd,w] = freqz_m(h,[1]); delta_w = pi/500;
Rpd = -min(db((wp1/delta w)+1:(wp2/delta w)+1)), % Actual passband ripple
Asd = floor(-max(db(1:(ws1/delta_w)+1))), % Actual Attn
figure; stem(n,w_ham); title('Hamming window');
xlabel('n'); ylabel('w(n)');
figure; stem(n,hd); title('Ideal impulse response');
xlabel('n'); ylabel('hd(n)');
figure; stem(n,h); title('Hamming filtered impulse response');
xlabel('n'); ylabel('h(n)');
figure; plot(w/pi,db,'linewidth',1); title('Magnitude response in dB');
```


```
xlabel('Frequency (w/pi)'); ylabel('deciBels');
function hd = ideal lp(wc,M);
% Ideal lowpass filter computation
% -----
% [hd] = ideal_lp(wc,M)
% hd = ideal impulse response between 0 to M-1
% wc = cutoff frequency in radians
%M = length of the ideal filter
%
alpha = (M-1)/2; n = [0:1:(M-1)];
m = n - alpha; fc = wc/pi; hd = fc*sinc(fc*m);
end
function [db,mag,pha,grd,w] = freqz_m(b,a);
% Modified version of freqz subroutine
% -----
% [db,mag,pha,grd,w] = freqz_m(b,a);
% db = relative magnitude in dB computed over 0 to pi radians
% mag = absolute magnitude computed over 0 to pi radians
% pha = phase response in radians over 0 to pi radians
% grd = group delay over 0 to pi radians
%w = 501 frequency samples between 0 to pi radians
%b = numerator polynomial of H(z) (for FIR: b=h)
%a = denominator polynomial of H(z) (for FIR: a=[1])
[H,w] = freqz(b,a,1000,'whole');
H = (H(1:1:501))'; w = (w(1:1:501))';
mag = abs(H); db = 20*log10((mag+eps)/max(mag));
pha = angle(H); grd = grpdelay(b,a,w);
figure; plot(mag); title('Magnitude response');
xlabel('Frequency in Hz'); ylabel('Magnitude');
%figure; plot(pha); title('Phase response');
%figure; plot(grd); title('Group delay');
end
```

# Result:





Lab 5 – FIR Filters



-----END OF DOCUMENT-----