Forklift battery charging (sample SOP)

1. Park the truck in the charging bay and set the brake.
2. Put on acid-resistant gloves and a face shield.
3. Check the vent caps and the electrolyte level.
4. Connect the charger only when it is switched off.
5. Charge to full without interrupting the cycle.
6. Switch off, disconnect and wipe the terminals.