



Shadow Tracker Vision III Installation Instructions

Introduction

The Shadow Tracker Vision III provides a very cost effective solution to real time vehicle tracking using GPS and GSM cellular technology. The very small unit is installed in a vehicle along with provided GPS and GSM antennas. A power cable that provides vehicle power to the Vision III is also provided. Proprietary PC software is supplied to allow the user to view real time status of each vehicle in the user network. Various reports can be generated from this acquired data.

Connecting Power

The Tracking Unit must remain connected to a continuous power supply during vehicle movement for accurate GPS collection and storage. The battery on the vehicle serves as the power source for the Tracking Unit.

Power Connections



Red Lead: Connect to continuous 12-volt power source.

Black Lead: Connect to ground.

Blue or Green Lead: Connect to 12-volt power source that is hot only when ignition is on in the vehicle. This is only a sensor for vehicle ignition activity

IMPORTANT: *If a Unit is left on for an extended period in which the vehicle is not running, the Unit may drain the vehicle battery to the point that the vehicle cannot be started.*

Mounting and Placement

Tracking Units are not weatherproof and are to be mounted inside the vehicle's passenger compartment. The recommended placement location is under the dashboard or in the glove compartment, but the Unit may be placed anywhere inside the vehicle's passenger compartment, as long as it is kept out of direct sunlight and excessive moisture. .

GPS Antenna Placement

The GPS Antenna requires an unobstructed view of the sky to obtain GPS satellite acquisition; therefore, antenna placement is critical to achieve consistent performance. The GPS Antenna supplied with your Tracking Unit is equipped with a magnetic mount. Recommended placement for the GPS Antenna is on top of the vehicle with a clear view of the sky. You may choose to mount the antenna *out of sight*. Keep in mind that the antenna will obtain a stronger, less disrupted signal if it is mounted under plastic or glass rather than covered by metal.

While external mounting is optimal, the options below historical have been the best locations to install if you do not want the drivers to know the location of the antennas.





Shadow Tracker Vision III Installation Instructions

Under the windshield defrost vents.
Between dashboard and instrument cluster.
Between dash and glove box.

Connecting the Unit

The Vision Micro unit should be connected in the following order:

Plug in the GPS antenna

Connect/Verify the GSM antenna is connected

Plug in the Power harness

Verification

The Shadow Tracker Vision Micro unit has a slit on the side that allows the installer to view an LED array inside the unit. When the unit is initialized it will run through a startup sequence, following this sequence verify the status of the following lights.

GPS- GPS acquisition light should blink green if parked with ignition off. Once the ignition is turned on the GPS Light should stay solid green. (if GPS Light stays red after 2-3 min, check antenna placement, and connection to unit.)

Safety and Care

Please follow these guidelines to ensure the safe and trouble-free operation of your Tracking Unit(s).

Safety

- Do not place the Unit near a heating device.
- Do not place the Unit in direct sunlight.
- Do not place anything heavy on the Unit.
- Do not place where spills can occur on the Unit.
- Do not subject the Unit to electrical shock.
- Do not apply any physical pressure to the Unit.
- Do not open or disassemble the Unit or any of its components.
- Only use the Antenna provided by ATTI®.

Care

Occasionally, the Tracking Units may need to be cleaned. Use the following precautions:

Cleaning

- Use a soft cloth to wipe the exterior.
- Do not use an alkaline detergent.
- Do not use alcohol on the Unit case.
- Avoid excessive moisture when cleaning the Unit.



Shadow Tracker Vision III Installation Instructions

Caring for the GPS Antenna

- Do not crimp or cut the GPS Antenna cable.
- Do not place heavy objects on the antenna.
- Do not pull on the antenna connections or connectors.
- Do not place the antenna near excessive heat

Federal Communications Commission (FCC) and Canadian Notices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules and Canada ICES-003-Class A. These limits are designed to provide reasonable protection against harmful interference when the equipment operates in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Only peripherals certified to comply with the Class A limits may be attached to this device. Operation with non-certified peripherals or peripherals not recommended by Advanced Tracking Technologies, Inc. are likely to result in interference to radio and television reception.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits.

ADVANCED TRACKING TECHNOLOGIES, INC. is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment.