## Error tolerance strategies

Table: Thermal noise of capacitors at 300 K ( $\sim$ 27  $^{\circ}$ C)

Capacitance	$V_{rms} = \sqrt{rac{k_{B}T}{C}}$	Noise charge $Q_n = \sqrt{k_B TC}$ in coulombs	Noise charge
1 (	2 \		
1 fF	2 mV	2 aC	13 e <sup>-</sup>
10 fF	640 $\mu$ V	6 aC	40 e <sup>-</sup>
100 fF	200 $\mu$ V	20 aC	$125~\mathrm{e^-}$
1000 fF	64 $\mu$ V	64 aC	400 e <sup>-</sup>

## Error tolerance strategies