**#1052**

# EVAPORATOR CORE CLEANER




## 01 // OUTSTANDING FEATURES

- Removes buildup of contaminants from the surface of the evaporator core.
- Can improve the flow of air, which can increase the efficiency of the air-conditioning system.
- Patented process for removing built-up contaminants.
- Quick and easy results.
- Can help alleviate allergic reactions by removing allergens from the system.

## 02 // DESCRIPTION

A specially formulated foam that quickly cleans and removes odor-producing build up on the surface of the evaporator core and housing of the HVAC system.

## 03 // SPECIFICATIONS

| TEST | ASTM METHOD | TYPICAL RESULTS |
|---|---|---|
| Appearance | N/A | **Clear to Hazy** |
| Density, U.S. (g/ml) @ 68°F(liquid portion) | D 4052 | **~1.00** |
| Density, U.S. (lbs/gal) @ 68°F (calculated) | N/A | **~8.3** |
| Flammability, NFPA Code 30B | N/A | **Level 1 Aerosol** |

## 04 // PACKAGING

| FILL | CASE QTY | CASE WT |
|---|---|---|
| **10 oz.** | 12 Cans | 12 lbs. |

**05 // APPLICATION CONTINUES ON PAGE 2**

# #1052 EVAPORATOR CORE CLEANER

## 05 // APPLICATION

VERY IMPORTANT! SHAKE WELL BEFORE AND DURING THE FLUSH PROCESS. Place cloth towels securely in front of all interior A/C vents (making sure vents are in the “open” position). Place a drip pan under the car to collect residual fluid from the residual drain tube. If HVAC system has a blower motor cooling tube, then remove the cooling tube end that is attached to the blower and insert a cloth into the tube hole. SERVICE PREPARATION:

1. In the car’s interior or under its hood (whichever is more accessible), drill a 3/8” hole in the middle of the evaporator case, halfway between the evaporator core and the blower fan. Avoid contact with any of the A/C components.
2. Insert the evaporator-case adapter (included) into the hole.
3. Snap the knurled tip of the MOC® hose assembly into the case adapter and start the engine.
4. Turn on A/C system and set blower to high. The vehicle is now ready for service. SERVICE PROCEDURE: 1) Inject product into evaporator case by pressing actuator tip on can. 2) Once blower fan begins to slow, stop injecting product for 15-30 seconds. 3) Repeat steps 1 and 2 until injector can is empty. 4) Turn off engine for 2 minutes.
5. Restart engine and allow A/C to run until no foam comes out of the interior vents (approximately 5 minutes).
6. Turn off engine and A/C system.
7. Remove MOC® hose assembly from evaporator case and place supplied plug into case adapter. NOTE: IF EVAPORATOR CASE IS NOT EASILY ACCESSIBLE. 1) With engine and A/C system off, insert knurled tip of MOC® hose assembly into A/C drain tube as far as it will go. 2) Evacuate entire contents of can. 3) Start engine. Turn on A/C system and put blower motor on high. Allow engine and A/C system to continue running for approximately five 5 minutes or until no foam comes out of the A/C interior vents.