#0118

PREMIUM ATF CLEANER



01 // OUTSTANDING FEATURES

- Helps suspend varnish, sludge and contaminants from the transmission system and housing, allowing for easier, more complete evacuation of contaminants during the fluid exchange process.
- Compatible with rubber seals and other system components.
- Prepares the torque converter, pump, ATF cooler and fluid lines for new ATF.

02 // DESCRIPTION

An effective blend of cleaners and dispersants that quickly remove and suspend accumulated deposits from the valve body, filter-screen, and other system components. This product is poured into the transmission through the dipstick tube prior to activating the MOC® Automatic Transmission Fluid Exchanger. This product is used in conjunction with MOC® Premium ATF Supplement #0119.

03 // SPECIFICATIONS

TEST	ASTM METHOD	TYPICAL RESULTS
Appearance	N/A	**Clear & Bright**
Color	N/A	**Yellow**
Odor	N/A	**Bland**
Density (g/mL)	D4052	**0.85**
Density, U.S. (lbs/gal), calculated	N/A	**7.09**
Boiling Point (°F)	N/A	**>420**
Flash Point (°F) (based on components)	N/A	**>201**

04 // APPLICATION

1. Pour entire contents of Premium ATF Cleaner into the transmission through the dipstick tube before beginning a fluid-exchange process.
2. With the engine running and parking brake set, place one foot on the brake pedal and slowly shift the transmission through all gears (continue this process for 5-8 minutes).
3. Put transmission into park and shut off the engine.
4. Follow the directions provided with the MOC® Automatic Transmission Fluid Exchanger to complete the process.

05 // PACKAGING

FILL	CASE QTY	CASE WT
11 oz.	#01941 Kit / 12	20 lbs.