**#10161**

# PLP PENETRANT LUBE




## 01 // OUTSTANDING FEATURES

- Protects against corrosion
- Displaces water and moisture
- Penetrates and frees rusted parts
- Stop squeaks on the trunk, hood, and door hinges

## 02 // DESCRIPTION

PLP Penetrant Lube has a fast-acting penetrating formula that frees rusted nuts, bolts, and other parts. This versatile product displaces moisture, forms a protective coating and prevents the formation of rust on metal surfaces. PLP leaves a lubricating film to reduce sticking, wear and squeaks in moving parts. Industrial uses: lubricates and prevents rust on machine parts and equipment. May be used for easy assembly and disassembly. Automotive uses: penetrates rusted intake-manifold bolts, heat risers, exhaust systems, wheel lug nuts, suspension bolts, and control linkages. Displaces water and moisture from electrical contacts, connections and distributors.

## 03 // SPECIFICATIONS

| TEST | ASTM METHOD | TYPICAL RESULTS |
|---|---|---|
| Appearance | N/A | **Transparent Liquid** |
| Color | N/A | **Yellow** |
| Odor | N/A | **Solvent** |
| Density, U.S. (lbs/gal) | N/A | **~7.01** |
| % VOC | N/A | **24** |
| Can Pressure, psi | N/A | **~98** |

## 04 // APPLICATION

NOT FOR SALE OR USE IN CALIFORNIA OR OTC STATES Directions: Shake Well Before Using For hard-to-reach areas, use extension tube. To penetrate: spray freely on frozen parts, tap lightly, allow a few minutes to penetrate. On heavily rusted parts, it may be necessary to repeat the application. To prevent rust and corrosion: spray all parts regularly to maintain a barrier. To displace moisture: spray parts or surfaces, wait a few minutes and wipe off with a clean cloth. To lubricate: spray parts or surfaces liberally.

## 05 // PACKAGING

| FILL | CASE QTY | CASE WT |
|---|---|---|
| **10 oz.** | 12 | 8 lbs. |