

<u>9-Digit</u>	<u>Description</u>	<u>Pos.</u>	<u>Verw.</u>	<u>Bemerkung</u>	<u>Zusatz nr.</u>
107-006-824	Pressure Spring	11	33045		
107-006-824	Pressure Spring	37	64031		
107-006-824	Pressure Spring	172	82585		
107-009-349	Bearing Housing	21	30310		
107-009-853	Toothed Lever	35	30310		
107-018-504	Washer	35	33045		
107-018-504	Washer	22	64302		
107-021-286	Fan Shaft	21	10122		
107-021-356	Draw Spring	22	82501		
107-021-411	Pressure Spring	11	30310		
107-022-526	Torsion Spring	34	33045		107-041-603
107-022-526	Torsion Spring	32	64031		
107-022-526	Pressure Spring	164	82585		
107-022-526	Pressure Spring	21	64302		
107-035-873	Brush	110	75002		107-035-872
107-035-873	Brush	66	75002		
107-035-873	Brush	262	75003		
107-039-024	Flat Belt			50 x 1310mm	
107-039-025	Flat Belt			50 x 1354mm	
107-039-026	Flat Belt			50 x 1400mm	
107-039-027	Flat Belt			50 x 1442mm	
107-039-548	Barrel Nut	17	37201		
117-001-159	Toggle Block	111	35110		
117-001-700	Pressure Spring	109	70101		
117-001-878	Roller	17	32501	608KDDB	146-000-296
117-003-788	Pressure Spring	85	82585		
117-005-362	Washer	46	40160		
117-005-435	Pull Rod	226	71070		
117-007-446	Draw Spring	147	72045		
117-008-598	Washer	80	35140		
117-008-671	Spring Hook				
117-008-672	Spring Hook				
117-008-674	Bearing Bush				
117-010-578	Spring Hook	171	72035		
117-010-578	Spring Hook	135	85020		
138-001-604	Hex Screw	11	34101	M 6	146-001-761
138-001-605	Seal Ring	10	34101		GKG-218-534
138-001-618	Supporting Disc	13	34101		GKG218-541
138-001-935	Pressure Spring	35	30120		GKG-208-508
138-001-937	Pressure Spring	50	77520		GKG-208-505
138-003-210	Safety Ring	15	34101		GKG-218-542
138-008-180	Nut	263	35101		107-034-836
138-010-197	Bearing Shaft	14	34101		107-031-823
138-010-969	Latch	36	35101		138-007-008
138-012-254	Cylinder	35	35101	12X10HUB	138-005-715

138-012-254	Cylinder	201	37731	12X10HUB	
138-012-254	Cylinder	200	37780	12X10HUB	
138-012-254	Cylinder	8	38110	12X10HUB	
138-012-254	Cylinder	11	64201	12X10HUB	
138-012-254	Cylinder	236	81151	12X10HUB	
138-012-254	Cylinder	236	81501	12X10HUB	
138-012-254	Cylinder	130	81560	12X10HUB	
138-012-254	Cylinder	67	81560	12X10HUB	
138-012-554	Bearing	10	34201	51107X	107-031-799
138-013-289	Stationary Shear Blade	44	40160		148-012-218
138-013-289	Scissors Blade (Ceramic)	44	40160		GKG-302-578
138-014-639	Draw Spring	22	80140		107-033-806
138-014-639	Draw Spring	38	80145		
138-014-639	Draw Spring	49	82005		
138-015-744	Pivoting Shear Blade	50	40160		138-013-311
138-015-744	Pivoting Shear Blade (Ceramic)	50	40160		GKG-302-581
138-015-744	Pivoting Shear Blade	20	36060		
138-015-936	Bush	33	33045	466-554	138-011-958
138-017-020	Leaf Spring	51	40160		138-013-324
138-018-675	Scissors Blade	258	81151		138-018-758
138-018-676	Scissors Blade	259	81151		138-018-759
138-018-758	Scissors Blade	258	81151		138-018-675
138-018-759	Scissors Blade	259	81151		138-018-676
146-000-024	Pinion	41	40101	Z=28	
146-000-025	Pinion	88	40101	Z=28	
146-000-025	Toothed Wheel	70	40101		
146-000-049	Elbow	11	41001		
146-000-057	Actuating Fork	34	41001		
146-000-075	Lifter Rod	78	41001		
146-000-086	Bearing Shaft	15	56801		
146-000-099	Swivel Lever	113	56801		
146-000-100	Swivel Lever	130	56801		
146-000-122	Cam Follower	34	56801		147-028-512
146-000-129	Spacer Ring	17	56801		
146-000-131	Pull Rod	905	56801		146-013-919
146-000-132	Pull Rod	168	56801		146-013-919
146-000-133	Pull Rod	902	56801		146-000-133
146-000-134	Pull Rod	141	56801		146-000-133
146-000-135	Pull Rod	903	56801		
146-000-136	Pull Rod	147	56801		
146-000-137	Pull Rod	904	56801		146-000-138
146-000-138	Pull Rod	163	56801		146-000-137
146-000-139	Strap	290	56801	Unten (under)	
146-000-142	Strap	275	56801		
146-000-145	Spacer Washer	84	56801		
146-000-148	Spacer Washer	199	56801		

146-000-169	Pressure Spring	75	40105		
146-000-184	Torsion Spring	84	42001		
146-000-186	Pull Rod	99	40105		
146-000-199	Pressure Spring	32	32501		
146-000-248	Pressure Rod	82	40101		
146-000-249	Catch Hook	75	40101		147-028-969
146-000-255	Housing	19	30120		147-030-576
146-000-256	Piston	20	30120		147-030-576
146-000-258	Cover	40	30120		
146-000-275	Catch Hook	193	56801		
146-000-276	Shaft	66	56801		
146-000-277	Shaft	80	56801		
146-000-289	Shaft	3	33005		
146-000-290	Pinion	6	33010		
146-000-295	Toothed Segment	34	33005	FO 1	147-028-499
146-000-296	Roller	17	32501		117-001-878
146-000-301	Cam Follower	49	33005	F 03	
146-000-305	Cam Follower	69	33005		147-028-500
146-000-309	Cam Follower	80	33005	f 04	147-028-501
146-000-315	Shaft	3	33010		
146-000-320	Toothed Segment	38	33010	FU 1	147-028-504
146-000-325	Locking Lever	53	33010		147-003-737
146-000-325	Locking Lever	53	33010		
146-000-326	Locking Lever	53	33010		
146-000-331	Toothed Wheel	84	33010		
146-000-343	Spacer Washer	14	56801		
146-000-357	Cover Tube	19	40101		
146-000-358	Excenter	19	42030		
146-000-380	Pressure Rod	66	41001		
146-000-448	Intermediate Gear	11	31610	Z=18	
146-000-525	Bush	35	32501		
146-000-553	Spacer Washer	16	56801		
146-000-555	Pinion	9	33015		146-015-022
146-000-556	Starting Disc	10	33015		
146-000-558	Clamping Piece	19	33015		147-008-063
146-000-563	Strap	39	33015		
146-000-566	Slider	47	33015		
146-000-567	Pull Rod	51	33015		
146-000-576	Draw Spring	78	33005		
146-000-577	Draw Spring	101	33005		147-018-801
146-000-577	Draw Spring	49	33010		147-018-801
146-000-577	Draw Spring	80	33010		147-018-801
146-000-577	Draw Spring	80	33010		
146-000-579	Shield	97	33010		147-000-173
146-000-585	Guide Bush	11	33060		
146-000-610	Adjusting Ring	11	30115		

146-000-610	Set Collar	8	30115		
146-000-627	Scissors Blade	19	33045		
146-000-628	Scissors Blade	20	33045		
146-000-629	Clamping Piece	43	33045		146-010-283
146-000-631	Pull Rod	50	33045		
146-000-632	Cpl.Pull Rod	4	30130		
146-000-640	Draw Spring	40	30130		
146-000-649	Screw	19	35101		147-023-377
146-000-657	Swivel Lever	3	35201		
146-000-661	Swivel Lever	18	35201		
146-000-666	Holder	7	31610		
146-000-681	Tension Lever	69	35201		
146-000-683	Guide Plate	66	35201		
146-000-705	Torsion Spring	36	41501		147-032-183
146-000-726	Pressure Lever	45	35201		
146-000-729	Lever	209	35101		
146-000-734	Lever	48	35101		
146-000-734	Lever	99	35101		
146-000-734	Lever	35	35110		
146-000-734	Lever	81	35110		
146-000-739	Toothed Wheel	68	35130		
146-000-742	Bearing Washer	22	35130		
146-000-933	Hinged Bracket	84	10150		
146-001-113	Bearing Washer	34	35130		
146-001-117	Pull Rod	55	35101		
146-001-117	Pull Rod	42	35110		
146-001-118	Strap	67	35101		
146-001-118	Strap	45	35110		
146-001-121	Draw Spring	60	33010		
146-001-121	Draw Spring	270	35101		
146-001-121	Draw Spring	223	35110		
146-001-171	Washer	73	35130		
146-001-177	Pinion	3	33001		
146-001-184	Carrier Plate	143	35101		
146-001-184	Carrier Plate	126	35110		
146-001-185	Feed Tray Bracket	131	35101		
146-001-185	Feed Tray Bracket	107	35110		
146-001-188	Strap	231	35110		146-013-610
146-001-188	Strap	290	35101		146-013-610
146-001-193	Draw Spring	275	35101		
146-001-193	Draw Spring	227	35110		
146-001-194	Pressure Spring	77	35201		
146-001-195	Pressure Spring	138	35101		
146-001-195	Pressure Spring	113	35110		
146-001-196	Torsion Spring	65	35201		
146-001-197	Rod	137	35101		

146-001-197	Rod	112	35110		
146-001-218	Bolt	34	35201		
146-001-234	Strap	112	35101		146-016-258
146-001-234	Strap	99	35110		
146-001-237	Pull Rod	108	35101		
146-001-237	Pull Rod	96	35110		
146-001-274	Guide Piece				
146-001-287	Control Lever	142	35301		147-015-466
146-001-296	Shield	49	56801		
146-001-311	Control Lever	10	37201		146-013-261
146-001-313	Chute Lever	201	35101		
146-001-319	Pull Rod	178	35101		
146-001-320	Bow	19	37201		
146-001-323	Spring	36	37201		
146-001-324	Pivot Strap (Right)	39	37201	Right	
146-001-326	Pivot Strap (Left)	43	37201	Left	
146-001-340	Cam Follower	66	33010	FU2	
146-001-359	Pull Rod	87	37201		
146-001-364	Pull Rod	98	37201		
146-001-365	Pull Rod	99	37201		
146-001-373	Pull Rod	233	35101	left	
146-001-380	Supporting Plate	15	35101		
146-001-388	Spring	37	37201		
146-001-436	Cam Follower	131	35110		
146-001-436	Cam Follower	169	35110		
146-001-464	Chute Lever	256	35110		
146-001-497	Connecting Rod	178	56801		
146-001-543	Bush	16	40101		
146-001-544	Washer	17	40101		
146-001-545	Washer	18	40101		
146-001-550	Draw Spring	263	35110		
146-001-551	Draw Spring	264	35110		
146-001-562	Torsion Spring	114	40101		
146-001-563	Locking Flap	33	42001		146-010-891
146-001-567	Pinion	55	40101	Z=40	
146-001-570	Toothed Lever	37	42001		
146-001-641	Tube Clamp	49	42001		
146-001-658	Torsion Spring	6	42035		
146-001-683	Coupling Gear	19	42001		
146-001-684	Pusher Head	41	42001		
146-001-685	Lifting Plunger	39	42001		
146-001-686	Limit Stop	45	42001		146-009-220
146-001-687	Base Plate	65	40105		146-009-340
146-001-688	Guide Plate Ceramik	66	40105		
146-001-695	Shaft	69	40101		
146-001-695	Shaft	87	40101		

146-001-729	Actuating Rod	3	30125		
146-001-730	Stop Cam	4	30125		
146-001-747	Starting Disc	8	32501		
146-001-757	Pressure Spring	6	34101		
146-001-758	Guide Bush	8	34101	1 Rille / 1 Groove	146-010-984
146-001-761	Hex Screw	11	34101	M 6	138-001-604
146-001-786	Torsion Spring	67	41501		
146-001-787	Elbow Lever	69	41501		
146-001-797	Adjusting Plate	9	35201		146-014-723
146-001-800	Fork	107	35201		146-012-739
146-001-821	Pull Rod	77	40160		
146-001-829	Cam Piece	42	32501		147-032-720
146-001-834	Hub	14	34201		
146-001-836	Pressure Pestle	35	40105		
146-001-856	Air Duct	202	56801		
146-001-873	Setting Wheel	47	40105		
146-001-874	Set Washer	48	40105		
146-001-950	Coupling Half	106	33010		147-022-600
146-001-950	Coupling Half	433	56801		
146-001-969	Central Lever	18	41001		
146-001-975	Pointer	303	56801		
146-002-003	Synchronus Lever	12	30130		
146-002-006	Adjusting Lever	33	30130		146-008-223
146-002-008	Strap	50	30130		
146-002-026	Tension Lever	42	30130		146-008-333
146-002-030	Support	14	30310		
146-002-031	Lifter Cam	49	30310		
146-002-034	Lever	69	30310		
146-002-044	Actuating Rod	51	41001		
146-002-050	Pinion	9	42030	Z=12/38	
146-002-051	Cpl.Bearing Shaft with Pinion	14	42030	Achtung teil ist Kpl.	
146-002-055	Cam	9	35130	AND 2	146-012-805
146-002-057	Cam	14	35130	AD 4.1	
146-002-061	Magnet Holder	2	42035		
146-002-064	Toothed Segment	8	42035		
146-002-098	Bolt	22	75001		
146-002-104	Cam	12	33005	F 02	
146-002-105	Cam	15	33005	F 03	
146-002-106	Cam	18	33005	F04	147-000-190
146-002-107	Cam	9	33010	FU 1	
146-002-108	Cam	13	33010	FU 2	
146-002-203	Seal	36	33015		
146-002-218	Slide Bush	13	33060		146-011-416
146-002-221	Coupling Gear	32	33060		147-031-505
146-002-228	Holding Ring	111	34101	DM 68	
146-002-265	Hollow Shaft	10	40105		

146-002-266	Pressure Lever	42	40105		
146-002-268	Buffer-Ring	19	40105		
146-002-269	Toothed Wheel	16	40105	Z=28	
146-002-301	Washer	17	56801		
146-002-351	Cover	33	33015		
146-002-472	Supporting Plate	65	35110		
146-002-484	Cover	12	30107		
146-002-505	Opener Arm	258	56801		146-013-544
146-002-507	Torsion Spring	272	56801		
146-002-584	Pressure Spring	42	42001		
146-002-605	Plug	5	42035		
146-002-728	Sleeve	73	35311		
146-002-779	Switch Plate	112	33010		
146-002-848	Spring	19	33060		
146-002-857	Plate	21	32510		
146-002-862	Mounting Bracket	16	30125		
146-002-886	Shaft	83	42001		
146-002-901	Pull Rod	19	80140		
146-002-901	Pull Rod	33	80145		
146-003-040	Piston	5	33060		
146-003-042	Cable Cover	16	32510	Rechts	
146-003-043	Cable Cover	14	32510	Quer	
146-003-099	Cylinder	9	33060		
146-003-100	Support	3	33060		146-011-414
146-003-139	Strap	290	56801		
146-003-142	Strap	275	56801		
146-003-213	Torsion Spring	43	40101		
146-003-221	Switch Housing	3	30107		147-014-748
146-003-320	Torsion Spring	56	33010		
146-003-420	Torsion Spring	329	56801		
146-003-436	Clamping Plate	16	41501		
146-003-453	Hinge Angle	50	10150		
146-003-471	Shaft	301	56801		
146-003-474	Lever	322	56801		
146-003-615	Pull Rod	80	72040		
146-003-622	Cam Follower	103	72040		147-030-890
146-003-635	Toothed Segment	21	72020		
146-003-641	Deflector Lever	48	72020		
146-003-646	Cam Follower	84	72020		
146-003-654	Toothed Segment	21	72025		
146-003-658	Pull Rod	41	72025		
146-003-660	Cam Follower	65	72025		147-030-887
146-003-672	Bearing Bolt	7	72035		
146-003-675	Bearing Bush	12	72035		
146-003-679	Tension Strap	20	72035		
146-003-682	Spacer Bolt	37	72035		

146-003-683	Bearing Bolt	39	72035		
146-003-686	Carrier Bush	44	72035		
146-003-690	Toothed Belt	54	72035		834-310-093
146-003-698	Shaft	78	72035		
146-003-703	Carrier Bush	98	72035		
146-003-707	Gear Wheel	112	72035		
146-003-710	Toothed Segment	129	72035		
146-003-718	Spacer Bush	87	72035		
146-003-719	Cpl. Pull Rod	140	72035		
146-003-720	Pull Rod	140	72035		146-003-719
146-003-773	Shield	129	72001		
146-003-800	Bearing Tube	33	71070		
146-003-825	Bearing Bolt	108	71070		146-016-423
146-003-848	Roller Lever	237	71070		147-030-885
146-003-886	Slide Bush	12	70101		
146-003-887	Torsion Spring	15	70101		
146-003-907	Shaft	33	71035		
146-003-909	Opener Roll	42	71035		
146-003-910	Traction Lever	48	71035		
146-003-913	Retainer Plate	97	71045		
146-003-914	Roller Lever	83	71035		147-030-880
146-003-920	Opener Arm	112	71035		
146-003-930	Toothed Wheel	45	71005	Z = 20	
146-003-936	Cam Shaft	41	71001		
146-003-981	Pull Rod	901	71045		
146-003-983	Roller Lever	65	71045	X-6	
146-003-994	Toothed Segmet	181	72001		
146-003-995	Gear Wheel	175	75001		
146-004-020	Guide Bush	113	72050		
146-004-031	Pull Rod	148	72050		
146-004-052	Pinion	138	75001		
146-004-067	Washer	38	71025		
146-004-071	Shaft	68	71025		
146-004-104	Contact Plate	247	71070		
146-004-108	Cam	21	56801	SC 4.2	
146-004-264	Torsion Spring	41	40105		
146-004-284	Beam Carrier Slide	15	71050		146-004-283
146-004-286	Pinion	22	71050	Z = 40	
146-004-363	Magnet Holder	4	71055		
146-004-364	Plunger Cap	9	71055		
146-004-390	Depressor Lever	15	71045		
146-004-393	Bearing Shaft	5	71045		
146-004-396	Traction Lever	33	71045		
146-004-401	Pull Rod	902	71045		
146-004-403	Opener Arm	20	71035		
146-004-405	Pull Rod	901	71035		

146-004-410	Toothed Segment	81	71070		
146-004-411	Plate	42	30310		
146-004-414	Retainer Plate	5	30310		
146-004-463	Angular Bearing	3	41001		
146-004-467	Buffer Rod	66	72020		
146-004-471	Cover	71	72020		
146-004-478	Cpl. Pull Rod	451	71050		146-004-479
146-004-479	Actuating Rod	451	71050		146-004-478
146-004-488	Protection Gasket	17	27050		146-008-233
146-004-490	Pull Rod	47	41501		
146-004-515	Torsion Spring	47	41001		
146-004-520	Torsion Spring	12	34101		
146-004-537	Gear Wheel	7	71005		
146-004-541	Gear Wheel	39	71005	Z = 22	
146-004-548	Clamping Piece	36	72030		
146-004-553	Collar Screw	44	72030		
146-004-554	Bush	47	72030		
146-004-561	Cam Follower	95	72030		
146-004-577	Bearing Shaft	33	71020		
146-004-586	Pinion	78	71020		
146-004-592	Lever	85	71020		
146-004-597	Scissors Blade	122	71020		
146-004-603	Roller	19	72030		146-004-547
146-004-614	Swing Lever	66	30310		
146-004-623	Lever	204	71030		
146-004-650	Shield	436	71030		
146-004-694	Magazine Carrier	36	35301		
146-004-708	Bow	238	35101		
146-004-761	Collar Screw	14	41501		
146-004-792	Starting Disc	117	71030	12,1X28X2	
146-004-806	Scissors Blade	214	72045		
146-004-807	Scissors Blade	227	72045		
146-004-808	Leaf Spring	228	72045		
146-004-809	Scissors Plate	213	72045		
146-004-828	Pull Rod	164	72045		146-004-829
146-004-829	Cpl. Pull Rod	164	72045		
146-004-830	Pull Rod	68	72045		146-004-831
146-004-831	Cpl. Pull Rod	68	72045		146-004-830
146-004-838	Flange	106	72001		
146-004-861	Bush	88	72045		
146-004-862	Control Lever	131	72045		
146-004-863	Actuating Lever	109	72045		
146-004-865	Bracket	40	72045		
146-004-881	Starting Disc	391	71030	50,1X58X1	
146-004-899	Draw Spring	149	72045		146-008-673
146-004-924	Ejector Ring	33	34101		

146-004-961	Support Angle	298	71050		
146-005-030	Torsion Spring	23	33050		
146-005-031	Pull Rod	34	33050		
146-005-048	Toothed Wheel	67	71005	Z = 25	
146-005-063	Cpl. Pull Rod	37	35321		
146-005-064	Pull Rod	37	35321		
146-005-125	Pressure Spring	178	35311		
146-005-133	Pull Rod	200	35311		
146-005-136	Cpl. Pull Rod	206	35111		
146-005-137	Pressure Rod	206	35111		
146-005-140	Cpl. Pull Rod	214	35321		
146-005-141	Pull Rod	214	35321		
146-005-198	Washer	7	37731		
146-005-220	Pull Rod	86	37780		
146-005-221	Pressure Rod	86	37731		
146-005-332	Clamping Piece	266	35110		
146-005-348	Cover	578	71030		
146-005-401	Actuating Lever	79	35101		146-012-839
146-005-401	Actuating Lever	70	35110		
146-005-431	Toothed Wheel	200	71001	Z = 75	
146-005-446	Flap Carrier	48	37201		
146-005-520	Pressure Spring	44	42001		
146-005-530	Starting Disc	267	71030		
146-005-530	Starting Disc	276	71030		
146-005-532	Intermediate Gear	264	71030		
146-005-544	Roller	309	71030		
146-005-562	Guide Rod	12	72040		
146-005-575	Spring Bolt	40	71030		
146-005-577	Pull Rod	328	71030		
146-005-583	Actuating Lever	338	71030		
146-005-655	Gasket	54	33045		147-005-655
146-005-676	Pull Rod	190	37731	rechts/right	
146-005-688	Cover Plate	98	40101		
146-005-689	Cover Plate	99	40101		
146-005-690	Pressure Fork	81	42001		Vorsicht Schrott
146-005-705	Torsion Spring	82	41501		
146-005-807	Bush	67	72020		
146-005-896	Shaft	132	72050		
146-005-899	Adjusting Bolt	343	56801		
146-005-900	Worm	342	56801		
146-005-901	Screw	488	71030		
146-005-902	Support	484	71030		
146-005-915	Lever	104	71030		
146-005-925	Pressure Lever	50	35201		
146-005-940	Stop Lever	35	30125		
146-005-956	Shield	66	71030		

146-005-958	Head	425	71030		
146-005-959	Pull Rod	541	71030		146-005-960
146-005-960	Cpl. Pull Rod	541	71030		146-005-959
146-005-961	Pull Rod	553	71030		
146-005-962	Cpl. Pull Rod	553	71030		
146-005-963	Cam Follower	518	71030		147-030-877
146-006-011	Pressure Fork	82	42001		Vorsicht Schrott
146-006-076	Pull Rod	321	71050		
146-006-125	Insert	189	52030		
146-006-137	Cam Follower	4	71020	X-2	
146-006-194	Pinion	49	40101	Z=20	
146-006-195	Guide Shaft	4	71050		146-013-674
146-006-217	Tension Lever	44	35130		
146-006-219	Draw Spring	51	35130		
146-006-224	Bearing Plate	13	71055		
146-006-227	Spring Bolt	17	71055		
146-006-236	Lever	52	71055		
146-006-240	Release Lever	66	71055		
146-006-245	Draw Spring	74	71055		
146-006-247	Cpl. Pull Rod	85	71055		
146-006-248	Pull Rod	85	71055		
146-006-250	Retainer Plate	104	71055		
146-006-265	Scissors Blade	230	56801		148-002-746
146-006-265	Scissors Blade (Ceramic)	230	56801		
146-006-281	Gear Wheel with Magnet	14	31610		
146-006-284	Gear Rim	33	33010		
146-006-285	Washer	16	33010		
146-006-349	Cam Piece	43	32501		
146-006-350	Spacer Bush	105	33010		147-022-600
146-006-366	Pressure Spring	42	75002		
146-006-366	Pressure Spring	21	75001		146-015-400
146-006-366	Pressure Spring	72	75001		
146-006-382	Lever	41	41001		147-031-482
146-006-405	Clamping Lever	50	71045		
146-006-424	Washer	104	71070		
146-006-432	Scissors Housing	9	33045		146-017-069
146-006-434	Cam	104	72001	X - Y26,1	
146-006-435	Cam	105	72001	X - R26,1	
146-006-554	Drum Spindle with Magnet	3	30301		146-017-275
146-006-573	Stop	21	33060		
146-006-587	Cam	9	33005	F 01.2	
146-006-588	Cover Plate	122	41501		146-016-138
146-006-590	Transfer Rod	104	35301		
146-006-598	Yarn Guide Plate	512	56801		
146-006-627	Toothed Wheel	353	56801		
146-006-628	Adjusting Lever	337	56801		

146-006-643	Shaft	176	72045		
146-006-657	Leaf Spring	236	56801		
146-006-731	Carrier Plate	95	70101		146-013-891
146-006-812	Cpl. Pull Rod	237	60151		
146-006-836	Cpl. Pull Rod	239	71050		000-000-146
146-006-837	Pull Rod	239	71050		146-006-836
146-006-861	Cam Follower	174	71050		147-030-882
146-006-869	Tension Roller	52	35130		
146-006-900	Retainer Plate	168	71025		
146-006-957	Cam	112	71001	X - 10.1	
146-006-998	Support	117	71050		
146-007-020	Brake Bush	17	34101	NI.SPBR.	147-025-010
146-007-042	Torsion Spring	43	72030		
146-007-107	Cam Follower	78	71061		
146-007-111	Pull Rod	98	71061		
146-007-116	Elbwo	135	71061		
146-007-132	Magnet Holder	46	71055		
146-007-163	Bolt	11	41501		147-030-632
146-007-236	Plate	38	70101		
146-007-237	Ring	37	70101		
146-007-250	Cam Follower	526	71030		147-030-878
146-007-374	Retainer Plate	19	34101		
146-007-380	Latch	77	41501		
146-007-386	Cutting Knife	102	41501		146-015-415
146-007-390	Torsion Spring	105	41501		
146-007-392	Elbow	111	41501		146-016-469
146-007-412	Transfer Rod	169	35311		
146-007-413	Transfer Rod	169	35311		
146-007-414	Bearing Shaft	65	71070		146-012-251
146-007-428	Pull Rod	574	71030		
146-007-438	Feeler Finger	620	71030	LI.DM 65	
146-007-440	Feeler Finger	624	71030	RE.DM 65	
146-007-444	Feeler Finger	623	71030	RE.DM 65	
146-007-446	Feeler Finger	621	71030	LI.DM 65	
146-007-451	Adaptor	72	34201	DM 28	
146-007-460	Bush	32	41501		147-030-629
146-007-471	Carrier Bush	17	34201		146-015-447
146-007-472	Toothed Wheel	99	71070		
146-007-478	Cap	590	71030		
146-007-503	Shaft	33	71055		
146-007-507	Control Lever	75	37701		
146-007-511	Sleeve	81	37701	146+147	
146-007-542	Clamping Piece	47	37701	146RM	
146-007-549	Pull Rod	83	35301		
146-007-550	Clamping Plate	107	35301		
146-007-554	Strap	129	35301		

146-007-608	Elbow	510	71030		
146-007-613	Clip	15	33015		
146-007-625	Toothed Segment	66	72030		
146-007-650	Roller	162	75001	Drm.:60mm	
146-007-659	Pressure Rod	148	35301		
146-007-711	Guide Plate	47	42001		147-020-660
146-007-716	Roller Shaft	53	75001		
146-007-721	Threading Plate	108	41501		147-000-081
146-007-723	Comb Strip 0,5mm	9	33020	0,5mm	
146-007-749	Carrier Bush	42	40101		
146-007-753	Cpl. Pull Rod	77	72030		146-007-754
146-007-754	Pull Rod	77	72030		
146-007-769	Lift Roller	17	72020		
146-007-796	Draw Spring	15	72030		
146-007-814	Cam	100	72001	X - 24.1	
146-007-829	Scissors Shaft	14	33045		
146-007-861	Cam	101	72001	X - 25.1	
146-007-864	Leaf Spring	113	71020		
146-007-866	Threaded Bush	231	56801		
146-007-915	Protection Plate	14	30380		
146-008-018	Switch Housing	5	30107		147-015-124
146-008-113	Cover	16	33045		
146-008-113	Cover	28	64031		
146-008-113	Cover	59	81551		
146-008-113	Cover	160	82585		
146-008-114	Bearing Flange	10	33050		146-017-197
146-008-118	Spacer Ring	15	33050		
146-008-188	Pivoting Plate	11	32501	3"*4"*5"*6	
146-008-190	Pull Rod	86	37201		
146-008-217	Positioining Bolt	21	71055		
146-008-218	Stop Strap	35	71055		
146-008-221	Synchronnus Lever	12	30130		Neue Ausfuehrung
146-008-223	Adjusting Lever	33	30130		146-002-006
146-008-228	Brake Ring with out Magnet	37	34101		146-016-394
146-008-267	Flat Belt	7	30305		
146-008-268	Bush	76	71020		
146-008-282	Pressure Spring	76	35301		
146-008-323	Pull Rod	4	30130		146-002-003
146-008-330	Feeler Finger	622	71030	DM 71	
146-008-332	Draw Spring	40	30130		146-000-640
146-008-333	Tension Lever	42	30130		146-002-026
146-008-349	Valve Shifter	37	71061		
146-008-351	Shaft	65	71061		
146-008-352	Strap	112	71061		
146-008-359	Yarn Trap	107	42001		146-016-014
146-008-371	Draw Spring	172	72035		

146-008-432	Supporting Flange	38	71050		146-012-063
146-008-444	Pull Rod	72	41001		
146-008-463	Yarn Clamp	266	56801		147-030-172
146-008-467	Draw Spring	44	56801		
146-008-468	Draw Spring	45	56801		
146-008-508	Cam	87	71001	X - 7.7	
146-008-520	Threaded Bush	239	56801		138-017-024
146-008-527	Flexibel Court -Blue-	166	71061		
146-008-535	Suspension Fork	46	56801		
146-008-561	Magnet Lever	323	71070		
146-008-586	Grpper Arm Tube	3	33050		146-010-724
146-008-606	Pull Rod	80	72040		
146-008-617	Bow	13	37210		
146-008-642	Deflection Plate	15	30380	6" Links	147-029-285
146-008-662	Draw Spring	75	71035		
146-008-663	Draw Spring	102	71045		
146-008-663	Draw Spring	129	71061		
146-008-663	Draw Spring	74	72040		
146-008-664	Draw Spring	180	71050		146-017-366
146-008-666	Draw Spring	9	71030		
146-008-666	Draw Spring	79	72025		
146-008-666	Draw Spring	109	72030		
146-008-666	Draw Spring	42	72040		
146-008-667	Draw Spring	10	71030		
146-008-669	Draw Spring	97	71030		
146-008-674	Clamping Lever	67	35301		
146-008-684	Cam Follower	49	35301		147-028-508
146-008-689	Connecting Flange	37	33050		
146-008-695	Clamp	18	41501		146-012-782
146-008-697	Bolt	107	70101		
146-008-712	Clamping Bolt	430	56801		
146-008-758	Draw Spring	193	71005		
146-008-758	Draw Spring	389	71070		
146-008-784	Cylinder	3	34101		146-011-166
146-008-791	Draw Spring	219	35110		
146-008-927	Ejector	80	35201		146-012-737
146-008-945	Toothed Wheel	465	71030	Z=24	146-016-839
146-008-946	Toothed Wheel	466	71030	Z=9	146-016-841
146-008-947	Shaft	457	71030		
146-009-004	Pressure Rod	13	37201		146-009-005
146-009-005	Pressure Rod	13	37201		146-009-004
146-009-006	Pressure Rod	14	37201		
146-009-011	Deflector Lever	49	72040		
146-009-013	Cam Follower	85	72045		146-004-858
146-009-015	Guide Lever	176	72050		
146-009-019	Pull Rod	236	72050		

146-009-045	Cam	73	71001	X - 4,4	
146-009-062	Cpl. Pull Rod	119	71025		146-009-063
146-009-063	Pull Rod	119	71025		146-009-062
146-009-066	Cpl. Pull Rod	38	72020		
146-009-085	Pull Rod	79	30310		
146-009-117	Clamping Lever	289	71030		
146-009-128	Pressure Spring	109	72050		
146-009-129	Tension Disc	19	40105		146-015-543
146-009-198	Strap	163	35110		
146-009-220	Lifting Plunger	903	42001		
146-009-231	Cam Follower	442	71050		147-030-883
146-009-237	Cam Follower	266	71050		
146-009-264	Cam Follower	160	71025	X-V11	
146-009-271	Cam Follower	158	71025	X-11	147-030-874
146-009-284	Roller Support	255	75002		
146-009-286	Cam	102	71001	X - 8,5	
146-009-287	Depressor Lever	11	72025		
146-009-289	Stop Strap	118	72035		
146-009-293	Depressor Roller	17	72025		
146-009-298	Cable Cover	15	32510	Links	
146-009-313	Deflection Plate	17	30380	6" Rechts	147-029-293
146-009-340	Base Plate	65	40105		147-015-014
146-009-354	Pull Rod	206	35321		146-012-152
146-009-373	Pull Rod	191	35110		
146-009-404	Trough Lever	278	35110		
146-009-406	Strap	250	35110		
146-009-477	Gear Plate	167	75002		
146-009-483	Toothed Wheel	182	75002	Z=72	
146-009-486	Intermediate Gear	202	75002	Z=52	
146-009-487	Toothed Wheel	203	75002	Z=18	
146-009-488	Toothed Wheel	206	75002	Z=64	
146-009-490	Covering Hood	212	75002		147-025-359
146-009-539	Roller	180	75002	Drm.:80mm	
146-009-562	Comb Strip 0,3mm	9	33020	0,3mm	
146-009-603	Pressure Spring	4	37701	146+147	
146-009-630	Draw Spring	354	71070		
146-009-648	Latch	38	41501		146-015-712
146-009-649	Spacer Tube	44	41501		
146-009-706	Intermediate Lever	21	30130		
146-009-739	Strap	194	35101		
146-009-749	Cam	83	71001	X - 6.1	
146-009-756	Limit Stop	22	32510		147-019-481
146-009-760	Torsion Spring	54	37701	146RM	
146-009-766	Torsion Spring	336	56801		146-004-417
146-009-768	Strap	257	35101		
146-009-798	Levers for Ejectors	97	35201		

146-009-942	Bearing Bush	392	71030		
146-009-949	Guide Wire	133	35301		146-017-235
146-009-951	Stop Lever	35	30125		146-005-940
146-010-105	Suction Tube	13	33015		146-011-556
146-010-126	Toothed Segment	95	71025		
146-010-128	Hollow Shaft	76	71025		
146-010-155	Pressure Spring	38	35101		
146-010-157	Ratched Wheel	3	31160		
146-010-161	Bearing Shaft	195	75002		146-017-114
146-010-162	Bearing Shaft	194	75002		146-017-113
146-010-194	Bobbin Peg	40	35201		146-001-180
146-010-199	Nozzle	37	42501		
146-010-248	Draw Spring	44	33005		
146-010-280	Scissors Blade (Ceramic)	19	33045		
146-010-280	Scissors Blade	19	33045		
146-010-281	Scissors Blade (Ceramic)	20	33045		
146-010-281	Scissors Blade	20	33045		
146-010-282	Cover	16	33045		147-032-435
146-010-283	Clamping Piece	43	33045		146-000-629
146-010-343	Wire	17	38110		
146-010-366	Lever	305	56801		
146-010-369	Cover	310	56801	13mm	148-022-712
146-010-370	Leaf Spring	311	56801		
146-010-421	Pull Rod	577	71030		146-007-249
146-010-438	Cylinder	77	20246		SP260049
146-010-549	Lever	155	35110		
146-010-553	Treading Plate	86	40101		
146-010-566	Feeder Arm	333	56801		146-006-625
146-010-594	Threading Plate	36	40160		146-012-220
146-010-596	Actuating Lever	113	35301		
146-010-602	Toothed Segment	70	56801		146-001-500
146-010-603	Pinion	98	56801		
146-010-631	Cam	21	35301	AN 5-21	146-012-813
146-010-632	Cam	7	35130	AN 1.2	146-012-812
146-010-683	Strap	14	35301		
146-010-711	Guide Plate	124	71020		
146-010-717	Valve Angle	3	33101		
146-010-721	Slide Plate	44	40101		
146-010-722	Cover Tube	24	40101		
146-010-724	Gripper Arm Tube	3	33050		146-016-704
146-010-726	Cpl. Roll with Bearing	317	71070		
146-010-738	Slide Washer	46	40101		
146-010-791	Toothed Segment	228	71050		
146-010-813	Opener Arm RED	34	32510		146-016-537
146-010-833	Cam	54	71001	X - 2.1	
146-010-853	Shield	17	35130		146-013-608

146-010-870	Knurled Screw	146	41501		
146-010-872	Lift Plate	138	71025		146-008-937
146-010-877	Cover	310	56801	16mm	148-022-714
146-010-891	Locking Flap	33	42001		
146-010-906	Clamping Lever	131	71025		146-008-370
146-010-963	Guide Plate	368	71050		
146-010-966	Cam Follower	354	71050		146-005-980
146-010-984	Guide Bush	8	34101	1 Rille / 1 Groove	146-001-758
146-010-997	Pressure Spring	145	72050		
146-010-997	Pressure Spring	373	71050		
146-011-025	Bearing Shaft	12	71035		
146-011-051	Draw Spring	308	71030		146-006-007
146-011-060	Washer	147	41501		
146-011-119	Spacer Bush	429	71030		
146-011-124	Bevel Gear	35	71035		
146-011-157	Pinion	13	33050		147-018-972
146-011-166	Cylinder	3	34101		
146-011-216	Shaft	3	35130		
146-011-218	Spring Eyelet	165	35101		
146-011-219	Draw Spring	163	35101		146-010-158
146-011-244	Roller Carrier	46	75001		146-007-714
146-011-248	Wax Shaft	97	42001		
146-011-267	Bearing Plate	73	71070		
146-011-282	Supporting Angle	251	71070		146-013-901
146-011-293	Shield	217	72045		
146-011-399	Wax Shaft	97	42001		
146-011-414	Support	3	33060		146-003-100
146-011-415	Piston	5	33060		146-003-040
146-011-416	Slide Bush	13	33060		146-002-218
146-011-428	Wax Shaft	97	42001		
146-011-430	Notch Bush		42001		
146-011-433	Pressure Spring	385	71050		
146-011-434	Torsion Spring	378	71050		
146-011-445	Cam	99	72001	X - 23,6	
146-011-556	Suction Tube	13	33015		146-017-289
146-011-591	Clamping Lever	492	71030		146-005-903
146-011-651	Lever	79	71030		146-009-812
146-011-676	Shaft	194	71030		146-005-822
146-011-681	Actuating Lever	5	40160		
146-011-683	Shaft	12	40160		146-013-707
146-011-684	Swivel Lever	67	40160		146-013-057
146-011-686	Cylinder	41	20246	16x40	SP260062
146-011-722	Torsion Spring	72	40160		
146-011-723	Torsion Spring	13	40160		
146-011-776	Tension Disc	33	40101		146-001-506
146-011-777	Shaft	33	40101	Nur Welle f.Spannteller	

146-011-912	Cam	14	35201		
146-011-929	Fork Lever	97	72050		
146-011-944	Lever	145	71030		146-004-750
146-012-152	Cpl. Pull Rod	209	35321		
146-012-200	Toothed Wheel	12	71025	Z=28	
146-012-201	Bevel Gear	45	72045		
146-012-201	Bevel Gear	9	72045	Z = 15	146-008-181
146-012-202	Toothed Wheel	14	71070	Z=19	
146-012-204	Shaft	433	71030		146-014-234
146-012-205	Shaft	432	71030		146-014-235
146-012-220	Threading Plate	36	40160		146-010-594
146-012-224	Shaft	3	72020		
146-012-227	Shaft	3	72025		
146-012-232	Carrier Bush	10	71050		
146-012-233	Pressure Spring	11	71050		
146-012-321	Toothed Wheel	116	71070		146-016-426
146-012-398	Cam	12	35130	AN3.21	
146-012-419	Slide	389	71050		
146-012-426	Scissors Blade	225	56801		148-005-258
146-012-426	Scissors Blade (Ceramic)	225	56801		
146-012-467	Pull Rod	13	71020		
146-012-506	Shaft	47	71020		
146-012-514	Bush	51	71020		
146-012-519	Shaft	66	56801		
146-012-520	Shaft	80	56801		
146-012-525	Roller Carrier	32	70101		
146-012-532	Bearing Bolt	33	70101		
146-012-539	Pressure Spring	11	71050		
146-012-571	Shaft	5	72045		
146-012-572	Lever	130	71030		147-030-876
146-012-583	Screw	304	56801		
146-012-587	Coupling Half	433	56801		146-001-950
146-012-633	Bush	23	72001	T	
146-012-657	Pull Rod	518	71050	6"	
146-012-665	Pull Rod	334	71050		
146-012-667	Lever	375	71050	Oben	
146-012-688	Cam	18	56801	SC 1.2	
146-012-689	Cam	19	56801	SC 2.1	
146-012-690	Cam	20	56801	SC 3.1	
146-012-691	Cam	21	56801		
146-012-697	Spacer Bolt		34101		
146-012-737	Ejector	80	35201		146-008-927
146-012-739	Fork	107	35201		146-001-800
146-012-782	Clamp	18	41501		146-008-695
146-012-805	Cam	9	35130	AND 2	146-002-055
146-012-812	Cam	7	35130	AN 1.2	146-010-632

146-012-813	Cam	21	35301	AN 5-21	146-010-631
146-012-814	Strap	129	35301		
146-012-839	Actuating Lever	70	35110		
146-012-846	Pinion		75001		
146-012-888	Draw Spring	165	71025		
146-012-889	Draw Spring	78	71055		
146-012-915	Plate with Ceramic Insert	457	56801		
146-012-917	Cover Plate	395	56801		
146-013-028	Cylinder	3	34101		146-011-166
146-013-069	Threading Plate	36	40160		146-010-594
146-013-261	Control Lever	10	37201		146-001-311
146-013-276	Toothed Wheel	114	71030		
146-013-281	Adapter Ring	73	34101	55/55mm	
146-013-322	Pressure Spring	109	72050		
146-013-328	Roller	18	35301		
146-013-527	Roller	36	70101		146-016-438
146-013-544	Opener Arm	258	56801		147-028-010
146-013-579	Clamping Plate	233	75010		
146-013-587	Coupling Half	106	33010		
146-013-605	Magazine Carrier	4	27050		146-007-572
146-013-608	Shield	17	35130		146-010-853
146-013-610	Strap	290	35101		146-001-188
146-013-619	Lever	305	56801		146-015-672
146-013-652	Shaft	17	72040		
146-013-667	Adapter Ring	89	34101	59mm (5^57)	146-011-166
146-013-707	Shaft	12	40160		147-023-351
146-013-756	Cam Assambly Shaft	3	33010		
146-013-757	Sleeve	164	72001		
146-013-801	Roller Support	35	75002		146-002-088
146-013-806	Shaft	174	75002		
146-013-807	Roller Carrier	16	70101		
146-013-887	Flange	390	71030		146-009-938
146-013-919	Pull Rod Cpl.	903	56801		146-000-131
146-014-024	Cpl. Guide Bow				
146-014-038	Button	6	30107		
146-014-105	Switch Lever	196	75010		
146-014-208	Lever	380	71050		
146-014-220	Damping Washer	48	32510	11x18x2,5	147-032-329
146-014-234	Toothed Wheel	433	71030		146-012-204
146-014-235	Toothed Wheel	432	71030		146-012-205
146-014-256	Swivel Lever	65	72050		
146-014-308	Shaft	449	71030		146-016-837
146-014-427	Drive Disk -Red-	104	42001		
146-014-545	Swivel Bow	7	72030		146-008-984
146-014-558	Transfer Wire	36	72045		146-007-256
146-014-563	Pointer	303	56801		

146-014-723	Adjusting Plate	9	35201		146-001-797
146-014-841	Mounting Angle	81	72050		
146-015-021	Drive Whell	73	72035		146-008-584
146-015-022	Pinion	9	33015	3"x4"x5"x6"	
146-015-046	Guide Wire	132	37201		
146-015-085	Conveyor Belt		60202	124 x 7.930 mm.	
146-015-098	Retainer Plate	8	70101		146-003-885
146-015-213	Adapter Ring	113	34101	68mm/Gummi	
146-015-213	Adaptor Ring	113	34101	68mm/ Metal	
146-015-224	Piston	12	30120		147-019-337
146-015-282	Strap	50	30130		
146-015-355	Cutting Plate	15	41501		147-027-287
146-015-400	Pressure Spring	99	75002		
146-015-401	Guide Bolt	43	75002		
146-015-403	Bush	98	75002		
146-015-415	Cutting Knife	102	41501		146-007-386
146-015-447	Carrier Bush	17	34201		146-004-471
146-015-466	Supporting Angle	62	41501		
146-015-542	Yarn Guide	367	56801		
146-015-543	Tension Disc	19	40105		
146-015-557	Cradle Lift	11	72020		146-007-751
146-015-589	Yarn Angel	61	30395		147-022-619
146-015-648	Nozzle Shutter	12	72030		146-007-766
146-015-672	Lever	305	56801		146-013-619
146-015-695	Toothed Wheel	433	71030		146-014-234
146-015-696	Pinion	432	71030		146-014-235
146-015-697	Shaft	457	71030		146-008-947
146-015-701	Head	425	71030		
146-015-765	Bush	44	71020		
146-015-885	Yarn Guide Clamp	60	30395	Links	147-029-097
146-015-974	Torsion Spring	130	40167		
146-015-998	Spring	41	40105		
146-016-006	Lever	3	30115		
146-016-011	Intermediate Shaft	81	71050		
146-016-014	Yarn Trap	107	42001		
146-016-043	Roller	22	70101		146-016-437
146-016-128	Clamp	18	41501		146-012-782
146-016-137	Supporting Angle	62	41501		146-015-466
146-016-138	Cover Plate	122	41501		146-006-588
146-016-144	Cover Plate	118	41501		
146-016-258	Strap	112	35101		146-001-234
146-016-300	Fuse Element	142	72050		
146-016-301	Bolt	144	72050		
146-016-356	Scissors Blade	112	71020		
146-016-391	Gera Wheel	39	35151		146-010-122
146-016-394	Brake Ring with out Magnet	37	34101		146-017-389

146-016-431	Cam	78	71001	X - 5.8	
146-016-437	Roller	22	70101	only the Roll	146-016-043
146-016-438	Roller	50	75002		
146-016-438	Roller	36	70101	Kpl.mit Lager	146-013-527
146-016-469	Elbow	111	41501		146-007-392
146-016-496	Shaft	72	71020		
146-016-537	Opener Arm RED	34	32510		146-010-813
146-016-608	Roller	17	32501	394290 ZZ	146-000-196
146-016-646	Clamping Pinion	405	71030		
146-016-704	Gripper Arm Tube	3	33050		146-010-724
146-016-706	Buffer	7	34101		146-017-240
146-016-736	Cover	41	71020		
146-016-752	Pressure Rod	132	40167		
146-016-800	Strap	321	71030		146-013-532
146-016-802	Lever	301	71030		146-013-819
146-016-837	Shaft	449	71030		146-014-308
146-016-839	Pinion	465	71030	Z=24	146-008-945
146-016-841	Pinion	466	71030	Z=9	146-008-946
146-016-846	DC Motor	397	71030		886-164-005
146-016-881	Guide Bush	8	34101	2 Rillen / 2 Grooves	
146-016-890	Mounting Bracket	16	30125		
146-017-043	Adjusting Bush	44	75002		
146-017-065	Base Plate	366	71050		
146-017-069	Scissors Housing	9	33045		147-032-545
146-017-069	Scissors Housing	67	81551		
146-017-069	Scissors Housing	171	82585		
146-017-088	Guide	90	71050		
146-017-113	Bearing Shaft	194	75002		146-010-162
146-017-114	Strap	195	75002		146-010-163
146-017-177	Adapter Ring	96	34101	62,5mm	
146-017-197	Bearing Flange	10	33050		146-008-114
146-017-207	Adapter Ring	117	34101	71mm	
146-017-240	Buffer	7	34101		146-017-582
146-017-275	Drum Spindle with Magnet	3	30301		
146-017-289	Suction Tube	13	33015		147-032-176
146-017-349	Lever	136	71050		
146-017-389	Brake Ring with out Magnet	37	34101		146-016-394
146-017-389	Brake Ring with Magnet	37	34101		
146-017-421	Adaptor	72	34201	DM 30	
146-017-457	Bearing Shaft	15	56801		146-000-086
146-017-582	Buffer	7	34101		146-017-240
146-340-411	Conveyor Belt			66 x 40.040mm	
146-340-412	Conveyor Belt			66 x 47.210mm	
146-342-106	Conveyor Belt		60101	124 x 43.990mm	
146-342-111	Conveyor Belt 124 x 38.802				
146-342-409	Conveyor Belt		60108	85 x 18.927mm	

146-343-702	Conveyor Belt 62 x 3.268mm				
146-343-703	Conveyor Belt			62 x 3.268mm	
146-345-111	Conveyor Belt 160 x 23.690mm				
146-655-451	Initiator	104	70101		
146-655-451	Initiator	50	75021	NPN 6 MMs	
147-000-081	Threading Plate	108	41501		146-007-721
147-000-103	Cam	20	56801	WSC 3	
147-000-104	Connecting Rod	178	56801		
147-000-109	Torsion Spring	184	56801		
147-000-166	Cam	12	33010	WFU 3	
147-000-173	Shield	97	33010		146-000-579
147-000-175	Cam Follower	66	33010	FU 2	147-028-506
147-000-187	Cam	9	33005	wf 01	
147-000-190	Cam	18	33005	wf 04	146-002-106
147-000-324	Grovenor	47	35101		147-006-524
147-000-400	Control Rod	197	35101		147-000-401
147-000-401	Control Rod	197	35101		147-000-400
147-000-885	Toothed Segment	96	35101		
147-000-886	Toothed Segment	113	35101		
147-001-175	Cam Follower	66	33010	WFu2	
147-001-263	Sleeve	112	42001		
147-001-497	Pinion	6	33005		
147-001-652	Limit Stop	205	81501		
147-001-733	Screw	202	81501		
147-001-984	Gripper Arm Tube	3	33050		146-010-724
147-002-492	Cam Shaft	3	33005	Oben	
147-002-526	Spacer Bush	50	33005		
147-002-597	Draw Spring	53	81501		
147-002-973	Gasket	44	33050		
147-003-076	Scissors Shaft	58	81551		
147-003-288	Gripper Arm Tube	4	33050		
147-003-290	Gripper Arm Tube	9	33050		
147-003-614	Gear Wheel	115	81280		
147-003-737	Cam Follower	52	33010	WFu3	147-028-507
147-003-740	Connecting Lever	141	35101		
147-003-791	Torsion Spring	22	35101		
147-003-797	Connecting Rod	72	35101		147-026-428
147-003-799	Pivoting Shear Blade	84	35101		
147-003-800	Leaf Spring	85	35101		
147-003-801	Pull Rod	99	35101		147-026-429
147-003-805	Elbow	40	35101		
147-003-806	Elbow	133	35101		
147-003-813	Cylinder	131	35101	DM 12X25	
147-003-879	Bracket	15	20101		
147-003-963	Rod	260	35101		
147-003-964	Connecting Rod	262	35101		

147-003-983	Connecting Rod	280	35101		
147-004-028	Joint	256	81250		
147-004-034	Bearing Piece	193	81250		
147-004-042	Drive Bush	146	81260		147-020-563
147-004-047	Lever	198	81250		
147-004-165	Connecting Rod	261	35101		
147-004-249	Motor Pinion	35	60530		
147-004-255	Pinion Shaft	8	60530		
147-004-259	Pinion Shaft	13	60530		
147-004-857	Buffer	42	80101		
147-004-931	Shaft	3	61010		
147-005-009	Conveyor Belt		83550	70 x 1.811mm	
147-005-112	Conveyor Belt	52	80201	70 x 4.388mm	
147-005-513	Torsion Spring	41	40105		
147-005-651	Clamping Piece	204	81250		
147-005-757	Cover Plate	99	40101		
147-005-830	Sider	111	81551		
147-005-842	Bush	115	81551		
147-005-843	Bush	116	81551		
147-005-843	Bush	191	81551		
147-005-921	Gear Wheel Shaft	15	83025		
147-005-922	Gear Wheel Shaft	10	83025		
147-005-946	Stopping Element	7	30107		
147-005-947	Pressure Spring	8	30107		
147-005-976	Bearing Bracket	130	81250		
147-005-993	Wall	7	77520		
147-006-003	Bolt	135	77520		
147-006-010	Inclination Roller	179	77520		
147-006-015	Clamping Half	208	77520		
147-006-016	Stop Bow	207	77520		
147-006-437	Roller	234	81250		147-032-874
147-006-524	Grovenor	47	35101		147-000-324
147-006-576	Ring	69	85501		
147-006-579	Cover	73	82501		
147-006-643	Intermediate Piece	13	64201		
147-006-646	Limit Stop	60	64201		
147-006-675	Actuating Fork	130	40101		
147-006-676	Cam	12	33005	WFO 2,2	
147-006-975	Roller Carrier	47	82505		
147-006-980	Roller Carrier	52	82505		
147-007-088	Torsion Spring	167	77520		
147-007-100	Lever	326	81250		147-020-400
147-007-403	Roller	42	82505		
147-007-474	Yarn Guide Plate	108	35101		
147-007-475	Yarn Guide Plate	111	35101		
147-007-499	Strap	228	83025		

147-007-502	Bolt	227	83025		
147-007-512	Hexagonal Tube	14	37701		147-015-491
147-007-777	Lever	208	35101		
147-007-778	Control Bolt	211	35101		
147-007-779	Bolt	209	35101		
147-007-782	Bracket	100	82511		
147-007-789	Bolt	105	82511		
147-007-791	Pressure Spring	136	82510		
147-007-816	Lever	170	77520		
147-007-817	Stop Lever	160	77520		
147-007-985	Draw Spring	68	33010		
147-008-025	Bearing Shaft	47	33050		
147-008-028	Bearing cover	51	33050		
147-008-029	Bearing Flange	53	33050		
147-008-034	Torsion Spring	56	33050		
147-008-134	Connecting Rod	457	35101		147-026-426
147-008-199	Funnel Half	62	85520		
147-008-276	Butterfly Lever	46	81501		
147-008-381	Yarn Guide Plate	103	35101		147-027-292
147-008-630	Conveyor Belt			70 x 2.210 mm.	148-006-978
147-008-713	Yarn Guide Plate	88	35101		
147-008-794	Conveyor Belt		63001	120 x 2.650 mm.	
147-008-795	Conveyor Belt	38	63001	60 x 483 mm.	
147-008-829	Bobbin Stop	13	85510		
147-008-848	Drive Roller	20	62530		
147-008-859	Drive Roller	30	62030		
147-009-211	Draw Spring	256	85505		
147-009-273	Stop Disc	66	85505		
147-009-288	Gasket	292	35101		
147-009-392	Opener Arm	12	82505		
147-009-437	Clamping Piece	95	81501		
147-009-506	Guide Roller	265	81151		
147-009-508	Side Part	212	81501		
147-009-509	Square Block	245	81501		
147-009-511	Swing Lever	255	81501		
147-009-520	Connecting Rod	242	81501		
147-009-601	Bracket	85	82501		
147-009-611	Draw Spring	72	82585		
147-009-668	Plate	131	81551		
147-009-781	Bush	213	81501		
147-009-782	Latch	283	81501		147-017-419
147-009-783	Pull Relief	225	81501		
147-009-784	Cover	185	81501		
147-009-785	Cover	186	81501		
147-009-788	Gasket	288	81501		
147-009-788	Gasket	288	81501		

147-009-807	Guide Plate	41	64201		
147-009-914	Latch	21	35101		147-018-502
147-010-296	Swing Lever	57	85050		
147-010-296	Swing Lever	63	85050		
147-010-299	Swing Lever	57	85050		
147-010-299	Swing Lever	63	85050		
147-010-308	Gear Wheel				
147-010-309	Gear Wheel				
147-010-311	Gear Wheel				
147-010-318	Shaft Joint	143	83570		
147-010-701	Torsion Spring	22	30125		
147-011-299	Draw Spring	55	82501		
147-011-316	Lever	3	63020		147-019-036
147-011-319	Centriering Wire	13	63020		
147-011-488	Bearing Flange	201	85530		
147-011-524	Bearing Ring	66	82501		
147-011-531	Adjusting Rod	295	85730		
147-011-533	Adjusting Rod	171	85730	Unten	
147-011-577	Pile Wheel	35	81501		
147-011-663	Cutter Plate	81	35101		
147-011-665	Swing Lever	249	35101		
147-011-666	Swing Lever	250	35101		
147-011-667	Support	75	35101		147-027-289
147-011-668	Deflection Lever	56	35101		
147-011-850	Locking Lever	275	85541		
147-011-867	Lever	47	85541		
147-011-878	Carrier		83025		
147-011-972	Draw Spring	215	85730		
147-012-098	Ejector Raw	34	82501		
147-012-101	Ejector Ring	38	82501		
147-012-186	Guide Plate	41	64201		
147-012-326	Draw Spring	251	81151		
147-012-373	Fixation Strap	54	30101		
147-012-402	Roller	249	81151		
147-012-402	Roller	249	81501		
147-012-439	Locking Ball	13	33050		147-015-996
147-012-440	Cover	15	33050		
147-012-791	Base Plate	230	81501		
147-012-941	Bearing	440	81250		
147-012-942	Shaft	446	81250		147-032-260
147-012-944	Roller	452	81260		147-021-908
147-012-944	Roller	452	81290		
147-012-945	Supporting Ring	451	81290		
147-012-947	Clamping Ring	444	81250		
147-012-978	Lever	225	81260		147-012-977
147-013-059	Guide	104	81501		

147-013-713	Clamping Piece	92	64201		
147-013-748	Plate	42	85060		
147-013-828	Draw Spring	214	85730		
147-013-926	Stop Lever	472	81280		
147-013-927	Switch Lever	467	81250		147-021-536
147-013-968	Sensor Bracket	457	81250		
147-014-139	Chain Carrier	140	40101		
147-014-141	Lever	150	40101		
147-014-307	Sude Rail	105	85050		
147-014-389	Toothed Wheel	49	85050	Z = 35	
147-014-402	Slider	16	33050		
147-014-406	Connecting Flange	37	33050		
147-014-408	Seal Ring	55	33050		
147-014-603	Limit Stop	140	85050		
147-014-611	Shaft	92	85050		147-027-763
147-014-612	Shaft	45	85050		
147-014-613	Shaft	39	85050		
147-014-614	Stay Bolt	28	85050		
147-014-618	Connecting Rod	73	85050		
147-014-621	Shield	98	85050		
147-014-623	Shield	96	85050		
147-014-636	Spacer Bolt	152	85050		
147-014-709	Base Plate	98	83501		
147-014-748	Switch Housing	3	30107		146-003-221
147-014-931	Control Lever	33	82505		
147-015-014	Base Plate	65	40105		146-009-340
147-015-019	Toothed Segment	35	33010		
147-015-033	Conveyor Belt	352	80251	70 x 4.089mm	
147-015-073	Cam	8	33010	WFU 1.6	
147-015-085	Conveyor Belt with Pegs			124 x 3.080mm	
147-015-094	Ejector Raw	18	82501		
147-015-124	Cpl. Switch Housing	5	30107	mit Knopf	146-008-018
147-015-124	Button Box -only-	2	30107	ohne alles	146-014-037
147-015-140	Spring	229	83025		
147-015-466	Control Lever	142	35301		146-001-287
147-015-491	Hexagonal Tube	14	37701		146-007-512
147-015-540	Lever	225	81280		
147-015-666	Control Lever	190	35101		147-026-251
147-015-667	Strap	167	35101		147-026-253
147-015-781	Shaft	129	61010		
147-015-795	Pinion Shaft	21	61010		
147-015-808	Pinion Shaft	85	61010		
147-015-996	Locking Ball	13	33050		147-025-476
147-016-022	Spring Bolt	145	82005		
147-016-025	Elbow	283	82005		
147-016-032	Chain Carrier	68	82005		147-017-731

147-016-034	Shaft	3	82007		147-025-475
147-016-041	Elbow Lever	154	82005		
147-016-164	Coupling Half	135	62551		
147-016-493	Drive Disc	112	64440		
147-016-506	Valve Plate	123	64440		
147-016-529	Adjusting Rod	200	85050		
147-016-530	Strap	202	85050		
147-016-532	Mounting Piece	207	85050		
147-016-549	Scissors Housing	98	64440		
147-017-113	Bearing	26	63020		
147-017-116	Bearing	26	63020		
147-017-355	Pin	393	83540		147-026-257
147-017-385	Guide Plate	280	81501		
147-017-508	Fork Link	42	64302		
147-017-600	Supporting Disc	145	81250		147-026-685
147-017-685	Ejector Ring (Only Ring)	125	81560		
147-017-731	Chain Carrier	68	82005		147-016-032
147-017-795	Scissors Blade	60	81501		
147-017-796	Scissors Blade	61	81501		
147-017-929	Yarn Relaeser	71	64201		147-023-213
147-017-930	Yarn Relaeser	70	64201		147-023-214
147-018-128	Locking Lever	145	62551		
147-018-261	Flap Bearing	25	64201		147-019-354
147-018-263	Support Angle	61	64201		
147-018-265	Clamping Piece	20	64201		
147-018-266	Lever	37	64201		147-019-350
147-018-273	Bush	46	64201		
147-018-273	Bush	59	81560		
147-018-408	Bolt	51	64201		147-019-348
147-018-499	Torsion Spring	45	64201		147-019-605
147-018-502	Latch	21	35101		147-009-914
147-018-532	Bearing Bolt	86	64201		147-019-455
147-018-558	Centrering	40	64201		
147-018-717	Lever	208	35101		
147-018-801	Connection Rod	40	33010		
147-018-972	Pinion	13	33050		146-011-157
147-019-036	Lever	3	63020		147-011-316
147-019-127	Yarn Guide Plate	108	35101		147-027-291
147-019-275	Centriering Wire	85	63021		
147-019-294	Yarn Trap	107	42003		147-001-042
147-019-337	Piston	12	30120		146-015-224
147-019-354	Flap Bearing	25	64201		147-018-261
147-019-356	Clamping Piece	20	64201		
147-019-426	Intermediate Piece	80	64201		147-018-513
147-019-481	Limit Stop	22	32510		146-009-756
147-019-513	Clamp Body	212	63601		

147-019-525	Conveyor Belt			60 x 2.633 mm.	
147-019-540	Coveyor Belt	55	61001	20x 924mm	147-010-074
147-019-551	Pinion	5	61010		
147-019-666	Retainertube		56801	Z/2	
147-019-669	Retainertube		56801	S/2	
147-019-680	Roller	31	61001		
147-019-681	Supporting Disc	29	61001		
147-019-709	Washer	28	61001		
147-019-938	Conveyor Belt			70 x 4.465mm	
147-020-000	Cam Follower	113	85730		
147-020-028	Shaft	23	85730		
147-020-029	Toothed Wheel	24	85730		
147-020-033	Bearing Flange	15	85730		
147-020-033	Bearing Flange	205	85730		
147-020-034	Fastening Plate	49	85730		
147-020-039	Spacer Tube	203	85730		
147-020-041	Spacer Bush	111	85730		
147-020-207	Chain Tens Gear Z=16	8	83510	Z=16	147-005-846
147-020-346	Yarn Relaeser	181	64201		
147-020-347	Yarn Relaeser	180	64201		
147-020-406	Buffer	42	80101		
147-020-528	Control Lever	75	37701	147 RM	
147-020-563	Drive Bush	146	81290		147-004-042
147-020-660	Guide Plate	47	42001		146-007-711
147-020-799	Connecting Rod	140	42001		
147-021-000	Adapter Ring	68	34101	52mm	
147-021-032	Cam	10	33010	WFU 2.1	
147-021-337	Segment	46	62510		
147-021-908	Roller	452	81260		147-012-944
147-022-009	Conveyor Belt	55	61001	20 x 859mm	
147-022-120	Scissors Housing	12	64302		
147-022-226	Lever Arm	232	85730		
147-022-600	Coupling Half	106	33010		146-001-950
147-022-600	Coupling Half	433	56801		
147-022-610	Bearing	52	61015		
147-022-619	Yarn Angel	61	30395		146-015-589
147-022-917	Centre Piece	209	63601		
147-022-939	Adapter Ring	103	34101	64mm/ Gummi	
147-022-990	Gasket Plate	69	64201		147-006-650
147-023-351	Shaft	12	40160		146-013-707
147-023-364	Scissors Shaft	58	81501		
147-023-377	Screw	19	35101		
147-023-620	Belt	130	85050		
147-023-774	Lifter Cam	49	30310		
147-023-923	Catch Hook	193	56801		147-032-674
147-024-124	Yarn Guide Plate	103	35101		147-024-125

147-024-142	Buffer	39	61010		
147-024-157	Bobbin Carrier (Top only) V Type / L=63	30	80591	18/21	
147-024-158	Bobbin Carrier (Top only) D Type / L=77	30	80591	18/21	
147-024-160	Bobbin Carrier (Top only) D Type / L=77	30	80591	20/23	
147-024-162	Bobbin Carrier (Top only) D Type / L=77	30	80591	22/25	
147-024-200	Latch	62	82520		
147-024-459	Cam Follower	54	85730		
147-024-491	Buffer	280	85501		
147-024-494	Guide Plate	186	85501		
147-024-513	Gear Wheel (Plastic)		61001		
147-024-534	Scissors Shaft	273	64302		
147-024-749	Pivoting Sleeve	51	72030		
147-024-850	Brake Ring Red		34101		
147-024-866	Yarn Cutter	659	28020		
147-024-887	Scissors Shaft	273	64302		
147-025-022	Torsion Spring	70	37701	147RM	
147-025-067	Feeler Arm	16	82007		
147-025-070	Feeler Arm	36	82007		
147-025-476	Locking Ball	13	33050		147-015-996
147-025-497	Shaft	66	56801		146-001-768
147-025-498	Shaft	80	56801		
147-025-554	Cover	20	80591		
147-025-724	Mounting Plate	50	64201		
147-025-905	Ejector Ring (Only Ring)	200	81560		
147-025-973	Conveyor Belt	30	63001		
147-025-974	Conveyor Belt	275	80251		147-010-745
147-025-975	Conveyor Belt	526	80251	60 x 3.437mm	
147-025-976	Conveyor Belt		80251	60 x 1.532mm	
147-025-977	Conveyor Belt		62501	20 x 1.595 mm.	147-015-643
147-025-994	Bobbin Carrier (Bottom only)	17	80591		
147-026-212	Connector	5	33050		
147-026-239	Gripper Arm Tube	9	33050		
147-026-241	Gripper Arm Tube	4	33050		
147-026-251	Control Lever	190	35101		147-019-152
147-026-253	Strap	167	35101		147-003-290
147-026-391	Ejector Ring	90	82502		147-003-288
147-026-426	Connecting Rod	457	35101		147-008-134
147-026-427	Connecting Rod	280	35101		147-015-667
147-026-428	Connecting Rod	72	35101		147-003-797
147-026-429	Pull Rod	99	35101		147-003-801
147-026-430	Connecting Rod	261	35101		
147-026-431	Connecting Rod	262	35101		
147-026-432	Rod	260	35101		
147-026-435	Scissors Blade	19	64302		
147-026-436	Scissors Blade	136	82520		
147-026-582	Retainer Tube	447	56801		

147-026-584	Retainer Tube	453	56801		
147-026-586	Retainer Tube	450	56801		
147-026-652	Cam	137	85730		
147-026-866	Shaft	26	61001		
147-026-916	Shaft	9	61001		
147-026-917	Shaft	3	61001		
147-027-289	Support	75	35101		147-011-667
147-027-291	Yarn Guide Plate	108	35101		
147-027-337	Torsion Spring	3	64201		147-018-499
147-027-954	Ejector Ring	144	64204		
147-028-010	Opener Arm	258	56801		
147-028-452	Ejector Ring	90	82502		
147-028-499	Toothed Segment	34	33005	FO 1	
147-028-500	Cam Follower	69	33005		146-013-544
147-028-501	Cam Follower	80	33005	f 04	
147-028-503	Lever	38	33010		147-032-530
147-028-504	Toothed Segment	38	33010	FU 1	146-000-305
147-028-505	Cam Follower	66	33012		
147-028-506	Cam Follower	66	33010	WFu2	146-000-309
147-028-507	Cam Follower	52	33010	WFu3	147-032-616
147-028-508	Cam Follower	49	35301		
147-028-512	Cam Follower	34	56801		146-000-122
147-028-661	Roller Carrier	71	75002		
147-028-662	Roller Carrier	12	75002		
147-028-878	Cover Plate	99	40101		
147-028-892	Spring	114	40101		
147-028-969	Catch Hook	75	40101		147-003-737
147-028-992	Carrier Plate	363	56801		
147-029-097	Yarn Guide Clamp	60	30395	Links	146-015-885
147-029-285	Deflection Plate	15	30380	6" Links	146-008-642
147-029-285	Deflection Plate (6-Left)	15	30380		
147-029-287	Deflection Plate	15	30380	6"Links	
147-029-293	Deflection Plate	17	30380	6"Rechts	
147-030-172	Yarn Clamp	266	56801		
147-030-303	Pull Rod	902	56801		
147-030-304	Pull Rod	903	56801		146-000-249
147-030-515	Locking Lever	126	40167		
147-030-539	Bearing Shaft	37	85730		
147-030-576	Piston	20	30120		146-000-256
147-030-628	Clamp	18	41501		146-008-463
147-030-629	Bush	32	41501		146-007-460
147-030-632	Bolt	11	41501		146-007-163
147-030-637	Latch	38	41501		146-009-648
147-030-638	Conveyor Belt			65 x 2.210mm	
147-030-844	Cam Follower	78	71061		
147-030-873	Cam Follower	4	71030		

147-030-874	Cam Follower	158	71025		146-016-128
147-030-876	Lever	230	71030		
147-030-878	Cam Follower	526	71030		???
147-030-880	Rollerlever	83	71035		146-009-271
147-030-881	Rollerlever	65	71045		146-012-572
147-030-882	Cam Follower	174	71050		146-007-250
147-030-883	Cam Follower	442	71050		146-003-914
147-030-885	Rollerlever	237	71070		
147-030-886	Cam Follower	84	72020		146-006-861
147-030-887	Cam Follower	65	72025		146-003-848
147-030-888	Cam Follower	95	72030		
147-030-889	Deflectorlever	49	72040		146-003-660
147-030-890	Cam Follower	103	72040		
147-030-891	Cam Follower	85	72045		146-004-561
147-030-914	Actuating Lever	134	40167		
147-031-482	Lever	41	41001		
147-031-505	Coupling Gear	32	33060		146-002-221
147-032-131	Stop Bush		71030		146-003-622
147-032-176	Suction Tube	13	33015		146-000-556
147-032-183	Torsion Spring	36	41501		146-000-705
147-032-219	Roller	234	81250		147-032-874
147-032-258	Shaft	135	81250		147-004-041
147-032-329	Damping Washer	29	32510		
147-032-350	Scissors Actuating Lever	105	56801		
147-032-435	Cover	16	33045		146-010-282
147-032-443	Cover	17	64302		
147-032-444	Toothed Segment	34	33005	FO 1	
147-032-522	Coupling	141	85720		
147-032-527	Swivel Lid	67	37701	147RM/Plastic	147-024-590
147-032-529	Lid Bearing	20	37701	147RM/Plastic	147-025-989
147-032-530	Toothed Segment	34	33005	FO 1	147-032-678
147-032-545	Scissors Housing	9	33045		146-006-432
147-032-581	Brake Ring with out Magnet	37	34101		
147-032-585	Brake Bush	17	34101		
147-032-615	Toothed Segment	30	33010		
147-032-616	Lever	38	33010		
147-032-678	Toothed Segment	34	33005	FO 1	146-000-295
147-032-775	Wax Shaft	97	42001		
147-032-874	Roller	234	81250		
147-343-207	Conveyor Belt 160 x 15.300mm				
147-343-213	Conveyor Belt			160 x 21.920mm	
147-343-218	Conveyor Belt 160 x 28.540mm				
147-343-235	Conveyor Belt			160 x 42.660mm	
147-343-902	Centrerling Half	72	85520	DM 65/36	147-032-444
147-343-903	Centrerling Half	72	85520	DM 65/30	
147-346-911	Conveyor Belt			49 x 19.049mm	147-355-111

147-351-824	Conveyor Belt			157 x 19,410mm	
147-351-826	Conveyor Belt			157 x 20,690 mm.	
147-351-829	Conveyor Belt	236	77505	157 x 23,225mm	
147-351-859	Conveyor Belt		77505	157 x 43,135mm	
147-351-860	Conveyor Belt 157 x 46,195mm			157 x 46,195mm	
147-355-005	Conveyor Belt			17,546 x 94mm	
147-355-009	Conveyor Belt			94 x 21,612mm	
147-355-013	Conveyor Belt	38	60530	94 x 25,458mm	
147-355-029	Conveyor Belt 94 x 45,348mm				
147-355-102	Conveyor Belt			49 x 9,860mm	
147-355-107	Conveyor Belt		62030	49 x 14,983 mm.	147-346-907
147-355-112	Conveyor Belt		62030	49 x 20,331mm	
147-355-113	Conveyor Belt			49 x 21,613mm	
147-355-118	Conveyor Belt			49 x 28,243mm	
147-355-129	Conveyor Belt		62030	49 x 41,603mm	
147-355-205	Conveyor Belt	400	61530	94 x 13,200mm	
147-355-209	Conveyor Belt			94 x 17,266mm	
147-355-213	Conveyor Belt			94 x 21,112mm	
147-355-218	Conveyor Belt			94 x 27,742mm	
147-355-224	Conveyor Belt 94 x 34,372mm				
147-355-229	Conveyor Belt	210	61530	94 x 41,002 mm.	
147-357-010	Conveyor Belt			124 x 31,603mm	
147-655-298	Circuit Board				
147-655-380	Light Barrier	8045	84560		
148-000-000	Gear Wheel for Tension Disc (old Typ)	for Pos 74	36001		
148-000-000	Gear Wheel for Tension Disc (New Typ)	for Pos 74	36001		
148-000-388	Torsion Spring	21	36811		
148-000-439	Torsion Spring	219	36811		
148-000-457	Leaf Spring	267	36802/36801		
148-000-458	Bush	268	36801		
148-000-566	Draw Spring	450	82010		
148-000-569	Pull Rod	1	30125		
148-000-574	Actuating Rod	11	30125		
148-000-835	Torsion Spring	67	37720		
148-000-840	Pull Rod	97	37720		
148-000-842	Switch Rod	105	37720		
148-000-876	Pressure Rod	110	37710		
148-000-963	Pressure Rod (left)	108	37740		
148-000-964	Pressure Rod (right)	109	37740		
148-001-450	Thrust Collar	42 & 50	50120		
148-001-558	Clamp Collar	19	30130		
148-001-718	Cpl.Pull Rod with Universal Joint		52050		
148-001-719	Connecting Rod	57	52050		
148-001-853	Seal		36301		
148-002-016	Toothed Lock Washer	2	52010		
148-002-018	Retainer Plate	22	32530		

148-002-107	Cpl.Pull Rod with Universal Joint		52160		
148-002-108	Toggle Rod		52160		
148-002-204	Pull Rod Plastic	97	36802/36801		
148-002-205	Pull Rod Plastic	109	36802/36801		
148-002-328	Pull Rod		52053		
148-002-329	Cpl.Pull Rod with Universal Joint		52050		
148-002-330	Cpl.Pull Rod with Universal Joint		52053		
148-002-331	Cpl. Pull Rod with Universal Joint		52120		
148-002-332	Pressure Rod	4	52120		
148-002-361	Cpl.Pull Rod with Universal Joint	29	52110		
148-002-362	Pull Rod	30	52110		
148-002-371	Pull Rod	33	52030		
148-002-419	Cpl.Pull Rod with Universal Joint		52130		
148-002-420	Pull Rod		52130		
148-002-746	Scissors Blade Metal	255	36802/36801		
148-002-906	Cam Follower	1	52160		
148-003-028	Cam Follower	1	52110		148-020-981
148-003-093	Cam Follower	1	52030		
148-003-098	Cam Follower	31	52030		
148-003-103	Cam Follower RAA6	1	52130		148-020-997
148-003-148	Slide Washer	92	36001		
148-003-672	Conveyor Belt 124 x 3,200mm with Pegs RH		40130		
148-003-674	Conveyor Belt 124 x 3,200mm with Pegs LH		40130		
148-003-864	Pull Rod Plastic	36	33045		
148-004-031	Deflection Plate		30380		
148-004-032	Deflection Plate (6-Right)	17	30380		
148-004-303	Pull Rod	19	52110		
148-004-369	Actuating Rod	69	52150		
148-004-516	Protective Covering	33	30125		
148-004-545	Cap	10	32535		
148-004-565	Roller	23	52120		
148-004-566	Cradle Lift (old Typ)	21	52120		
148-004-570	Roller	26	52130		
148-004-597	Bolt	35	32501		
148-004-607	Carrier Bush	17	32535		
148-004-619	Hub	31	32535		
148-004-646	Cam Follower	1	52150		148-020-971
148-004-650	Adapter Plate Left (6-4)	7&18&31&	32535		
148-004-662	Cam Follower	14	52150		
148-004-742	Gasket	6	33045		
148-004-783	Gear Wheel Z=18	20	33015		
148-004-797	Draw Spring	44	37710		
148-004-870	Segment Lever	57	52030		
148-004-942	Actuating Lever	105	36001		
148-005-029	Cpl.Pull Rod with Universal Joint		52030		
148-005-030	Pull Rod	7	52030		

148-005-057	Cpl.Pull Rod with Universal Joint		52030		
148-005-057	Cpl.Pull Rod with Universal Joint		52030		
148-005-142	Drive Shaft	54	52030		
148-005-258	Scissors Blade Metal	250	36802/36801		
148-005-300	Rocker Shaft	153	52030		
148-005-312	Actuating Rod	169	52030		
148-005-499	Lifting Wire	404	83501		
148-005-714	Brake Ring	37	32530	immer Bild Senden	
148-005-801	Wire	22	38410		
148-006-003	Cam Follower RAH34	1	52120		
148-006-017	Cpl. Wire	50	52050		
148-006-064	Toothed Wheel Z=31 (old Typ)	81	36001		148-022-743
148-006-100	Bow		33045		
148-006-218	Housing Cover (Old Typ)	25	38060		
148-006-262	Draw Spring	49	33010		
148-006-393	Hinge Pin	81	40130		
148-006-443	Cam Follower KRA10	1	52050		148-012-810
148-006-444	Cam Follower KRR11	26	52050		
148-006-474	Holding Wire	21	11030		
148-006-702	Drive Roller	2	60550		
148-006-752	Bush	60	36502		
148-006-767	Pull Rod	14	37740		
148-006-768	Pressure Rod	24	37701		
148-006-772	Pull Rod	42	36060		
148-007-137	Draw Spring	15	30125		
148-007-286	Conveyor Belt 120 x 1.742mm				
148-007-613	Cam Follower HAA8	38	52140		148-020-993
148-007-619	Strap	31	52140		
148-007-804	Buffer	77	71050		
148-007-807	Conveyor Belt 60 x 3.896,5mm				
148-007-842	Gasket	130	65530		
148-007-843	Gasket	38	63020		
148-007-859	Roller	288	36831		
148-007-921	Belt 2440 x 10mm	62	70155		
148-007-976	Coding Magnet	7	78010		
148-008-035	Lever	17	36065		
148-008-070	Lever	116	36801		148-007-416
148-008-160	Conveyor Belt 60 x 1.859mm				
148-008-299	Threading Plate	155	36001		
148-008-401	Belt 2103 x 10mm	41	71050		
148-008-449	Conveyor Belt			85 x 1.378mm	
148-008-573	Friction Layer 118 x 78,5 x 2mm	8	65520		
148-008-592	Friction Layer 118 x 64 x 2mm	9	65520		
148-008-657	Spring Hook	140	99710		
148-008-712	Conveyor Belt			20 x 1.111mm	
148-008-796	Drive Roller	46	61020		

148-008-799	Conveyor Belt 49 x 6.601mm				
148-008-801	Conveyor Belt 49 x 10.614mm				
148-008-804	Conveyor Belt 49 x 13.143mm				148-021-587
148-008-806	Conveyor Belt			49 x 14.408mm	
148-008-834	Gasket	20	38001		
148-008-844	Rod	64	38001		
148-008-851	Pressure Spring	71	38001		
148-008-854	Draw Spring	84	38001		
148-008-855	Pull Rod Plastic	85	38001		
148-008-878	Pull Rod	46	38010		
148-008-879	Pull Rod	50	38010		
148-008-888	Draw Spring	82	38010		
148-008-893	Transfer Rod	23	52051		
148-008-930	Gasket	4	38050		
148-009-000	Conveyor Belt 60 x 495mm				
148-009-005	Roller	23	63025		
148-009-020	Conveyor Belt 4,372 x 95mm				
148-009-128	Drive Bush	142	64015		
148-009-218	Conveyor Belt 60 x 928mm				
148-009-265	Torsion Spring	12	38060		
148-009-266	Torsion Spring	20	38060		
148-009-416	Hook	35	30130		
148-009-500	Toothed Wheel Z=31 (New Typ)	81	36001		
148-009-575	Brake Bow (Old Typ)	6	37760	immer Bild Senden	
148-009-620	Conveyor Belt				
148-009-702	Stop Plate	8	50140		
148-010-084	Snarl Brake	18	38060	immer Bild Senden	
148-010-188	Lever	11	36065		
148-010-191	Base Plate	98	36001		
148-010-221	Tension Lever	128	37720		
148-010-223	Draw Spring	166	37601		
148-010-410	Pull Rod	131	36001		
148-010-501	Gasket	39	33045		148-005-805
148-010-554	Pull Rod	137	37740		
148-010-555	Pull Rod	138	37740		
148-010-600	Drive Wheel	6	52140		
148-010-602	Limit Stop	46	32510		
148-010-692	Spring Hook	22	52130		
148-011-016	Cpl.Pull Rod with Universal Joint	55	36501		
148-011-028	Roller w/o Bearing	194	64015		148-009-137
148-011-032	Cpl. Roller with Bearing	302	64015		
148-011-075	Limit Wire		37740		
148-011-193	Pressure Fork	118	36301		
148-011-249	Conveyor Belt 60 x 1.867mm				
148-011-363	Buffer	235	73030		
148-011-461	Torsion Spring	24	37720		

148-011-514	Brush	10	99710		138-015-652
148-011-851	Suction Tube	4	33020		
148-011-897	Draw Spring	41	33010		
148-011-953	Draw Spring	83	38001		
148-011-958	Locking Flap	5	36301		
148-012-012	Housing (Old Typ)	10	38060		148-010-219
148-012-029	Torsion Spring	102	37701		
148-012-095	Conveyor Belt 60 x 1.844mm				148-009-409
148-012-169	Depressor Lever	23	52130		
148-012-218	Stationary Shear Blade	16	36060		
148-012-257	Swivel Rod	99	37701		
148-012-270	Wax Shaft	144	36301		148-010-039
148-012-288	Actuating Rod	11	30125		
148-012-411	Actuating Rod	9	30125		148-000-573
148-012-572	Leaf Spring	125	36802/36801		148-010-455
148-012-612	Bearing Plate	70	38040		
148-012-782	Air Tube (left)				
148-012-784	Air Tube (right)				
148-012-803	Air Tube				
148-012-821	Pull Rod	22	52021		
148-012-822	Pull Rod	23	52051		
148-013-131	Leaf Spring	21	36060		
148-013-182	Cam Follower	15	52030		
148-013-196	Slide Washer	76	36001		
148-013-349	feeder Arm	130	36801		
148-013-364	Pressure Spring	44	65510		
148-013-752	Guide Wire	60	85575		
148-013-754	Guide Wire	60	85575		
148-013-937	Base Plate	5	36065		
148-014-123	Plate	74	38040		
148-014-181	Guide Wire		38210		
148-014-285	Pull Rod	14	36068		
148-014-340	Pull Rod	25	38201		
148-014-341	Pull Rod	31	38201		
148-014-477	Adapter Ring (Rubber) DM68mm	70	32530		
148-014-556	Draw Spring	38	38201		
148-014-562	Conveyor Belt 2.336 x 55mm				
148-014-829	Brake Lining	20	32530		148-002-013
148-015-292	Roller with Bearing	407	64010		
148-015-293	Roller Black w/o Bearing	411	64015		
148-015-768	Actuating Rod	9	30125		
148-015-813	Roller Oila	56	64010		
148-015-854	Scissors Shaft	11	38040		148-008-907
148-016-172	Clamping Lever Plastic	35	30125		148-000-578
148-017-127	Cradle Carrier Shaft	4	30115		148-006-852
148-017-423	Snarl Brake	18	38060	immer Bild Senden	

148-017-518	Bolt	8	33045		148-003-860
148-017-581	Stopping Element	6	30107		147-005-946
148-017-664	Brake Ring	36	32530	immer Bild Senden	148-005-467
148-017-671	Brake Ring	38	32530	immer Bild Senden	
148-017-674	Belt 5760 x 14mm Gellow				
148-017-733	Wire		78010		
148-017-748	Conveyor Belt 95 x 4.372mm				
148-017-763	Clamping Lever Plastic	5	30125		148-000-570
148-017-945	Adapter Plate	277	36802/36801		148-010-661
148-018-555	Housing (New Typ)	10	38060		
148-018-563	Lid Bearing Black	92	37701		148-004-960
148-018-564	Swivel Lid Black	104	37701		148-004-962
148-018-613	Housing Cover (New Typ)	25	38060		
148-019-324	Cpl.Pull Rod with Universal Joint		86011		
148-019-325	Pressure Rod		86011		
148-019-460	Connecting Rod		855410		
148-019-461	Connecting Rod		85541		
148-019-866	Pull Rod	36	36069		
148-020-026	Pull Rod	120	99710		
148-020-205	Tension Disc right (New Typ)	74	36001		
148-020-222	Cover Plate	152	36001		148-008-299
148-020-275	Lever	13	38060		148-016-057
148-020-535	Rubber Sleeve	165	36001		148-013-087
148-020-573	Control Rod		85520		
148-020-651	Actuating Rod	38	30125		
148-020-698	Scissors Blade	88	66020		
148-020-875	Cradle Lift (New Typ)	21	52120		
148-020-892	Magnet / Chip	39	78010		
148-021-010	Bow	118	99710		138-014-540
148-021-276	Suction Pipe Shutter	11 & 40	33050		148-016-316
148-021-277	Snarl Brake	18	38060	immer Bild Senden	
148-021-298	Cpl.Suction Pipe Shutter	18&12&	33050		
148-021-299	Bolt	18	33050		148-014-063
148-021-316	Rubber Cap 18 x 2 x 13,5mm	65	32510		
148-021-438	Guide Bow				
148-021-523	Starting Disc	77	36001		148-013-088
148-021-581	Conveyor Belt 49 x 5.355mm				
148-021-589	Conveyor Belt 49 x 14.408mm				
148-021-716	Intermediat Piece	122	36010		
148-021-731	Conveyor Belt				
148-021-830	Cam RAA6	20	52020		
148-021-863	Brake Bow (New Typ)	6	37760	immer Bild Senden	
148-022-457	Wire	32	52051		
148-022-509	Coupling Half	87	36802/36801		147-022-600
148-022-711	Cover 13mm	280	36840/36801		146-010-369
148-022-811	Tension Disc Left	141	36010		148-016-889

148-022-846	Guide Plate	9	36301		148-004-827
148-022-915	Rubber Washer	28	32510		
148-022-917	Screw Bolt	18	32530		148-021-315
148-023-047	Tension Disc right (old Typ)	74	36001		148-012-893
148-023-244	Gasket	34	33045		148-005-930
148-023-410	Conveyor Belt 120 x 1.742mm				
148-344-806	Conveyor Belt 124 x 42.480mm				
148-346-503	Conveyor Belt 94 x 16.000mm				
148-346-506	Conveyor Belt 94 x 19.846mm				
148-346-509	Conveyor Belt			94 x 23.912mm	
148-346-510	Conveyor Belt 94 x 25.194mm				
148-346-511	Conveyor Belt 94 x 26.476mm				
148-346-529	Conveyor Belt 94 x 45.064mm				
148-346-603	Conveyor Belt 90 x 12.134mm				
148-346-606	Conveyor Belt			90 x 15.980mm	
148-346-607	Conveyor Belt 90 x 17.482mm				
148-346-609	Conveyor Belt			90 x 20.046	
148-346-610	Conveyor Belt 90 x 21.328mm				
148-346-611	Conveyor Belt 90 x 22.610mm				
148-346-629	Conveyor Belt 90 x 41.218mm				
148-346-744	Conveyor Belt 157 x 42.800mm				
148-348-423	Drive Belt			10 x 26.204mm	
148-348-429	Conveyor Belt 10 x 27.455mm				
148-348-444	Drive Belt 10 x34.184mm				
148-348-463	Drive Belt			10 x 41.284mm	
148-348-475	Drive Belt 10 x 45.255mm				
148-348-476	Drive Belt 10 x 45.627mm				
148-352-511	Conveyor Belt			157 x 20.350mm	
148-352-515	Conveyor Belt 157 x 22.920mm				
148-352-518	Conveyor Belt 157 x 24.200mm				
148-352-536	Conveyor Belt 157 x 36.170mm				
148-352-544	Conveyor Belt 157 x 42.800mm				
148-353-815	Drive Belt			10 x 23.700mm	
148-353-821	Drive Belt			10 x 26.204mm	
148-353-825	Conveyor Belt 10 x 27.455mm				
148-353-828	Drive Belt 10 x 28.922mm				
148-353-870	Drive Belt 10 x 45.627mm				
148-656-060	Light Barrier (WT18-3N110S03)	5	50110		
148-675-403	Light Barrier (WL170-N135S03)	4	79030		
149-007-384	Wire	12	36301		
155-000-500	Bolt	185	85730		
155-001-112	Intermediate Piece	92	64302		
155-003-540	Friction Disc	77	10130	dia.=34 mm.	
155-004-828	Friction Disc	77	10130	dia.=62 mm.	
155-004-847	Friction Disc	77	10130	dia.=48 mm.	
155-344-204	Conveyor Belt			66 x 18.288mm	

155-344-206	Conveyor Belt		40120	66 x 21.610 mm.	
155-344-208	Conveyor Belt		40120	66 x 24.165 mm.	
155-352-712	Tube	48	10120		
158-001-444	Roller				
158-005-366	Round Cord Belt (blue)	21	35050	188 x 6 mm.	158-022-434
158-006-186	Stretcher Plate	25	35101		
158-006-328	Torsion Spring	38	35101		
158-010-969	Bush	53	61010		
158-011-655	Release Bow	20	35101	rechtes	
158-012-687	Draw Spring	170	85501		
158-015-198	Scissors Blade	3	19910		
158-015-199	Scissors Blade				
158-015-200	Scissors Blade				
158-015-201	Scissors Blade	86	85020		
158-015-202	Scissors Blade	44	85020		
158-017-416	Toggle Joint	166	85730		
158-017-522	Pressure Spring	125	64440		
158-018-293	Pressure Spring	38	85020		
158-018-302	Bracket	24	85020		
158-018-306	Bolt	26	85020		
158-018-421	Torsion Spring	101	85020		
158-018-879	Shield	4	85035		
158-018-891	Lever	38	85035		
158-018-894	Clamping Half	46	85035		
158-018-895	Clamping Half	47	85035		
158-018-897	Cover Support Bar	53	85035		
158-019-005	Conveyor Belt			100 x 3.910mm	
158-019-098	Release Bow	21	35101		
158-019-101	Stretcher Plate	26	35101		
158-019-202	Cover Plate	70	85035		
158-019-227	Guide Plate	48	85030		
158-019-641	Toothed Wheel	73	85501		
158-019-703	Scraper	28	35101		
158-019-705	Scraper	29	35101		
158-019-796	Crank Rod	19	85035		
158-019-993	Round Cord Belt			931 x 6mm.	158-006-628
158-022-006	Bearing Bolt	71	85730		
158-022-353	Conveyor Belt w/o Cleats / Left		65002	124 x 6.656 mm.	
158-022-353	Conveyor Belt w/o Pegs			124 x 6.656 mm.	
158-022-354	Conveyor Belt w/o Cleats / Right		65002	124 x 6.656 mm.	
158-022-375	Pressure Spring	75	64201		147-017-761
158-022-434	Round Cord Belt (blue)	21	35050	188 x 6 mm.	158-005-366
824-894-023	Maintenance Spray RS400				im moment nicht I
830-321-013	Grooved Nut	74	35130	KM 3	
830-335-001	Spacer Washer	11	35130	22,2x44x3	830-335-001
830-335-002	Spacer Washer	10	33005	22,2x44x4	

830-335-002	Spacer Washer	13	33005	22,2x44x4	
830-335-002	Spacer Washer	7	33005	22,2x44x4	
830-335-005	Spacer Washer	13	33005		
832-655-002	Needle Bearing			HK 0810	
832-655-003	Needle Bearing			HK 1210	
832-655-004	Needle Bearing			HK 1522	
832-655-005	Needle Bearing			HK 1010	
832-655-042	Needle Bearing			HK 1516	
832-655-053	Needle Bearing			HK 0808	832-830-123
832-655-061	Needle Bearing			HK 1512	
832-655-900	Needle Bearing			HK 0609	
832-698-009	Cam Roller				
832-698-013	Cam Roller				832-698-011
832-805-012	Starting Disc			15X25X1,5	
832-805-012	Starting Disc			15X25X2,5	
832-805-012	Starting Disc			15X25X2,5	
832-805-014	Starting Disc			8X18X1	
832-805-015	Starting Disc			25X36X2	
832-805-015	Starting Disc			15X25X1,5	
832-805-016	Starting Disc			15X25X1,5	
832-805-017	Starting Disc			8X18X2	
832-805-018	Starting Disc			35x50x2,5	
832-805-019	Starting Disc			12X22X2,5	
832-805-019	Starting Disc			12X22X2	
832-805-046	Starting Disc			10X20X1,5	
832-805-047	Starting Disc			10X20X1,5	
832-805-047	Starting Disc			10X20X2	
832-805-048	Starting Disc			12X22X1,5	
832-805-048	Starting Disc			12X22X2,5	
832-805-049	Starting Disc			10X20X2	
832-805-053	Starting Disc			6X15X1,5	
832-805-054	Starting Disc			20X30X1,5	
832-805-063	Starting Disc			8X12X1	
832-805-064	Starting Disc			30x42x2	
832-805-065	Starting Disc			5X12X1	
832-805-066	Starting Disc			30X42X2	
832-805-067	Starting Disc			6X15X1	
832-805-069	Starting Disc			12X22X4	
832-805-071	Starting Disc			8X18X1,5	
832-805-073	Starting Disc			4X10X1	
832-815-031	Bearing Bush	7	32501		
832-830-056	Bush	194	81250	12x16x12,5	
832-830-122	Bush				
832-832-002	Bush	12	33050		148-016-318
832-850-007	Bush				
832-850-046	Spacer Bush	53	35101	5,x12	

832-850-058	Bush	18	35301	6x10x9	
836-238-001	Tightening Element 30x35mm				
836-238-003	Tightening Element 35x40mm				
836-238-005	Tightening Element 28x32mm				
836-238-007	Tightening Element 18x22mm				
836-238-008	Tightening Element 45x52mm				
836-238-010	Tightening Element 38x44mm				
836-238-012	Tightening Element 15x19mm				
836-238-015	Tightening Element 25x30mm				
836-238-017	Tightening Element 32x36mm				
836-238-018	Tightening Element 12x15mm				
836-238-023	Tightening Element 60x68mm				
836-238-024	Tightening Element 20x25mm				
836-238-025	Tightening Element 19x24mm				
836-240-001	Buffer	53	75002	26XM6	
836-266-002	Ball Socket	322	71050	DM 6	
836-269-009	Ball Joint			SFIK 6F	
836-269-011	Ball Joint			SFIK 8F	
836-269-020	Ball Joint			SFILK 6F	
836-269-023	Ball Joint			SFILK 5F	
836-269-024	Ball Joint			SFIK 5F	836-269-035
836-269-032	Ball Joint			SFILK8F	
836-450-022	Grooved Ring 36x30x3mm		34101		
836-450-029	Grooved Ring 25x19x3mm	9	34101	25x19x3	
836-450-033	Grooved Ring 25x19x3,25mm		34101		
836-460-001	O-Ring	52	40105	8 x 2	
836-460-131	O-Ring	17	41501	5 x 1,5	
836-460-238	Ring	15	34201	12x6	836-465-058
836-460-240	O-Ring 56 x 3mm	16	33015		
836-460-241	O-Ring 30x2	19	33050		
836-465-058	Round Cord Ring	15	34201	12X6	836-460-238
836-473-016	Locking Ring 59 x 49 x 9mm	25	33015		
836-480-042	Plug	9	40105	LIO,5	
842-410-018	Scrwed Joint	4	34101	4x5MM	842-010-418
842-410-018	Screwed Joint	38	33060		
842-410-030	Screwed Joint	240	81501	4 M5	
842-410-032	Plug	52	33101	4/Y	842-410-121
842-410-044	Elbow Joint	38	35101	4x5MM	
842-410-047	Fitting	37	33101		842-410-138
842-410-098	Fitting	37	33101		842-410-101
842-410-101	Fitting	37	33101		842-410-098
842-410-102	Fitting	164	81551	8X1/8"	
842-410-121	Scrwed Joint	4	34101		
852-130-045	Valve 3/2				
852-130-057	Valve 5/2				
858-180-027	Pressure Regulator	18	13180		

858-180-035	Gasket				
858-180-036	Mebrane	24	13180	GKG-100-745	
858-180-037	Plunger		13180	GKG-100-746	
858-310-007	Valve	34	33101	2/2	
858-330-012	Cylinder SP.260049	78	20246		
858-330-019	Cylinder SP.260062	42	20246	16x40	
858-330-025	Lifting Cylinder	62	64201		147-001-006
860-986-001	Scissors (Teflon) 17,5cm Long			GKG-903-024	
868-290-035	Metalic Paper Roll				
868-290-048	Thermo Paper Roll				
883-212-017	Lifter Magnet	6	71055	2552260024	
885-405-034	Pile Wheel 2-Pol		34101		
885-910-034	Initiator	86	80251	NPN6MM S	885-910-035
885-910-035	Initiator	348	80251	NPN6MM S	883-212-012
886-164-003	DC Motor	3	72050	24V	
889-623-049	Reflex Light Scanner		70101		
889-623-050	Light Barrier (WT12-2N010S41)	24	45001		
889-623-050	Light Barrier (WTB12-3N1011S41)	24	45001		
889-623-057	Light Barrier (WT12-2N110S42)	17	80190		
889-623-057	Light Barrier (WTB12-3N1011S42)	17	80190		
889-623-062	Light Barrier (WTB12-3N1011S47)	125	85502		
889-633-005	Reflektor PL50A	204	72010		
900-084-202	Zylinder Screw	20	34101	M 4 x 6	
900-125-004	Washer	17	85050	DM 6.4	
900-439-090	Hex. Nut	22	33005	M 22x1,5	
900-471-004	Washer	77	71020	12 x 1	
900-472-012	Locking Ring	5	34101	32x1,2	
900-625-045	Grooved Ball Bearing	467	71030	625	
900-625-061	Grooved Ball Bearing	76	30310	625-2Z	
900-625-064	Grooved Ball Bearing	198	75002		
900-625-090	Grooved Ball Bearing	135	75001	609-2Z	900-625-256
900-625-090	Grooved Ball Bearing	144	75001	609-2Z	
900-625-127	Grooved Ball Bearing	441	81260	6001-2Z	900-625-058
900-625-222	Grooved Ball Bearing	115	72050	6002-2Z	
900-625-304	Grooved Ball Bearing	39	72001	6204-2Z	490-104-990
900-625-307	Grooved Ball Bearing	4	35130	6003-2Z	900-625-136
900-625-317	Grooved Ball Bearing	175	75002		
900-912-012	Cylinder Screw	194	35101	M6x20	
900-933-054	Hex. Head Screw	40	72030		
900-934-005	Hex. Nut	29	64201		
900-934-006	Hex. Nut	54	75001		
900-934-301	Hex Nut	265	35101	M6 (LI)	
900-963-104	Countersunk Skrew	233	56801	M 2,5x6	606-204-064
900-965-019	Countersunk Screw	240	56801	M 3x5	
901-185-025	Bush	218	81560	8X10X8	
901-494-007	Bush	44	70101	15x17x10	900-063-024

901-850-012	Bush	54	30130	6x8x4	
901-850-014	Bush	75	30310	5x9x5	
901-850-015	Bush	11	42010	5X7X5	
901-850-016	Bush	10	42010	10X12X6	
901-850-017	Bush	17	30130	10X12X6	
901-850-018	Bush	43	30101	8X10X10	
901-850-020	Bush	56	71055	20x23x15	
901-850-023	Bush	13	35101	6X8X8	
901-850-024	Bush	39	33005	12X14X12	
901-850-025	Bush	21	40101	8X10X8	
901-850-027	Bush	9	42010	6X8X6	
901-850-030	Bush	325	56801	14X16X1	
901-850-033	Bush	59	33010	6X8X6	
901-850-034	Bush				
901-850-036	Bush	85	64301	6X8X10	
901-850-037	Bush				
901-850-038	Bush	11	35101	10X12X10	
901-850-040	Bush		72050	10X16X10	
901-850-042	Bush	57	71055	T 12X14X15	
901-850-045	Bush	118	85530		
901-850-050	Bush	12	35110	T15x17x12	
901-850-051	Bush	71	33010	T 12X14X20	
901-850-052	Bush	9	30115	8x14x6	
901-850-053	Bush	13	64302	10x16x6	
901-850-055	Bush	56	32510	S 10X12X9	
901-850-056	Bush	78	35110	6x8x10	
901-850-057	Bush	253	35101	6X12X10	
901-850-059	Bush	39	35110	8x14x10	
901-850-062	Bush	42	30101	18X20X12	
901-850-063	Bush	271	35110	8x10x8	
901-850-064	Bush	14	35101	8x10x10	
901-850-065	Bush	44	33005	12x14x1	
901-850-073	Bush	70	40160	5x7x5	
901-850-074	Bush	41	33010	8X10X6	
901-850-075	Bush	218	82005	8X10X6	
901-850-078	Bush	134	64301		
901-850-078	Bush	139	82585		
901-850-079	Bush	47	35301	12x14x8	
901-850-082	Bush	154	40101	T 5x7x5	
901-850-083	Bush	69	35101	T 4x5,5x4	
901-850-085	Bush	52	35101	T 5x7x5	
901-850-091	Bush	316	35101	T 20X23X20	
901-850-092	Bush	315	35101	S 20X23X20	
901-850-115	Bush	371	99850		
903-770-002	O-Ring	393	56801		
906-331-002	Collar Nut	39	32510	M6	

906-799-003	E-Ring (4)				
906-799-004	E-Ring (5)				
906-799-006	E-Ring (7)				
906-799-007	E-Ring (8)				
906-799-008	E-Ring (9)				
906-799-009	E-Ring (12)				
906-799-010	E-Ring (15)				
906-799-011	E-Ring (19)				
909-021-003	Washer	163	85050		
909-021-019	Washer	51	40102		