

Pump P-101 Shutdown Procedure

1. Inform the control room before shutdown.
2. Gradually close the discharge valve.
3. Stop the pump using the local stop pushbutton.
4. Isolate electrical power and apply lockout/tagout.
5. Close suction and discharge isolation valves.
6. Drain the pump casing if maintenance is required.
7. Verify zero energy state before opening equipment.
8. Record the shutdown time and reason in the maintenance log.

Pump P-101 Restart Procedure

1. Remove lockout/tagout after maintenance clearance.
2. Open the suction valve fully.
3. Keep the discharge valve partially open.
4. Prime the pump and vent trapped air.
5. Start the pump and monitor vibration and seal leakage.
6. Gradually open the discharge valve to operating position.
7. Confirm normal operating pressure and temperature.