


merit entertainment

Megatouch Entertainer and eVo Wallette Security Key Installation

Follow the security key installation instructions for your specific model below.


Megatouch Entertainer Games

Unlock and open the CPU section and install the provided security key (labeled SA3555-XX) on the control board as shown in Figure 1 below.



eVo Wallette Games

Unlock and open the CPU section and install the provided security key (labeled SA3548-XX) on the control board as shown in Figure 2 below. Then, install the provided ES key (labeled SA3556-XX) on the I/O board as shown in Figure 2 below.



IMPORTANT ENTERTAINER CONNECTION INFORMATION

If you are installing an Entertainer unit, you must make a successful connection to Merit's server in order for the unit to function. See "AMI Music Setup" in your owner's manual for information on how to set up your game to connect to the server.

If you attempted to connect, but cannot make a successful connection due to a server error, your game will still operate for 3 days. However, your game must connect within those 3 days or it will stop working.

Remember:

In order for game functionality to continue, you must connect once every 5 days.

NOTE: Once you have made a successful connection, the game will automatically attempt to call in call in every day by default.

PM0678-02 PAGE 1 OF 1