
JUST ONE MORE MOMENT

ENCLOSURE / ASSEMBLY

REV 02 / 28 OCT 2026

01 / EXPLODED ENCLOSURE

13 printed parts, one of each. E1-E7 are purchased components. Numbers match the STL filenames.



PRINT EACH PART ONCE

BASE

- 01 Base housing
- 02 Bottom and rear cover
- 03 Front trim, left
- 04 Front trim, right
- 05 Cable guide, upper
- 06 Cable guide, lower

DISPLAY

- 07 Display main bracket
- 08 Display inner bezel
- 09 Display outer frame
- 10 Display rear cover

CAMERA

- 11 Camera lower shell
- 12 Camera upper shell
- 13 Camera front ring

PURCHASED / DO NOT PRINT

- E1 Touch Display 2
- E2 Raspberry Pi 5 + cooler
- E3 Logitech C270 camera
- E4 Arcade button + LED
- E5 SW01 / AI mode
- E6 SW02 / EN-DE
- E7 12 NeoPixels / WS2812B

Grey shapes and red details identify parts, not filament colours. Dashed lines link the positions. Not to scale.

BASE > DISPLAY > CAMERA / Positions come from the shared CAD assembly coordinates.


JUST ONE MORE MOMENT

ENCLOSURE / ASSEMBLY

REV 02 / 28 OCT 2026

02 / DISPLAY AND RASPBERRY PI

From rear to front: cover 10, Pi E2, bracket 07, display E1, inner bezel 08 and outer frame 09.



PRINTED PARTS

- **07** **Display main bracket**
  07-display-main-bracket.stl
- **08** **Display inner bezel**
  08-display-inner-bezel.stl
- **09** **Display outer frame**
  09-display-outer-frame.stl
- **10** **Display rear cover**
  10-display-rear-cover.stl

ELECTRONICS

- **E1** **Touch Display 2**
  Screen faces the front.
- **E2** **Raspberry Pi 5**
  Behind the display, inside cover 10.

1 / PLACE THE DISPLAY

Fit E1 into bracket 07. Put bezel 08 and outer frame 09 on the front side.

2 / PLACE THE PI

Position E2 behind the display. Check the cooler, USB plugs and ribbon cable space before fitting cover 10.

3 / CLOSE THE BACK

Fit cover 10 after routing the wires. Use the mounting features in the model.

> **E1 + E2 / SCHEMATIC COMPONENTS**
> Their envelopes follow the supplied CAD references. Pi chips and ports are simple symbols. See page 05 for their installed position.


JUST ONE MORE MOMENT

ENCLOSURE / ASSEMBLY


REV 02 / 28 OCT 2026

03 / BASE, FRONT TRIMS AND CABLE GUIDE

The bottom cover also forms the rear closing wall. The cable guide is split into upper and lower halves.



REAR CABLE GUIDE / 05 + 06



Put the cable between the two guide halves. Align the guide with the hole in the rear wall of bottom cover 02. Upper half: 05. Lower half: 06.

PRINTED PARTS

- 01 **Base housing** — 01-base-housing.stl
- 02 **Bottom and rear cover** — 02-base-bottom-cover.stl
- 03 **Front trim, left** — 03-base-front-trim-left.stl
- 04 **Front trim, right** — 04-base-front-trim-right.stl
- 05 **Cable guide, upper** — 05-rear-cable-guide-upper.stl
- 06 **Cable guide, lower** — 06-rear-cable-guide-lower.stl

E4	Illuminated button
E5	SW01 / AI mode
E6	SW02 / EN-DE

LED placement: page 06.

1 / PREPARE THE FRONT

Fit trims 03/04. Put E4 in the large hole and E5/E6 in the two small holes.

2 / ADD THE CABLE GUIDE

Put 05 above 06 at the rear cable outlet. Route the cable before closing.

3 / CLOSE THE BASE

Check the cables, then fit cover 02 with its closing wall at the back.


JUST ONE MORE MOMENT

ENCLOSURE / ASSEMBLY

REV 02 / 28 OCT 2026

04 / LOGITECH C270 AND CAMERA SHELLS

Shells 11 and 12 surround the camera. Ring 13 sits in front of the large lens opening.



E3 / POSITION REFERENCE

The grey body and black lens show where the webcam sits. The red ring is printed part 13. The camera itself is not a part to print.

PRINTED PARTS

11 **Camera lower shell**
11-camera-lower-shell.stl

12 **Camera upper shell**
12-camera-upper-shell.stl

13 **Camera front ring**
13-camera-lens-ring.stl

E3 **Logitech C270**
Purchased USB webcam.

1 / ALIGN THE CAMERA

Put E3 in lower shell 11. Align its lens with the large round opening. Keep the USB cable clear.

2 / CLOSE THE SHELL

Align lower shell 11 with the top of the display housing. Fit upper shell 12 from above.

3 / FIT THE FRONT RING

Place ring 13 around the front lens opening. Its location follows the supplied CAD coordinates.

CAMERA SHAPE

E3 is a rough shape, aligned to the lens opening. It does not define a measured camera model or a disassembly method.


JUST ONE MORE MOMENT

05 / WHERE THE ELECTRONICS SIT

These views use the original assembled positions. Covers are hidden so the purchased parts are visible.

A / DISPLAY REAR


Rear cover 10 removed.



E2 sits behind E1. The Pi and cooler are shown within the supplied Pi reference envelope. Keep space for the display ribbon and USB cables.

B / CAMERA INTERIOR

Upper shell 12 removed.



E3 sits inside lower shell 11, below upper shell 12. Its lens faces ring 13. The body is approximate; the lens opening sets its position.

PRINT SCOPE / 13 FILES / MM / 100% SCALE

Print parts 01-13 once each. Purchased parts E1-E7 do not belong on the print bed. Front controls and the 12 NeoPixels are shown on page 06.

JUST ONE MORE MOMENT

ENCLOSURE / ASSEMBLY


REV 02 / 28 OCT 2026

06 / BUTTON, SWITCHES AND 12 NEOPIXELS

The button has its own LED. The separate 12 NeoPixels sit under the base ceiling and shine through the side vents.

A / FRONT CONTROLS

Installed in the front holes.




E4 Illuminated arcade button, including its LED.

E5 SW01: Local AI / Cloud AI + Cam.

E6 SW02: EN / DE.

B / BASE INTERIOR, FROM BELOW

Cutaway: cover 02 and lower lip hidden.



E7: 12 WS2812B NeoPixels fixed inside the base, under its ceiling. Their light shines through the side ventilation slots. Spacing in this view is schematic.

> **PURCHASED PARTS / DO NOT PRINT**
>
> E4 includes the button LED. E7 is the separate 12-LED strip. Wire E4-E7 using hardware/WIRING.md; the assembly views show positions, not electrical connections.