PHKI / HSLU / SIMON BALMER

# JUST ONE MORE MOMENT

WIRING OVERVIEW

REV 03 / 28 OCT 2026

## 01 / TOUCH DISPLAY 2

JUST ONE MORE
MOMENT_
remaining: ...

P2 / 5 V
P6 / GND

POWER: P2 / P6
VIDEO + TOUCH: DSI / FFC

## 05 / LOGITECH C270

USB / VISUAL CONTEXT

## 03 / SW01 / AI MODE

P15 / GPIO22
P20 / GND
LOCAL AI / CLOUD AI + CAM

GPIO / TOP VIEW

2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40
1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39

J8 / PIN 1

USB

## 04 / SW02 / LANGUAGE

P16 / GPIO23
P25 / GND
EN / DE

## 02 / ILLUMINATED ARCADE BUTTON

+TIME

COM / P9
NO / P11 / GPIO17
LED+ P13 / GPIO27
LED- / P14

33 mm / WHITE LED

RASPBERRY PI 5 / 8 GB

CAM/DISP

USB-C

DSI / FFC

OFFICIAL
27 W
USB-C PSU

## 06 / WS2812B / 12 LEDs

+V
DIN
01 02 03 04 05 06 07 08 09 10 11 12
GND

DIN -> PIXEL 01 -> ... -> PIXEL 12

D1 / MIC 1N4001
BAND / K

P4 / 5 V -> D1 -> STRIP +V

P19 / GPIO10 -> DIN

P34 / COMMON GND

## READ THE DRAWING

- 5 V supply
- GND / common return
- GPIO signal (3.3 V)

Pxx = physical header pin.
Crossings do not join wires.
Component views are not to scale.

## D1 / MIC 1N4001 / 5 V LEAD

PI 5 V — STRIP +V

A K

Cathode band faces the strip.
DIN connects directly to GPIO10.
I use the Adafruit supply-drop method.

## WHY I USE THE DIODE

D1 lowers the strip supply voltage.
This helps it read 3.3 V data as HIGH.
GPIO10 itself stays at 3.3 V.
P4 = 5 V / P34 = common GND.
Power off before changing wires.
USB/DSI port positions: illustrative.