

FIGURE 5.4 Internal organization of a DRAM. Modern DRAMs are organized in banks, typically four for DDR4. Each bank consists of a series of rows. Sending a PRE (precharge) command opens or closes a bank. A row address is sent with an Act (activate), which causes the row to transfer to a buffer. When the row is in the buffer, it can be transferred by successive column addresses at whatever the width of the DRAM is (typically 4, 8, or 16 bits in DDR4) or by specifying a block transfer and the starting address. Each command, as well as block transfers, is synchronized with a clock.