Remaining MIPS-32	Name	Format	Pseudo MIPS	Name	Format
exclusive or (*rs* ⊕ *rt*)	xor	R	absolute value	abs	rd,rs
exclusive or immediate	xori	I	negate *(signed or unsigned)*	negs	rd,rs
shift right arithmetic	sra	R	rotate left	rol	rd,rs,rt
shift left logical variable	sllv	R	rotate right	ror	rd,rs,rt
shift right logical variable	srlv	R	multiply and don't check oflw *(signed or uns.)*	muls	rd,rs,rt
shift right arithmetic variable	srav	R	multiply and check oflw *(signed or uns.)*	mulos	rd,rs,rt
move to Hi	mthi	R	divide and check overflow	div	rd,rs,rt
move to Lo	mtlo	R	divide and don't check overflow	divu	rd,rs,rt
load halfword	lh	I	remainder *(signed or unsigned)*	rems	rd,rs,rt
load byte	lb	I	load immediate	li	rd,imm
load word left *(unaligned)*	lwl	I	load address	la	rd,addr
load word right *(unaligned)*	lwr	I	load double	ld	rd,addr
store word left *(unaligned)*	swl	I	store double	sd	rd,addr
store word right *(unaligned)*	swr	I	unaligned load word	ulw	rd,addr
load linked (*atomic update*)	ll	I	unaligned store word	usw	rd,addr
store cond. (*atomic update*)	sc	I	unaligned load halfword *(signed or uns.)*	ulhs	rd,addr
move if zero	movz	R	unaligned store halfword	ush	rd,addr
move if not zero	movn	R	branch	b	Label
multiply and add (S or *uns.*)	madds	R	branch on equal zero	beqz	rs,L
multiply and subtract (S or *uns.*)	msubs	I	branch on compare *(signed or unsigned)*	bxs	rs,rt,L
branch on ≥ zero and link	bgezal	I	(x = lt, le, gt, ge)		
branch on < zero and link	bltzal	I	set equal	seq	rd,rs,rt
jump and link register	jalr	R	set not equal	sne	rd,rs,rt
branch compare to zero	bxz	I	set on compare *(signed or unsigned)*	sxs	rd,rs,rt
branch compare to zero likely	bxzl	I	(x = lt, le, gt, ge)		
(x = lt, le, gt, ge)			load to floating point *(s or d)*	l.*f*	rd,addr
branch compare reg likely	bxl	I	store from floating point *(s or d)*	s.*f*	rd,addr
trap if compare reg	tx	R			
trap if compare immediate	txi	I			
(x = eq, neq, lt, le, gt, ge)					
return from exception	rfe	R			
system call	syscall	I			
break *(cause exception)*	break	I			
move from FP to integer	mfc1	R			
move to FP from integer	mtc1	R			
FP move *(s or d)*	mov.*f*	R			
FP move if zero *(s or d)*	movz.*f*	R			
FP move if not zero *(s or d)*	movn.*f*	R			
FP square root *(s or d)*	sqrt.*f*	R			
FP absolute value *(s or d)*	abs.*f*	R			
FP negate *(s or d)*	neg.*f*	R			
FP convert *(w, s, or d)*	cvt.*f*.*f*	R			
FP compare un *(s or d)*	c.xn.*f*	R			

FIGURE 3.25 Remaining MIPS-32 and Pseudo MIPS instruction sets. *f* means single (s) or double (d) precision floating-point instructions, and *s* means signed and unsigned (u) versions. MIPS-32 also has FP instructions for multiply and add/sub (madd.f/ msub.*f*), ceiling (ceil.*f*), truncate (trunc.*f*), round (round.*f*), and reciprocal (recip.*f*). The underscore represents the letter to include to represent that datatype.