

Formula List for Physics of sensors

1. Temperature dependence of resistance

$$R = R_0 (1 - \alpha T)$$

Where;

- R = Resistance and temperature $T^{\circ} \text{C}$
- R_0 = Resistance and temperature 0°C
- α = Temperature coefficient of resistance
- T = Temperature in $^{\circ} \text{C}$