
Mail service for activation code generation.

- As usual the activation codes can be generated in http://himatrix.hima.de
 http://himatrix.hima.com
- → An additional new e-mail service is available:
- Send an e-mail to license@hima.com and get an e-mail with the activation codes.
- The tasks are specified by the subject in the e-mail.
- License number is the number you find on your delivery note (6 numeric characters). Activation code is the >20 character string you have to enter in ELOP II Factory.





How to use mail registration.








Page 2

Authentication (temporary).

> Send an e-mail with the subject:

"authentication /name=<name> /firstname=<firstname> /email=<email-address> /custno=<customer number>"

to receive an answer confirming that you can receive activation codes within the next 7 days for max. 24h to your e-mail account.







Page 3

- <name> is your name
 - <firstname> is your firstname
 - <email-address> is the email address from that you send the
 request and to where you`ll get the answer
 - <customer number> is your customer number that you find
 on the delivery note. (6 numeric characters)

test me.

> Send an e-mail with the subject:

"test me"
to receive an
answer whether
you are a
able to receive



activation codes from the e-mail account you are using.






Page 4

Registration (1/3).

> Send an e-mail with the subject:

"registration [text] /outputmode=<x>"

to receive an answer including the activation codes.





[text] will be returned in the subject of the reply mail.

<x>=1 codes in the mail

<x>=2 codes in the attached text file (default)

Attach a text file (see next page)



Page 5

Registration (2/3).

→ Attach a text file with the following format (to be edited with MSExcel or any ASCII Editor like VI or MSEdit):

| f.code 0 | IP Address 192.168.0.1 | SRS 1.0.1 | MMEth 123455 | MMRS 0 | MSEth 123457 | MSRS 0 | SRTCP 123458 | EIP 0 | CUT 0 |
|-------------|---------------------------|--------------|-----------------|-----------|-----------------|-----------|-----------------|----------|----------|
| 0 | 192.168.0.10 | 10.0.1 | 0 | 123456 | 123457 | 0 | 0 | 123459 | 0 |
| 0 | 192.168.0.15 | 15.0.1 | 0 | 0 | 0 | 0 | 123458 | 0 | 1234560 |
| 0 | 192.168.0.20 | 20.0.1 | 0 | 0 | 0 | 0 | 123458 | 0 | 0 |
| | | | | , | , | , | , | , | |

TABs for separation



> IPs are checked for plausibility.
SRS checked & completed "x" -> "x.0.1"; "x.y" -> "x.y.1".

Page 6

Registration (3/3).

- It is possible to upgrade an activation code. (downgrade is impossible)
- Enter your existing activation code in the column "f.code".
- The IP and SRS have to be entered and will be checked whether they are the same as in the existing code.
- → Enter the license number(s) for the type of option(s) you want to add. It is the users responsibility not to use an option twice in the same code.



Page 7

Help.

> Send an e-mail with the subject:

"help"
to get a brief
description of
the functionalities
of the mail access.





Page 8