



ALARM BOT


BUILDING & PROGRAMMING MANUAL




WHAT'S IN THE KIT?




EXPANSION SHIELD
(x1)



ARDUINO NANO
(x1)



SCREEN
(x1)




CLOCK MODULE
(x1)



COIN BATTERY
(x1)



JUMPER WIRES
(x20)



KNOB
(x1)



KNOB NUT
(x1)



KNOB CAP
(x1)




BATTERY HOLDER
(x1)



BUZZER
(x1)



SCREWDRIVER
(x1)






MOTOR
(x2)



M2X5 SCREWS
(x6)

PICK YOUR COLOURS!



BEFORE BUILDING

If you need help, don't be afraid to ask!


Take advantage of your screwdrivers being magnetic.

We have tweezers available if you are having difficulty wiring parts.


After every **CHECKPOINT** please ask one of our helpers to check on your progress

Please keep volume down. Though we encourage a playful environment, we ask that you keep discussions amongst your neighbours only.

1




2




3

CHECKPOINT




4




6


UPPER BODY





5



7




8
CHECKPOINT




**BACK VIEW
OF THE SCREEN**


9




10




11



12




13




THE "+", CAN BE FOUND ON
TOP OF THE BUZZER

14
CHECKPOINT




15




16




17




18




19




20




21
CHECKPOINT



22



23




PROGRAMMING TIME!

Congratulations on reaching the programming section. In this section we will teach you how to code the bot's alarm tone, it's movement path and finally how to integrate these codes into the final overall code.


1

Access our website at projectbeacon.org.au




2

Click on the resources tab at the top of the page.




3

Enter the access code provided by your instructor




4

Scroll down to view all three code templates




5

Press "Download" for all three code templates. You should have three files named movement-code.ino, alarm-code.ino, and overall-code.ino




6

Press the "Downloads" button on the top right of your browser and open alarm-code.ino. (If you are asked what app to open the file with, select Arduino IDE)



7

Press "OK" when asked to create a new folder




8

Click "Select Board" on the top-left of your screen then "Select other board and port"




9

In the search bar type "Arduino Nano", and click on it.




10

Connect your bot to a USB port with the provided blue cable. Select the new COM Serial Port (USB) that pops up when you do this. Then click OK.


11

Click on the bookshelf on the side to open the Library Manager




12

Search "RTCLib by NeuroN" and click INSTALL




13

Search "Adafruit SH110X" and click INSTALL



14

When asked to install library dependencies select "INSTALL ALL"



15

Type your alarm code into the STUDENT ALARM CODE section



```

16
17
18  /* =====
19  ===== STUDENT ALARM CODE (START HERE) =====
20  ===== */
21
22
23  // type your alarm code here
24
25
26  /* =====
27  ===== STUDENT ALARM CODE (END HERE) =====
28  ===== */
29
30
31  endSoundSequence();
32  }
33
34  #undef playTone
  
```

playTone(pitch, duration);

High pitch note → 2000
Low pitch note → 300

Duration of the note
(in seconds)

Examples:

- playTone(1800, 5); → High pitched note that runs for 5 seconds
- playTone(800, 15); → Moderately low pitched note that runs for half a second

wait(duration);

Duration of silence from
one note to the next note


Examples:

- playTone(400, 10);
wait(2); → 2 second silence before the next playTone command

You can find some example code of famous tunes on our website!

16

Click on the top-left arrow to upload the code



The screenshot shows the Arduino IDE interface. The top menu bar includes File, Edit, Sketch, Tools, and Help. Below the menu bar, there are three icons: a checkmark, a right-pointing arrow (circled in red), and a play button. To the right of these icons is a dropdown menu showing 'Arduino Nano'. The main area displays a code file named 'alarm_test.ino'. The code includes comments for 'STUDENT ALARM CODE (START HERE)' and 'STUDENT ALARM CODE (END HERE)'. A red box highlights the following code lines:

```


23 playTone(1000, 5);
24 playTone(350, 1.5);
25 wait(2);
26 playTone (750,3);
27 playTone(1800,6);
28 wait(4);

```


Get your code checked before uploading!

Once you are happy with your alarm tone, move onto programming your movement path


17 Go back to your browser (do not close alarm-code.ino) and open movement-code.ino



18 Repeat steps 8-11 to set up the board and USB port



19 Type your code inside the STUDENT MOVEMENT CODE section



Delete this line and replace with leftMotor, rightMotor and wait commands

`leftMotor(speed);`
`rightMotor(speed);`

Fast forward → 90
Moderate forward → 30
Slow forward → 10
Stop → 0
Slow reverse → -10
Moderate reverse → -30
Fast forward → -90

Do not exceed these speeds in the testing arena!

Examples:

- `leftMotor(30);`
`rightMotor(30);` → Bot will move forward at a moderate speed
- `leftMotor(-10);`
`rightMotor(-10);` → Bot will move backwards at a slow speed
- `rightMotor(90);`
`leftMotor(-90);` → Bot will rotate left at a fast speed
- `rightMotor(0);`
`leftMotor(0);` → Bot will stop


`wait(duration);`

How long the previous motor commands will run for

Examples:


- `leftMotor(30);`
`rightMotor(30);`
`wait(2);`
→ Bot will move forwards for 2 seconds

The motors are not always precise so even though you may assign the same values to the left and right motors, the bot may slightly turn left or right instead of going straight. To counteract this, slightly raise or lower one of the motor's values until the bot drives straight.



20

Click on the **arrow** to upload your alarm code to the bot



```

File Edit Sketch Tools Help


movement_test.ino
19
20  /* =====
21  |===== STUDENT MOVEMENT CODE (START HERE) =====
22  |===== */
23
24
25  leftMotor(50);
26  rightMotor(50);
27  wait(10);
28
29  leftMotor(-20);
30  rightMotor(20);
31  wait(3);
32
33  leftMotor(-60);
34  rightMotor(-60);
35  wait(7);
36
37  leftMotor(30);
38  rightMotor(30);
39  wait(2);
40
41
42  /* =====
43  |===== STUDENT MOVEMENT CODE (END HERE) =====
44  |===== */
45
  
```

Get your code checked before uploading!

Once you are happy with your movement path, you can move onto integrating your alarm and movement codes into the overall code.


21

Go back to your browser (do not close **movement-code.ino**) and open **overall-code.ino**




22

Repeat steps 8-11 to set up the board and USB port




23

Copy and paste your typed code from **movement-code.ino** to **overall_code.ino**



24

Copy and paste your typed code from **alarm_test.ino** to **overall_code.ino**



25

Click on the arrow to upload your overall code to the bot



```

File Edit Sketch Tools Help
Arduino Nano
overall_code.ino
25 beginMoveSequence();
26
27 /*
28  ===== STUDENT MOVEMENT CODE (START HERE) =====
29  ===== */
30 leftMotor(50);
31 rightMotor(50);
32 wait(10);
33 leftMotor(-20);
34 rightMotor(20);
35 wait(3);
36 leftMotor(-60);
37 rightMotor(-60);
38 wait(7);
39 leftMotor(30);
40 rightMotor(30);
41 wait(2);
42
43 /*
44  ===== STUDENT MOVEMENT CODE (END HERE) =====
45  ===== */
46 endMoveSequence();
47
48 #undef leftMotor
49 #undef rightMotor
50 #undef wait
51 #define playTone(p, sec) soundPlayToneCmd(p, (unsigned long)((sec) * 1000))
52 #define wait(sec) soundWaitCmd((unsigned long)((sec) * 1000))
53
54 void alarmSound() {
55   beginSoundSequence();
56
57   /*
58   ===== STUDENT ALARM CODE (START HERE) =====
59   ===== */
60   playTone(1000,5);
61   playTone(350, 1.5);
62   wait(2);
63   playTone(750,3);
64   playTone(1800,6);
65   wait(4);
66
67   /*
68   ===== STUDENT ALARM CODE (END HERE) =====
69   ===== */
70

```

Be sure to email a copy of these codes to yourself so you can continue testing from home!

Congratulations you have finished building your Alarm Bot!
Please raise your hand to receive some final instructions.

HOW CAN I CONTINUE PROGRAMMING AT HOME?

The manual and code can be readily accessed from our website, projectbeacon.org.au, using the same password provided to you today. If you would like to continue working on the code you made during the workshop, be sure to save the file if you are on laptop (or email the code to yourself if you are on a school PC). Should you run into any issues, be sure to send us an email at support@projectbeacon.org.au, and we will get back to you as soon as possible.

THANKS FOR COMING BY!
STAY CURIOUS!

