## DOWN VIEW (HAIFA OR ARDUINO)

GND > GND
IN1 or CR0 -> D9
IN2 or CR1 -> D8
IN3 or CR2 -> D7
IN4 or CR3 -> D6
IN5 or CR4 -> D5
IN6 or CR5 -> D3
IN7 or CR6 -> D4
IN8 or CR7 -> D2
Vcc > 5V

LEFT SIDE

5V	A3	GND	GND
F	1	1	ľ
Vcc	OUT	GND	GND
	(OUT_VOI	.T)	

## PCB LENGTH

ARDUINO N	ANO (USB)
D12	D13
D11	3V3
D10	REF
D9	Α0
D8	A1
D7	A2
D6	А3
D 5	A4
D4	A5
D3	A6
D2	A7
GND	5 <b>V</b>
RST	RST
RXO	GND
TX1	VIN

GND	5V	A4	A5
1	I	I	1
GND	VCC	SDA	SLC

## RIGHT SIDE

D8	> CR1
A1	> VIN2
Α0	> VIN1
D9	> CR0
5V	> Vcc
GN	D -> GND

5V	A2	GND	GND	
I	ľ	Ť	I	
Vcc	OUT	GND	GND	
	(IN_VOLT)			

