INSTRUCTIONS

AF3125 INVERTER DRIVES

GEK-62575

OPERATION — TROUBLE SHOOTING — REPAIR

INVERTER ASSEMBLIES: 6VGAC2015C1, 6VGAD2015C1, 6VGAW2015C1
(15HP, 230V, 3Ph)

DIAGRAMS:

System	Elem/Conn	36C766708AA
	Inter-Conn	36C766712AB
Power Module	Elem	36D870027AA

PRINTED CIRCUIT CARD DIAGRAMS:

Snubber	Elem	36C764421AA
	Card Diag	36D871005AA
Amplifier	Elem	36C764422AA
	Conn	36D871007AA
Inverter Control	Elem/Card Diag	36D871015AA
Regulator	Elem	36D871013AC
	Card Diag	36B590287AA

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

GENERAL ELECTRIC