INSTRUCTIONS

AF3125 INVERTER DRIVES

GEK-62576

OPERATION — TROUBLE SHOOTING — REPAIR

SYSTEM FOLLOWER OPTION
6VSF11KA1, 6VSF11KFMA1

DIAGRAMS:

System Follower Card	Elem/Card Diag	36C764425AA

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

GENERAL ELECTRIC