INSTRUCTIONS

AF3125 INVERTER DRIVES

GEK-62580

OPERATION — TROUBLE SHOOTING — REPAIR

DYNAMIC BRAKING OPTION

6VBR10KA1,	6VBR10KFMA1	(1HP)
6VBR11KA1,	6VBR11KFMA1	(1½HP)
6VBR12KA1,	6VBR12KFMA1	(2HP)
6VBR13KA1,	6VBR13KFMA1	(3HP)
6VBR14KA1,	6VBR14KFMA1	(5HP)
6VBR15KA1,	6VBR15KFMA1	(7½HP)
6VBR16KA1,	6VBR16KFMA1	(10HP)
6VBR17KA1,	6VBR17KFMA1	(15HP)

DIAGRAMS:

Dynamic Braking Cards	Elem	36B590271AA
	Card Diag	36C764426AA

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

GENERAL ELECTRIC