GEK-83751B

DRIVE SYSTEM INSTRUCTIONS

JOINT VOLTAGE CONTROL

3S7931JC100A5

Information contained herein is proprietary information of General Electric Company. The dissemination, use, or duplication of this information for any purpose other than that for which the information is provided is prohibited by General Electric Company except by expressed permission.

GENERAL ELECTRIC

ISSUE DATE: February 1981

REVISED: October 1981

REVISED: December 1986

This document contains Proprietary Information of General Electric Company, USA and is furnished to its customer solely to assist that customer in the installation, testing, and/or maintenance of the equipment described herein. This document shall not be reproduced in whole or in part nor shall its contents be disclosed to any third party without the written approval of General Electric Company, Drive Systems Department.

CHAPTER 1

1-1. INTRODUCTION

The 3S7931JCIOO Joint Voltage Control provides a common voltage control for all units of a multi-unit generating station. Reactive load is balanced between machines in proportion to the rating of each machine.

1-1.1. RECEIVING AND HANDLING

Immediately upon receipt, the equipment should be carefully unpacked and examined for any damage that might have been sustained in transit. If injury or rough handling is evident, a damage claim should be filed immediately with the transportation company and the nearest General Electric Sales Office should be notified promptly.

1-1.2. DESCRIPTION

A one line diagram of the equipment is shown on sheet 1 of the elementary diagram. The joint voltage regulator has a motor driven voltage adjuster which is operated by supervisory control. Error output of the joint voltage regulator is applied to an indicating meter and a time delay relay which can be used for trip and/or alarm.

The voltage error is applied to a static motor drive for each regulator voltage adjuster. This is the principal motor drive input. Each drive positions its voltage adjuster to reduce the station voltage error to zero when all unit regulators have been repositioned.

Signals proportional to vars are obtained from var sensors connected to the instrument transformers associated with each machine. These signals are summed and fed to a total var indicator. Because the generators are identical, the proportioning var channel is simplified to an averaging channel. The sum is divided by the number of units to obtain a signal proportional to average vars. A var unbalance signal for each machine is obtained by comparing its own var signal with the average. This is a secondary error input to the static motor drive for each unit.

The joint voltage regulator circuit is shown in the top portion of sheet 5 of the elementary diagram. Input transformer IT has 5 volt taps from 75 to 145 volts for approximate match to the P.T. secondary. The rectified output of IT secondary is approximately 30 volts. Output voltage is nominally 0.1 volts per percent terminal voltage error. Potentiometers 7P and 8P control the range and level of the voltage adjuster.

The var transducer circuit is shown on the lower portion of sheet 5 of the elementary diagram. Separate instructions GEI-88846 cover the var transducer. (This publication can be ordered from the Instrument Dept. of General Electric Co., West Lynn, Mass.)

The var transducers are shown on elementary diagram sheet 2 and 5 together with amplifiers l-O.A. through 3-0.A. which amplify and filter the transducer outputs. The output of each amplifier is normalized by means of a feedback potentiometer. Test jacks 1-3TJ are provided for the amplifier outputs. The three var signals are summed by amplifier 7-0.A and total vars indicated by IM. The signals are averaged by 6-0.A. whose gain is varied in inverse proportion to the number of input signals. On the right side of sheet 2 are the motor drive input resistors. Current into each drive point is proportional to the algebraic sum of the inputs and opposite in sign. The inputs are unit vars, average vars, and the voltage error which has been amplified by 5-0.A. Note that this application is for generators of equal rating. Thus, the var proportioning operation simplifies to var averaging.

1-1.3. MOTOR CONTROL

The motor control circuitry is shown on sheet 10 of the elementary diagram. The input current signal, circuit 1, is summed with a feedback current from 21R, amplified and inverted by 5Q and 6Q. Added to the preamp output, circuit 10 to circuit 16, is an ac voltage which lags the ac supply by 90 degrees. A negative dc voltage is added to the circuit 16 voltage to obtain the forward firing-control voltage, circuit 17. A positive ac voltage is added to circuit 16 voltage to obtain the reverse firing control voltage, circuit 15.

The relaxation oscillator IUJT, 8R and 4C fires the forward thyristor with pulses of current through the primary of 2T if 2Q is non-conducting. This requires that lQ be conducting and circuit 17 be positive. The reverse firing circuit oscillates if 4Q is non-conducting. This requires that 3Q be non-conducting and circuit 15 be negative. The dc offset in circuit 15 and 17 voltages can be varied by lP to control the zero input firing point of the thyristors. A negative input signal, inverted by the preamp, raises circuit 15 and 17 voltages equally, causing forward firing to occur earlier in the cycle and reverse firing to occur later or not at all, depending upon whether circuit 15 voltage goes negative or remains positive. A current limit circuit prohibits full voltage from being applied to a motor at standstill. An ac voltage lagging the supply by 90 degrees is obtained from BC and 15R. It is combined with the back emf of the motor by 16R ad 17R and fed through 18R, 5D and 7D to the base of firing control transistors lQ and 3Q. The effect is to prohibit firing until the resultant current will not exceed a safe value.

WARNING

This equipment contains a potential hazard of electrical

shock or burn. Only personnel who are adequately trained and thoroughly familiar with the equipment and these instructions should install, operate, or maintain this equipment.

1-1.4. TEST AND ADJUSTMENT

WARNING

This equipment is designed to operate in a normal industrial atmosphere. Operating radio transmitters nearby may cause the control equipment to misoperate. It is recommended that radio transmitters not be operated within the vicinity of the control equipment when the panel doors are open, nor at any time within the confines of any power control room.

WARNING

Isolation of test equipment from the equipment under test presents potential electrical hazards. If the test equipment cannot be grounded to the equipment under test, the test equipment's case must be shielded to prevent contact by personnel.

1-1.5. Joint Voltage Regulator

1. Set 5P input gain control of 5-0.A at midpoint.
2. Adjust taps on lT to nearest 5 volts corresponding to nominal P.T. voltage.
3. Insert a variable autotransformer in place of the signal PT and adjust 7P and 8P for the desired voltage range and maximum voltage. With the joint voltage control in TEST position, operate lOM to move lOP wiper to the maximum voltage end. Set the autotransformer for the desired maximum voltage and adjust 8P to obtain 0 output from 5-0.A. It is recommended that an oscilloscope be used in adjustment of this equipment. Set the input voltage at the desired minimum, the voltage adjuster lOP at the other end of its travel and adjust 7P for 0 output from 5-0.A. Repeat the adjustment of 8P and 7P until no further adjustment is required. Check meter 2M for proper indication.

1-1.6. VAR Transducers and Amplifiers

1. Apply nominal PT voltage to each var transducer. Place an in-phase current into the current input. The value of this current should be the reactive CT secondary current at rated MvA and p.f. Adjust the gain of each var signal amplifier to obtain +5.0 volts output.
2. Calibrate the total var meter by means of 6P gain control for amplifier 7-0.A. See notes at the bottom of sheet 2 of the elementary diagram.

1-1.7. Unit Motor Drives

The motor control boards are factory adjusted for optimum operation and further adjustment should be required only if component parts are replaced. Adjustment is made with the motor connected to the motor control. Unplug amplifiers l-O.A. through 6-0.A. and ground vTJ test point. An extender board should be inserted between the motor control board and its connector. Connect an oscilloscope to the motor armature being careful to connect the oscilloscope ground to the motor ground. Apply power and rotate the balance adjustment 2P (nearest pin end of board) to stop the motor. This will be indicated on the oscilloscope by a trace of which the horizontal portion is zero volts, average, indicating 0 Vdc back emf from the motor. The overlap adjustment lP (nearest handle end of board) is set to obtain a horizontal trace 2 1/2 times the length of other portion of the trace in which the thyristor is conducting; this corresponds to approximately 40 degree overlap.

1-1.8. Level Sensor

With 0 volts at input pin 35, 6P should be adjusted for 0 volts at BT. P.; the relay connected to output pin 31 should be energized. It should drop out at the desired positive-going or negative-going level set by 16P (external) and/or 4P and 5P.

1-1.9. Pushbuttons, JVC Switch, Relays, and Lights

These components should function to place generating units 1, 2, and 3 in joint voltage control and indicate their status as shown on the elementary diagram. Relays and lights operate by 24 volts from the power supply, or from 125 volts dc (except for the excessive voltage error relay 60).

1-1.10. Power Supply

All ac and dc voltages shown on the elementary diagram should be measured periodically.

1-1.11. Motor Operated Voltage Adjuster

The gearmotor speed should be set at 3/4 r.p.m. with resistor Rl. Check for Proper relay operation, potentiometer direction of rotation, and cam-operated switches.

1-1.12. Cabinet Light, Receptacles and Heater

These require little maintenance or adjustment.

WARNING

TO PREVENT HAZARD OF ELECTRICAL SHOCK OR BURN, APPROVED GROUNDING PRACTICES AND PROCEDURES MOST BE ADHERED TO.

1-2. OPERATING INSTRUCTIONS

The function of the joint voltage regulator and var controller is to replace operators in changing the voltage set-points of the several generating units in the station as power system demand varies. It is not a fast-acting regulator in itself, but it will continuously adjust the fast-acting voltage regulators in an effort to maintain constant station output voltage and proper reactive power division.

The operational amplifier networks, meter calibration, and motor-drive units are factory preset as indicated on the elementary diagram. The voltage regulator range and level rheostats may require field adjustment - perhaps even the regulator input transformer tap connection may require changing. The level sensor threshold can be changed after gaining operating experience which may indicate a more desirable setting. Also the time delay of the relay which it operates may be changed.

The operating controls are the local and remote control switches. Relays 90JIX2-1, -2, and -3 place their respective generators under joint control. Those relays are operator selected, with unit line circuit breaker interlocking. The selector switches, remotely located, are CS-I/JVC, CS-2/JVC, and CS-3/JvC. Thus a generating unit must be connected to the power system in order to be put under joint control. If a generating unit's excitation system is transferred to dc regulator control, it should be removed from joint voltage control. Also, if a unit's var-sensing circuitry goes out of calibration, it should be removed from joint control. Loss of station battery control power, or trouble with the internal power supply will automatically take the joint control out of service. If two of the three units must be removed from joint voltage control, the remaining unit should be removed, also.

Control switch ICS and pushbutton switches lPB, 2PB and 3PB may be used to operate the test relays 90JIXI-l, -2 and -3, which are provided to test each of the three channels in the equipment without actually placing that channel in service.

The joint regulator set-point can be changed, remotely, by lOCS.

1-2.1. REFERENCE DOCUMENTS

44C308284	Elementary Diagram
44B309216	Outline Drawing
GEI-93161	Reversing Statotrol* Drives, 3S7507RS series
GEI-88846	Watt Transducer
278A2011	Factory Test Instructions

*Trademark of General Electric Company, U.S.A.

1-3. RENEWAL PARTS

When ordering renewal parts, address the nearest General Electric Sales Office; specify the quantity required, and circuit #ymbol as shown on the elementary diagram. In addition, give the 3S number of the equipment. The principal Electrical parts in the equipment are given in the following tabulation:

DESIGNATION	QTY.	PART No.	DESCRIPTION
LSW	1	44C372098-G02	Switch, Receptacles
HTR	1	SD2082	Space Heater
23	1	6A426Gl	Thermostat
HSW	1	TEB122015	Circuit Breaker
ST	1	206B4414P5	Transformer
QlD-Q6D	6	68A7250P2	Diode
QlC, Q2C, Q3C	3	68A7051P0470F	Capacitor,.047 MFD.
IR-l,IR-2, IR-3	3	68A7004B50E390JA/XlOlAE	Resistor, Adj., 390 ohms, 50W
IMCR, 2MCR, 3MCR	3	68A7004A20ClOOOCA	Resistor, IK, 20W
IFU - 4FU	4	CSC#OT6	Fuse, 6A
LTG	1	167A8499P2	Lamp, 220V, 50W
IM	1	50-162012MTMT2LLH	VAR. Meter (DCVM.)
2M	1	933B574P15	Volt. Error Mtr. (DCVM.)
1-4TJ, ATJ, GTJ	6	289A700P2	Jack
ICS	1	CR2940UB203B	Selector Switch

DESIGNATION	QTY.	PART No.	DESCRIPTION
1-3PB	3	CR103DC221B	Pushbutton Switch
ICS/IL	1	CR103DD221X	Indicator
	8	125A4423P28	Lamp, 28V
Var. Trans. 1, 2, 3	3	50-470121AWAAl	Watt Transducer
	3	STA #SJK-20K04-S	Transducer CT SWitch
60X	1	CR2820B211AA41K	Time Delay Relay, 125V
	1	3S7932HA115G58	Motor-Op. Voltage Adjuster
IOM	1	278A3369Pl	Motor, P.M., 75V
K	1	218A4274P21	Relay, 125V
IOP	1	573A384P15A	Potentiometer, 5K, 25W
Rl	1	B50E2500JA/XlOlAE	Resistor, Adj. 2.5K,50W
LS1-6	6	44A212115-001	Cam-Operated Switch
	1	3S7931JC200All	Relay Module
4JV, 27V, 90JIX-(6)	10/8	3S2791G138A3	Relay, Min., 125V
27A, 27B, 60	5/3	3S2791G138A4	Relay, Min., 28V
	8/6	68A7250P2	Diode, lA.
	1	3S7931JC200A12	Power Supply Module
3Z, 5Z	2	68A7233P07BN	Zener Diode, 12v
6Z	1	68A8210P0621	Zener Diode, 6V
4Z	1	44A213761-001	Zener Diode, 5V
3T	1	206B4414Pl	Transformer
IX, 2X	2	44B211629-GOl	Reactor
ICB	1	CRIOIH	Switch
	1	CR123H12.2B	Overload Heater for ICB
IC, 2C	2	44A339814-M15	Capacitor, EL.,1500 MFD, 50 V
IR, 2R	2	68A7004A20C22DA/XlOlAC	Resistor, 22 ohm, 20W
IZ, 2Z	2	44A337972-005	Zener Diode, 15V
IT	1	44B213349-GOl	Transformer
2T	1	395B581Pl	Transformer
1-4D	4	167A8419Pl	Diode
	1	44B315610-G03	Component Board
5D	1	68A7250P2	Rect. lA 500V
7R,8R	2	68A7004AlOBlOOCA	Res., 100 Ohm, lOW
5R,6R	2	68A7004AlOB68CA	Res. 680hms, lOW
3R	1	68A7001P471	Resistor, 470 Ohm, lW
4R	1	68A7001P102	Resistor, 1000 Ohm, lW
10, llR	2	68A7004AlOB2200CA	Res., 2200 Ohm
9Rl, 9R2	2	68A7004AlOB33CA	Resistor, 33 Ohm, lOW
	1	3S7931JC200A4	Voltage Regulator
IT	1	44B216024-GOl	Transformer
IX	1	44B211608-GOl	Reactor
IZ	1	lN2620B	Zener Diode, 9.3V
1-4D	4	44B232011-001	Diode
3RA	1	687001P471	Resistor, 470 Ohm, lW
IR	1	68A7001P331	Resistor, 330 Ohm, lW
2R	1	6BA7001P221	Resistor, 220 ohm, lW
3RB	1	68A7001P151	Resistor, 150 Ohm, lW
7P,8P	2	277A7704Pl	Potentiometer, 250 Ohm, 2W
IC	1	44A339814-LlO	Capacitor, 100 MFD, 50V
	4/3	44D236353-G02	Motor Control Print Ckt. Bd.
13R, 14R	2	277A7785C47	Res. 4.7 Ohms, 3W
IUJT, 2UJT	2	68A7369Pl	Transistor
2T, 3T	2	933B272Pl	Transformer
15R	1	68A7001P561	Res. 560 Ohms, lW
17R	1	68A7001P222	Res. 2.2K Ohms, lW

DESIGNATION	QTY.	PART No.	DESCRIPTION
lC	1	44A337922-J20	Capacitor, 2 MFD.
lP	1	277A7782F50	Pot 5K Ohms, .5W
2P	1	277A7782G50	Potentiometer, 50K, .5W
9C	1	44A337973-GlO	Cap. .01 UF, 500 VDC
lCD, 2CD	2	44B212739-007	Thyristor
lT	1	44B311324-GOl	Transformer
30R, 31R	2	68A7000P471	Res. 470 Ohms, .5W
4R, 5R, 9R	3	68A7000P102	Resistor, lK, .5W
lR	1	68A7000P122	Res. 1.2K Ohms .5W
8R, 12R	2	68A7000P332	Res. 3.3K Ohms .5W
18R, 27R	2	68A7000P472	Res. 4.7K Ohms .5W
23R	1	68A7000P682	Res. 6.8K Ohms .5W
28R	1	68A7000P103	Res. lOK Ohms .5W
26R	1	68A7000P243	Res. 24K Ohms .5W
6R, lOR, 22R	3	68A7000P273	Res. 27K Ohms .5W
32R	1	68A7000P513	Res. 51K Ohms .5W
7R	1	68A7000P563	Res. 56K Ohms .5W
24R	1	68A7000P154	Res. .15 MegOhms .5W
llR	1	68A7000P224	Res. .22 MegOhms .5W
16R	1	68A7001P562	Res. 5.6K Ohms lW
25R	1	68A7001P753	Res. 75K Ohms lW
4C, 5C, llC	3	206B4404H22	Capacitor, .22 MFD.
8C	1	44A337922-J40	Capacitor, 4 MFD.
2C, 3C	2	206B4436L50	Capacitor 500MFD 12V
6C, 7C	2	278A2115MlO	Capacitor, 1000 MFD, 25V
lD-12D, 19D-24D	18	44B232011-001	Diode, 100 MA.
4Q	1	277A7793P7	Transistor
lQ, 2Q, 3Q, 5Q, 6Q	5	206B4429-001	Transistor
21R	1	68A7000P134	Res. 130K Ohms .5W
lO.A.-80.A	5/3	44D236354-G03	Stabilized Op. Ampl. Printed Circuit Board
lA, 2A	2	278A2110-001	OP. Amplifier
lP, 2P	2	983B583H20	Pot., 200K Ohms .25W
lD-4D	4	206B4422Pl	Diode
lZ-4Z	4	44A376684-C91	Zener 9.1V 400MW
lR-4R	4	68A7000P183	Res. 18K Ohms .5W
5R-6R		2 68A7000P105	Res. l.OM Ohms .5W
lC,2C	2		Capacitor, 330 pf.
	2/1	IC3606JVCAlA	Resistor Printed Ckt. Bd.
lR	1	68A7030P562F	Res 56.2K Ohms
2R	1	68A7030PlOOE	Res. lK Ohm
102R, 202R 302R, 104R 204R, 304R 105R, 205R 305R	9	68A7030PlOOF	Res. lOK Ohms
lOlR, 201R 301R 106R, 107R 206R, 207R 306R, 307R 108R, 208R	6	68A7030P121E	Res. 1.21K Ohms
103R, 203R 303R	5	68A7030P499E	Res. 4.99K Ohms
308R	1	68A7030P750E	Res. 7.50K Ohms
lP-3P, 5P, 6P	5	68A7125P502	Pot. 5K Ohms

DESIGNATION	QTY.	PART No.	DESCRIPTION
9P, 12P	2	68A7125P103	Pot. lOK Ohms
16P	1	68A7125P253	Pot. 25K Ohms
lOlC, 201C, 301C	3	68A7052PlOHlO	Cap. 10 uf
lC	1	68A7052P4A20	Cap. 4 uf
LS-2	2/1	44D221533-GOl	Level Senser Printed Ckt. Bd.
lD-4D, 9D-12D	8	lN459	Diode 40MA 200V
lBD, 2BDS	2	lN3020B	Zener Diode lOV lW
lQ, 2Q, 5Q, 6Q	4	44B311057-001	Transistor
3P, 6P	2	983B558F50	Pot. 5K Ohms, 1/4 W.
lP, 2P, 4P, 5P	4	983B558GlO	Pot. lOK Ohms, 1/4 W.
3Q, 4Q, 7Q, BQ	4	44B238203-001	Transistor
5D-8D, 13D-16D	8	44B232011-001	Diode
lC, 2C	2	933B597G47	Capacitor .047 MFD
llOR, llR			
25R, 26R	4	933B590D47	Res. 47 Ohms, 1/2 W.
9R, 24R	2	933B590F33	Res. 3.3K Ohms, 1/2 W.
3R-5R, 18R-20R	6	933B590F47	Res. 4.7K Ohms, 1/2 W.
7R, 22R	2	933B590F56	Res. 5.6K Ohms, 1/2 W.
15R, 27R	2	933B590F68	Res. 6.8K Ohms, 1/2 W.
13R, 30R	2	933B590G12	Res. 12K Ohms, 1/2 W.
6R, 21R	2	933B590G18	Res. 18K Ohms, 1/2 W.
2R, 8R, 17R, 23R	4	933B590HlO	Res. lOOK ohms, 1/2 W.
12R, 29R	2	933B590H22	Res. 220K Ohms, 1/2 W.
14R, 28R	2	M6986159F18	Res. 1.8K Ohms, 1/2 W.
lR	1	M6936159ElO	Res. lOOK Ohms, 1/2 W.
16R	1	M6986159E47	Res. 470K ohms, 1/2 W.
	1	44D222911-GOl	Extender Board
	1	3S7932HA115G58	Motor-operated voltage adj.
lOM	1	278A3369Pl	Motor
K	1	218A4274P21	Relay
Rl	1	68A7004B25D3600DA/XlOlADD	Resistor, 3.6K,25 W.
lOP	1	573A384P15A	Potentiometer, 5K,25W.
LSl-LS6	6	44A212115-001	Switch
	6	44A217958-GOl	Cam Assembly
	1	44A217974-002	Coupling
	1	44B314828-002	Coupling Body
	2	44B314828-003	Coupling Segment
	1	44A217945-001	Shaft
lOCS			
10 P Lights			

GENERAL ELECTRIC


44C308284 CONT ON SHEET 2 SH NO. 1

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± | DECIMALS ± | ANGLES ±

TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM

PALMAR – URUGUAI
REQN. 140-J11-T80284

ONE LINE DIAGRAM



1CS – JVC TEST SWITCH
1PB – JVC TEST PUSHBUTTON FOR GEN. NO. 1
2PB – JVC TEST PUSHBUTTON FOR GEN. NO. 2
3PB – JVC TEST PUSHBUTTON FOR GEN. NO. 3
4JV – APPLIES 120 VAC INPUT TO POWER SUPPLY
27A – POSITIVE 24 VOLT MONITORING RELAY
27B – NEGATIVE 24 VOLT MONITORING RELAY
27JV – AUXILIARY RELAY TO 27A AND 27B ENABLES JVC OPERATION WHEN POWER SUPPLY IS ENERGIZED
60 – VOLTAGE ERROR SENSING RELAY
60X – VOLTAGE ERROR ALARM RELAY
90J1X1-1 – APPLIES VAR SIGNAL FROM GEN. NO. 1 TO SUMMING AMPLIFIERS AND MOTOR DRIVE CIRCUIT, ETC.
90J1X1-2 – APPLIES VAR SIGNAL FROM GEN. NO. 2 TO SUMMING AMPLIFIERS AND MOTOR DRIVE CIRCUIT, ETC.
90J1X2-1 – JVC TRANSFER RELAY FOR GEN. NO. 1 TRANSFER CONTROL OF VOLTAGE-ADJUSTING POTENTIOMETER FROM OPERATORS SWITCH TO JVC ETC.
90J1X2-2 – JVC TRANSFER RELAY FOR GEN. NO. 2 TRANSFER CONTROL OF VOLTAGE-ADJUSTING POTENTIOMETER FROM OPERATORS SWITCH TO JVC, ETC.
52 – GENERATOR CIRCUIT BREAKER


NOTES:
** ITEMS SUPPLIED BY CUSTOMER
* ITEMS SUPPLIED BY OTHER DEPTS.
◎ (Q NO'S.) OUTGOING CONNECTION POINTS FROM JVC CUBICLE.
△ MOUNTED ON CUSTOMERS CONTROL BOARD.
o PANEL TERMINAL POINTS IN JVC CUBICLE
⊡ CUSTOMER CONNECTION POINTS (IN OTHER EQUIPMENT FROM JVC CUBICLE)
S = VAR RATING FOR EACH GENERATOR (S_1 = VAR RATING FOR UNIT 1, S_2 = VAR RATING FOR UNIT 2, ETC.)

REVISIONS
1 REVISED APP 12 1973

PRINTS TO
3 E A

MADE BY 9/27/77
ISSUED OCT 6 1977
APPROVAL
DRIVE SYSTEMS PROD. DEPT. WAYNESBORO, VA.
44C308284 CONT ON SHEET 2 SH NO. 1


FF-808-F (2-77) PRINTED IN U.S.A.



GENERAL ELECTRIC
44C308284
CONT ON SHEET 3
SH NO. 2
UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-
APPLIED PRACTICES
SURFACES
TOLERANCES ON MACHINED DIMENSIONS
FRACTIONS
DECIMALS
ANGLES
TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM
PALMAR - URUGUAI
REQN. 140-J11-T80284
TO UNIT CT AND PT SEE SHEET 5
SET AT +5V FOR 214.25 VARS
1P 5K
10K 1 0 2R
101C 10.0
(+) Q1
1TJ
VAR. TRANSDUCER 1
SEE SH. 5 DETAILS
7TB
TYPE 4701
1MA AT 500 VARS
R1SL1 83(1) 2.21K 101R (2) (19) 87
1-0A (25)
R2SL1
SEE SH. 8 FOR DETAILS
91
R1SL1 (3)
JOINT VOLTAGE REGULATOR SEE SH. 5
STATION VOLTAGE SIGNAL
Q17 56 57 Q18
3TB
REF. & COMP. CKT.
SET FOR 5V CHANGE ON 2M WHEN STATION VOLTAGE CHANGES 5%
56.2K 1R 1C 4.0
SET POINT ADJUSTER 5K Ω
H18 H19 H20
1 0 P
Q48 55 59 58
Q66 +VE 60 VE
R1SL1 (10) REF. -VFB
5P 5K
R1SL1 (11) (09) 111
5-0A (25)
R2SL5
-VS 112
SHEET 3
R1SL1 (12)
SIGNAL AT SUMMING POINT IS 2X STATION VOLTAGE ERROR PLUS UNIT VAR DIFFERENTIAL
S.P. = SUMMING POINT
R1SL1 (25) 10K 105R
R1SL1 (26) 4.99K 103R 79
R1SL1 (27) 10K 104R
R1SL1 (28) S.P.
TO UNIT 1 MOTOR DRIVE CIRCUIT SHEET 4, B-1
2TJ
90J1X1-1 5 4 77
R3TB-28
(+) Q2
R1TB-23
SET AT +5V FOR 214.25 VARS
2P 5K
10K 2 0 2R
R1SL1 (6) 201C 10.0
R1TB-22
VAR. TRANSUCER 2
Q4 Q4A Q3 Q3AT Q12 Q11
6TB
TYPE 4701
NEGATIVE FOR OVEREXCITED VARS R1SL1 2.21K 201R (5) (27) 88
2-0A (29)
R2SL1
1MA AT 500 VARS. R1SL1 (4)
84 55
90J1X1-1 R1SL1 (14) 91 8 7 R1TB-19 95 1.2K 106R
1.2K 107R R1SL1 (17) 99 12 13 90J1X1-1
R3TB-24
90J1X1-2 R1SL1 R3TB-17 (15) 92 8 7 96 1.2K 206R 103
1.2K 207R R1SL1 (18) 100 90J1X1-2
R3TB-25
90J1X1-3 R1SL1 (16) 8 7 R3TB-19 97 1.2K 306R
1.2K 307R R1SL1 (19) 101 90J1X1-3
R3TB-26
R3TB-23 ATJ
R1SL1 (13)
6-0A (27) (29)
R2SL5
- PROPORTIONATE VARS (QA)
55 GTJ
4.99K 203R 80
10K 204R S.P.
R1SL1 (29)
R1SL1 (30) 10K 205R
TO UNIT 2 MOTOR DRIVE CIRCUIT SHEET 4, B-4
90J1X1-2 5 4 75
R3TB-29
69 104 112
SET 3P FOR +5V ON OUTPUT OF 3-0.A. AT 214.25 VARS TO TRANSDUCER.
3P 5K
10K 3 0 2R
301C 10.0
R1LS1 (9)
VAR TRANSDUCER 3
Q5 Q5A Q6 Q6A Q14 Q13
5TB
TYPE 4701
R1SL1 85 (7) 2.21K 301R (8) (19) 89
3-0A (25)
R2SL3
1MA AT 500 VARS
7.5-0-7.5 VOLTS 1000Ω/ VOLT SCALE: 120-0-120 (J.V.C. CUBICLE)
90J1X1-1 R1SL1 (22) 10 9 105A 9P 10K R1TB-20
4.99K 108R 1K 2R 6P 5K Q60 1M
90J1X1-2 R1SL1 (23) 10 9 106A 12P 10K R3TB-18
4.99K 208R
90J1X1-3 R1SL1 10 9 107A (24) 107 7.50K 308R 39
R2SL7 7-0A (25) 110
R1SL1 (20)
(-) TOTAL VARS △ (Q7)
1M Q48 55
R1SL1 (21)
R1TB-21 R3TB-20
4.99K 303R 81
10K 304R S.P.
R1SL1 (31)
R1SL1 (32) 10K 305R
TO UNIT 3 MOTOR DRIVE CIRCUIT SHEET 4, D1
90J1X1-3 5 4 73
R3TB-30
69
SHEET 3
WITH 4.13V APPLIED TO CIRCUIT 107A, ADJUST 6P FOR 40MVAR ON 1M.
JUMPER CIRCUIT 107A TO 106A AND ADJUST 12P FOR 80MVAR ON 1M.
JUMPER CIRCUITS 105A, 106A, 107A TOGETHER AND ADJUST 9P FOR 120MVAR ON 1M.
4-0A (27) (29)
SPARE
R2SL3
3TJ
R2SL7
8-0A (27) (29)
SPARE
REVISIONS
1 REVISED APR 12 1978
2 RGP 8-14-80 GEN CORRECTIONS
PRINTS TO
BENI
MADE BY D. Wilson 9/27/77
ISSUED OCT 6 1977
APPROVALS
DRIVE SYSTEMS PROD. DEPT.
WAYNESBORO, VA.
44C308284
CONT ON SHEET 3
SH NO. 2
FF-808-P (3.77) PRINTED IN U.S.A.

GENERAL ELECTRIC | 44C308284 | CONT ON SHEET 4 | SH NO. 3

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± | DECIMALS ± | ANGLES ±

TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM
PALMAR – URUGUAI
REQN. 140-J11-T80284





REVISIONS		PRINTS TO
1	APR 12 1978	3E H1
2	RGP 8-14-80 GEN CORRECTIONS	

MADE BY D. Wilson 9/27/77 | ISSUED OCT 6 1977 | APPROVALS | DRIVE SYSTEMS PROD. DEPT. DIV. OR DEPT | WAYNESBORO, VA. LOCATION | 44C308284 | CONT ON SHEET 4 | SH NO. 3


FF-508-F (2-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 5 SH NO. 4

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± DECIMALS ± ANGLES ±

TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM
PALMAR - URUGUAI
REQN. 140-J11-T80284



REVISIONS			PRINTS TO
1	REVISED MB APR 12 1976		3EM
2	RGP 8-14-80 GEN CORRECTIONS		

MADE BY S.W. 9/27/77 | APPROVALS W.H. J.H. | DRIVE SYSTEMS PROD. DEPT. WAYNESBORO, VA. | 44C308284 | CONT ON SHEET 5 | SH NO. 4

REVISED OCT 6 1977

FF-809-F (8-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 6 SH NO. 5

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:—
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± | DECIMALS ± | ANGLES ±

TITLE
JOINT VOLTAGE CONTROL

FIRST MADE FOR 3S7931JC100A5


ELEMENTARY DIAGRAM

SEE SHEET 2
JOINT VOLTAGE
ADJUSTER

PALMAR – URUGUA1
REQN. 140-J11-T80284

Q-TABLE - TERMINAL

(T) TERM	UNIT(1)	UNIT(2)	UNIT(3)
T18	Q10	Q12	Q14
T19	Q9	Q11	Q13
T20	Q1/Q1A	Q4/Q4A	Q5/Q5A
T21	Q2/Q2A	Q3/Q3A	Q6/Q6A



VAR TRANSDUCER (MOUNTED IN JVC CUBICLE)

NOTE: OUTPUT TERMINAL (12) WILL BE POSITIVE WITH RESPECT TO (1) FOR OVEREXCITED VARS WITH INSTRUMENT TRANSFORMER POLARITIES AS SHOWN.

WHEN THE GENERATOR IS SUPPLYING RATED VARS TO THE POWER SYSTEM, THE SIGNALS TO THE TRANSDUCER ARE 115V (POTENTIAL) AND I1. (REACTIVE COMPONENT ONLY – TOTAL CURRENT, AT RATED KVA, IS I2. THE TRANSDUCER IS CALIBRATED TO DELIVER 1.000MA INTO 2200Ω, (2.2V) WITH 500 VARS APPLIED. THUS THE OUTPUT CORRESPONDING TO GENERATOR RATED VARS WILL BE $2.2V \times \frac{115V \times I1}{500\ VA}$ = VOLTS

SEE CHART BELOW

	I2	I1	V
GEN. 1	4.27	1.86	.943
GEN. 2	4.27	1.86	.943
GEN. 3	4.27	1.86	.943

50-470121AWAA1
(GEI-88846 – WEST LYNN)

REVISIONS		PRINTS TO
1	REVISED M. Tinsley APR 13 1977 RDP 7 8-14-80 GEN CORRECTIONS	BEHI
2		

MADE BY S. Williams 9/27/77 ISSUED OCT 6 1977
APPROVALS W. H. Hill
DRIVE SYSTEMS PROD. DEPT DIV OR DEPT WAYNESBORO, VA. LOCATION
44C308284 CONT ON SHEET 6 SH NO. 5

FF-609-F (2-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 7 SH NO. 6

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-

APPLIED PRACTICES	SURFACES	TOLERANCES ON MACHINED DIMENSIONS FRACTIONS	DECIMALS	ANGLES
	✓	±	±	±

TITLE

JOINT VOLTAGE CONTROL

FIRST MADE FOR 3S7931JC100A5

ELEMENTARY DIAGRAM

PALMAR - URUGUAI
REQN. 140-J11-T80284

TEST BUS

1CS TEST

1CS OPERATE

Q19 3FU 6A Q58

TO CUSTOMER 125 V.D.C. 2.0A BURDEN

Q20 4FU 6A

INPUT TO POWER SUPPLY SEE SH.3

4JV 27JV 27A 27B 60 60X TDPU 4TB(A) 4TB(B)

R1TB-24 R1TB-25 R2TB-8 R2TB-9 R2TB-7 27JV

1PB-A 2PB-A 3PB-A B3 B4

52* (GEN-#1) 52* (GEN-#2) 52* (GEN-#3)

CS-1* JVC CS-2* JVC CS-3* JVC

Q49 Q50 Q51 Q52

R3TB-1 R3TB-4 R3TB-5 R3TB-8 R3TB-9 R3TB-12 R3TB-2 R3TB-6 R3TB-10

90 J1X1-1 90 J1X2-1 90 J1X1-2 90 J1X2-2 90 J1X1-3 90 J1X2-3

Q117 Q118 Q119 Q120 Q121 Q122

10-CS RAISE 10-CS LOWER

Q135 Q131 Q130

10M LS6 10M LS5 10M LS3 10M LS2 10M LS1

H3 H2 H10 H8 H5 H9 H11 H4 H24 H23 H17 H22

118D 118E 118A 118B 118C

1TB(1) 1TB(2) 1TB(3) 10M (M1) (M2) ARM 75VDC

10P SEE SH.2 LOC B3 1TB5 1TB6 R1 2500Ω 50W

Q133 Q132 Q134

POSITION INDICATOR LOWER LIMIT UPPER LIMIT

△ 10CS SB1

CONTACTS	HANDLE END	NO	LOWER	OFF	RAISE
1 1C 2C 2		1			X
		2	X		
3 3C 4C 4		3	X		X
		4		X	
5 5C 6C 6		5			X
		6	X		

ESCUTCHEON

10CS

LOWER RAISE

PISTOL GRIP

10M LIMIT SWITCH SETTINGS

CONTACT CLOSED (OT = OVERTRAVEL)

CONTACT OPEN

OT RAISE LOWER OT

LS-1 LS-3 LS-2 LS-4 LS-6 LS-5

NOT USED

50%

100%

REVISIONS			PRINTS TO
1	REVISED McSlaughter APR 12 1978		3E4
2	WDSlaughter 11-13-78		
3	RGP 8-14-80 GEN CORRECTIONS		

MADE BY 9/27/77 APPROVALS

ISSUED OCT 6 1977

DRIVE SYSTEMS PROD. DEPT. WAYNESBORO, VA.

44C308284 CONT ON SHEET 7 SH NO. 6

FF.808-F (2-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 8 SH NO. 7

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:—

APPLIED PRACTICES	SURFACES	TOLERANCES ON MACHINED DIMENSIONS FRACTIONS	DECIMALS	ANGLES
	✓	±	±	±


TITLE

JOINT VOLTAGE CONTROL

FIRST MADE FOR 3S7931JC100A5


ELEMENTARY DIAGRAM


PALMAR – URUGUAI
REQN. 140-J11-T80284




1CS IS A TYPE CE CR2940 THREE POSITION SELECTOR SWITCH WITH BTM CONTACTS USED FOR IND. LIGHTS. (BACK VIEW)

NOTE:
TEST PUSHBUTTONS 1PB THRU 3PB ARE ILLUMINATED – ALTERNATE ACTION PUSHBUTTONS.







REVISIONS			PRINTS TO
1	REVISED PER MCLAUGHLIN		3SN1
2	RGP 8-14-80 GEN CORRECTIONS		

MADE BY P.W. 9/27/77 ISSUED OCT 6 1977

APPROVALS W.L. Wharton

DRIVE SYSTEMS PROD. DEPT OR ENGINEERING DEPT WAYNESBORO, VA. LOCATION

44C308284 CONT ON SHEET 8 SH NO. 7

FF-808-F (2-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 9 SH NO. 8

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-


APPLIED PRACTICES	SURFACES	TOLERANCES ON MACHINED DIMENSIONS FRACTIONS	DECIMALS	ANGLES
	✓	±	±	±

TITLE
JOINT VOLTAGE CONTROL

FIRST MADE FOR 3S7931JC100A5

ELEMENTARY DIAGRAM

PALMAR - URUGUAI
REQN. 140-J11-T80284



NOTE

BALANCE ADJUSTMENTS SHOULD BE CENTERED FOR NORMAL OPERATION.

REVISIONS		PRINTS TO
1	RGP 8-14-80 GEN CORRECTIONS	3E/H

MADE BY J. Wilson 9/27/77
ISSUED OCT 6 1977
APPROVALS W. Haughton W. H. Hopkins
DRIVE SYSTEMS PROD. DEPT DIV OR DEPT
WAYNESBORO, VA. LOCATION
44C308284 CONT ON SHEET 9 SH NO. 8

FF-502-F (2-77) PRINTED IN U.S.A.


GENERAL ELECTRIC

44C308284 CONT ON SHEET 10 SH NO. 9

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:—
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± | DECIMALS ± | ANGLES ±

TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM
PALMAR – URUGUAI
REQN. 140–J11–T80284

LEVEL SENSER BOARD



PIN NO.	FUNCTION
1	-18V DC
3	0 VOLTS
5	+12V DC
7	+6V DC
9	NO CONNECTION
11	RELAY OUTPUT LS-1
13	NO CONNECTION
15	INPUT LS-1
17	NO CONNECTION
19	LOGIC OUTPUT LS-1
21	NO CONNECTION
23	NO CONNECTION
25	NO CONNECTION
27	NO CONNECTION
29	NO CONNECTION
31	RELAY OUTPUT LS-2
33	NO CONNECTION
35	INPUT LS-2
37	NO CONNECTION
39	LOGIC OUTPUT LS-2
41	NO CONNECTION

NOTE: LS-1 NOT USED IN THIS EQUIPMENT. IT MAY BE USED AS A SPARE IN PLACE OF LS-2 BY CHANGING CONNECTIONS.


VDC VOLTAGES SHOWN ARE MEASURED WITH VACUUM TUBE VOLTMETER AND ARE REFERRED TO O VOLTS. VALUES ARE TYPICAL AND MAY DEVIATE ±10% FROM THOSE SHOWN.

UNLESS OTHERWISE SPECIFIED:
RESISTANCE VALUES ARE 5%
RESISTANCE WATTAGE RATING IS 1/2 WATT


THIS PORTION NOT USED

LS-1:
- 11TP OUTPUT
- 15TP INPUT
- 1P PULSE LEVEL
- ATP BALANCE
- 2P MINUS LEVEL
- 3P BALANCE


LS-2:
- 31TP OUTPUT
- 35TP INPUT
- 4P PLUS LEVEL
- BTP BALANCE
- 5P MINUS LEVEL
- 6P BALANCE



ANALOG TO ANALOG



SEE TABLE FOR POWER CONNECTIONS



LOGIC SYMBOL

DESCRIPTION:

THIS UNIT CONTAINS TWO IDENTICAL SECTIONS. THE INPUT TO THE "A" SECTION IS INTO A DIODE SWITCH 2D AND 4D WHICH CONNECTS THE INPUT SIGNAL TO THE BASE OF 1Q WHEN THE INPUT EXCEEDS A LEVEL IN EXCESS OF THAT AT THE SLIDERS OF 1P AND 2P. INPUT SWITCH BIAS IS PROVIDED BY DIODES 1D AND 3D. THE INPUT SIGNAL APPLIED TO THE BASE OF 1Q IS AMPLIFIED AND SWITCHED TO THE BASE OF 3Q BY MEANS OF DIODES 5D AND 6D. TRANSISTOR 3Q DRIVES 4Q TO OPERATE THE RELAY. SNAP ACTION IS INSURED BY FEEDBACK THROUGH RESISTOR 12R. OPERATION OF THE "B" SECTION IS SIMILAR.

ADJUSTMENTS:

WITH NO INPUT SIGNAL THE OUTPUT IS +6 VOLTS DC AND THE ASSOCIATED RELAY IS ENERGIZED. UPON APPLICATION OF AN APPROPRIATE INPUT SIGNAL THE RELAY IS DE-ENERGIZED THE INPUT OPERATING LEVEL MAY BE ADJUSTED FOR POSITIVE GOING SIGNALS BY MEANS OF 1P/4P AND FOR NEGATIVE GOING SIGNALS BY MEANS OF 2P/5P OVER THE RANGE OF ±0.5 TO ±5.0 VOLTS DC.

BALANCE CONTROLS 3P AND 6P SERVE TO BALANCE THE SWITCHED INPUT AT A.T.P. & B.T.P. TO ZERO WITH ZERO INPUT.

THE SIGNAL INPUT IMPEDANCE IS APPROXIMATELY 100K OHMS AND A MAXIMUM OF ±175V DC MAY BE APPLIED AT THE INPUT.

REVISIONS		PRINTS TO
1	RGP 8-14-80 GEN CORRECTIONS	3S741

MADE BY 9/27/77 ISSUED OCT 6 1977 | APPROVALS | DRIVE SYSTEMS PROD. DEPT. DIV OR DEPT WAYNESBORO, VA. LOCATION | 44C308284 CONT ON SHEET 10 SH NO. 9

FF-809-F (3-77) PRINTED IN U.S.A.

GENERAL ELECTRIC

44C308284 CONT ON SHEET 11 SH NO. 10

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:-
APPLIED PRACTICES | SURFACES ✓ | TOLERANCES ON MACHINED DIMENSIONS: FRACTIONS ± | DECIMALS ± | ANGLES ±


TITLE
JOINT VOLTAGE CONTROL

FIRST MADE FOR 3S7931JC100A5

ELEMENTARY DIAG. PALMAR - URUGUAI

REQN. 140-J11-T80284

HALF WAVE REVERSING MOTOR CONTROL
WITH CURRENT LIMIT (3/4 HP MAX.)



REVISIONS

1	RGP 8-14-80 GEN CORRECTIONS	

PRINTS TO 3EH

MADE BY W.W.D. 9/27/77 ISSUED OCT 8 1977

APPROVALS

DRIVE SYSTEMS PROD. DEPT DIV OR DEPT WAYNESBORO, VA. LOCATION

44C308284 CONT ON SHEET 11 SH NO. 10

FF-505-F (3-77) PRINTED IN U.S.A.

GENERAL ELECTRIC


44C308284 CONT ON SHEET FNL SH NO. 11

UNLESS OTHERWISE SPECIFIED USE THE FOLLOWING:–

APPLIED PRACTICES	SURFACES	TOLERANCES ON MACHINED DIMENSIONS FRACTIONS	DECIMALS	ANGLES
	✓	±	±	±

TITLE
JOINT VOLTAGE CONTROL
FIRST MADE FOR 3S7931JC100A5
ELEMENTARY DIAGRAM
PALMAR – URUGUAI
REQN. 140–J11–T80284

POWER SUPPLY CHASSIS



NOTE: (1) THIS "STANDARD" POWER SUPPLY CONTAINS CIRCUITS AND FEATURES NOT USED WITH JVC EQUIPMENT 3S7931JC100A5. SPECIFICALLY NO CONNECTIONS ARE MADE TO TERMINALS 11, 12, 14, 15, 17, 20, 21, 23, 24, 25 OF PTB, THUS THESE CIRCUITS IN POWER SUPPLY ARE NOT USED. TERMINALS 16, 17, AND 27 OF PTB ARE JUMPERED BY WIRE NO. 156 TO BYPASS CONTACT OF UNUSED RELAY. TERMINALS 3 AND 22 GO TO GROUND.

(2) TIE AND TAPE LEAD 2T(4)

REVISIONS			PRINTS TO
1	REVISED APR 12 1978		3EH1
2	ROF 8-14-80 GEN. CORRECTIONS		

MADE BY 9/27/77 ISSUED OCT 6 1977 APPROVALS

DRIVE SYSTEMS PROD. DEPT DIV OR DEPT WAYNESBORO, VA. LOCATION

44C308284 CONT ON SHEET FNL SH NO. 11

FF-809-F (2-77) PRINTED IN U.S.A.

GENERAL ELECTRIC COMPANY • DRIVE SYSTEMS OPERATIONS
SALEM, VIRGINIA 24153

GENERAL ELECTRIC