



### INTRODUCTION


- Clock synchronization is essential in numerous applications, ranging from telecommunications and network protocols to industrial automation and financial transactions
- Accuracy of synchronized clocks is paramount, as deviations in timekeeping can lead to:
  - data inconsistencies
  - communication errors
  - operational disruptions
- Servos (servomechanisms) play a critical role in achieving accurate clock synchronization

# TIME, PHASE & FREQUENCY

We all know what time is - unit is second [s]


Phase is the angle of a rotating vector; in clock terms: time related to the period of a repetitive signal - unit is radians [rad]


Frequency is a statistical term; number of events per second - unit is Hertz [Hz]



### THERE ARE TWO "THINGS" TO SYNCHRONIZE

Frequency and Time








205-12#sh clock \*13:38:54.805 UTC Mon Apr 2 2012




### WHAT IS "SYNCHRONIZATION"



# FREQUENCY SYNCHRONIZATION

### FREQUENCY SYNCHRONIZATION




Two clocks are frequency synchronized if the frequency of the two clocks have common denominator.

Two clocks are called plesiochronous if the difference in their common denominator is bounded.

The difference in position of rising edges of the clocks is called phase offset.


Two common frequencies which have constant phase offset are phase-locked and implicitly frequency synchronized.

## PHYSICAL LAYER FREQUENCY DISTRIBUTION




## SIGNIFICANT INSTANTS – PHYSICAL DISTRIBUTION

Timing Signal and Noise



Example: 25 MHz signal




TIE ... Time Interval Error



### PACKET-BASED FREQUENCY DISTRIBUTION


- Three key steps:
  - Generation: from physical signal to packet
  - Transfer: timing events (frame or packet flow) transmission over packet network
  - Recovery: from packet-based signal to physical signal




Adaptive Clock Recovery (ACR) using IEEE1588 Precision Time Protocol (PTP)

#### SIGNIFICANT INSTANTS PACKET-BASED DISTRIBUTION

- Timing signal could either be
  - Periodic with known send frequency (e.g., CES) or
  - With additional information (e.g., PTP timestamps) defining the ideal position in time of the significant instant relative to a master time scale.






CES ... Circuit Emulation Service; PTP ... Precision Time Protocol

#### PACKET-BASED TIMING RECOVERY


#### Three Major Tasks:

- 1. Classify the packets
- 2. Select the "good" packets depending on network conditions

3. Process the "good" packets to recover clock



Source: ITU-T G.8260 (202211)



XO

Local reference


**Packet** 

PLL

# TIME SYNCHRONIZATION

## TIME - A CLOSER LOOK


■ Time = Phase + Time of Day



\*13:38:54.805 UTC Mon Apr 2 2012

## TIME DISTRIBUTION


Packet Layer distributing Phase & Time of Day



# SYNCHRONIZATION PROTOCOLS

### TWTT PROTOCOL BASICS

Basic PTP Message Exchange




TWTT ... Two-Way Time Transfer

# WHAT IS PRECISION TIME PROTOCOL (PTP)?

#### IEEE Std 1588<sup>™</sup>-2019


Abstract: In this standard, a protocol is defined that provides precise synchronization of clocks in packet-based networked systems. Synchronization of clocks can be achieved in heterogeneous systems that include clocks of different inherent precision, resolution, and stability. The protocol supports synchronization accuracy and precision in the sub-microsecond range with minimal network and local computing resources. Customization is supported by means of profiles. The protocol includes default profiles that permit simple systems to be installed and operated without the need for user management. Sub-nanosecond time transfer accuracy can be achieved in a properly designed network.



FTS ... Full Time Support; PTS ... Partial Time Support;

Protocol defined by the IEEE in standard 1588-2008 (v2) or 1588-2019 (v2.1)

- Profile (<u>how</u> to configure the protocol and what optional features to use, if applicable) defined by the ITU-T in recommendation G.8265.1 (SOOC), G.8275.1 (FTS) or G.8275.2 (APTS/PTS)
  - Other industries define their own profiles
- An OC or BC with a PTP port in the SLAVE state <u>must</u> synchronize its local PTP clock to the GM clock – but means of synchronization is <u>outside scope of</u> IEEE standard (and sometimes not even mentioned in the Profile)





APTS ... Assisted PTS

# I REPEAT, 1558 IS A PROTOCOL


- The biggest misunderstand of what 1588 provides is time or clock "synchronization" precision vs accuracy
- It's a time/clock distribution protocol, but by itself, it only provides a measurement of time/phase offset at a specific instance of sending and receiving an event packet

#### 1. Scope

This standard defines a network protocol, the Precision Time Protocol (PTP), enabling accurate and precise synchronization of the real-time clocks of devices in networked distributed systems. The protocol is applicable to systems where devices communicate via networks, including Ethernet. The standard allows multicast communication, unicast communication or both. The standard specifies requirements for mapping the protocol to specific network implementations and defines such mappings, including User Datagram Protocol (UDP)/Internet Protocol (IP versions 4 and 6), and layer-2 IEEE 802.3 Ethernet.

The protocol enables heterogeneous systems that include clocks of various inherent precision, resolution, and stability to synchronize to a grandmaster clock. The protocol supports synchronization in the submicrosecond range with minimal network bandwidth and local clock computing resources. The protocol enhances support for synchronization to better than 1 nanosecond. The protocol specifies how corrections

Looking a tradition PLL model, all PTP provides is the function of the phase/frequency detector (PFD)




#### You still need a servo!

If required as specified in 12.1, an Ordinary Clock or Boundary Clock with a PTP Port in the SLAVE state shall synchronize its Local PTP Clock to the Local PTP Clock of its Parent PTP Instance in the synchronization hierarchy established by the best master clock algorithm. While this standard defines a synchronization protocol, the specific means and details of synchronization are out of the scope of this standard. These means of synchronization shall minimize the value currentDS.offsetFromMaster, which is computed and stored in the data set by the Slave Clock per 11.2.

IEEE Std 1588<sup>™</sup>-2019



### TYPICAL LINUX PTP IMPLEMENTATION



# PHASE-LOCKED LOOP (PLL)

... A CONTROL SYSTEM THAT GENERATES AN OUTPUT SIGNAL WHOSE PHASE IS RELATED TO THE PHASE OF AN INPUT SIGNAL. THERE ARE SEVERAL DIFFERENT TYPES; THE SIMPLEST IS AN ELECTRONIC CIRCUIT CONSISTING OF A VARIABLE FREQUENCY OSCILLATOR AND A PHASE DETECTOR IN A FEEDBACK LOOP. WIKIPEDIA


#### WHAT DOES A PLL DO?


Generate a clock that is phase and frequency locked to an input clock.

- The output clock frequency can be of the same frequency, an integer multiple or a fraction of the input clock frequency.
- Input edge to output edge phase alignment can be achieved.


Input clock frequency to output clock frequency ratio must be a positive integer or fractional number.

- 19.44 MHz to 66/64\*255/237\*78125/77760\*622.08 MHz is possible.
- 10 MHz to π MHz is not possible (afaik).





#### PLL BUILDING BLOCKS: PHASE COMPARATOR



The Phase Comparator establishes the "error" between the reference input and the clock output; using a feedback

Most Digital PLLs (DPLLs) use a Time to Digital Converter (TDC) for the Phase Frequency Detector (PFD) to measure the phase of the two clocks and produce a digital word representing the error

TDC can be looked at as a timestamper, resolution determined by the sampling clock


The TDC timestamps the reference and feedback edges, and the PFD mathematically tracks the phase offset between the selected reference and feedback clocks

The measured phase difference can go well beyond 1 period, or Unit Interval (UI), of the reference and feedback clocks; thus, the phase comparator must be able to measure over a large range of multiple input/feedback clock periods

- Various telecom standards define a jitter & wander tolerance requirement the widest is defined is 18µsp-p
- For example, if the input clock has a nominal period of 8ns (125 MHz), then the jitter tolerance requirement equates to ± 1125 UI



#### PLL BUILDING BLOCKS: LOOP FILTER



The phase error is processed by the loop filter (LF)

- LF is a combination of proportional and integral (PI) control, which generates a control signal for controlling the oscillator
- The integrator is an additional pole, therefore 2nd order (may be referenced as "Type 2" PLL)

The LF determines the bandwidth (BW) of the PLL (i.e. cut-off frequency)


• Other functionality, such as phase slope limiting (PSL), locking range, and holdover functionality may be done as well

The step response has an overshoot and the frequency domain transfer function has peaking.

- Phase corrections mainly done through proportional path, along with any PSL
- Frequency offset, or drift corrections, is done through the integrator path, including damping (i.e. gain peaking control)




#### PLL BUILDING BLOCKS: CONTROLLED OSCILLATOR




- a free-running crystal oscillator (XO)
- A digital synthesizer which pulls the frequency up or down using a Control Signal from loop filter (a digital word representing a fractional frequency offset (FFO))


#### **TYPE 2 DPLL**



- A loop filter with an additional integrator is inserted.
- The integrator is an additional pole, therefore 2<sup>nd</sup> order.
- The DCO pole and the transfer function constants of the PFD and DCO act as a low pass filter.
- The jitter transfer function has only 20dB/dec roll-off.
- Type 2 DPLL. A non-zero delta freq. no longer requires a non-zero phase offset. So at a non-zero frequency offset the DPLL will lock with zero phase offset.
- The step response has an overshoot and the frequency domain transfer function has peaking.



#### PLL: USE WITH PACKET CLOCKS



A timing protocol, such as IEEE 1588, can be used as the phase (or time) comparator

- Still follows same model as PLL, but may introduce a packet selection block
- Without packet selection, the packet delay variation (PDV) will have a significant impact to the loop filter

The LF will typically be designed to support much lower update intervals of the phase error


- This is due to packet dropping, or to attenuate the impact of the PDV
- Typically requires a more stable local clock source (oscillator, or maybe physical layer assistance)



## PLL MODES: LOCKED, HOLDOVER AND FREERUN

- Freerun mode; the DPLL does not track any input clock. The output clock is at the centre frequency, offset is zero.
- i.e. switch is open.
- Normal / Lock mode; the DPLL tracks the input clock. The output clock is phase & frequency locked to the input clock.
  - i.e. switch is in position 1.
- Holdover mode; Typically used when the input clock fails. The PLL no longer tracks its input clock but uses the last valid frequency offset from memory (MEM). The proportional path is reset to zero and the integrator frozen at its last value. The phase detector is reset to flush out its phase history.
  - i.e. switch is in position 2.
  - clock becomes an autonomous synchronization source

In freerun mode or after entry into holdover mode, frequency is subject to ageing drift and to the influence of temperature.




# PLL MODES: HOLDOVER @ CONSTANT TEMPERATURE

#### Fractional frequency:

$$y(t) = y_0 + D \cdot t$$

where  $y_0$  = initial frequency offset

D =frequency drift rate (constant)




#### Time error:

$$x(t) = x_0 + y_0 \cdot t + \frac{D}{2} \cdot t^2$$

where  $x_0$  = initial phase offset

 $y_0$  = initial frequency offset

D =frequency drift rate (constant)



# **LOOKING AT NOISE**




#### PLL: JITTER & WANDER FILTERING


#### What is jitter/wander?

- Jitter, wander, phase noise is a variation of the clock's frequency/period/phase
- Essentially a phase modulation (due to noise or other disturbances) of the carrier clock when compared to an ideal reference
  - Jitter = short-term variations
  - Wander = long-term variations
- ITU-T G.810 defines noise frequencies <10Hz as wander and frequencies >10Hz as jitter
  - In Telecom, the period of the clock is called Unit Interval (UI)

The function of a PLL is to attenuate jitter and transfer wander


 In other words, tolerate noise at the input without losing lock to the reference







## PLL: RESPONSE TO INJECTED NOISE




$$X_{OUT}(t) = X_{IN}(t) * h_{IN}(t)$$

$$X_{OUT}(s) = X_{IN}(s) \cdot H_{IN}(s)$$

where  $h_{IN}(t)$  = impulse response

$$H_{IN}(s)$$
 = transfer function = Laplace  $\{h_{IN}(t)\}$ 




$$X_{OUT}(s) = X_{OSC}(s) \cdot H_{OSC}(s)$$


where  $h_{OSC}(t)$  = impulse response

 $H_{OSC}(s)$  = transfer function = Laplace  $\{h_{OSC}(t)\}$ 

#### PLL is a low-pass filter for input noise




#### PLL is a high-pass filter for oscillator noise





#### PTP4L SW FILTER TEST RESULTS FOR G.8273.2

Simple SW based Low Pass Filtering (BW = 0.4-0.5Hz), no PDV



1pps TE Absolute Oute: 2021-09-30 File: OnePpsAccuracyTod100.CDF Offset Removal Applied: False: Zero Offset: -1.553ns

1pps TE Absolute
-50
-200
-250
0 500 1 000 1 500 2 000 2 500 3 000 3 500 4 000

Elapsed Time [s]

Even if ptp4l settings adjusted for cut-off frequency (i.e. to be <0.1Hz), it will still be difficult to pass gain peaking (>2db!)

#	Freq (Hz)	Ampl (ns)	Duration (s)	Pk-Pk Output (ns)	Gain (dB)	Upper Pk- Pk Limit (ns)	Lower Pk- Pk Limit (ns)
1	0.00391	200	1024	199.77	-0.01	215	130
2	0.00781	200	896	200.11	0.00	215	130
3	0.01563	200	448	201.19	0.05	215	130
4	0.03125	200	224	205.06	0.22	215	130
5	0.06156	200	243.65	217.68	0.74	215	-
6	0.12313	200	251.78	255.64	2.13	140	-
7	0.24625	200	251.78	240.95	1.62	90	-
8	0.4925	200	249.75	124.11	-4.14	50	-
09	0.985	200	249.75	58.95	-10.61	35	-
10	1.985	200	249.87	26.83	-17.45	30	-




### DPLLS BECOMING COMPATIBLE WITH THE LINUX PTP HW CLOCK

Linux PTP supports PTP Linux PTP v4.0 filtering in hardware timing chip to meet stringent ITU-T User Space -G.8273.2 Class D compliance **Protocol Stack** Servo  $(\max |TE|_1 \le 5 \text{ns},$ gain peaking < 0.1dB) Same **PHC APIs PTP** timestamps **APIs** Hardware filter is simpler to SO TIMESTAMPING PHC configure and use compared to Linux Kernel -**Socket Option** Infrastructure software-based PI-filter included in ptp4l Drivers in Servo compliance becomes **Kernel Driver Kernel Driver** Main Line a mathematical certainty Linux Clock Local MAC **PLL** Oscillator Signal (HW Servo) **Packet** Hardware PTP PPS Switched Master Clock **TSU** TOD<sub>PHC</sub> Network TOD<sub>TSU</sub> Time is synchronized using the



Linux PTP ts2phc application


### BENEFIT OF AN ADAPTIVE FILTER




# PHASE LOCKED LOOPS (PLL)

**CLOCK COMBINING** 


## **COMBINING TWO PLLS**



### TWO PLLS: RESPONSE TO INJECTED NOISE



Band-pass filter for In2 Noise to Out





### TWO PLLS: APPLICATIONS


 GNSS & Cesium clock in enhanced Primary Reference Time Clocks (ePRTC)

GNSS & Miniature Atomic Clock
 (MAC) in OCP-TAP Time Card

 PTP & SyncE in boundary clocks (T-BC) and slave clocks (T-TSC)









#### G.8273.2 T-BC: RESPONSE TO INJECTED SYNCE NOISE

