

Makita Battery Tool - Troubleshooting Guide V4.0.1

If you run into any hiccups while connecting your tool or reading a battery, don't worry! Most connection issues are easily solved in a few seconds. Look for your specific issue below:

1. The Pop-Up Says "No compatible devices found"

- **What it means:** The website is working, but your Windows computer does not recognize the tool plugged into your USB port. This happens when your computer is missing the communication "driver" for the hardware.
- **How to fix it:**
 1. Download the USB Driver provided via the link on the tool web page (CH341 or CP210x Driver).
 2. Open the downloaded file and click Install.
 3. Once the installation says "Successful", close the installer.
 4. Unplug the tool from your computer, plug it back in, and refresh the web page. Your device should now appear in the pop-up list!

2. Error Message: "undefined is not an object..."

- **What it means:** You are trying to run the tool on an unsupported web browser (most commonly Apple Safari or Mozilla Firefox). Apple and Mozilla restrict hardware from talking to websites for security reasons.
- **How to fix it:**
 1. Close your current browser.
 2. Open the latest version of Google Chrome or Microsoft Edge (Update if needed first).
 3. Navigate back to the tool's web address, and it will work perfectly. (**Note: This tool requires a desktop/laptop computer and will not work on an iPhone or iPad.**)

3. The Pop-Up Closes, but says "Connection Failed"

- **What it means:** Your computer sees the tool, but the port is currently "locked" or being held hostage by another program running in the background.
- **How to fix it:**
 1. Make sure you do not have the tool open in multiple browser tabs at the same time. Close any extra tabs.
 2. Ensure you don't have 3D printing software (like Cura) or coding software (like the Arduino IDE) open, as these automatically hijack USB serial ports.
 3. Unplug the USB cable, wait 5 seconds, plug it back in, and click "Connect Device" again.

4. Tool Connects, but says "No battery detected or battery is unreadable"

- **What it means:** The computer is talking to the hardware adapter perfectly, but the adapter is not receiving data from the Makita battery. (this can happen if the battery is a Fake / Copy battery which will not work with this tool).
- **How to fix it:**
 1. Ensure the battery is slid all the way onto the adapter until it firmly clicks into place.
 2. Check the metal terminal prongs on the adapter and the battery. If they are covered in workshop dust, grease, or debris, wipe them clean with a dry cloth to ensure a solid electrical connection.

3. Click the green Read Data button to try again.

5. The Lock Screen Says "Authentication Failed"

- **What it means:** The tool failed its security authentication and could be because it is not an official tool or there is a fault with the tool.
- **How to fix it:**
 1. Simply click OK or refresh the web page and try connecting again. A slight bump to the USB cable during the initial wake-up process can interrupt the authentication if a loose usb connection happens.

6. Cell Imbalance Warning: "(Check internal physical connections)"

- **What it means:** The tool detected a voltage spread of 0.300v or higher between your highest and lowest cells.
- **How to fix it:** This usually indicates a broken spot weld on the cell balancing tabs inside the pack, rather than a degraded cell. You will need to open the battery casing and physically inspect the nickel strip connections.

7. Repair Frame Button says "Repair Blocked (Unsupported Type)"

- **What it means:** The tool successfully read the battery but detected a Type 5 or Type 6 internal BMS board.
- **How to fix it:** You cannot bypass this. Writing a new EEPROM frame to these specific models carries a high risk of permanently bricking the pack, so the tool locks the feature out for your safety. Use the "Clear Errors (1st Step)" button instead.