

Auto increment / Auto decrement Mode : —

> In this Mode the register is Auto incremented / Auto-decremented after or before its value is used to access the memory.

Direct addressing Mode : —

> In this Mode the address part of the instruction is equal to the effective address.
> The Operands resides in the Memory and the address is given directly to the instruction address field.

Indirect addressing Mode : —

> In this Mode the address field in available instruction gives the address in which the effective address get stored in the memory.
> The Control signal fetches the instruction, i.e., available in memory and then uses its address to access the memory to read its effective address.

Index addressing Mode : —

> In this Mode the Content of given index register (XR) get is added to the instruction address part so it becomes

Indexed Addressing Mode = $\text{XR} + \text{address}$.