

Synchronously transfer :-

$R_1 \leftarrow R_2, R_3 \leftarrow R_4$

Addressing Modes :-

It helps as a specify the way in which One Operant effective address can be represented in any given instruction.

Some addressing modes allows referring to a large range of area efficiently like some linear array of address along with a list of address.

An addressing mode can be described as an efficient and flexible way to define complex effective address. Generally programs are written in high level language as its a convenient way in which one can define variables along with operation that a programmer perform. This programs are later compile to generate the actual machine code which includes low level instruction.