## 1 | Silicon

- 1.1 | refirenry
- 1.1.1 | from sand
- 1.1.2 | **melted**
- 1.1.3 | small molten crystal "seed" lower into a vat
- 1.1.4 | crystal forms
- 1.1.5 | pull cylander from molten reigon
- 1.1.6 ground to form ingots
- 1.1.7 | sawed with diamond blade to form wafers
- 1.1.8 | wafer scrubbed
- 1.1.9 edges rounded and surfaces ground smooth and to create uniform thickness
- 1.1.10 | rinsed and etched in "chemicals" to remove impurities
- 1.1.11 | final polish on one side of the wafer
- 1.1.12 all so that there are no scratches or contamination
- 1.1.13 | then, measured for resistivity
  - 1. function of dopant concentratian
- 1.2 | **design**
- 1.2.1 circuit design
- 1.2.2 organization of design team
  - 1. based on organization of the chip
  - 2. establish microarchitecture that regulates sequences and timings
  - 3. design divided into areas

Taproot · 2020-2021 Page 1

- 1.3 | structure
- 1.3.1 | cubic atomic structure
- 1.3.2 | 4 electrons valence shell
- 1.3.3 perfect crystal will have no holes
- 1.3.4 | but at room temperature, free electrons can conduct
- 1.4 | impurities called dopants
- 1.4.1 | negative
  - 1. arsenic or phospherus
  - 2. one more valence
  - 3. n type crystal because negative free carriers
- 1.4.2 | positive
  - 1. boron
  - 2. missing electron acts like positive carrier, "hole"
- 1.4.3 | silicon can be either good or poor conductor (semiconductor)
  - 1. controlled by concentration of dopant

Taproot · **2020-2021** Page 2