mincarb

Solar Desalination System



Document Number		
Document Name	Solar Desalination Sys v3.3D PPD	

Date	Version	Description of Change	Eng	Author
25/09/2017	v0.1D	Latest Draft		PK
26/11/2018	v0.3D	Generic Variant		PK

Supplier | Manufacturing | Product | Client | Customer

Legend

Incoming Inspection | Metrology/ Test
Destructive Test | Temporary Recyclable Material
Production Process | Incoming Material
Assembly Process | Enclosed Steps are One Process
KPI | Outgoing Inspection
Data | Packaging
Installation Process

Flex (0100)

ABS 0100-0001 | Flex 0100-0002 | Maxrin 0100-0003 | Digikey 0100-0004 | Asmal AVR 0100-0005

Inspection 0100-0100 → PCB Flex Assembly 0100-0200 → Programming 0100-0300 → FIT/ST 0100-0301 → Packaging 0100-0400

Stack Assembly (0200)

Graphite 0200-0001 | AC 0200-0002 | PTFE 0200-0003 | EVOH 0200-0004

Inspection 0200-0100 → Plate Production 0200-0200 → Lamination 0200-0300 → PC Sheet Cutting 0200-0400 | PC Sheet Cutting 0200-0500 → Stack Assembly 0200-0600 → Laser Etch Circuits 0200-0700 → Install Stack 0200-0800

IEX-CX 0200-0005 | IEX-AX 0200-0006 | Mesh Spacer 0200-0007 | ABS 0200-0008 | AUX Panel Mount 0200-0009 | Fasteners 0200-0010 | 316 SS Plate 0200-0011 | Compressor 0200-0012

Enclosure 0200-0900 → Install Fittings to Plate 0200-1000 → Assemble Pump to Plate 0200-1100 → Install Pump 0200-1200 → Potting Compound 0200-0013 → FIT/ST 0200-1300 → Potting Weir 0200-1400 → FIT/ST 0200-1500 → Install Stack 0200-1600

Module Assembly (0300)

Fittings 0300-0001 | Copper Bus 0300-0002 | Casing 0300-0003 | Lexan Sheet 0300-0004

Install bus fittings 0300-0100 → Cutting 0300-0200 → Back Install 0300-0300 → Back Assembly 0300-0400 → Install Stack 0300-0500 → System Test 0300-0600

Dynamic Energy Management System (0800)

Power Supply 24V 250A 0800-0001 | Wiring Enclosure 0800-0002 | Wiring Subsys 0800-0003 | Aux Panel Mount 0800-0004 | TT DSP 0800-0005 | Mincarb Main Board 0800-0006 | High Current Relay 0800-0007 | Power Resistor 0800-0008 | Enclosure 0800-0009 | Fan 0800-0010 | Copper Bus 0800-0011

Power Supply Brackets 0800-0100 → Power Supply Assembly 0800-0200 | Wiring Enclosure Assembly 0800-0300 → Wiring Enclosure Install 0800-0400 | Programming 0800-0500 → Wiring Subsys Assembly 0800-0600 → Wiring Subsys Install 0800-0700 → Enclosure Assembly 0800-0800 → Enclosure Install 0800-0900

Power Supply Install 0800-0210 | Cable Gen Assembly 0800-0600 | Wiring Pre-Install 0800-0800 | System Test 0800-1100

Fluoride Online Sensor (0900)

Enclosure 0900-0001 | Ark Membrane Button Panel 0900-0002 | LCD Display 0900-0003 | Trolase Sensor 0900-0004 | Acrylic 0900-0005 | Panel Mount Connector 0900-0006 | Mode Selector Switch 0900-0007 | Pump 0900-0008 | Tubing 0900-0009 | Fittings 0900-0010 | 2-Way Valve 0900-0011 | Mini Peristaltic Pump 0900-0012

Enclosure Assembly 900-1000 → Mode Selector Mechanical 900-1100 | Select LCD 900-1200 | Trolase Front Panel 900-1300 → Panel Pre-Paint 900-1400 → Panel Mechanical 900-1500 → Mode Selector Install 900-1600 → Assembled Pump 900-1700 → Tubing Assembly 900-1800 → Stainless Nipples 900-1900 → Stainless Nipples Install 900-2000 → Wiring 900-2100 → Wiring Install 900-2200 → Electrical Test 900-2300 → Final Assembly 900-2400 → Clean 900-2500

Laser Engraved Cut 900-1210 → Laser Engraved Cut Install 900-1220 → Mount Sensor 900-1230 → Sensor Install 900-1240 → Panel Mount Connector 900-1810 → Mode Selector Switch 900-1820 → Pump Assembly 900-1830 → Pump Install 900-1840 → Tubing Install 900-1850 → Fittings Install 900-1860 → 2-Way Valve Install 900-1870

PCB 0900-0013 → PCB Calculation 900-1600 → PCB Assembly 900-1700 → Controller Assembly 900-1800 → Controller Install 900-1900

ATMega3052 0900-0014 → Programming 900-1500

Enclosure (0400)

Maxrin 0400-0001 | Fasteners 0400-0010 | Aluminium Sheet Metal 0400-0011 | Melamine 0400-0012 | SS Bench 0400-0021 | Sealer 0400-0022

Cutting 0400-0100 → Assembly Frame 0400-0200 → Install Frame 0400-0300 → Bottom Panel 0400-0400 → Back Panel 0400-0500 → Weather Proofing 0400-0600

Final Assembly (0500)

Kilnn Cable Ducting 0500-0001 | Endurogel Potting 0500-0002 | 20T Filter 0500-0003 | UV Lamp 0500-0004 | Main Pump 0500-0005 | Solenoid Valves 0500-0006 | NFC Reader SubAss 0500-0007 | Wiring SubAss 0500-0008 | HMI 0500-0020 | GSM Equipment 0500-0050

Cutting 0500-0100 → Incoming Inspection 0500-0200 → Install Cable Ducting 0500-0300 → Panel Mount 0500-0400 → Install PC Mounted Components 0500-0500 → Install Pump 0500-0600 → Install Pump Suction 0500-0700 → Install Pump Discharge 0500-0800 → Install Drilled Holes 0500-0900 → Install Filter 0500-1000 → Install UV Lamp 0500-1100 → Install Main Pump 0500-1200 → Mount Solenoid Valves 0500-1300 → Install Valves 0500-1400 → Install Power Supply 0500-1500 → Diagnostic Installation 0500-1600 → Final Wiring 0500-1700 → Leak Test 0500-1800 → Install Drilling Mechanism 0500-1900 → System Test 0500-2000

Photovoltaics (1200)

Subsystem 5200-0001 | 40mm Cable Ducting 1200-0002 | Hardware 1200-0010 | Wiring SubAss 1200-0050

Cable Duct Install 1200-0100 → Cable Duct Install 1200-0200 → Hardware Install 1200-0300 → Wiring Install 1200-0400

Electrical Enclosure (1100)

B&A 1100-0001 | Cable Duct 1100-0002 | DIN Rail 1100-0003 | Panel Mount Items 1100-0004 | MeanWell PS 1100-0005 | DIN Rail 1100-0006 | Transmitters 1100-0007 | Wiring Sub 1100-0008

Wiring and Cable Duct 1100-0100 → Cable Duct Install 1100-0200 → DIN Rail Install 1100-0300 → Install Panel Mount Items 1100-0400 → Mean Well PS Install 1100-0500 → DIN Rail Install 1100-0600 → Transmitters Install 1100-0700 → Wiring Install 1100-0800

Main Fluidics (1300)

SchNEI DN 20 GF++ 1300-0001 | SchNEI Fittings GF++ 1300-0010 | Sensors 1300-0020 | Dosing Pump 1300-0030

Pipe Cutting 1300-0100 → Pipe Subassembly 1300-0200 → Sensor Installation 1300-0300 → Dosing Pump Installation 1300-0400

Dispenser (1400)

SchNEI Fittings GF++ 1400-0001 | Flowmeter/Valve 1400-0002 | SchNEI Piping GF++ 1400-0003

Dispenser Assembly 1400-0100

Packaging/ Freight (0600)

Pir Panels 0600-0001 | Alu Profile 0600-0010 | Product Kit 0600-0030

Packaging Assembly 0600-0100 → Panel Build 0600-0200 → Packaging Install 0600-0300

Final Package 0600-1000

Register Final Unit → Packing Photo Taken 0600-1100 → Freight 0600-3000

Site Installation (0700)

Batteries,PV 0700-0010

Site Preparation 0700-0100 → Installation 0700-0200 → Register Final Unit → Calibration 0700-0300 → Activate 0700-0400

Asset Management (1500)

Filters 1500-0000 | Electrodes 1500-0030 | Batteries 1500-0010 | Reagent 1500-0040

Maintenance 1500-0500