

## Sphinx Technologies Pte Ltd

PH Phua - Hp: 96703880

## <u>At Virdi Finger Print Terminal – Virdi AC2100</u>

- A. To Add A New User with 2 Fingerprints.
- 1. Press and Hold **F3** (For Main Menu)
- 2. Press **F4** ENT Key (To select 1. User Menu)
- 3. For registered admin using FP or card, just input registered finger or flash card
- 4. Press **F4** ENT Key (To select 1. Add Menu)
- 5. Press **F4** ENT Key (Screen will display User ID [New])

User ID [NEW] ID : 000**1** [←] [-] [+][→]


Use the F1 for [←] and F4 for [→] to move cursor from left or right And F2 for [-] and F3 for [+] to change to desired ID number.


## Once completed, press and hold F4 key

- 6. Press **F4** ENT Key (To select 1. FP Menu)
- 7. Press **F4** ENT Key again
- 8. When the FP Sensor lights up, put Index Finger onto the glass area. Take the finger away when the light goes off.
- 9. When the FP Sensor lights up the second time, put back the same registered finger for successful registration confirmation.
- 10. It will display "Registration Completed" with a blip sound if successful
- 11. It will display "Fingerprint Registration Failed" with 2 blips sound if not successful.
- 12. There will be 3 automatic fingerprint registration attempts for unsuccessful Fingerprint registration.

# To Add 2<sup>nd</sup> Finger Registration

#### At the User Menu





Use the F1 for [←] and F4 for [→] to move cursor from left or right And F2 for [-] and F3 for [+] to change to desired ID number to be modified.

### Once completed, press and hold F4 key

- 14. Press **F3** [↓] (To select 2.Add FP Menu)
- 15. Press **F4** ENT Key
- 16 When the FP Sensor lights up, put the other Index Finger onto the glass area. Take the finger away when the light goes off.
- 17. When the FP Sensor lights up the second time, put back the same registered finger for successful registration confirmation.
- 18. It will show "Registration Completed" with a blip sound if successful
- 19. It will display "Fingerprint Registration Failed" with 2 blips sound if not successful.
- 20. There will be 3 attempts for unsuccessful Fingerprint registration.
- 21. Once completed, Press F1 [ESC] 2 times to return to operation mode.