FKL CENTRAL AND ADMIN

Master data for every hub. From the Workshop App to KART.

STEPS

1. Select your Hub > **FKL Central**.
2. **Parts catalogue** > **Master parts**: search, **Add part** (MPN required), **Edit part** (pencil), **Suppliers**.
3. **Catalogues**: **New catalogue**, add parts, then set its exact **Kart generation**. **Hub catalogues**: what each hub sees.
4. **Part requests** > **Review**: **Link part**, **Add part**, **Keep local** or **Reject request**.
5. **Master review**: check hub-local parts, merge into a master part.
6. **Service checklists**: choose the class, **New draft**, open a section, **Add check**.
7. **Check before publishing** says No errors? **Publish** with **What changed (required)**.
8. **Servicing**: tyre tread, alignment, battery voltage, axle run-out. Each box has its own **Save**.
9. Admins: **Admin Access** > **User Administration** > **All Users**.
10. Set **Hub Access** and **Permissions**; save each.
11. **Deactivate user** with a reason is a soft switch-off; **Reactivate user** undoes it.

REMEMBER

Your hub lead and FKL Central agree new parts. Hub managers can give only Workshop and Reliability; only admins give Purchasing.

WATCH OUT

Publishing a checklist changes it for every hub with that kart class from the next service. Tell the hub managers first.