## **ASSEMBLY INSTRUCTION**

Ax1	Gx1	Mx4	
Bx1	Hx1(L/R)	Nx4	
Cx1(L/R)	Ix1(L/R)	Ox1	H(L) B H(R)
Dx1	Jx1(L/R)	Px1	2
Ex1	Kx20		I(L) I(R)
Fx1	L×4		J(L) J(R)

