

Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 1. Overview (GCF20FA, CM1638A)



Figure 2. Overview (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 3. Overview (GCF20FA, CM1638A)



Figure 4. Overview (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 5. Overview (GCF20FA, CM1638A)




Figure 6. Overview (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 7. Internal view (GCF20FA, CM1638A)




Figure 8. Internal view (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 9. Internal view (GCF20FA, CM1638A)




Figure 10. Overview (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 11. Main PCB view (GCF20FA, CM1638A)




Figure 12. Main PCB view (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 13. Control PCB view (GCF20FA, CM1638A)




Figure 14. Control PCB view (GCF20FA, CM1638A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 15. Solenoid valve (GCF20FA, CM1638A, 4700 GENSE, CM1670A)




Figure 16. Adding alternative water pump (All models)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 17. Overview (4700 GENSE, CM1670A)



Figure 18. Overview (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 19. Overview (4700 GENSE, CM1670A)



Figure 20. Overview (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 21. Internal view (4700 GENSE, CM1670A)




Figure 22. Internal view (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 23. Internal view (4700 GENSE, CM1670A)




Figure 24. Internal view (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 25. Internal view (4700 GENSE, CM1670A)




Figure 26. Main PCB view (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 27. Main PCB view (4700 GENSE, CM1670A)




Figure 28. Control PCB view (4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 29. Control PCB view (4700 GENSE, CM1670A)




Figure 30. Solenoid valve (GCF20FA, CM1638A, 4700 GENSE, CM1670A)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 31. Overview (CM1666)



Figure 32. Overview (CM1666)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,



Figure 33. Overview (CM1666)



Figure 34. Overview (CM1666)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 35. Overview (CM1666)




Figure 36. Control PCB view (CM1666)



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,






Figure 38. Main PCB view (CM1666)

Page 20 of 20

**Report Number:** CN225P6Z 003



Model: CM1633, 3700 PRO, GCF20FM, CM1663, 3700 GENSE, GCF20F,

CM1662, 3700 ESSENTIAL, CM1635, CM1665B, 4700 GENSE, CM1638A,




Figure 39. Main PCB view (CM1666)