

ASSEMBL Y INSTRUCTION



ASSEMBL Y INSTRUCTION



Part List С D Α В 1 pc 1 pc 1 pc 1 pc F H G Ε 1 pc 1 pc 2 pcs 1 pc K J 1 pc 2 pcs 2 pcs 2 pcs M Ν P O 1 pc 2 pcs 2 pcs 4 pcs **Hardware List** 3 1 2 4 M8X50 M8 **M8** M6X20 6 pcs 6 pcs 6 pcs 22 pcs 5 6 7 8 M6 M6 M6X10 4X35 18 pcs 4 pcs 4 pcs 32 pcs 10 11 12 9 ********** M4X25 8 pcs 1 pc 8 pcs 8 pcs 13 14 15 1 pc 1 pc 3/9 2 pcs

