8.7

References

## **Section 8 Motion/Vibration Analysis**

8.1	Recurring Abbreviations
8.2	First Order Motion
8.2.1	Elements of First Order Motion
8.2.2	First Order Motion Descriptive Parameters
8.2.3	Determining Descriptive Parameter $\tau$
8.3	Second Order Motion
8.3.1	Elements of Second Order Motion
8.3.2	Second Order Motion Descriptive Parameters
8.3.3	Determining Descriptive Parameters
8.4	Complex Plane
8.5	Parameter Conversions
8.6	Vibration Nomograph

#### 8.1 Recurring Abbreviations

```
C_{1/x}
         number of cycles to achieve 1/x amplitude
         damping
D_1,D_2 peak-to-peak displacement (subsequent)
        final value
FV
        forcing function
F(t)
         frequency, cycles/sec = \omega/(2\pi)
f
HCAR half cycle amplitude ratio (i.e., x_2/x_1, x_3/x_2, etc.)
Im
         imaginary axis
M
         mass
MP
         peak overshoot
         real axis
Re
         root mean square
rms
         equation roots of second order
s_1, s_2
T
         period = 1/f = 2\pi/\omega_d (seconds)
T_d
         delay time (i.e., time to 50% of FV)
T_r
         rise time (i.e., time from 10% to 90% of FV)
         time to peak amplitude
T_{p}
TPR
         transient peak ratio
T_{s}
         settling time (time to settle within x\% of FV)
T_{1/2}
         time to achieve 1/x amplitude
\boldsymbol{x}
         displacement
         peak displacements (subsequent)
x_1, x_2
         velocity
v
         peak velocity
v_o
         =\zeta\omega_n/\omega_d=\zeta/[1-\zeta^2]^{.5}
\varepsilon
         phase lag (radians)
\phi
ζ
         damping coefficient (non-dimensional)
\sigma
         damping rate = \zeta \omega_n = 1/\tau
         time constant = 1/\zeta \omega_n
τ
         frequency, radians/sec
ω
         damped natural frequency (rad/sec)
\omega_d
         natural frequency (rad/sec)
\omega_n
```

#### 8.2 First Order Motion

Found in classical aircraft roll and spiral modes. Named first-order because the motions are described by mathematics using the first derivative of a parameter.

#### 8.2.1 Elements of First Order Motion

- Mechanical analogy contains elements of mass, damping and sometimes a forcing function.
- Example: Determine the vertical velocity of a diver as she hits the water at 10 ft/s (assume constant body position & neutral buoyancy)

Summing vertical forces 
$$\sum F_{vert}: M \frac{dV}{dt} + DV = 0$$
 
$$\frac{dV}{V} + \frac{D}{M} dt = 0$$
 
$$\int \frac{dV}{V} = -\int \frac{D}{M} dt$$

Since 
$$D \& M$$
 are constant  $nV = \frac{-D}{M}t + C = \frac{-D}{M}t + \ln c$   $V_C = ce^{\frac{-D}{M}t}$  (complementary solution)

Apply initial condition 
$$V(t=0) = 10 \ ft/s \Rightarrow 10 = C$$

$$V(t=0) = 10 \ ft/s \Rightarrow 10 = C$$

$$V_{\scriptscriptstyle T}=10e^{\frac{-D}{M}t}$$

Plot response over time

Exponential rate of decay described by D/M ratio

Example 2: Diver with 20 lb submerged weight releases from zero velocity at top of pool (quiescent condi-

Solve using Laplace analysis methods:

$$M\dot{V} + DV = 20$$
 (step input)

$$M[sV(s)-V(0)]+DV(s)=\frac{20}{s}$$

$$sV(s)-V(0)+\frac{D}{M}V(s)=\frac{20}{M}\frac{1}{s}$$

$$V(s)\left(s + \frac{D}{M}\right) = \frac{1}{s}\frac{20}{M} + V(0)$$

$$V(s)\left(s + \frac{D}{M}\right) = \frac{1}{s} \frac{20}{M} + V(0)$$

$$V(s) = \frac{\frac{1}{s} \frac{20}{M} + V(0)}{s + \frac{D}{M}} = \left\{\frac{\frac{20}{M}}{s(s + \frac{D}{M})}\right\} + \frac{V(0)}{s + \frac{D}{M}}$$

usepartial fraction = 
$$\left\{\frac{\frac{20}{M}}{s(s+\frac{D}{M})}\right\} = \frac{A}{s} + \frac{B}{s+\frac{D}{M}}$$

usepartial fraction = 
$$\left\{ \frac{\frac{20}{M}}{s(s + \frac{D}{M})} \right\} = \frac{A}{s} + \frac{B}{s + \frac{D}{M}}$$

$$\left\{ \frac{\frac{20}{M}}{s(s + \frac{D}{M})} \right\} = \frac{A(s + \frac{D}{M})}{s(s + \frac{D}{M})} + \frac{Bs}{s(s + \frac{D}{M})} = \frac{A(s + \frac{D}{M}) + Bs}{s(s + \frac{D}{M})}$$


let 
$$s = \frac{-D}{M}$$
;  $\frac{20}{M} = B \frac{-D}{M} \Rightarrow B = \frac{-20}{M}$ , let  $s = 0 : \frac{20}{M} = A \frac{D}{M} \Rightarrow A = \frac{20}{D}$ 

$$V(s) = \left\{ \frac{\frac{20}{D}}{S} + \frac{-\frac{20}{D}}{s + \frac{D}{M}} \right\} + \frac{V_{(0)}}{s + \frac{D}{M}},$$

$$v(t) = \left\{ \frac{20}{D} - \frac{20}{D} e^{-(D_M')^2} \right\} + V_{(0)} e^{-(D_M')^2} \text{ since } V(0) = 0 \text{ then } v(t) = \frac{20}{D} \left[ 1 - e^{-(D_M')^2} \right]$$

Note that  $\frac{20}{D}$  is the steady state value i.e.  $v(t) = V_{ss} \left[ 1 - e^{\frac{-D}{M}t} \right]$ 

$$v(t) = V_{ss} \left[ 1 - e^{\frac{-D}{M}t} \right]$$



- Several methods can be used to describe the quickness of convergence toward steady state (i.e., time to 99.999 % of  $V_{ss}$ , time to  $1/2 V_{ss}$ ).
- By convention, we use a % that directly reflects the exponent.
- Establish a time constant  $\tau$  based on D/M.


$$\frac{D}{M} \equiv \frac{1}{\tau}$$
 so  $e^{-\frac{D}{M}t} = e^{-\frac{t}{\tau}}$ 

when 
$$t = \tau$$
, then  $e^{-\frac{t}{\tau}} = e^{-\frac{\tau}{\tau}} = e^{-1} = 0.36788$ 

so, after 
$$\tau\left[\left(\frac{D}{M}\right)^{-1}\right]$$
 seconds have elapsed,  $V = V_{ss}\left[1 - 0.36788\right] = 63.212\%V_{ss}$ 

 $\tau$  = time constant (time for parameter to reach 63% of its steady state value)

## **8.2.2** First Order Motion Descriptive Parameters



when  $t = 0.6931\tau$ :  $x = e^{-.6931}$ = 0.5 (time to half amplitude) = 0.37

when  $t = \tau$ :

$$x = e^{-1}$$

when 
$$t = 3\tau$$


$$x = e^{-3} = 0.05$$

when 
$$t = 4\tau$$
:

$$x = e^{-4}$$

$$= 0.02$$

If exponent > 0, then motion is divergent.



- $\tau$  again describes the exponential rate of divergence.
- By convention, the "time to double amplitude"  $(t_2)$  is usually applied as the evaluation metric.
- $x_{(t2)} = 2x_{(0)}$  where  $x_{(0)} = ce^{m0}$

Therefore 
$$x_2 = 2c$$

$$2c = ce^{mt_2}$$

$$2=e^{mt_2}$$


$$\ln 2 = mt_2$$

$$\therefore \text{ Time to double amplitude } \quad \frac{0.6931}{m} = t_2 = 0.693\tau$$

## 8.2.3 Determining $\tau$ from Step Input Time History

### Method #1

 $\tau$  = time to reach 0.632  $x_{ss}$ 




#### Method #2

- 1. Define  $x_{ss}$
- 2. Measure  $x_1$  at some time  $t_1$
- 3. Calculate  $x_2 = 0.632 \left( x_{ss} + .58 x_{(t_1)} \right)$
- 4. Find  $t_2$  corresponding to  $x_2$
- 5.  $t_2 t_1 = \tau$

 $0.632 (x_{SS} + .58 x_{(t1)}) = x_q$ 


#### Method #3

- 1. Pick any time  $t_1$ .
- 2. Draw tangent at  $t_1$ .
- 3. Note  $t_2$  where tangent intercepts  $x_{ss}$ .
- 4.  $\tau = t_2 t_1$



**Method #4** When  $X_{SS}$  is unknown use

$$\tau = \frac{\Delta t}{\ln\left(\frac{A_1}{A_2}\right)}$$




Method #5 When Xss is known, use  $\tau = \frac{-\Delta_t}{\ln \left[ \frac{X_{SS} - X_1}{X_{SS} - X_2} \right]}$ 


## **Linearity check:**

Note parameter change between even time increments.

Plot parameter changes vs elapsed time on semi-log scale



Slope of line equals  $\tau$ 




#### 8.3 Second Order Motion

Found in classical aircraft phugoid, Dutch roll and short period modes as well as noise filter and vibration testing. Named second-order because the motions are described by mathematics using the second derivative of a parameter.

#### 8.3.1 Elements of Second Order Motion

Mechanical systems have elements of spring, mass, and usually damping. Forcing functions can be included (see illustration).



Natural character is observed when system is allowed to move with no external input [F(t) = 0]

$$\sum F_{vort} : M\ddot{x} + D\dot{x} + Kx = 0$$

Apply operator technique:

let 
$$x = e^{st}, \dot{x} = se^{st}, \ddot{x} = s^2 e^{st}$$
  
 $\Rightarrow e^{st} (Ms^2 + Ds + K) = 0$ 

Divide out  $e^{st}$ , since it never equals zero, the characteristic equation remains:

$$Ms^{2} + Ds + K = 0$$
 or  $s^{2} + \frac{D}{M}s + \frac{K}{M} = 0$ 

The values of s that satisfy this equation are called the roots

$$\left[ x = c_1 e^{s_1 t} + c_2 e^{s_2 t} \right]$$

Solve for the roots using the quadratic equation

### **8.3.2** Second Order Motion Descriptive Parameters

Solution (x) calculated as

$$x = c_1 e^{s_1 t} + c_2 e^{s_2 t}$$
 where  $s_1, s_2 = \frac{-D}{2M} \pm j \sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2}$ 

Apply Euler's identity for complex conjugate roots

$$x = Ae^{\frac{-D}{2M}t}\sin\left(\sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2}t + \phi\right)$$

- φ defines the **phase shift**.
- A defines the **initial amplitude**.
- The real part of the root [D/2M] defines the **envelope** of the motion.
- The imaginary part of the root identifies the **damped frequency**  $\sqrt{\frac{K}{M}} - \left(\frac{D}{2M}\right)^2$ of the oscillations,  $\omega_d$  (rad/sec).

$$\omega_d = \sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2}$$

If damping is reduced to D = 0 then only  $[K/M]^{1/2}$  remains.

This is the undamped or

men only 
$$[K/M]$$
 remains.

"natural" frequency  $(\omega_{\eta})$ .

 $\omega_n \equiv \sqrt{\frac{K}{M}}$ 

$$\omega_n \equiv \sqrt{\frac{K}{M}}$$

• If  $\left(\frac{D}{2M}\right)^2 = \frac{K}{M}$  then D is considered to be critical [just enough to prevent oscillations]

$$D_{crit} = \sqrt{\frac{K}{M}} 2M = 2\sqrt{KM}$$

For oscillatory motion, actual system damping is typically expressed as a fraction critical damping. Define damping ratio as

$$\zeta \equiv \frac{D}{D_{crit}} = \frac{D}{2\sqrt{KM}}$$


Combining 
$$\omega_d \equiv \sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2}$$
  
with  $\omega_n \equiv \sqrt{\frac{K}{M}}$  and  $\zeta = \frac{D}{2\sqrt{KM}}$   
gives  $\omega_d \equiv \omega_n \sqrt{1 - \zeta^2}$  and  $\frac{D}{2M} = \zeta \omega_n$ 

The values can be substituted to give

$$x = Ae^{-\frac{D}{2M}t} \sin\left(\sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2} + \phi\right)$$

$$= Ae^{-\zeta\omega_n t} \sin\left(\omega_d + \phi\right)$$

$$= Ae^{-\zeta\omega_n t} \sin\left(\omega_n \sqrt{1 - \zeta^2} + \phi\right)$$
where
$$\phi = \tan^{-1}\frac{\omega_d}{\zeta\omega_n} = \tan^{-1}\frac{\omega_n \sqrt{1 - \zeta}}{\omega_n} = \tan^{-1}\frac{\sqrt{1 - \zeta}}{\zeta}$$



Roots 
$$s_{1,2} = \frac{-D}{2M} \pm j\sqrt{\frac{K}{M} - \left(\frac{D}{2M}\right)^2} = -\zeta\omega_n \pm j\omega_n\sqrt{1-\zeta^2}$$

#### Possible Solutions:

if $\left(\frac{D}{2M}\right)^2$	then roots are	and system response is	
$>\frac{k}{m}$	Real and unequal	Non-oscillatory $\sim$ convergent if $D > 0$ $\sim$ divergent if $D < 0$	$\begin{bmatrix} x \\ x \end{bmatrix} \xrightarrow{t} t$
$=\frac{k}{m}$	Real and equal	Non-oscillatory $\sim$ convergent if $D > 0$ $\sim$ divergent if $D < 0$	<i>x</i>
$<\frac{k}{m}$	Complex (purely imaginary if $D = 0$ )	Non-oscillatory $\sim$ convergent if $D > 0$ $\sim$ neutral if $D = 0$ $\sim$ divergent if $D < 0$	


• The various combination of K, M, and D and their effects on system response can be related to damping ratio  $\zeta$  as follows:

ζ > 1	Real & unequal roots exponential, convergent	$x(t) = c_1 e^{-\omega_n \left(\zeta + \sqrt{\zeta^2 - 1}\right)t} + c_2 e^{-\omega_n \left(\zeta - \sqrt{\zeta^2 - 1}\right)t}$
$\zeta = \pm 1$	Real & equal roots exponential, conv or div	$x(t) = c_1 e^{-\zeta \omega_n t} + c_2 t e^{-\zeta \omega_n t}$
0 < ζ < 1	Complex pair roots sinusoidal, convergent	$x(t) = Ae^{-\zeta\omega_n t} \sin(\omega_n t + \phi)$
	Imaginary pair roots sinusoidal, neutral	$x(t) = A\sin(\omega_n t + \phi)$ $= A\cos\omega_n t$
$-1 < \zeta < 0$	Complex pair roots sinusoidal, divergent	$x(t) = Ae^{-\zeta\omega_n t} \sin(\omega_d t + \phi)$
ζ<-1	Real & unequal roots exponential, divergent	$x(t) = c_1 e^{-\omega_n \left(\zeta + \sqrt{\zeta^2 - 1}\right)t} + c_2 e^{-\omega_n \left(\zeta - \sqrt{\zeta^2 - 1}\right)t}$

#### Damping ratio effect on second order system


Response of various second order systems to an impulse input.


Second-order systems are oscillatory if  $-1 > \zeta > 1$ .




Motion typically described by  $\omega_n$  and  $\zeta$ 

T,  $\omega_d$ ,  $\omega_n$  and  $\zeta$  are linked such that knowledge of any two will yield the other two.





# $2nd\ order\ system\ response\ to\ unit\ step\ input\ for\ underdamped\ systems$



#### Decay rates (for $0 < \zeta < 1$ ) and Useful Insights

• Time to decay 
$$\zeta \omega_n = \frac{\ln \frac{x_1}{x_2}}{t_2 - t_1} \Rightarrow \Delta t = \frac{\ln \frac{x_1}{x_2}}{\zeta \omega_n}$$
Time to  $\frac{1}{2}$  amplitude 
$$\equiv \Delta t_{\frac{1}{2}} = \frac{\ln \frac{2}{1}}{\zeta \omega_n} = \frac{0.6931}{\zeta \omega_n}$$
Time to  $\frac{1}{10}$  amplitude 
$$\equiv \Delta t_{\frac{1}{10}} = \frac{\ln \frac{10}{1}}{\zeta \omega_n} = \frac{2.3026}{\zeta \omega_n}$$
Time to  $\frac{1}{x}$  amplitude 
$$\equiv \Delta t_{\frac{1}{x}} = \frac{\ln x}{\zeta \omega_n}$$

• #cyclesto 
$$\frac{1}{2}$$
 amplitude#cycles=  $\frac{\Delta t}{T} = \frac{\Delta t \omega_d}{2\pi}$ 

#cyclesto  $\frac{1}{2}$  amplitude  $\equiv C_{\frac{1}{2}} = \frac{0.6931}{\zeta \omega_n} \frac{\omega_d}{2\pi} = \frac{0.6931}{2\pi} \frac{\omega_d}{\zeta \omega_n} = \frac{0.1103}{\varepsilon}$ 

#cyclesto  $\frac{1}{10}$  amplitude  $\equiv C_{\frac{1}{10}} = \frac{2.3026}{\zeta \omega_n} \frac{\omega_d}{2\pi} = \frac{2.3026}{2\pi} \frac{\omega_d}{\zeta \omega_n} = \frac{0.3665}{\varepsilon}$ 

#cyclesto  $\frac{1}{x}$  amplitude  $\equiv C_{\frac{1}{x}} = \frac{\ln x}{2\pi} \frac{\omega_d}{\zeta \omega_n}$ 

• Same analysis applies for exponential growth

For same 
$$\Delta t$$
  $\frac{x_1}{x_2} = \frac{x_2}{x_3} = \frac{x_3}{x_4}$  etc

Therefore  $\frac{x_1}{x_3} = \frac{x_1}{x_2} \frac{x_2}{x_3} = \left(\frac{x_1}{x_2}\right)^2 \Rightarrow HCAR = \sqrt{\text{full cycle amp ratio}}$ 


HCAR  $\equiv \frac{x_1}{x_2} = e^{\zeta \omega_n (t_2 - t_1)} = e^{\zeta \omega_n (\Delta t)} = e^{\zeta \omega_n (\frac{T}{2})} = e^{\zeta \omega_n (\frac{2\pi}{2\omega_d})}$ 

$$= e^{\zeta \omega_n \left(\frac{\pi}{\omega_n \sqrt{1 - \zeta^2}}\right)} = e^{\frac{\pi \zeta}{\sqrt{1 - \zeta^2}}} \text{ Note } HCAR = f(\text{only})$$

$$\Rightarrow \ln \frac{x_1}{x_2} = \frac{\pi \zeta}{\sqrt{1 - \zeta^2}} \Rightarrow \zeta = \sqrt{\frac{\left(\ln \frac{x_1}{x_2}\right)^2}{\pi^2 + \left(\ln \frac{x_1}{x_2}\right)^2}} \text{ This can be applied in graphical form (transient peak ratio method)}$$

## **8.3.3** Determining Descriptive Parameters

Time domain metrics



Peak Value, MP: largest value

Final Value, FV: steady state value

Delay Time,  $T_d$ : 50% of final value

Rise Time,  $T_r$ : 10% - 90% of FV


Peak Time,  $T_p$ : time to MP

Settling Time,  $T_s$ : time to reach some defined % of final value

% Overshoot, PO:  $\frac{MP-1}{1} \times 100\%$  target value = unity

#### Method #1 Basic Analysis

Note 
$$x(t) = Ae^{-\zeta\omega_n t}\sin(\omega_d t + 0)$$
  
 $[\zeta\omega_n]$  and  $[\omega_d]$  describe a time history



Easily measured values: can use any points on envelope

Define 
$$\varepsilon = \frac{\zeta \omega_n}{\omega_d} = \frac{\frac{\ln \frac{31}{x_2}}{(t_2 - t_1)}}{\frac{2\pi}{T}} = \frac{T \ln \frac{x_1}{x_2}}{2\pi (t_2 - t_1)}$$

where  $(t_2 - t_1) = \frac{T}{2} \Rightarrow \frac{\zeta \omega_n}{\omega_d} = \frac{\ln \frac{x_1}{x_2}}{\pi} = \varepsilon = \ln[x_1/x_2]/\pi$ 

recall  $\omega_d = \omega_n \sqrt{1 - \zeta^2}$ 


$$\varepsilon = \frac{\zeta \omega_n}{\omega_n \sqrt{1 - \zeta^2}} = \frac{\zeta}{\sqrt{1 - \zeta^2}} \Rightarrow \varepsilon^2 = \frac{\zeta^2}{1 - \zeta^2} \Rightarrow \varepsilon^2 (1 - \zeta^2) = \zeta^2 \Rightarrow \varepsilon^2 = \zeta^2 [1 + \varepsilon^2]$$


$$\zeta = \sqrt{\frac{\varepsilon^2}{1 + \varepsilon^2}} \qquad \omega_n = \frac{\zeta \omega_n}{\zeta} = \frac{\omega_d}{\sqrt{1 - \zeta^2}}$$

$$\begin{vmatrix} x_1 \\ x_2 \end{vmatrix} = \text{ Half - Cycle Amplitude Ratio } (HCAR) \qquad = e^{\zeta \omega_n (t_2 - t_1)}$$

### Method #2 Transient Peak Ratio Analysis

1) Measure either *D* or *x* distances as shown.






- 2) Note ratio of adjacent peak values (transient peak ratios).
- 3) Average several TPRs.
- 4) Use equation to find  $\zeta$ :

$$\zeta = \sqrt{\frac{\left(\ln\frac{x_1}{x_2}\right)^2}{\pi^2 + \left(\ln\frac{x_1}{x_2}\right)^2}}$$


- First TPR:  $\frac{D_2}{D_1} = \frac{117 86}{117 80} = \frac{31}{37} = 0.8378$
- Second TPR:  $\frac{D_3}{D_2} = \frac{112 86}{117 86} = \frac{26}{31} = 0.8387$ 
  - Third TPR:  $\frac{D_4}{D_3} = \frac{112 90}{112 86} = \frac{22}{26} = 0.8462$

Average TPR = 0.8409

- 4a) Can use  $D_1/D_2$  or  $x_1/x_2$  ratios in above equation.
- 4b) In lieu of equation, use adjacent look-up curve to find  $\zeta$ .
- 4c) Time ratio method works better with heavy damping.



#### Method #3 Multiple TPR Analysis



Subsidence ratio,  $x_m/x_0$ 

#### To determine damping ratio

~ Use the m = 1 line when comparing the next ratio.  $\frac{\Delta x_1}{\Delta x_0} = \frac{2.5}{4.5} = 0.56$   $\zeta = 0.16$ 

$$\frac{\Delta x_2}{\Delta x_1} = \frac{1.5}{2.5} = 0.60 \qquad \zeta = 0.14$$


 $\sim$  Use the m=2 line for comparing every other peak ratio.

$$\frac{\Delta x_2}{\Delta x_0} = \frac{1.5}{4.5} = 0.33 \qquad \zeta = 0.16$$

$$\frac{\Delta x_3}{\Delta x_1} = \frac{1.0}{2.5} = 0.40 \qquad \zeta = 0.14$$


### Method #4 Time Ratio Analysis

- If the damping ratio is between 0.5 and 1.0 (two or less overshoots), then the time ratio method can be used to determine frequency and damping ratio. Select a peak where the response if free.
- Note times for amplitude to reduce to 73.6%, 40.9%, and 19.9% of the peak value.



- Form the time ratios  $t_2/t_1$ ,  $t_3/t_1$ , and  $[t_3-t_2]/[t_2-t_1]$
- Enter the next figure at the time ratio side to find  $\zeta$  for each time ratio.
- This technique is valid if the system transfer function has no zeros.
- If recorded measurements are not available and if the number of overshoots is between 2 and 6, then


$$\zeta \approx \frac{7 - \#overshoots}{10}$$




Frequency Time Products  $(\omega_n \Delta t_3)$ ,  $(\omega_n \Delta t_2)$ ,  $(\omega_n \Delta t_1)$ 

Page 08 - 20

## Method #5 Maximum Slope Analysis






- Calculation of  $\zeta$  somewhat sensitive to  $\Delta x_1$  measurement
- $\omega_n = \frac{\omega_n \Delta t}{\Delta t}$  not too sensitive to  $\Delta x_1$
- Best if  $0.5 \le \zeta \le 1.4$
- Initial overshoot approximation: let (step inputs only)  $K = \frac{X_{pK}}{X_{ss}} 1$


$$\zeta = \left[ \frac{\left( \frac{-1}{\pi} \ln K \right)^2}{1 + \left( \frac{-1}{\pi} \ln K \right)^2} \right]^{\frac{1}{2}}$$

### **Method #6** Separated Real Root Analysis (when $\zeta > 1$ )

1) Determine several steady state  $\Delta X(t)$  values from time history



2) Plot  $\Delta X$  vs t on semi-log scale



3) After the faster root has decayed, the semi-log plot will be a straight line whose slope determines the slower root  $(1/\tau_1)$ 

$$\tau_1 = \frac{t_1 - t_2}{\ln\left(\frac{\Delta \chi_1}{\Delta \chi_2}\right)}$$


4) Determine by extrapolating the straight line portion of the response to establish the values

$$\frac{1}{\Delta \chi_0} & \Delta \chi_0$$


$$\tau_2 = \tau_1 \left(\frac{\Delta \chi_0}{\Delta \chi_0}\right) \qquad \boxed{\omega_n = \sqrt{\frac{1}{\tau_1} \frac{1}{\tau_2}}} \text{ and } \zeta = \frac{-\left(\frac{1}{\tau_1} + \frac{1}{\tau_2}\right)}{2\omega_n} = \frac{-\left(\frac{1}{\tau_1} + \frac{1}{\tau_2}\right)}{2\sqrt{\frac{1}{\tau_1} \frac{1}{\tau_2}}}$$

### Method #7 Modified Separated Real Root Analysis

- Method #6 is sensitive to errors in determining steady state values
- Alternate method is to avoid need for steady state value
- Define  $\Delta X(t) \equiv [x(t + \Delta T) x(t)]$  where  $\Delta T$  is a time increment
- 1) From time history, measure  $\Delta X$  values according to definition



2) Plot  $\Delta X(t)$  vs time on semi-log scale




- 3) Use previous method to determine roots and characteristics
- Gross error will result if  $\zeta$  is actually <1
- If  $\zeta$  is near 1, check results using time ratio or slope method

### Method #8 Frequency Sweep Analysis

Determine  $\omega_n$  and  $\zeta$  using sinusoidal inputs.

- This "forced response" method most useful when damping is heavy.
- For a second order system, output/input amplitude ratio and phase shift are a function of input frequency.




- Amplitude ratio peaks at "resonant" frequency,  $\omega_r$
- Resonant peaks increase as  $\zeta$  decreases below 0.707.
- Peak amplitude ratio "rolls off" as  $\zeta$  increases above 0.707.
- Resonant frequency approaches natural fre quency as damping decreases:

$$\omega_r = \omega_n [1 - 2\zeta^2]^{.5}$$


• Phase shift =  $90^{\circ}$  if excited at  $\omega_n$ , regardless of

$$\zeta = 0.5(\omega_2 - \omega_1)/\omega_n$$




Frequency Sweep Analysis (continued)


- 1. Using sinusoidal inputs excite system @  $\omega$  near  $\omega_n$
- 2. Measure phase lag  $(\phi)$  of  $\frac{output}{input}$



- 3. Excite system @ another  $\omega$  near  $\omega_n$
- 4. Again Measure phase lag  $\phi$




5. Plot  $\phi$  vs input frequency



6.  $\omega_n$  occurs at  $\phi = 90^{\circ}$ 

## **Linearity Check / Accuracy Improvement**

- 1) On semi-log scale, plot ratio of initial amplitude to subsequent peak amplitudes at each half cycle (points *a-e*).
- 2) Fair straight line (f) through these points.



- 3) Draw line (g) parallel (f) intercepting the ordinate at TPR=1
- 4) Average TPR occurs at T/2 on line g

### **8.4 Complex Plane**

Begin with sum of forces in spring-mass-damper example

$$M\ddot{x} + D\dot{x} + Kx = f(t)$$

let  $x = e^{st}$ , find transient solution


$$(Ms^2 + Ds + K)e^{st} = 0$$

Apply quadratic equation to solve for roots

$$s_{1,2} = \frac{-D}{2M} \pm \sqrt{\left(\frac{D}{2M}\right)^2 - \frac{K}{M}}$$

Recall previous analogy


$$s_{1,2} = -\zeta \omega_n \pm j\omega_n \sqrt{1-\zeta^2}$$



Location of Roots on Complex Plane

- 1. Line of constant damping ratio  $\zeta$  varying  $C_{1/n}$  and  $\omega_n$ 
  - 2. Line of constant  $\omega_n$  varying  $\zeta$
- .......... 3. Line of constant  $\omega_d$  and period (T)
- --- 4. Line of constant real part  $(\zeta \omega_n)$  and time to damp  $(T_{1/n})$


 $\sigma = \zeta \omega_n = 1/\tau =$ damping rate



### Sample second order root plots and corresponding time histories


(time histories represent trends only)

Examples of "two real roots"



#### More sample second order root plots and corresponding time histories

Examples of "imaginary roots"



#### **8.5 Parameter Conversions**

For conversion of accelerometer measurements.

- For magnitude conversion substitute  $2\pi f$  for  $j\omega$ .
- Assumes linear spectra.
- Conversion factor should be squared for power spectra.

#### Acceleration to velocity

to convert from	to multipl	<u>y by</u>
$ft/s^2 rms$	ft/s rms	$1/j\omega$
$ft/s^2 rms$	in/s rms	12/jω
$ft/s^2 rms$	in/s peak	$16.97/j\omega$
g rms	in/s rms	386/jω
g rms	in/s peak	$545.8/j\omega$
$m/s^2 rms$	mm/s rms	$1000/j\omega$
$m/s^2 rms$	mm/s peak	$1414/j\omega$
g rms	mm/s rms	9806/jω
g rms	mm/s peak	$13865.7/j\omega$

#### Acceleration to Displacement

to convert from	to multipl	<u>y by</u>
$ft/s^2 rms$	in rms	$12/(j\omega)^2$
$ft/s^2 rms$	in p-p	$33.9/(j\omega)^2$
$ft/s^2 rms$	mil p-p	$33.9 E 03/(j\omega)^2$
g rms	in rms	$386/(j\omega)^2$
g rms	in p-p	$1091.6 E 03/(j\omega)^2$
g rms	mil p-p	$1091.6 E 03/(j\omega)^2$
$m/s^2 rms$	mm rms	$1000/(j\omega)^2$
$m/s^2 rms$	mm p-p	$2828/(j\omega)^2$
$m/s^2 rms$	micron <i>p-p</i>	$2828 E \frac{03}{(j\omega)^2}$

*E*= engineering exponent (x10 \_\_\_)

g = 32.174 ft/sec2

*in*= inches


mil = thousandths of an inch

mm = milimeters

p-p = peak-to-peak

*rms* = root mean square

## 8.6 Vibration Nomograph



#### 8.7 References

- 8.7.1 Lawless, Alan R., *Math and Physics for Flight Testers*, "Chapter 9, Motion Analysis," National Test Pilot School, Mojave CA, 1999.
- 8.7.2 Ward, Don, Introduction to Flight Testing, Texas A&M, Elsevier, 1993.
- 8.7.3 Lang, George F., *Understanding Vibration Measurements*,
  Application Note 9, Rockland Scientific Corporation, Rockleigh, New Jersey, December 1978.
- 8.7.4 *The Fundamentals of Modal Testing*, Application Note 243-3, Hewlett-Packard Company,

#### **Additional Reading**

Hartog, J.P. Den, Mechanical Vibrations, Dover Publications, New York, New York, 1984.

Jacobsen, Ludik S. and Ayre, Robert S., *Engineering Vibrations*, McGraw-Hill Book Company, New York, New York, 1958.

Meirovitch, Leonard, *Elements of Vibration Analysis*, McGraw-Hill Book Company, New York, New York, 1986.

Meirovitch, Leonard, *Analytical Methods in Vibrations*, Macmillan Publishing Company, New York, New York, 1967.

Myklestad, N.O., *Vibration Analysis*, McGraw-Hill Book Company, New York, New York, 1944.