The following opcodes are used for **Division**:

- DIVI Divide by Signed Integer
- DIVU Divide by Unsigned Integer
- DIVF Divide by Floating Point

DIVI — Divide by Signed Integer

```
L2 = L2 / <signed_imm>
L2 = L2 / <reg_val>
L2 = L2 / <const>
```

=== "DIVI Example"

```
'``linenums="1" hl_lines="1 3 5 7"
; imm +ve
    DIVI    1
; imm -ve
    DIVI    -123
; reg val
    DIVI    val(QT)
; const
    DIVI    SOME_CONST_VAL
```

=== "DIVI Properties"

DIVU — Divide by Unsigned Integer

```
L3 = L3 / <unsigned_imm>
L3 = L3 / <reg_val>
L3 = L3 / <const>
```

=== "Example"

```
; imm +ve
DIVU 1
; reg val
DIVU val(QT)
; const
DIVU SOME_CONST_VAL
```

DIVF — Divide by Float value

```
; const
DIVF SOME_CONST_VAL
```