Vehicle Name: Bad Wolf Turbo Mk2
Product: Haltech Nexus R3 VCU

Assigned Resources:

Connections			Assigned Functions	
Analogue Voltage In	Analogue Voltage Inputs on Nexus R3 VCU:			
	[W], C10	AVI1	Brake Pedal Switch 1 Input, for Brake Pedal Switch	
	[W/Y], C11	AVI2	Clutch Switch Input, for Clutch Switch	
	[W/GY], C12	AVI3	Coolant Temperature Input, for Coolant Temperature Sensor	
	[W/V], C13	AVI4	Oil Pressure Input, for Oil Pressure Sensor	
	[W/G], C14	AVI5	Throttle 1 Sensor A, for Drive By Wire	
	[W/O], C15	AVI6	Throttle 1 Sensor B, for Drive By Wire	
	[W/B], C16	AVI7	Intake Air Temperature Input, for Intake Air Temperature Sensor	
	[W/BR], C17	AVI8	Pedal Sensor A, for Drive By Wire	
	[W/R], C18	AVI9	Pedal Sensor B, for Drive By Wire	
	[LG], C27	AVI10	Oil Temperature Input, for Oil Temperature Sensor	
	[LG/B], C28	AVI11	Fuel Pressure Input, for Fuel Pressure Sensor	
Digital Pulsed Outpu	ts on Nexus R3 VCU	:		
	[V/B], A9	DPO1	Output 1, for Generic Output 4 (Speedometer)	
	[V/BR], A12	DPO2	Tacho Output, for Tachometer	
	[V/R], A14	DPO3	Boost Control Solenoid, for Boost Control	
	[V/O], A15	DPO4	Output 1, for Generic Output 9 (Boost Gauge)	
	[V/Y], A16	DPO5	Check Engine Light Output, for Check Engine Light	
Sync Pulsed Inputs o	Sync Pulsed Inputs on Nexus R3 VCU:			
	[GY/BR], C5	SPI1	Vehicle Speed Input, for Vehicle Speed Drive Train Sensor	
Knock Inputs on Nex	Knock Inputs on Nexus R3 VCU:			
	[B/L], C23	KNOCK1	Knock Sensor 1	
-				

Injection Outputs on Nexus R3 VCU:					
	[L], A1	INJ1	Injector Output 1		
	[L/B], A2	INJ2	Injector Output 2		
Ignition Outputs on N	Nexus R3 VCU:				
	[Y/B], A27	IGN1	Ignition Output for Cylinders 1 and 4		
	[Y/R], A28	IGN2	Ignition Output for Cylinders 3 and 2		
Half Bridge Outputs	on Nexus R3 VCU:				
	[BR/B], A19	HBO1	Throttle 1 Motor A, for Drive By Wire		
	[BR/R], A20	HBO2	Throttle 1 Motor B, for Drive By Wire		
	[BR/G], A21	HBO3	Output 1, for Generic Output 8 (Oil Pressure Gauge)		
	[BR/P], A22	HBO4	Output 1, for Generic Output 7 (Coolant Temp Gauge)		
	[P/R], A18	HBO5	CAN Power Output 1, for CAN System		
	[P/BR], A25	нво6	Output 1, for Generic Output 10 (Speed & USB)		
25A High Current Ou	tputs on Nexus R3 V	CU:			
	[R/L], E1	25A-HCO1	Injector Power Output 1, for Injection System		
	[R/Y], E2	25A-HCO2	Ignition Coil Power Output 1, for Ignition System		
	[R/O], E3	25A-HCO3	Fuel Pump Relay Output, for Primary Fuel Pump		
	[R/G], E4	25A-HCO4	Thermofan 1 Output, for Thermofan 1		
CAN Ports on Nexus	CAN Ports on Nexus R3 VCU:				
	[W], A23, CAN 1 H [L], A24, CAN 1 L	CAN1	Haltech CAN Bus Port 1, for CAN System		
	[W], C21, CAN 2 H [L], C22, CAN 2 L	CAN2	Haltech CAN Bus Port 2, for CAN System		
Trigger on Nexus R3 VCU:					
	[GY], C1	Trigger (+ve)	Trigger System (+)		

_	Pressure Inputs on Nexus R3 VCU:					
			OBPS 1	Manifold Pressure Input, for Manifold Pressure Sensor		
_	Wideband Inputs on Nexus R3 VCU:					
		[GY], C29, WBI 1 HEAT	TER+			
		[Y], C30, WBI 1 INPUT				
		[R], C31, WBI 1 PUMP	Internal Wideband	Wideband O2 1 Input, for Wideband O2 1 Sensor		
		[B], C32, WBI 1 NERNS		Wideballd OZ 1 Iliput, for Wideballd OZ 1 Selfsor		
		[W], C33, WBI 1 HEAT	ER-			
<u>-</u>		[G], C34, WBI 1 CAL				
_	System References on Nexus R3 VCU:					
		[O], C25	+5V Sensor Supply	5V Sensors		
_		[B/W], C26	Sensor GND	Sensor ground		
_		[O/W], C9	+8V Sensor Supply	8V Sensors		
			+12V ECU Power	Battery (+ve)		
-			Battery Ground	Battery (-ve)		
-		[B], A10, POWER GRO	Power GND Out	Power Ground Out		
Do not dire	ectly connect any other device	s to the ignition switch				
		[P], A13	Ign SW Input	Ignition Switch		
_		[R/L], A26	lgn SW Power	Ignition Switch Power		
-	Other Connections on Drive By Wire:					
_			ldle	Main Output, for Idle Control		
_	Channels:					
	Channel		Override Switch (GenCond1 Out)	Override Switch, for Generic Output 1 (Secondary Circuits)		

Analogue Voltage Inputs on PD16 Box A (Boot Power Distro) :					
	[W], A20	PD16A AVI 1	Park Light Input, for Headlight Control		
	[W/Y], A21	PD16A AVI 2	Head Light Input, for Headlight Control		
	[W/GY], A27	PD16A AVI 3	Left Indicator Input, for Indicator Control		
	[W/V], A28	PD16A AVI 4	Right Indicator Input, for Indicator Control		
Sync Pulsed Inputs or	Sync Pulsed Inputs on PD16 Box A (Boot Power Distro) :				
	[GY/BR], A14	PD16A SPI1	Override Switch, for Generic Output 5 (Heater)		
	[GY/R], A15	PD16A SPI2	Start Button Input, for Engine Starter Control Function		
	[GY/O], A16	PD16A SPI3	Override Switch, for Generic Output 2 (Wipers)		
	[GY/Y], A19	PD16A SPI4	Override Switch, for Generic Output 3 (Fog Lamps)		
Half Bridge Outputs o	n PD16 Box A (Boot	Power Distro) :			
	[BR/Y], A1	PD16A HBO1	Oil Pressure Light, for Oil Pressure Light		
	[BR/L], A2	PD16A HBO2	Battery Light Output, for Battery Voltage Light		
8A High Current Outp	outs on PD16 Box A	(Boot Power Distro) :			
	[P/R], A3	PD16A 8A-HCO1	Left Indicator Output, for Indicator Control		
	[P/BR], A4	PD16A 8A-HCO2	Output 2, for Generic Output 10 (Speed & USB)		
	[P/B], A5	PD16A 8A-HCO3	Output 1, for Generic Output 1 (Secondary Circuits)		
	[P/O], A6	PD16A 8A-HCO4	Output 1, for Generic Output 5 (Heater)		
	[P/Y], A7	PD16A 8A-HCO5	Output 2, for Generic Output 1 (Secondary Circuits)		
	[P/G], A8	PD16A 8A-HCO6	Alternator Control Output, for Alternator Control		
	[P/V], A9	PD16A 8A-HCO7	Starter Motor Relay Output, for Engine Starter Control Function		
	[P/L], A10	PD16A 8A-HCO8	Right Indicator Output, for Indicator Control		
	[P/GY], A17	PD16A 8A-HCO9	Brake Light Output, for Brake light Control		
	[P/W], A18	PD16A 8A-HCO10	Park Lights Output, for Headlight Control		

25A High Current Outp	outs on PD16 Box A (Boot Power Distro) :			
	[R/L], E1	PD16A 25A-HCO1	Head Lights Output, for Headlight Control	
	[R/Y], E2	PD16A 25A-HCO2	Output 1, for Generic Output 2 (Wipers)	
	[R/O], E3	PD16A 25A-HCO3	Output 1, for Generic Output 3 (Fog Lamps)	
	[R/G], E4	PD16A 25A-HCO4	Output 1, for Generic Output 6 (Stereo system)	
System References on	PD16 Box A (Boot Po	wer Distro) :		
		PD16A +12V Power	Battery (+ve)	
	[O], A12	PD16A Sensor 5V	Sensor 5V	
	[B/W], A11	PD16A Sensor GND	Sensor ground	
	[B], A31, POWER GROU	IND		
		PD16A Power GND In	Power ground	
Do not directly connect any other devices to the ignition switch				
	[P], A13	PD16A Ign SW Input	Ignition Switch Input	
	[R/L], A26	PD16A Ign SW Power	Ignition Switch Power	
	[W], A23	PD16A CAN High	CAN High	
	[L], A24	PD16A CAN Low	CAN Low	
	[P], A25	PD16A CAN Power	CAN Power	
	[B], A22	PD16A CAN Ground	CAN Ground	
	System References on	[R/L], E1 [R/Y], E2 [R/O], E3 [R/G], E4 System References on PD16 Box A (Boot Policy of the content of the	[R/V], E2 PD16A 25A-HCO2 [R/O], E3 PD16A 25A-HCO3 [R/G], E4 PD16A 25A-HCO4 System References on PD16 Box A (Boot Power Distro): PD16A +12V Power [O], A12 PD16A Sensor 5V [B/M], A11 PD16A Sensor GND [B], A31, POWER GROUND [B], A32, POWER GROUND [B], A33, POWER GROUND [B], A34, POWER GROUND	

Vehicle Name: Bad Wolf Turbo Mk2
Product: Haltech Nexus R3 VCU

Available Resources:

Connections				
Digital Pulsed Outputs on Nexus R3 VCU:				
	[V/G], A17	DPO6		
Sync Pulsed Inputs o	Sync Pulsed Inputs on Nexus R3 VCU:			
	[GY/R], C6	SPI2		
	[GY/O], C7	SPI3		
	[GY/Y], C8	SPI4		
	[GY/P], C19	SPI5		
	[GY/LG], C20	SPI6		
Knock Inputs on Ne	xus R3 VCU:			
	[B/G], C24	KNOCK2		
Injection Outputs or	n Nexus R3 VCU:			
	[L/BR], A3	INJ3		
	[L/R], A4	INJ4		
	[L/O], A5	INJ5		
	[L/Y], A6	INJ6		
	[L/G], A7	INJ7		
	[L/V], A8	INJ8		
Ignition Outputs on	Ignition Outputs on Nexus R3 VCU:			
	[Y/O], A29	IGN3		
	[Y/G], A30	IGN4		
	[Y/BR], A31	IGN5		
	[Y/L], A32	IGN6		

Ignition Outputs on Nexus R3 VCU:			
	[Y/V], A33	IGN7	
	[Y/GY], A34	IGN8	
Trigger on Nexus R3 \	VCU:		
	[GY], C2	Trigger (-ve)	
	[GY/B], C3	Home (+ve)	
	[GY/B], C4	Home (-ve)	
Virtual Outputs on Ne	exus R3 VCU:		
Virtural Guripout No Physical Connection		Virtual Output 1	
Wirkusal Quripout No Physical Commedium		Virtual Output 2	
Viirkusal Ouripout No Physical Commedium		Virtual Output 3	
Virtural Contport No Physical Connection		Virtual Output 4	
Viirkusal Curipout No Physical Connection		Virtual Output 5	
Virtural Contport No Physical Connection		Virtual Output 6	
Virtural Contport No Physical Connection		Virtual Output 7	
Viiriusal Ouripout No Physical Connection		Virtual Output 8	
Wirkural Conipont No Physical Connection		Virtual Output 9	

Vehicle Name: Bad Wolf Turbo Mk2
Product: Haltech Nexus R3 VCU

Virtual Outputs on Nexus R3 VCU:

Virtual Output

No Physical Connection Virtual Output 10

Inertial Measurement Unit (IMU) on Nexus R3 VCU:



Internal IMU