REPORT

<u>Title: PWM Out – Servo Motor</u>



Submission Date	2021.10.29	Major	Mechanical and control engineering
Subject	Embedded Controller	Professor	Young-Keun Kim
Name	Yeong-Won Song	Student Number	21700375
Partner Name	Sang-Hyeon-Kim	Partner Number	21700102

Contents

1. Introduction	3
1.1 Purpose	3
1.2 Parts List	
II. Procedure	4
2.1 Create EC_HAL functions	4
2.2 RC Servo motor: RC Servo Motor (SG90)	5
2.3 Configuration	6
2.4 RC servo motor control	8
III. Conclusion	

Appendix

I. Introdution

1.1 Purpose

In this lab, we are required to create a simple program that control a sevo motor with PWM output. Create HAL drivers for Timer and PWM control and use these APIs for the lab.

1.2 Parts List

Parts	Specification	Quantity
RC Servo-Motor	SG90	1
breadboard	-	1
NUCLEO-F411RE	Arm®(a) Cortex®-M4 with FPU	1

Table 1. Part List




Table 2. experiment equipment

II. Procedure


2.1 Create EC_HAL functions

Include File	Function	Description
ecGPIO.h,c	//modify functions or add new functions to allow AF mode for TIMx	
ecTIM.h,c	<pre>voidTIM_init(TIM_TypeDef *timerx, uint32_t msec); void TIM_period_us(TIM_TypeDef* timx, uint32_t usec); voidTIM_period_ms(TIM_TypeDef* timx, uint32_t msec); voidTIM_INT_init(TIM_TypeDef* timerx, uint32_t msec); void TIM_INT_enable(TIM_TypeDef* timx); void TIM_INT_disable(TIM_TypeDef* timx); uint32_t is_UIF(TIM_TypeDef *TIMx); void clear_UIF(TIM_TypeDef *TIMx);</pre>	Initialize timer counter period of usec. For Timerx=TIM1, TIM2, Update Interrupt
ecPWM.h,c	<pre>typedef struct{ GPIO_TypeDef *port; int pin; TIM_TypeDef *timer; int ch; } PWM_t; voidPWM_init(PWM_t *pwm, GPIO_TypeDef *port, int pin); voidPWM_period_ms(PWM_t *pwm, uint32_t msec); voidPWM_period_us(PWM_t *PWM_pin, uint32_t usec); voidPWM_pulsewidth_ms(PWM_t*pwm,floatpulse_width_ms); void PWM_duty(PWM_t *pwm, float duty);</pre>	PWM_t is a structure type for initializing GPIO port, pin and the nubmer of timer, channel. You can use this variable as a handler of PWM signal.

2.2 RC Servo motor: RC Servo Motor (SG90)

An RC servo motor is a tiny and light weight motor with high output power. It is used to control rotation angles, approximately 180 degrees (90 degrees in each direction) and commonly applied in RC car, and Small-scaled robots.

The angle of the motor can be controlled by the pulse width (duty ratio) of PWM signal. The PWM period should be set at 20ms or 50Hz. Refer to the data sheet of the RC servo motor for detailed specifications.






Figure 1. External Circuit

2.3 Configuration

Create a new project named as "LAB_PWM_Servo".

Name the source file as "LAB_PWM_Servo.c"

You MUST write your name in the top of the source file, inside the comment section.

• Configure Input and Output pins

Digital In: Button	Digital Out:
GPIOC, Pin 13	PA1
Digital Input	AF output
Set PULL-UP	Push-Pull
	No Pull-up Pull-down
	Fast
TIMER	PWM
TIMER TIM2: Counter Period 1kHz	PWM TIM2 CH2: GPIO A, Pin 1
	TIM2_CH2: GPIO A, Pin 1
	TIM2_CH2: GPIO A, Pin 1 PWM period: 20ms




Figure 2. Flow chart

2.4 RC Servo Motor control


Make a simple program that changes the angle of the RC servo motor by pressing the push button (PC13).

- The button input must be External Interrupt
- Use Port A Pin 1 as PWM output pin, for TIM2 Ch2.

Increase the angle of RC servor motor from 0° to 180° each time you push the button. After reaching 180° , decrease the angle back to 0° .

• Divide 180° into 10 intervals.

You need to observe how the PWM signal output is generated as input button is pushed, using an oscilloscope. You need to captute the Oscilloscope output in the report.






Figure 4. The duty cycle of the servo motor output to the Oscilloscope

- Discussion

1) Derive a simple logic to calculate for CCR and ARR values to generate x[Hz] and y% duty ratio of PWM. How can you read the values of input clock frequency and PSC?

In this LAB, PLL clock was used. First, f_{sys_CLK} is lowered to enter the time counter through a PSC

$$\frac{f_{sys_CLK}}{(psc+1)} = f_{cnt_CLK}$$

Since we must set the period, we want to generate an event, we set the value to the desired interrupt frequency through the ARR value.

$$\frac{f_{sys_CLK}}{(psc+1)(ARR+1)} = f_{update}$$

In this way, we have determined the frequency to generate the event and can determine the duty ratio in PWM through CCR values.

We will explain using the TIM period ms() function we created in this lab.

If an msec value is added to the TIM_period_ms() function, an event should be generated every 1 ms. We made 10[kHz] through PSC, and 10[kHz] has a cycle of 0.1[ms], so a total of 10 steps must pass to be 1 ms. Therefore, the ARR value is set to 9.

If you want to set the duty ratio to 50%, you must receive only 5 steps out of 10 steps. If so, the CCR value must be 5 so that we can set the duty ratio we want as 50%. If this is implemented with simple logic, it is as follows.

$$Duty\ ratio = \frac{CCR}{ARR + 1} \times 100\ [\%]$$

To use the system clock, HSI, HSE, and PLLON are first turned on. Then, the unlocked bit is automatically assigned to HSIRDY, HSERDY, and PLLRDY. Therefore, check each bit of HSIRDY, HSERDY, and PLLRDY in the RCC_CR register to find out which clock is used. After that, the corresponding clock frequency is returned. The psc value is obtained through the mathematical correlation expression between the system input clock frequency and the count clock frequency value.

2) What is the smallest and highest PWM frequency that can be generated for Q1?

Previously, we set the values of PSC, ARR, and CCR to create the frequency and duty ratio of the desired PWM.

$$\frac{f_{sys_CLK}}{(psc+1)(ARR+1)} = f_{update}$$

The PSC register and the ARR register may allocate a value of up to 65535 at 16-bits. That is, it would be convenient to give a PSC value of 84000 to make 84MHz a cycle of 1 ms, but the actual PSC value is maximum of 65535, so the PSC value cannot be set to 84000. Therefore, a desired PWM frequency may be set through an appropriate combination of PSC and ARR values. Therefore, if there is a frequency $\frac{f_{sys_cLK}}{(psc+1)} = f_{cnt_cLK}$ that is prescaled, f_{pwm} is minimized when the ARR value is 65535, and f_{pwm} is maximized when the ARR value is 0.

$$\frac{f_{cnt_CLK}}{ARR_{min} + 1} = f_{pwm_max}$$

$$\frac{f_{cnt_CLK}}{ARR_{max} + 1} = f_{pwm_min}$$

3) What is the major difference of advanced timer and general-purpose timer?

TiM1 and TIM8 is advanced-control timers. TIM2~5, TIM9~14 is general purpose timers. The advanced-control timers consist of a 16-bit auto-reload counter and the general-purpose timers consist of a 16-bit or 32-bit auto-reload counter driven by a programmable prescaler. Advanced-control timers and general-purpose timers have a common role. They may be used for a variety of purposes which is measuring the pulse lengths of input signals or generating output waveforms. They have independent 4 channels for input capture, Output capture, PWM generation and one-pulse mode output. However, there are three major differences between advanced timer and general-purpose timer. Advanced timer can generate complementary PWM with programmable dead-time. The dead time is necessary to prevent the short circuit. Second, it can break input to put the timer's output signals in reset state or in a known state. Also, it is repetition counter that update the timer registers only after a given number of cycles of the counter.

III. Conclusion

The functions used for Timer and PWM were directly created, and the servo motor was operated using the created functions. In addition, the duty cycle was checked using oscilloscope. Through this process, we were able to improve our understanding by reviewing what we learned in class, and to learn about the operation of the servo motor.

In the process of conducting this experiment, Oscilloscope was used for the first time in a long time, so it was difficult to measure the duty cycle with inexperienced manipulation. Fortunately, however, we were able to get the data we wanted safely through the help of our friends around us and our continuous efforts.

In the remaining LAB, we will try to experiment with familiarity with the equipment to be used so that there is no problem like above.

Troubleshooting

Q. How did you solve the problem that the servo motor did not rotate as much as the value of the duty ratio?

A. The CCR value on the pwm_duty() function should be $(ARR + 1) \times duty$ ratio, but the CCR value was $CCR = (ARR + 1) \times duty$ ratio -1. Recognizing that it was an error in the code, it was confirmed that it worked accurately after correcting the code.

Q. What is the solution to operating the servo motor without using the pwm_duty() function?

A. Instead of the pwm_duty() function, the pwm_pulsewidth_ms() function is used. In the pwm_pulsewidth_ms() function, given the pulse_width_ms variable, the CCR value is calculated, so we can easily implement it by adding the pulse width without calculating the duty ratio.

Appendix

Video demo Link

Click here watch video.

Documentation

TIM_init()

6.3.11 RCC APB1 peripheral clock enable register (RCC_APB1ENR)

Address offset: 0x40

Reset value: 0x0000 0000

Access: no wait state, word, half-word and byte access.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	Reserved	9	PWR EN		Resi	erved		I2C3 EN	I2C2 EN	I2C1 EN		Reserved		USART2 EN	Reser- ved
		rw					rw	rw	rw				rw	100	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SPI3 EN	SPI2 EN	Res	erved	WWDG EN		Reserved							TIM4 EN	TIM3 EN	TIM2 EN
rw	rw			rw								rw	rw	rw	rw

13.4.1 TIMx control register 1 (TIMx_CR1)

Address offset: 0x00

Reset value: 0x0000 13 12 11 10

void TIM_init(TIM_TypeDef *timerx, uint32_t msec);

Bit 0 CEN: Counter enable
0: Counter disabled
1: Counter enabled
1: Counter enabled
note: External clock, gated mode and encoder mode can work only if the CEN bit has been previously set by software. However trigger mode can set the CEN bit automatically by hardware.
CEN is cleared automatically in one-pulse mode, when an update event occurs.

- timex : Timer number
- integer : msec

Example code

TIM_init(TIM2, 20); //Initialize Timer2 20ms

TIM_period_us()

13.4.11 TIMx prescaler (TIMx_PSC)

Address offset: 0x28



Bits 15.0 PSC[15:0]: Prescaler value

The counter clock frequency CK_CNT is equal to f_{CK_PSC} / (PSC[15:0] + 1).

PSC contains the value to be loaded in the active prescaler register at each update event (including when the counter is cleared through US bit of TIM_EGR register or through trigger controller when configured in "reset mode").

13.4.12 TIMx auto-reload register (TIMx_ARR)

Address offset: 0x2C

Reset value: 0xFFFF FFFF (for 32-bits timer) 0x0000 FFFF (for 16-bits timer)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						ARR(3	1:16] (dep	ending or	timers)						
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw.	rw	rw	rw	rw	rw	rw
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							ARR	[15:0]							
rw	rw	:rw	rw	rw	ΓW	rw	ΓW	rw	rw:	rw	ΓW	rw	rw	rw	rw

void TIM_period_us(TIM_TypeDef* timx, uint32_t usec);

Parameters

- timex: Timer number
- integer: usec

Example code

TIM_TIM_period_us(TIM2, 1); //Initialize Timer2 lus

TIM_period_ms()

13.4.11 TIMx prescaler (TIMx_PSC)

Address offset: 0x28



Bits 15.0 P8C[15:0]: Prescaler value

The counter clock frequency CK_CNT is equal to f_{CK_PSC} / (PSC[15:0] + 1).

PSC contains the value to be loaded in the active prescaler register at each update event (including when the counter is cleared through U.S bit of TitMx_EGR register or through trigger controller when configured in "reset mode").

13.4.12 TIMx auto-reload register (TIMx_ARR)

Address offset: 0x2C

Reset value: 0xFFFF FFFF (for 32-bits timer) 0x0000 FFFF (for 16-bits timer)



void TIM_period_ms(TIM_TypeDef* timx, uint32_t msec);

Parameters

- timex : Timer number
- integer : msec

Example code

TIM_period_ms(TIM2, 20); //Initialize Timer2 20ms

TIM_INT_init()

Initialize timerx and enable Update Event Interrupt.

```
void TIM_INT_init(TIM_TypeDef* timerx, uint32_t msec);
```

Parameters

- timex: Timer number
- integer : msec

Example code

TIM_INT_init(TIM2, 20); //Initialize Timer2 20ms

TIM_INT_enable()

Enable Timer Update Interrupt

13.4.4 TIMx DMA/Interrupt enable register (TIMx_DIER)

Address offset: 0x0C Reset value: 0x0000



Bit 0 UIE: Update interrupt enable
0: Update interrupt disabled
1: Update interrupt enabled

void TIM_INT_enable(TIM_TypeDef* timx);

Parameters

• timex: Timer number

Example code

TIM_INT_init(TIM2); //enable Timer2

TIM_INT_disable()

disable Timer Update Interrupt

13.4.4 TIMx DMA/Interrupt enable register (TIMx_DIER)

Address offset: 0x0C Reset value: 0x0000



Bit 0 UIE: Update interrupt enable 0: Update interrupt disabled 1: Update interrupt enabled

void TIM_INT_disable(TIM_TypeDef* timx);

Parameters

• timex: Timer number

Example code

TIM_INT_disablet(TIM2, 20); //disable Timer2

is_UIF() check the update interrupt flag. No update occured or update interrupt pending. 13.4.5 TIMx status register (TIMx_SR) Address offset: 0x10 Reset value: 0x0000 14 17 17 11 10 8 7 6 6 4 3 2 1 0 RESERVED | CONF | COLOR | C Bit 0 UIF: Update interrupt flag This bit is set by hardware on an update event. It is cleared by software. On su colate occurred. 1: Update interrupt pending. This bit is set by hardware when the registers are updated: At overflow or underflow (or TIME to TIMS) and If UDIS=0 in the TIMs, CR1 register. When CRT is reinitialized by software using the UG bit in TIMs_EGR register, if URS=0 and UDIS=0 in the TIMs_CR1 register. When CRT is reinitialized by a trigger event (refer to the synchro control register description), if URS=0 and UDIS=0 in the TIMs_CR1 register. uint32_t is_UIF(TIM_TypeDef *TIMx); **Parameters** • timex: Timer number Example code void TIM2_IRQHandler(void){ if(is_UIF(TIM2)){// update interrupt flag _count++; if (_count >1000) { LED_toggle(); _count=0;} clear_UIF(TIM2);// clear by writing 0 } } clear_UIF() clear the update interrupt flag. No update occured. 13.4.5 TIMx status register (TIMx_SR) Address offset: 0x10 Reset value: 0x0000 Bit 0 UIF: Update interrupt flag " This bit is set by hardware on an update event. It is cleared by software. O: No update occurred. 1: Update interrupt pending. This bit is set by hardware when the registers are updated: A overthow or underflore (for TIM2 to TIM5) and if UDIS=0 in the TIMs_CRT register. When CNT is reinitialized by software using the UG bit in TIMs_EGR register, if URS=0 and UDIS=0 in the TIMS_CRT register. When CNT is reinitialized by a flower event (refer to the synchro control register description), if URS=0 and UDIS=0 in the TIMS_CRT register. void clear_UIF(TIM_TypeDef *TIMx); **Parameters** • timex : Timer number Example code void TIM2_IRQHandler(void){ if(is_UIF(TIM2)){// update interrupt flag _count++; if (_count >1000) { LED_toggle(); _count=0:}

Figure 5. documentation of TIMER

clear_UIF(TIM2);// clear by writing 0

}

PWM_init()

GPIO port mode register (GPIOx_MODER) (x = A..E and H)

Address offset: 0x00

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MODER	R15[1:0]	MODE	R14[1:0]	MODE	R13[1:0]	MODE	R12[1:0]	MODE	R11[1:0]	MODE	R10[1:0]	MODE	R9[1:0]	MODE	R8[1:0
rw :	rw	rw	rw.	rw	rw	rw	rw								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MODE	R7[1:0]	MODE	R6[1:0]	MODE	R5[1:0]	MODE	R4[1:0]	MODE	R3[1:0]	MODE	R2[1:0]	MODE	R1[1:0]	MODE	R0[1:0]
TW.	rw	rw	rw	7W	rw.	rw	rw	rw	rw.	rw	rw :	rw	rw	rw	TW

Bits 2y 2y+1 MODERy[1:0]: Port x configuration bits (y = 0.15)
These bits are written by software to configure the I/O direction mode.
00. Input (reset state)
01: General purpose output mode
10: Alternate function mode
11: Analog mode

8.4.9 GPIO alternate function low register (GPIOx_AFRL) (x = A..E and H)

Address offset: 0x20 Reset value: 0x0000 0000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	AFRL	7[3:0]			AFRL	6[3:0]			AFRI	.5[3:0]			AFRL	4[3:0]	
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	AFRL	3[3:0]			AFRL	2[3:0]			AFRI	1[3:0]			AFRL	0[3:0]	
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw

Bits 31:0 **AFRLy:** Alternate function selection for port x bit y (y = 0..7) These bits are written by software to configure alternate function I/Os

AFRLy selection:
0000: AF0
0001: AF1
0010: AF2
0011: AF3
0100: AF4
0101: AF5
0110: AF6
0111: AF7 1000: AF8 1001: AF9 1010: AF10 1011: AF11 1100: AF12 1101: AF13 1110: AF14 1111: AF15

void PWM_init(PWM_t *pwm, GPIO_TypeDef *port, int pin);

Parameters

• pwm: typedef pwm structure

• port : GPIOx port

• pin : Output pin number

Example code

PWM_init(&pwm,GPIOA,PA1);

PWM_period_ms()

```
void PWM_period_ms(PWM_t *pwm, uint32_t msec);
```

Parameters

• pwm: typedef pwm structure

• integer: msec

Example code

PWM_period_ms(&pwm,20);

PWM_period_us() void PWM_period_us(PWM_t *PWM_pin, uint32_t usec); **Parameters** • pwm: typedef pwm structure • integer : usec Example code PWM_period_us(&pwm,20000); PWM_pulsewidth_ms() void PWM_pulsewidth_ms(PWM_t *pwm, float pulse_width_ms); **Parameters** • pwm: typedef pwm structure • float : puelse width msec Example code PWM_pulsewidth_ms(&pwm,0.5); PWM_duty() void PWM_duty(PWM_t *pwm, float duty); **Parameters** • pwm: typedef pwm structure • float : duty ratio Example code PWM_duty(&pwm,0.5/20); ratio of 0.5ms/20ms

Figure 6. documentation of PWM